

---

# Foundry Management Information Base Reference



**FOUNDRY  
NETWORKS**

2100 Gold Street  
P.O. Box 649100  
San Jose, CA 95164-9100  
Tel 408.586.1700  
Fax 408.586.1900  
[www.foundrynetworks.com](http://www.foundrynetworks.com)

January 2006

---

---

Copyright © 2006 Foundry Networks, Inc. All rights reserved.

No part of this work may be reproduced in any form or by any means – graphic, electronic or mechanical, including photocopying, recording, taping or storage in an information retrieval system – without prior written permission of the copyright owner.

The trademarks, logos and service marks ("Marks") displayed herein are the property of Foundry or other third parties. You are not permitted to use these Marks without the prior written consent of Foundry or such appropriate third party.

*Foundry Networks, BigIron, FastIron, IronView, JetCore, NetIron, ServerIron, TurboIron, IronWare, EdgeIron, IronPoint* the Iron family of marks and the Foundry Logo are trademarks or registered trademarks of Foundry Networks, Inc. in the United States and other countries.

F-Secure is a trademark of F-Secure Corporation. All other trademarks mentioned in this document are the property of their respective owners.

---

## CHAPTER 1

### **GETTING STARTED..... 1-1**

AUDIENCE .....	1-1
NOMENCLATURE .....	1-1
RELATED PUBLICATIONS .....	1-1
HOW TO GET HELP .....	1-2
WEB ACCESS .....	1-2
EMAIL ACCESS .....	1-2
TELEPHONE ACCESS .....	1-2
WARRANTY COVERAGE .....	1-2

## CHAPTER 2

### **OVERVIEW OF THE FOUNDRY MIB..... 2-1**

OBTAINING AND INSTALLING THE FOUNDRY MIBS .....	2-2
OBTAINING THE MIB FROM THE PRODUCT CD .....	2-2
DOWNLOADING THE MIB FROM FOUNDRY NETWORKS WEB SITE .....	2-2
DOWNLOADING THE MIB FROM FOUNDRY NETWORKS FTP SITE .....	2-2
STANDARD OBJECTS .....	2-2
SUPPORTED ON TERATHON DEVICES .....	2-2
SUPPORTED ON OTHER DEVICES .....	2-3
RFC 1213: MANAGEMENT INFORMATION BASE (MIB-II) .....	2-4
RFC 1493: DEFINITIONS OF MANAGED OBJECTS FOR BRIDGES .....	2-6
RFC 1643: ETHERNET-LIKE INTERFACE TYPES .....	2-6
RFC 2515: DEFINITIONS OF TEXTUAL CONVENTIONS AND OBJECT IDENTITIES FOR ATM MANAGEMENT .....	2-6
RFC 1742: APPLE TALK MANAGEMENT INFORMATION BASE II .....	2-7
RFC 1757: REMOTE NETWORK MONITORING MANAGEMENT INFORMATION BASE .....	2-7
RFC 2096: IP FORWARDING TABLE MIB .....	2-8
RFC 2233: THE INTERFACES GROUP MIB USING SMIV2 .....	2-8
RFC 2674: DEFINITIONS OF MANAGED OBJECTS FOR BRIDGES WITH TRAFFIC CLASSES, MULTICAST FILTERING AND VIRTUAL LAN EXTENSIONS .....	2-9

RFC 2932 IPV4 MULTICAST ROUTING MIB .....	2-9
RFC 2933 IGMP MIB .....	2-11
RFC 2934 PIM MIB FOR IPV4 .....	2-12
RFC 3176: INMON CORPORATION'S SFLOW: A METHOD FOR MONITORING TRAFFIC IN SWITCHED AND ROUTED NETWORKS. ....	2-14
PROPRIETARY OBJECTS .....	2-15
STRUCTURE OF THIS GUIDE .....	2-21
GENERAL NOTES .....	2-21

**CHAPTER 3**  
**REGISTRATION..... 3-1**

**CHAPTER 4**  
**PHYSICAL PROPERTIES OF A DEVICE..... 4-1**

COMMON OBJECTS .....	4-1
POWER SUPPLY .....	4-2
FAN .....	4-3
BOARDS .....	4-4
CHASSIS NUMBER .....	4-7
AGENT BOARD TABLE .....	4-7
AGENT TEMPERATURE TABLE (SNAGENTTEMP TABLE) .....	4-14
CONFIGURED MODULE TABLE .....	4-15
REDUNDANT MODULES .....	4-19
STACKABLE PRODUCTS .....	4-21
BOARDS .....	4-22
LEDS .....	4-23
CHASSIS PRODUCTS .....	4-25
GENERAL CHASSIS .....	4-25
POWER SUPPLY TABLE .....	4-26
FAN TABLE .....	4-26
TEMPERATURE .....	4-27
FLASH CARD .....	4-28

**CHAPTER 5**  
**BASIC CONFIGURATION AND MANAGEMENT..... 5-1**

SOFTWARE IMAGE .....	5-1
RELOAD .....	5-2
NVRAM .....	5-2
CONFIGURATION NOTES ON SNAGERASENVRAM AND SNAGWRITENVRAM.....	5-3
FILE DOWNLOAD AND UPLOAD .....	5-4
SOFTWARE IMAGE DETAILS .....	5-8
BOOT SEQUENCE TABLE .....	5-11
SOFTWARE CONFIGURATION .....	5-12
SWITCH IP CONFIGURATIONS .....	5-12
AGENT SYSTEM PARAMETERS CONFIGURATION TABLE .....	5-12
SWITCH GROUP CONFIGURATION .....	5-14

SWITCH CONFIGURATION SUMMARY GROUP .....	5-19
DNS GROUP .....	5-19
DHCP GATEWAY LIST TABLE .....	5-20
NTP GENERAL GROUP .....	5-21
NTP SERVER TABLE .....	5-23
BANNERS .....	5-24
ENCODED OCTET STRINGS TABLE .....	5-24
AGENT'S GLOBAL GROUP .....	5-25
ERROR MANAGEMENT .....	5-26
FDP AND CDP .....	5-26
FDP/CDP GLOBAL CONFIGURATION OBJECTS .....	5-27
FDP INTERFACE TABLE .....	5-27
FDP CACHE TABLE .....	5-28
FDP CACHED ADDRESS ENTRY TABLE .....	5-30

## CHAPTER 6

### **USER ACCESS..... 6-1**

AGENT USER ACCESS GROUP .....	6-1
AGENT USER ACCOUNT TABLE .....	6-2
GENERAL SECURITY OBJECTS .....	6-2
CONFIGURATION NOTES .....	6-5
IP COMMUNITY LIST TABLE .....	6-6
IP COMMUNITY LIST STRING TABLE .....	6-7
AUTHORIZATION AND ACCOUNTING .....	6-8
RADIUS GENERAL GROUP .....	6-10
RADIUS SERVER TABLE .....	6-13
TACACS GENERAL OBJECTS .....	6-14
TACACS SERVER TABLE .....	6-15

## CHAPTER 7

### **INTERFACES..... 7-1**

SWITCH PORT INFORMATION .....	7-1
SWITCH PORT INFORMATION TABLE .....	7-1
SWITCH PORT INFORMATION GROUP .....	7-14
INTERFACE ID LOOKUP TABLE .....	7-23
INTERFACE INDEX LOOKUP TABLE .....	7-25
TRUNK PORT CONFIGURATION GROUP .....	7-26
MULTI-SLOT TRUNK PORT TABLE .....	7-26
PACKET PORT INFORMATION TABLE .....	7-27
POS ALARMS AND ERROR CONDITIONS .....	7-31
LOOPBACK INTERFACE CONFIGURATION TABLE .....	7-32
PORT STP CONFIGURATION GROUPS .....	7-34
PORT STP CONFIGURATION GROUPS (SNPORTSTPTABLE) .....	7-34
PORT STP CONFIGURATION GROUP (SNIFSTPTABLE) .....	7-37
PORT MONITOR TABLE .....	7-40

## CHAPTER 8

### **FILTERING TRAFFIC..... 8-1**

MAC FILTERS .....	8-1
MAC FILTER TABLE .....	8-2
MAC FILTER PORT ACCESS TABLES .....	8-3
FORWARDING DATABASE STATIC TABLE INFORMATION .....	8-4
MAC PORT SECURITY TABLE .....	8-6
ACLs .....	8-7
GLOBAL ACL .....	8-7
ACL TABLE .....	8-8
ACL BIND TO PORT TABLE (SNAGACLBINDTOPORTTABLE) .....	8-15
ACL PORT TABLE (SNAGACLIFBINDTABLE) .....	8-17

## CHAPTER 9

### **TRAFFIC CONTROL AND PRIORITIZATION..... 9-1**

QUALITY OF SERVICE .....	9-1
QoS PROFILE TABLE .....	9-1
QoS BIND TABLE .....	9-2
CAR .....	9-2
CAR PORT TABLE .....	9-3
VLAN CAR OBJECTS .....	9-5

## CHAPTER 10

### **MULTICAST..... 10-1**

IGMP .....	10-1
GENERAL IGMP OBJECTS .....	10-2
IGMP INTERFACE TABLE .....	10-2
IGMP STATIC GROUP MIB TABLE .....	10-3
PIM .....	10-4
COMMON PIM OBJECTS .....	10-4
PIM VIRTUAL INTERFACE TABLE .....	10-6
PIM NEIGHBOR TABLE .....	10-7
PIM VIRTUAL INTERFACE STATISTICS TABLE .....	10-8
PIM-SM .....	10-10
PIM SPARSE: CANDIDATE BSR TABLE .....	10-10
PIM RP SET TABLE.....	10-11
PIM RP CANDIDATE TABLE.....	10-12
DVMRP .....	10-12
GLOBAL DVMRP OBJECTS .....	10-13
DVMRP VIRTUAL INTERFACE TABLE .....	10-14
DVMRP NEIGHBOR TABLE .....	10-16
DVMRP ROUTE TABLE .....	10-17
DVMRP ROUTING NEXT HOP TABLE .....	10-18
DVMRP VIRTUAL INTERFACE STATISTICS TABLE .....	10-19

**CHAPTER 11**

<b>VLANS .....</b>	<b>11-1</b>
VLAN BY PORT INFORMATION TABLE .....	11-1
VLAN BY PORT MEMBERSHIP TABLE .....	11-6
PORT VLAN CONFIGURATION TABLE .....	11-7
VLAN BY PROTOCOL CONFIGURATION TABLE .....	11-12
VLAN BY IP SUBNET CONFIGURATION TABLE .....	11-14
VLAN BY IPX NETWORK CONFIGURATION TABLE .....	11-17
VLAN BY APPLE TALK CABLE CONFIGURATION TABLE .....	11-19

**CHAPTER 12**

<b>ROUTER REDUNDANCY PROTOCOLS.....</b>	<b>12-1</b>
FSRP OBJECTS .....	12-1
FSRP GLOBAL VARIABLES .....	12-2
FSRP INTERFACE TABLE .....	12-2
VRRP GLOBAL VARIABLES .....	12-4
VRRP INTERFACE TABLES .....	12-5
VRRP INTERFACE TABLE .....	12-5
VRRP AND VRRPE INTERFACE TABLE 2 .....	12-6
VRRP VIRTUAL ROUTER PARAMETERS TABLES .....	12-7
VRRP VIRTUAL ROUTER TABLE .....	12-7
VRRP AND VRRPE PARAMETER TABLE 2 .....	12-13
VSRP .....	12-18
GLOBAL VSRP OBJECTS .....	12-18
VSRP INTERFACE TABLE .....	12-19
VSRP VIRTUAL ROUTER TABLE .....	12-20

**CHAPTER 13**

<b>GLOBAL ROUTER AND IP .....</b>	<b>13-1</b>
GLOBAL ROUTER OBJECTS .....	13-1
IP GENERAL GROUP .....	13-2
IP STATIC ROUTE TABLE .....	13-4
IP FILTER TABLE .....	13-5
IP INTERFACE PORT ADDRESS TABLE .....	13-8
IP INTERFACE PORT ACCESS TABLE .....	13-9
PORT CONFIGURATION TABLES .....	13-10
IP INTERFACE PORT CONFIGURATION TABLE .....	13-10
IP INTERFACE CONFIGURATION TABLE .....	13-12
BROADCAST FORWARDING GROUP .....	13-12
GENERAL UDP BROADCAST FORWARDING GROUP .....	13-13
UDP BROADCAST FORWARDING PORT TABLE .....	13-13
UDP HELPER TABLE .....	13-14
TRACE ROUTE GROUP .....	13-15
GENERAL TRACE ROUTE GROUP .....	13-16
TRACE ROUTE RESULT TABLE .....	13-17

IP FORWARDING CACHE TABLE .....	13-18
IP PREFIX LIST TABLE .....	13-19
IP AS-PATH ACCESS LIST TABLE .....	13-22
IP AS-PATH ACCESS LIST STRING TABLE .....	13-22

## CHAPTER 14

<b>RIP .....</b>	<b>14-1</b>
IP RIP GENERAL GROUP .....	14-1
IP RIP PORT CONFIGURATION TABLE .....	14-3
REDISTRIBUTION TABLE .....	14-3
IP RIP ROUTE FILTER TABLE .....	14-5
IP RIP NEIGHBOR FILTER TABLE .....	14-6
IP RIP PORT ACCESS TABLE .....	14-7
GLOBAL RIP STATISTICS .....	14-8

## CHAPTER 15

<b>OSPF .....</b>	<b>15-1</b>
OSPF GENERAL OBJECTS .....	15-2
OSPF AREA TABLE .....	15-4
AREA RANGE TABLE .....	15-5
OSPF INTERFACE CONFIGURATION TABLES .....	15-6
OSPF INTERFACE CONFIGURATION TABLE .....	15-7
OSPF INTERFACE 2 CONFIGURATION TABLE .....	15-10
OSPF VIRTUAL INTERFACE TABLE .....	15-13
OSPF REDISTRIBUTION OF ROUTES TABLE .....	15-16
OSPF NEIGHBOR TABLE .....	15-18
OSPF VIRTUAL NEIGHBOR TABLE .....	15-21
OSPF LINK-STATE DATABASE .....	15-23
OSPF LINK STATE DATABASE, EXTERNAL .....	15-25
OSPF AREA STATUS TABLE .....	15-26
OSPF INTERFACE STATUS TABLE .....	15-27
OSPF VIRTUAL INTERFACE STATUS TABLE .....	15-31
OSPF ROUTING INFORMATION TABLE .....	15-34

## CHAPTER 16

<b>BGP4 .....</b>	<b>16-1</b>
BGP4 GENERAL VARIABLES .....	16-2
BGP4 NETWORK TABLE .....	16-7
BGP4 ADDRESS FILTER TABLE .....	16-8
BGP4 AGGREGATE ADDRESS TABLE .....	16-9
BGP4 ATTRIBUTE ENTRIES TABLE .....	16-11
BGP4 AS-PATH FILTER TABLE .....	16-12
BGP4 COMMUNITY FILTER TABLE .....	16-13
BGP4 ROUTE MAP FILTER TABLE .....	16-14
BGP4 ROUTE MAP MATCH CONFIGURATION TABLE .....	16-15



BGP4 ROUTE MAP SET CONFIGURATION TABLE .....	16-18
BGP4 REDISTRIBUTION OF ROUTES TABLE .....	16-20
BGP4 ROUTES OPERATIONAL STATUS TABLE .....	16-22
BGP4 NEIGHBOR GENERAL CONFIGURATION TABLE .....	16-24
BGP4 NEIGHBOR DISTRIBUTE GROUP TABLE .....	16-27
BGP4 NEIGHBOR FILTER GROUP TABLE .....	16-29
BGP4 NEIGHBOR ROUTE MAP TABLE .....	16-30
BGP4 NEIGHBOR OPERATIONAL STATUS TABLE .....	16-31
BGP4 NEIGHBOR SUMMARY TABLE .....	16-33
BGP4 CLEAR NEIGHBOR COMMAND TABLE .....	16-35
BGP4 NEIGHBOR PREFIX GROUP TABLE .....	16-35

## CHAPTER 17

<b>IPX .....</b>	<b>17-1</b>
IPX GENERAL OBJECTS .....	17-1
IPX CACHE TABLE .....	17-4
IPX ROUTE TABLE .....	17-5
IPX SERVER TABLE .....	17-5
IPX FORWARD FILTER TABLE .....	17-6
IPX RIP FILTER TABLE .....	17-8
IPX SAP FILTER TABLE .....	17-9
IPX IF FORWARD ACCESS TABLE .....	17-10
IPX IF RIP ACCESS TABLE .....	17-10
IPX IF SAP ACCESS TABLE .....	17-11
IPX PORT ADDRESS TABLE .....	17-12
IPX PORT COUNTERS TABLES .....	17-13

## CHAPTER 18

<b>APPLETALK.....</b>	<b>18-1</b>
APPLETALK GENERAL GROUP .....	18-1
APPLETALK SOCKET PRIORITY TABLE .....	18-4
APPLETALK PORT ZONE FILTER TABLE .....	18-5
APPLETALK PORT TABLE .....	18-6
APPLETALK FORWARDING CACHE TABLE .....	18-7
APPLETALK ZONE TABLE .....	18-8
APPLETALK ADDITIONAL ZONE FILTER TABLE .....	18-9

## CHAPTER 19

<b>MPLS .....</b>	<b>19-1</b>
MPLS OBJECTS .....	19-1
THE MPLS LSP TABLE .....	19-1

## CHAPTER 20

<b>MONITORING AND LOGGING .....</b>	<b>20-1</b>
CPU UTILIZATION .....	20-1
SYSTEM CPU UTILITY TABLE .....	20-2

DYNAMIC MEMORY UTILIZATION .....	20-3
SYSTEM DRAM INFORMATION GROUP .....	20-4
ARP TABLES .....	20-4
RARP TABLE .....	20-5
STATIC ARP TABLE .....	20-5
GLOBAL ARP STATISTICS .....	20-7
SFLOW .....	20-8
SFLOW SOURCE .....	20-8
SFLOW COLLECTOR .....	20-8
NETFLOW EXPORT .....	20-9
GLOBAL NETFLOW OBJECTS .....	20-10
NETFLOW EXPORT COLLECTOR TABLE .....	20-10
NETFLOW EXPORT AGGREGATION TABLE .....	20-11
NETFLOW EXPORT INTERFACE TABLE .....	20-13
SYSTEM LOGGING .....	20-13
GLOBAL OBJECTS .....	20-14
DYNAMIC SYSTEM LOGGING BUFFER TABLE .....	20-16
STATIC SYSTEM LOGGING BUFFER TABLE .....	20-17
SYSTEM LOG SERVER TABLE .....	20-18
CAM STATISTICS .....	20-19
IP CAM STATISTICS TABLE .....	20-19
CAM STATISTICS TABLE .....	20-20
SYSTEM PROCESS UTILIZATION TABLE .....	20-23
OBJECTS FOR DEBUGGING .....	20-24

## CHAPTER 21

<b>LAYER 4 SWITCH GROUP.....</b>	<b>21-1</b>
SESSION .....	21-2
SERVER LOAD BALANCING TRAFFIC INFORMATION .....	21-3
HOT STANDBY .....	21-5
LAYER 4 POLICIES .....	21-6
LAYER 4 POLICY TABLE .....	21-6
LAYER 4 POLICY PORT ACCESS TABLE .....	21-8
HEALTH CHECKS .....	21-9
WEB CACHE SERVER OBJECTS .....	21-9
SERVER CACHE GROUPS .....	21-10
WEB CACHE GROUP TABLE .....	21-11
WEB CACHE TABLE .....	21-12
WEB CACHE REAL SERVER PORT TABLE .....	21-14
WEB CACHE TRAFFIC STATISTICS TABLE .....	21-15
WEB UNCACHED TRAFFIC STATISTICS TABLE .....	21-17
REAL SERVER OBJECTS .....	21-18
REAL SERVER CONFIGURATION TABLE .....	21-18
REAL SERVER PORT CONFIGURATION TABLE .....	21-19
REAL SERVER STATISTICS TABLE .....	21-21
REAL SERVER PORT STATISTIC TABLE .....	21-23

VIRTUAL SERVER OBJECTS .....	21-26
VIRTUAL SERVER CONFIGURATION TABLE .....	21-27
VIRTUAL SERVER PORT CONFIGURATION TABLE .....	21-29
VIRTUAL SERVER STATISTIC TABLE .....	21-31
VIRTUAL SERVER PORT STATISTICS TABLE .....	21-33
BIND TABLE .....	21-34
L4 BIND TABLE .....	21-34
L4 VIRTUAL SERVER BIND TABLE .....	21-35
GSLB SITE REMOTE SERVERIRON CONFIGURATION TABLE .....	21-36
MONITOR GROUPS .....	21-37
REAL SERVER HISTORY CONTROL TABLE .....	21-38
REAL SERVER HISTORY GROUP .....	21-40
REAL SERVER PORT HISTORY CONTROL GROUP .....	21-42
REAL SERVER PORT HISTORY GROUP .....	21-44
VIRTUAL SERVER HISTORY CONTROL GROUP .....	21-45
VIRTUAL SERVER HISTORY TABLE .....	21-47
VIRTUAL SERVER PORT HISTORY CONTROL TABLE .....	21-48
VIRTUAL SERVER PORT HISTORY TABLE .....	21-50

## CHAPTER 22

### WIRELESS FEATURES ..... 22-1

GENERAL MIB OBJECTS .....	22-1
WIFI INTERFACE TABLE .....	22-1
ROAMING PEER TABLE .....	22-2
ACCESS POINT AUTOMATIC DISCOVERY AND CONFIGURATION TABLE .....	22-3
VPN PASSTHROUGH SERVER TABLE .....	22-4
VPN PASSTHROUGH FILTER TABLE .....	22-5
VPN PASSTHROUGH POLICY TABLE .....	22-6

## CHAPTER 23

### TRAPS AND OBJECTS TO ENABLE TRAPS ..... 23-1

OBJECTS TO ENABLE OR DISABLE STANDARD TRAPS .....	23-1
OBJECTS FOR FOUNDRY TRAPS .....	23-2
TRAP INFORMATION .....	23-2
TRAP RECEIVER TABLE .....	23-2
GENERAL CHASSIS AND AGENT TRAPS .....	23-4
ENABLE VRRP TRAPS .....	23-5
ENABLE FSRP TRAPS .....	23-5
ENABLE VSRP TRAPS .....	23-6
ENABLE OSPF TRAP OBJECTS .....	23-6
ENABLE SWITCH GROUP TRAPS .....	23-7
OBJECTS TO ENABLE LAYER 4 TRAPS .....	23-8
STANDARD TRAPS .....	23-10
SYSTEM STATUS TRAPS .....	23-10
TRAPS FOR SPANNING TREE PROTOCOL .....	23-11
TRAPS FOR ALARMS .....	23-12

FOUNDRY TRAPS .....	23-12
GENERAL TRAPS .....	23-13
VRRP TRAP .....	23-19
FSRP TRAP .....	23-20
VSRP TRAPS .....	23-20
OSPF TRAPS .....	23-20
LAYER 4 TRAPS .....	23-26
ICMP TRAPS .....	23-30
TCP TRAP .....	23-30
MPLS TRAPS .....	23-31
BGP TRAPS .....	23-32
PORT SECURITY TRAPS .....	23-32
MRP TRAPS .....	23-33
TRAPS FOR WIRELESS FEATURES. ....	23-33
WIRELESS FEATURE TRAPS .....	23-33
WIRELESS MOBILITY TRAPS .....	23-34
ADC TRAP .....	23-34
AUTOMATIC PORT DISABLEMENT TRAPS .....	23-35
EXAMPLES .....	23-35

## **APPENDIX A**

### **USING SNMP TO UPGRADE SOFTWARE .....A-1**

UPGRADING A STACKABLE DEVICE OR A CHASSIS MODULE'S MANAGEMENT PROCESSOR ..... A-1

UPGRADING SWITCHING PROCESSORS ON A CHASSIS DEVICE ..... A-2

### **INDEX BY OBJECT NAME.....Index-1**

### **INDEX BY TOPIC.....Index-33**

---

# Chapter 1

## Getting Started

This guide describes the objects supported in the Foundry Management Information Base (MIB) on Foundry devices except for the Edgellon devices and IronPoint access points. A MIB is a database of objects that can be used by network management systems to monitor devices on the network. It contains the definitions of the object properties within a managed device. Each managed device keeps a database of values for each of the definitions in the MIB.

### Audience

This manual is designed for network administrators with a working knowledge of the following:

- Layer 2 and Layer 3 switching and routing
- Layer 4 to 7 networking

If you are using a Foundry Layer 3 Switch, you should be familiar with the following protocols if applicable to your network: IP, RIP, OSPF, BGP4, IGMP, PIM, DVMRP, IPX, AppleTalk, FSRP, and VRRP.

### Nomenclature

This guide uses the following typographical conventions to show information:

*Italic* highlights the title of another publication and occasionally emphasizes a word or phrase.

***Bold Italic*** highlights a term that is being defined.

---

**NOTE:** A note emphasizes an important fact or calls your attention to a dependency.

---

### Related Publications

The following Foundry Networks documents supplement the information in this guide.

- *Foundry Switch and Router Installation and Basic Configuration Guide* – provides configuration guidelines for Layer 2 and Layer 3 devices and installation procedures for the Foundry devices with IronCore and JetCore modules.
- *Foundry Security Guide* – provides procedures for securing management access to Foundry devices and for protecting against Denial of Service (DoS) attacks.
- *Foundry Enterprise Configuration and Management Guide* – provides configuration information for enterprise routing protocols including IP, RIP, IP multicast, OSPF, BGP4, VRRP and VRRPE.

- *Foundry NetIron Service Provider Configuration and Management Guide* – provides configuration information for IS-IS and MPLS for Foundry devices that support IS-IS and MPLS, except for the NetIron IMR 640.
- *Foundry NetIron IMR 640 Service Provider Configuration and Management Guide* – provides configuration information for IS-IS and MPLS for for the NetIron IMR 640.
- *Foundry Switch and Router Command Line Interface Reference* – provides a list and syntax information for all the Layer 2 Switch and Layer 3 Switch CLI commands.
- *Foundry Diagnostic Guide* – provides descriptions of diagnostic commands that can help you diagnose and solve issues on Layer 2 Switches and Layer 3 Switches.
- *Foundry BigIron MG8 Switch Installation and Basic Configuration Guide* – provides installation procedures for the BigIron MG8. This guide also presents the management modules available in the device.
- *Foundry NetIron 40G Switch Installation and Basic Configuration Guide* – provides installation procedures for the BigIron MG8. This guide also presents the management modules available in the device.
- *NetIron IMR 640 Installation and Basic Configuration Guide* – provides procedures for installing modules into and connecting your DC power source(s) to the NetIron IMR 640 chassis, cabling the Ethernet interface ports, and performing a basic configuration of the software.
- *Foundry Management Information Base Reference* – presents the Simple Network Management Protocol (SNMP) Management Information Base (MIB) objects that are supported in the Foundry devices.
- *Foundry IPv6 Configuration Guide* – provide configuration information for IPv6 features.
- *Foundry IronPoint Wireless LAN Configuration Guide* – presents the features for the IronPoint wireless LAN (WLAN).

To order additional copies of these manuals, do one of the following:

- Call 1.877.TURBOCALL (887.2622) in the United States or 1.408.586.1881 outside the United States.
- Send email to [info@foundrynet.com](mailto:info@foundrynet.com).

## How to Get Help

Foundry Networks technical support will ensure that the fast and easy access that you have come to expect from your Foundry Networks products will be maintained. If you have comments, questions, and corrections to this document, contact Foundry Networks technical support.

### Web Access

The latest product information and technical tips are always available to our customers from the Foundry Networks web site. You can access the web site at the following URL:

- <http://www.foundrynetworks.com>

### Email Access

Technical requests can also be sent to the following email address:

- [support@foundrynet.com](mailto:support@foundrynet.com)

### Telephone Access

- 1.877.TURBOCALL (887.2622) United States
- 1.408.586.1881 Outside the United States

## Warranty Coverage

Contact Foundry Networks using any of the methods listed above for information about the standard and extended warranties.







---

## Chapter 2

# Overview of the Foundry MIB

The Management Information Base (MIB) is a database of objects that can be used by a network management system to manage and monitor devices on the network. The MIB can be retrieved by a network management system that uses Simple Network Management Protocol (SNMP). The MIB structure determines the scope of management access allowed by a Foundry device. By using SNMP, a manager application can issue read or write operations within the scope of the MIB.

This document has been updated to reflect the MIBs supported up to the following software releases:

- Enterprise IronWare software releases 07.6.04, 07.6.05, 07.7.00, 07.7.01, 07.8.0x, and 08.0.00. These releases apply to the following products:
  - NetIron 400/800/1500 Chassis devices with IronCore or JetCore management modules
  - BigIron 4000/8000/15000 Chassis devices with IronCore or JetCore management modules
  - FastIron II, FastIron II Plus, and FastIron III with M2 or higher management modules
  - FastIron 400/800/1500 Chassis devices with JetCore modules
  - FastIron 4802 Stackable device
- Service Provider IronWare software releases 09.1.00, 09.1.01, 09.1.02. These releases apply to the following products:
  - NetIron 400/800/1500 Chassis devices with IronCore or JetCore management modules
  - BigIron 4000/8000/15000 Chassis devices with IronCore or JetCore management modules
  - NetIron 4802 Stackable device
  - FastIron 4802 Stackable device
- IronWare software release 09.0.00 for the NetIron 4802
- IronWare software releases 03.0.00, 03.1.00, 03.1.01, 03.1.02. These releases apply to the following products:
  - FastIron Edge Switch (FES) 2402, FES 4802, FES 9604, and FES 12GCF
  - FES Power Over Ethernet (POE) series
- IronWare software release 01.0.00 for the FastIron Edge Switch X-series (FES-X).
- Terathon IronWare software releases 01.0.00 through 02.2.00 for the BigIron MG8 and NetIron 40G
- Switch software release 09.0.00S and 09.1.01S for ServerIron Chassis devices
- Router software release 08.0.00 and 08.1.00R for ServerIron Chassis devices

- Software release 07.3.07XL and 07.4.00XL for the ServerIronXL Stackable device

---

**NOTE:** For a list of standard MIBs supported on Edgelron devices, refer to the Edgelron Release Notes.

---

- IronPoint-FES devices.

## Obtaining and Installing the Foundry MIBs

You can obtain the Foundry MIBs:

- From the product CD-ROM
- By downloading the file from Foundry Networks Web site or FTP site.

After obtaining the MIB, follow the instructions for your network management system to be able to use the MIB.

### Obtaining the MIB from the Product CD

On the product CD-ROM, look for the MIB file under the “image” folder. MIB files have a .mib extension.

### Downloading the MIB from Foundry Networks Web Site

To download the MIB from the Foundry Networks Web site, you must have a user name and password to access the Foundry Networks support site. Then do the following:

1. Open your Web browser and enter the following URL:  
`http://www.foundrynet.com/`
2. Click Service -> Technical Support to display the Technical Support page.
3. Click the Log In button and enter your user name and password.
4. Click a product on the left frame of the Technical Support site and find the appropriate IronWare release for that product. Each IronWare release has a link for its corresponding MIB.
5. Click the link for the MIB to open the file or save it to disk.

### Downloading the MIB from Foundry Networks FTP Site

You can also download the MIB from the Foundry ftp support site. Contact Foundry support for details. (Refer to “How to Get Help” on page 1-2.)

## Standard Objects

The Foundry MIB supports certain standard MIB objects, which are derived from Request for Comments (RFCs) documents. This section summarizes the standard objects that are supported in the Foundry MIB. Refer to the appropriate RFC for details.

### Supported on Terathon Devices

The following standard MIBs are supported on the BigIron MG8 and NetIron 40G.

- 1155 – Structure and Identification of Management Information (SMI)
- 1157 – Simple Network Management Protocol (SNMP) version 1
- 1212 – Concise MIB Definitions
- 1215 – SNMP generic traps
- 1493 – Bridge MIB (excluding filtering of objects)
- 1657 – Definitions of Managed Objects for the Fourth Version of the Border Gateway Protocol (BGP-4) using SMIv2

- 1724 – RIP Version 2 MIB Extension
- 1850 – OSPF Version 2 Management Information Base
- 1905 – Protocol Operations for Version 2 of the Simple Network Management Protocol (SNMPv2)
- 1906 – Transport Mappings for Version 2 of the Simple Network Management Protocol (SNMPv2)
- 2011 – SNMPv2 Management Information Base for the Internet Protocol using SMIv2
- 2012 – SNMPv2 Management Information Base for the Transmission Control Protocol using SMIv2
- 2013 – SNMPv2 Management Information Base for the User Datagram Protocol using SMIv2
- 2096 – IP Forwarding MIB
- 2233 – The Interfaces Group MIB using SMIv2
- 2452 - IP Version 6 Management Information Base for the Transmission Control Protocol
- 2454 - IP Version 6 Management Information Base for the User Datagram Protocol
- 2465 - Management Information Base for IP Version 6: Textual Conventions and General Group
- 2466 - Management Information Base for IP Version 6: ICMPv6 Group
- 2570 – Introduction to Version 3 of the Internet-standard Network Management Framework
- 2571 – An Architecture of Describing SNMP Management Frameworks
- 2572 – Message Processing and Dispatching for the Simple Network Management Protocol (SNMP)
- 2574 – User-based Security (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)
- 2575 – View-based Access Control Model (VACM) for the Simple Network Management Protocol (SNMP)
- 2578 – Structure of Management Information Version 2 (SMIv2)
- 2580 – Conformance Statements for SMIv2
- 2665 – Ethernet Like MIB (incorporates RFC 1398)
- 2674– Definitions of Managed Objects for Bridges with Traffic Classes, Multicast Filtering and Virtual LAN Extensions
- 2787 – Definitions of Managed Objects for the Virtual Router Redundancy Protocol
- 2932 – IPv4 Multicast Routing MIB
- 2933 – Internet Group Management Protocol MIB
- 2934 – Protocol Independent Multicast MIB for IPv4
- 3176 – InMon Corporation's sFlow: A Method for Monitoring Traffic in Switched and Routed Networks
- 3411 – Simple Network Management Protocol (SNMP) Management Frameworks
- 3412 – Message Processing and Dispatching for the Simple Network Management Protocol (SNMP)
- 3414 – User-based Security Model (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)
- 3415 – View-based Access Control Model (VACM) for the Simple Network Management Protocol (SNMP)
- 3418 – Management Information Base (MIB) for the Simple Network Management Protocol (SNMP)
- rstpmib Internet draft

## Supported on Other Devices

The standard MIBs below are supported on devices other than the BigIron MG8, NetIron 40G, and EdgIron. Refer to the EdgIron Release Notes for a list of standard MIBs supported on those devices.

Beginning with Enterprise software release 07.6.03, Foundry devices support the following standard MIBs:

- RFC 1850: OSPF Version 2 Management Information Base

---

**NOTE:** RFC is not supported on FastIron Edge Switch devices beginning with release 03.1.02.

---

- RFC 1657: Definitions of Managed Objects for the Fourth Version of the Border Gateway Protocol (BGP-4) using SMIv2

---

**NOTE:** This RFC is not supported on FastIron Edge Switch devices.

---

Support for proprietary MIB objects for OSPF and BGP is still available in the Foundry MIB in addition to support for standard OSPF and BGP MIBs.

Beginning with software release 07.6.05, the following SNMP v3 standard MIBs are supported:

- RFC 3411: An Architecture for Describing Simple Network Management Protocol (SNMP) Management Frameworks
- RFC 3412: Message Processing and Dispatching for the Simple Network Management Protocol (SNMP)
- RFC 3414: User-based Security Model (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)
- RFC 3415: View-based Access Control Model (VACM) for the Simple Network Management Protocol (SNMP)

Portions of the following standard MIBs are supported in the Foundry devices. Refer to the following sections for a list of supported objects:

- “RFC 1213: Management Information Base (MIB-II)” on page 2-4
- “RFC 1493: Definitions of Managed Objects for Bridges” on page 2-6
- “RFC 1643: Ethernet-Like Interface Types” on page 2-6
- “RFC 1742: AppleTalk Management Information Base II” on page 2-7
- “RFC 1757: Remote Network Monitoring Management Information Base” on page 2-7
- “RFC 2233: The Interfaces Group MIB using SMIv2” on page 2-8
- “RFC 2515: Definitions of Textual Conventions and Object Identities for ATM Management” on page 2-6
- “RFC 2674: Definitions of Managed Objects for Bridges with Traffic Classes, Multicast Filtering and Virtual LAN Extensions” on page 2-9
- “RFC 2932 IPv4 Multicast Routing MIB” on page 2-9 (devices running Enterprise software release 08.0.00.)
- “RFC 2933 IGMP MIB” on page 2-11 (devices running Enterprise software release 08.0.00.)
- “RFC 2934 PIM MIB for IPv4” on page 2-12 (devices running Enterprise software release 08.0.00.)
- “RFC 3176: InMon Corporation’s sFlow: A Method for Monitoring Traffic in Switched And Routed Networks.” on page 2-14

## RFC 1213: Management Information Base (MIB-II)

The following objects from RFC1213 are supported in Foundry devices.

Object Group Name	Object Identifier
system	1.3.6.1.2.1.1
interfaces	1.3.6.1.2.1.2
ifTable	1.3.6.1.2.1.2.2

ifEntry	1.3.6.1.2.1.2.2.1
ifIndex (See note below.)	1.3.6.1.2.1.2.2.1.1
ip	1.3.6.1.2.1.4
icmp	1.3.6.1.2.1.5
tcp	1.3.6.1.2.1.6
udp	1.3.6.1.2.1.7
transmission	1.3.6.1.2.1.10
snmp	1.3.6.1.2.1.11
rmon	1.3.6.1.2.1.16
dot1dBridge	1.3.6.1.2.1.17

The following groups from RFC 1213 are not supported.

- at

---

**NOTE:** The table ipNetToMediaTable (OID 1.3.6.1.2.1.4.22) is used instead of the atTable. The atTable has been obsoleted in RFC 1213.

---

- egp

---

**NOTE:**

The ifIndex values allocated for physical ports do not change as modules are inserted and removed. However, they may have changed between software releases of Foundry products to accommodate a greater number of ports per module. In IronWare software previous to release 07.1.xx, a block of 32 ifIndex values was allocated for each slot. Ports in slot 1 would have ifIndex values from 1 to 32, slot 2 would have values from 33 to 64, and so on.

In IronWare TrafficWorks software release 07.2.xx, the number of allocated ifindex was changed to allow 64 ports for modules. Ports in slot 1 would have ifIndex values from 1 to 64, slot 2 would have values from 65 to 128, and so on.

Virtual and loopback interface ifIndex values are allocated from ranges above those used for physical ports

ATM subinterfaces and PVCs have ifIndex values allocated in a dynamic fashion, which is not readily predictable.

In IronWare software release 07.5.00 and TrafficWorks software release 08.0.00, the following blocks of ifIndexes have been allocated:

Physical ports:	1 – 680 (48-T blades * 14 slots + 8 management ports)
VE:	255 (configurable to 2048)
Loopback: :	8
Multicast tunnel	32
GRE IP tunnel	4
ATM subinterface	10
Unused	10
MPLS tunnel	8192
PVC tunnel	4096

These allocations can change in future releases.

---

## RFC 1493: Definitions of Managed Objects for Bridges

The following groups are supported in Foundry devices.

Object Group Name	Object Identifier
dot1dBridge	1.3.6.1.2.1.17
dot1dBase	1.3.6.1.2.1.17.1
dot1dStp	1.3.6.1.2.1.17.2
dot1dTp	1.3.6.1.2.1.17.4

---

**NOTE:** The dot1dTpFdbTable (OID 1.3.6.1.2.1.17.4) in RFC 1493 is used to find dynamically learned MAC addresses. Statically configured MAC addresses are in the snFdbTable (refer to “Forwarding Database Static Table Information” on page 8-4).

---



---

**NOTE:** The SNMP MIB object dot1dDtpPortTable (OID: 1.3.6.1.2.1.17.2.15) does not display information for tagged ports that belong to an 802.1W RSTP configuration. The design of that MIB table is based on Single STP standard, and does not accommodate Multiple STPs. Therefore, the table displays information only for SSTP and for untagged port.

---

## RFC 1643: Ethernet-Like Interface Types

The following groups are supported in Foundry devices.

Object Group Name	Object Identifier
dot3	1.3.6.1.2.1.10.7
dot3StatsTable	1.3.6.1.2.1.10.7.2
dot3CollTable	1.3.6.1.2.1.10.7.5
dot3Tests	1.3.6.1.2.1.10.7.6
dot3Errors	1.3.6.1.2.1.10.7.7
dot3ChipSets	1.3.6.1.2.1.10.7.8

## RFC 2515: Definitions of Textual Conventions and Object Identities for ATM Management

Only The following objects groups from RFC 2515 are supported in Foundry devices.

Object Group Name	Object Identifier
atmMIB	1.3.6.1.2.1.37
atmMIBObjects	1.3.6.1.2.1.37.1
atmInterfaceConfTable	1.3.6.1.2.1.37.1.2

atmInterfaceTCTable	1.3.6.1.2.1.37.1.4
aal5VccTable	1.3.6.1.2.1.37.1.12
atmTCMIB	1.3.6.1.2.1.37.3

Other object groups from this RFC are not supported.

## RFC 1742: AppleTalk Management Information Base II

The following groups from this RFC are supported in Foundry devices.

Object Group Name	Object Identifier
appletalk	1.3.6.1.2.1.13
aarp	1.3.6.1.2.1.13.2
atport	1.3.6.1.2.1.13.3
ddp	1.3.6.1.2.1.13.4
rtmp	1.3.6.1.2.1.13.5
zipRouter	1.3.6.1.2.1.13.7
rtmpStub	1.3.6.1.2.1.13.16
zipEndNode	1.3.6.1.2.1.13.17
perPort	1.3.6.1.2.1.13.18

The following object groups from RFC 1742 are not supported in Foundry devices.

- llap
- ddp
- kip
- nbp
- atecho
- atp
- pap
- asp
- adsp
- atportptop

## RFC 1757: Remote Network Monitoring Management Information Base

The following groups from this RFC are supported in Foundry devices.

Object Group Name	Object Identifier
rmon	1.3.6.1.2.1.16

statistics	1.3.6.1.2.1.16.1
history	1.3.6.1.2.1.16.2
alarm	1.3.6.1.2.1.16.3
event	1.3.6.1.2.1.16.9

The following object groups in RFC 1757 are not supported in Foundry devices.

- hosts
- hostTopN
- matrix
- filter
- capture (packet capture)

### RFC 2096: IP Forwarding Table MIB

The following MIB objects can be used to read the routing table on a BigIron MG8 and ServerIron devices.

Object Group Name	Object Identifier
1.3.6.1.2.1.4.24.4.1.1	ipCidrRouteDest
1.3.6.1.2.1.4.24.4.1.2	ipCidrRouteMask
1.3.6.1.2.1.4.24.4.1.3	ipCidrRouteTos
1.3.6.1.2.1.4.24.4.1.4	ipCidrRouteNextHop
1.3.6.1.2.1.4.24.4.1.5	ipCidrRouteIfIndex
1.3.6.1.2.1.4.24.4.1.6	ipCidrRouteType
1.3.6.1.2.1.4.24.4.1.7	ipCidrRouteProto
1.3.6.1.2.1.4.24.4.1.8	ipCidrRouteAge
1.3.6.1.2.1.4.24.4.1.9	ipCidrRouteInfo
1.3.6.1.2.1.4.24.4.1.10	ipCidrRouteNextHopAS
1.3.6.1.2.1.4.24.4.1.11	ipCidrRouteMetric1
1.3.6.1.2.1.4.24.4.1.12	ipCidrRouteMetric2
1.3.6.1.2.1.4.24.4.1.13	ipCidrRouteMetric3
1.3.6.1.2.1.4.24.4.1.14 (BigIron MG8 only)	ipCidrRouteMetric4
1.3.6.1.2.1.4.24.4.1.15 (BigIron MG8 only)	ipCidrRouteMetric5
1.3.6.1.2.1.4.24.4.1.16 (BigIron MG8 only)	ipCidrRouteStatus

### RFC 2233: The Interfaces Group MIB using SMIv2

---

**NOTE:** RFC 2233 is supported in Foundry devices, starting with IronWare release 07.5.01.

---



The following groups from this RFC are supported in Foundry devices.

Object Group Name	Object Identifier
ifMIB	1.3.6.1.2.1.31
ifMIBObjects	1.3.6.1.2.1.31.1
ifXtable	1.3.6.1.2.1.31.1.1
ifStackTable	1.3.6.1.2.1.31.1.2
ifConformance	1.3.6.1.2.1.31.2

### RFC 2674: Definitions of Managed Objects for Bridges with Traffic Classes, Multicast Filtering and Virtual LAN Extensions

The following groups from this RFC are supported in Foundry devices.

Object Group Name	Object Identifier
pBridgeMib	1.3.6.1.2.1.17.6
qBridgeMib	1.3.6.1.2.1.17.7

### RFC 2932 IPv4 Multicast Routing MIB

Support for RFC 2932 is available on devices running Enterprise software release 08.0.00 and later as presented below.

Object	Supported?	Object Identifier
ipMRouteEnable	Yes	1.3.6.1.2.1.83.1.1.1
ipMRouteEntryCount	Yes	1.3.6.1.2.1.83.1.1.2.1

#### ipMRouteTable (IP multicast route table)

ipMRouteGroup	Yes	1.3.6.1.2.1.83.1.1.2.1.1
ipMRouteSource	Yes. Returns the IP address of the multicast server.	1.3.6.1.2.1.83.1.1.2.1.2
ipMRouteSourceMask	Yes. Always shows "1".	1.3.6.1.2.1.83.1.1.2.1.3
ipMRouteUpstreamNeighbor	Yes	1.3.6.1.2.1.83.1.1.2.1.4
ipMRouteInIfIndex	Yes	1.3.6.1.2.1.83.1.1.2.1.5
ipMRouteUpTime	Yes	1.3.6.1.2.1.83.1.1.2.1.6
ipMRouteExpiryTime	Yes	1.3.6.1.2.1.83.1.1.2.1.7
ipMRoutePkts	No	1.3.6.1.2.1.83.1.1.2.1.8
ipMRouteDifferentInIfPackets	Yes	1.3.6.1.2.1.83.1.1.2.1.9

Object	Supported?	Object Identifier
ipMRouteOctets	No	1.3.6.1.2.1.83.1.1.2.1.10
ipMRouteProtocol	Yes	1.3.6.1.2.1.83.1.1.2.1.11
ipMRouteRtProto	Yes	1.3.6.1.2.1.83.1.1.2.1.12
ipMRouteRtAddress	Yes. Returns the IP address of the multicast server.	1.3.6.1.2.1.83.1.1.2.1.13
ipMRouteRtMask	Yes. Always shows "1".	1.3.6.1.2.1.83.1.1.2.1.14
ipMRouteRtType	Yes	1.3.6.1.2.1.83.1.1.2.1.15
ipMRouteHCOctets	No. Always shows "0".	1.3.6.1.2.1.83.1.1.2.1.16

**ipMRouteNextHopTable (IP multicast next hop table)**

"Next hop" in this table refers to downstream traffic.

ipMRouteNextHopGroup	Yes	1.3.6.1.2.1.83.1.1.3.1.1
ipMRouteNextHopSource	Yes	1.3.6.1.2.1.83.1.1.3.1.2
ipMRouteNextHopSourceMask	Yes	1.3.6.1.2.1.83.1.1.3.1.3
ipMRouteNextHopIfIndex	Yes	1.3.6.1.2.1.83.1.1.3.1.4
ipMRouteNextHopAddress	Yes	1.3.6.1.2.1.83.1.1.3.1.5
ipMRouteNextHopState	Yes. Always shows forwarding(2).	1.3.6.1.2.1.83.1.1.3.1.6
ipMRouteNextHopUpTime	No. Always shows "0".	1.3.6.1.2.1.83.1.1.3.1.7
ipMRouteNextHopExpiryTime	No. Always shows "0".	1.3.6.1.2.1.83.1.1.3.1.8
ipMRouteNextHopClosestMemberHop	No. Always shows "0".	1.3.6.1.2.1.83.1.1.3.1.9
ipMRouteNextHopProtocol	Yes	1.3.6.1.2.1.83.1.1.3.1.10
ipMRouteNextHopPkts	No. Always shows "0".	1.3.6.1.2.1.83.1.1.3.1.11

**ipMRouteInterfaceTable (IP multicast route table for interfaces)**

ipMRouteInterfaceIfIndex	Yes	1.3.6.1.2.1.83.1.1.4.1.1
ipMRouteInterfaceTtl	Yes. Range: 1—31	1.3.6.1.2.1.83.1.1.4.1.2
ipMRouteInterfaceProtocol	Yes	1.3.6.1.2.1.83.1.1.4.1.3
ipMRouteInterfaceRateLimit	No	1.3.6.1.2.1.83.1.1.4.1.4
ipMRouteInterfaceInMcastOctets	Yes. Returns packet count	1.3.6.1.2.1.83.1.1.4.1.5
ipMRouteInterfaceOutMcastOctets	Yes. Returns packet count	1.3.6.1.2.1.83.1.1.4.1.6
ipMRouteInterfaceHCInMcastOctets	Yes. Returns packet count	1.3.6.1.2.1.83.1.1.4.1.7
ipMRouteInterfaceHCOutMcastOctets	Yes. Returns packet count	1.3.6.1.2.1.83.1.1.4.1.8

**IP Multicast Scope Boundary Table (IP multicast scope boundary table)**

ipMRouteBoundaryIfIndex	Yes	1.3.6.1.2.1.83.1.1.5.1.1
-------------------------	-----	--------------------------

Object	Supported?	Object Identifier
IpMRouteBoundaryAddress	Yes. Value is obtained from ACLs.	1.3.6.1.2.1.83.1.1.5.1.2
IpMRouteBoundaryAddressMask	Yes. Value is obtained from ACLs.	1.3.6.1.2.1.83.1.1.5.1.3
IpMRouteBoundaryStatus	Yes. Read only.	1.3.6.1.2.1.83.1.1.5.1.4

#### **ipMRouteScopeNameTable (IP multicast scope group name table)**

Objects in this table are supported.

## **RFC 2933 IGMP MIB**

Support for RFC 2933 is available on devices running Enterprise software release 08.0.00 and later as presented below.

Object	Supported?	Object Identifier
--------	------------	-------------------

#### **igmpInterfaceTable (IGMP Interface Table)**

igmpInterfaceIfIndex	Yes	1.3.6.1.2.1.85.1.1.1.1
igmpInterfaceQueryInterval	Yes. Global value only.	1.3.6.1.2.1.85.1.1.1.2
igmpInterfaceStatus	Yes	1.3.6.1.2.1.85.1.1.1.3
igmpInterfaceVersion	Yes	1.3.6.1.2.1.85.1.1.1.4
igmpInterfaceQuerier	Yes	1.3.6.1.2.1.85.1.1.1.5
igmpInterfaceQueryMaxResponseTime	Yes. Global value only.	1.3.6.1.2.1.85.1.1.1.6
igmpInterfaceQuerierUpTime	Yes	1.3.6.1.2.1.85.1.1.1.7
igmpInterfaceQuerierExpiryTime	Yes	1.3.6.1.2.1.85.1.1.1.8
igmpInterfaceVersion1QuerierTimer	Yes, but only the following values are supported: <ul style="list-style-type: none"> <li>0 = no V1 querier</li> <li>1 = no time</li> </ul>	1.3.6.1.2.1.85.1.1.1.9
igmpInterfaceWrongVersionQueries	Yes	1.3.6.1.2.1.85.1.1.1.10
igmpInterfaceJoins	Yes	1.3.6.1.2.1.85.1.1.1.11
igmpInterfaceProxyIfIndex	No	1.3.6.1.2.1.85.1.1.1.12
igmpInterfaceGroups	Yes	1.3.6.1.2.1.85.1.1.1.13
igmpInterfaceRobustness	Yes. Global value only.	1.3.6.1.2.1.85.1.1.1.14
igmpInterfaceLastMemQueryIntvl	Yes	1.3.6.1.2.1.85.1.1.1.15

#### **igmpCacheTable (IGMP Cache Table)**

igmpCacheAddress	Yes	1.3.6.1.2.1.85.1.2.1.1
igmpCacheIfIndex	Yes	1.3.6.1.2.1.85.1.2.1.2

Object	Supported?	Object Identifier
igmpCacheSelf	Yes	1.3.6.1.2.1.85.1.2.1.3
igmpCacheLastReporter	Yes	1.3.6.1.2.1.85.1.2.1.4
igmpCacheUpTime	Yes	1.3.6.1.2.1.85.1.2.1.5
igmpCacheExpiryTime	Yes	1.3.6.1.2.1.85.1.2.1.6
igmpCacheStatus	Yes	1.3.6.1.2.1.85.1.2.1.7
igmpCacheVersion1HostTimer	Yes	1.3.6.1.2.1.85.1.2.1.8

### RFC 2934 PIM MIB for IPv4

Support for RFC 2934 is available on devices running Enterprise software release 08.0.00 and later as presented below.

Object	Supported?	Object Identifier
pimJoinPruneInterval	Yes	1.3.6.1.3.61.1.1.1

#### pimInterfaceTable (PIM Interface Table)

pimInterfaceIfIndex	Yes	1.3.6.1.3.61.1.1.2.1.1
pimInterfaceAddress	Yes	1.3.6.1.3.61.1.1.2.1.2
pimInterfaceNetMask	Yes	1.3.6.1.3.61.1.1.2.1.3
pimInterfaceMode	Yes	1.3.6.1.3.61.1.1.2.1.4
pimInterfaceDR	Yes	1.3.6.1.3.61.1.1.2.1.5
pimInterfaceHelloInterval	Yes. Global value only.	1.3.6.1.3.61.1.1.2.1.6
pimInterfaceStatus	Yes	1.3.6.1.3.61.1.1.2.1.7
pimInterfaceJoinPruneInterval	Yes. Global value only.	1.3.6.1.3.61.1.1.2.1.8
pimInterfaceCBSRPreference	Yes. Global value only.	1.3.6.1.3.61.1.1.2.1.9

#### pimNeighborTable (PIM Neighbor Table)

pimNeighborAddress	Yes	1.3.6.1.3.61.1.1.3.1.1
pimNeighborIfIndex	Yes	1.3.6.1.3.61.1.1.3.1.2
pimNeighborUpTime	Yes	1.3.6.1.3.61.1.1.3.1.3
pimNeighborExpiryTime	Yes	1.3.6.1.3.61.1.1.3.1.4
pimNeighborMode	Yes	1.3.6.1.3.61.1.1.3.1.5

#### pimIpMRouteTable (PIM IP Multicast Route Table)

pimIpMRouteUpstreamAssertTimer	Yes	1.3.6.1.3.61.1.1.4.1.1
pimIpMRouteAssertMetric	Yes	1.3.6.1.3.61.1.1.4.1.2

Object	Supported?	Object Identifier
pimIpMRouteAssertMetricPref	Yes	1.3.6.1.3.61.1.1.4.1.3
pimIpMRouteAssertRPTBit	Yes	1.3.6.1.3.61.1.1.4.1.4
pimIpMRouteFlags	Yes	1.3.6.1.3.61.1.1.4.1.5

#### **pimIpMRouteNextHopTable (PIM Next Hop Table)**

The pimIpMRouteNextHopTable is not supported.

#### **pimRpTable (PIM RP Table)**

pimRPGroupAddress	Yes, but read-only and only active groups.	1.3.6.1.3.61.1.1.5.1.1
pimRPAddress	Yes, but read-only.	1.3.6.1.3.61.1.1.5.1.2
pimRPState	Yes, but read-only and value is always up(1).	1.3.6.1.3.61.1.1.5.1.3
pimRPStateTimer	No	1.3.6.1.3.61.1.1.5.1.4
pimRPLastChange (	No	1.3.6.1.3.61.1.1.5.1.5
pimRPRowStatus	Yes, but read-only.	1.3.6.1.3.61.1.1.5.1.6

#### **pimRpSetTable (PIM RP Set Table)**

pimRpSetGroupAddress	Yes	1.3.6.1.3.61.1.1.6.1.1
pimRpSetGroupMask	Yes	1.3.6.1.3.61.1.1.6.1.2
pimRpSetAddress	Yes	1.3.6.1.3.61.1.1.6.1.3
pimRpSetHoldTime	Yes	1.3.6.1.3.61.1.1.6.1.4
pimRpSetExpiryTime	Yes	1.3.6.1.3.61.1.1.6.1.5
pimRpSetComponent	No	1.3.6.1.3.61.1.1.6.1.6

#### **pimCandidateRPTable (PIM Candidate-RP Table)**

pimCandidateRPGroupAddress	Yes	1.3.6.1.3.61.1.1.11.1.1
pimCandidateRPGroupMask	Yes	1.3.6.1.3.61.1.1.11.1.2
pimCandidateRPAddress	Yes	1.3.6.1.3.61.1.1.11.1.3
pimCandidateRPRowStatus	Yes	1.3.6.1.3.61.1.1.11.1.4

#### **pimComponentTable (PIM Component Table)**

SET operation for this table is not available, since the BSR is in one domain only. This table has only one row.

Use the CLI command **ip pim border** at the interface level to stop the flooding of the bootstrap messages.

pimComponentIndex	Yes	1.3.6.1.3.61.1.1.12.1.1
pimComponentBSRAddress	Yes	1.3.6.1.3.61.1.1.12.1.2

Object	Supported?	Object Identifier
pimComponentBSRExpiryTime	Yes	1.3.6.1.3.61.1.1.12.1.3
pimComponentCRPHoldTime	Yes	1.3.6.1.3.61.1.1.12.1.4
pimComponentStatus	Yes, but read-only	1.3.6.1.3.61.1.1.12.1.5

### RFC 3176: InMon Corporation's sFlow: A Method for Monitoring Traffic in Switched And Routed Networks.

IronWare release 07.5.01 and later provide support for RFC 3176, "InMon Corporation's sFlow: A Method for Monitoring Traffic in Switched and Routed Networks". Support for this MIB enables you to configure the sFlow Export feature.

The following groups from this RFC are supported in Foundry devices.

Object Name	Object Identifier	Description
sFlowAgent	1.3.6.1.4.1.4300.1.1	
sFlowVersion	1.3.6.1.4.1.4300.1.1.1	Returns a version string (for example, "1.2; Foundry Networks")
sFlowAgentAddressType	1.3.6.1.4.1.4300.1.1.2	Returns value 1 (ipv4)
sFlowAgentAddress	1.3.6.1.4.1.4300.1.1.3	Management IP
sFlowTable	1.3.6.1.4.1.4300.1.1.4	sFlow Table
sFlowDataSource	1.3.6.1.4.1.4300.1.1.4.1.1	ifIndex of sFlow port
sFlowOwner	1.3.6.1.4.1.4300.1.1.4.1.2	Always null. Not supported in the CLI.
sFlowTimeout	1.3.6.1.4.1.4300.1.1.4.1.3	Always 0. Not supported in the CLI.
sFlowPacketSamplingRate	1.3.6.1.4.1.4300.1.1.4.1.4	Port sampling rate. Set this value to 0 to disable sflow for a port.
sFlowCounterSamplingInterval	1.3.6.1.4.1.4300.1.1.4.1.5	Global counter poll interval
sFlowMaximumHeaderSize	1.3.6.1.4.1.4300.1.1.4.1.6	Always 128
sFlowMaximumDatagramSize	1.3.6.1.4.1.4300.1.1.4.1.7	Always 1400
sFlowCollectorAddressType	1.3.6.1.4.1.4300.1.1.4.1.8	Always 1 (ipv4)
sFlowCollectorAddress	1.3.6.1.4.1.4300.1.1.4.1.9	Address of first collector. For other collectors, use snSflowCollectorTable. (Refer to "sFlow Collector" on page 20-8.)
sFlowCollectorPort	1.3.6.1.4.1.4300.1.1.4.1.10	Port of first collector. For other collectors, use snSflowCollectorTable. (Refer to "sFlow Collector" on page 20-8.)
sFlowDatagramVersion	1.3.6.1.4.1.4300.1.1.4.1.11	Always 4

## Proprietary Objects

Proprietary objects are MIB objects that have been developed specifically to manage Foundry products. This section presents a summarized list of these objects.

Table 2.1 shows the hierarchy of the MIB objects that are proprietary to Foundry products. These objects may also be referred to as the private (or enterprise) MIBs.

On the MIB tree, the object named “foundry” marks the start of the Foundry MIB objects. The “foundry” object branches into the “products” branch, which branches further into three major nodes:

- switch – Includes general SNMP MIB objects and objects related to switching functions.
- router – Contains objects for routing protocols, such as IP, OSPF, BGP.
- registration – Includes the objects for each model of the Foundry product line.

Each of these major nodes are further divided into smaller categories.

Table 2.1 contains a summary of the major categories or MIB object groups under each major node. The MIB object groups can be divided into the individual MIB objects or additional object groups.

The column “Object Group Name” presents the name of the MIB object. The “Object Identifier” column shows the MIB object’s identifier (OID). In this guide, the Foundry objects are presented with their object names and object their identifiers (OIDs). As shown in Table 2.1, OIDs are presented in the format fdry.x.x.x.x, where:

- “fdry” represents the number 1.3.6.1.4.1.1991
- .x.x.x.x is the remainder of the number

For example, the OID for the object snChassis is 1.3.6.1.4.1.1991.1.1.1, but appears as fdry.1.1.1 in this guide.

The Description column indicates the section in this guide that contains details for that object.

**Table 2.1: Summary of MIB Objects Proprietary to Foundry Products**

Object Group Name	Object Identifier	Sections to Refer To
<b>foundry</b>	<b>fdry</b>	<b>All sections in this manual</b>
<b>products</b>	<b>fdry.1</b>	<b>All sections in this manual</b>
<b>switch</b>	<b>fdry.1.1</b>	<b>All sections under the switch branch</b>
snChassis	fdry.1.1.1	
snChasGen	fdry.1.1.1.1	“Common Objects” on page 4-1
snChasPwr	fdry.1.1.1.2	“Power Supply” on page 4-2
snChasFan	fdry.1.1.1.3	“Fan” on page 4-3
snAgentSys	fdry.1.1.2	
snAgentBrd	fdry.1.1.2.2	“Agent Board Table” on page 4-7
snAgenTrp	fdry.1.1.2.3	“Trap Receiver Table” on page 23-2
snAgentBoot	fdry.1.1.2.4	“Boot Sequence Table” on page 5-11
snAgCfgEos	fdry.1.1.2.5	“Encoded Octet Strings Table” on page 5-24
snAgentLog	fdry.1.1.2.6	“System Logging” on page 20-13

**Table 2.1: Summary of MIB Objects Proprietary to Foundry Products (Continued)**

<b>Object Group Name</b>	<b>Object Identifier</b>	<b>Sections to Refer To</b>
snAgentSysParaConfig	fdry.1.1.2.7	“Agent System Parameters Configuration Table” on page 5-12
snAgentConfigModule	fdry.1.1.2.8	“Configured Module Table” on page 4-15
snAgentUser	fdry.1.1.2.9	“Agent User Access Group” on page 6-1
snAgentRedundant	fdry.1.1.2.10	“Redundant Modules” on page 4-19
snAgentCpu	fdry.1.1.2.11	“CPU Utilization” on page 20-1
snSwitch	fdry.1.1.3	“Basic Configuration and Management” on page 5-1
snSwInfo	fdry.1.1.3.1	“Switch Group Configuration” on page 5-14
snVlanInfo	fdry.1.1.3.2	“VLAN By Port Information Table” on page 11-1
snSwPortInfo	fdry.1.1.3.3	“Switch Port Information Table” on page 7-1
snFdbInfo	fdry.1.1.3.4	“Forwarding Database Static Table Information” on page 8-4
snPortStpInfo	fdry.1.1.3.5	“Port STP Configuration Groups” on page 7-34
snTrunkInfo	fdry.1.1.3.6	“Trunk Port Configuration Group” on page 7-26
snSwSummary	fdry.1.1.3.7	“Switch Configuration Summary Group” on page 5-19
snDnsInfo	fdry.1.1.3.9	“DNS Group” on page 5-19
snMacFilter	fdry.1.1.3.10	“MAC Filter Table” on page 8-2 and “MAC Filter Port Access Tables” on page 8-3
snNTP	fdry.1.1.3.11	“NTP General Group” on page 5-21 and “NTP Server Table” on page 5-23
snRadius	fdry.1.1.3.12	“Authorization and Accounting” on page 6-8 and “RADIUS General Group” on page 6-10
snTacacs	fdry.1.1.3.13	“TACACS General Objects” on page 6-14 and “TACACS Server Table” on page 6-15
snQos	fdry.1.1.3.14	“QoS Profile Table” on page 9-1 and “QoS Bind Table” on page 9-2
snAAA	fdry.1.1.3.15	“Authorization and Accounting” on page 6-8
snCAR	fdry.1.1.3.16	“CAR” on page 9-2
snVlanCAR	fdry.1.1.3.17	“VLAN CAR Objects” on page 9-5
snNetFlow	fdry.1.1.3.18	“NetFlow Export” on page 20-9
sFlowCollectorTable	fdry1.1.3.19.2	“sFlow” on page 20-8



**Table 2.1: Summary of MIB Objects Proprietary to Foundry Products (Continued)**

<b>Object Group Name</b>	<b>Object Identifier</b>	<b>Sections to Refer To</b>
snFdp	fdry.1.1.3.20.1	"FDP and CDP" on page 5-26
snvsrp	fdry.1.1.3.21	"VSRP" on page 12-18
snarp	fdry.1.1.3.22	"Static ARP Table" on page 20-5
snMac	fdry.1.1.3.24	"MAC Port Security Table" on page 8-6
snPort Monitor	fdry.1.1.3.25	"MAC Port Security Table" on page 8-6
snL4	fdry.1.1.4	"Layer 4 Switch Group" on page 21-1
snL4Gen	fdry.1.1.4.1	"Layer 4 Switch Group" on page 21-1
snL4Bind	fdry.1.1.4.6	"Bind Table" on page 21-34
snL4Policy	fdry.1.1.4.11	"Layer 4 Policy Table" on page 21-6
snL4PolicyPortAccess	fdry.1.1.4.12	"Layer 4 Policy Port Access Table" on page 21-8
snL4Trap	fdry.1.1.4.13	"Layer 4 Traps" on page 23-26
snL4WebCache	fdry.1.1.4.14	"Web Cache Table" on page 21-12 and "Server Cache Groups" on page 21-10
snL4WebCacheGroup	fdry.1.1.4.15	"Web Cache Group Table" on page 21-11
snL4WebCacheTrafficStats	fdry.1.1.4.16	"Web Cache Traffic Statistics Table" on page 21-15
snL4WebUncachedTrafficStats	fdry.1.1.4.17	"Web Uncached Traffic Statistics Table" on page 21-17
snL4WebCachePort	fdry.1.1.4.18	"Web Cache Real Server Port Table" on page 21-14
snL4RealServerCfg	fdry.1.1.4.19	"Real Server Configuration Table" on page 21-18
snL4RealServerPortCfg	fdry.1.1.4.20	"Real Server Port Configuration Table" on page 21-19
snL4VirtualServerCfg	fdry.1.1.4.21	"Virtual Server Configuration Table" on page 21-27
snL4VirtualServerPortCfg	fdry.1.1.4.22	"Virtual Server Port Configuration Table" on page 21-29
snL4RealServerStatistic	fdry.1.1.4.23	"Real Server Statistics Table" on page 21-21
snL4RealServerPortStatistic	fdry.1.1.4.24	"Real Server Port Configuration Table" on page 21-19
snL4VirtualServerStatistic	fdry.1.1.4.25	"Virtual Server Statistic Table" on page 21-31
snL4VirtualServerPortStatistic	fdry.1.1.4.26	"Virtual Server Port Statistics Table" on page 21-33

**Table 2.1: Summary of MIB Objects Proprietary to Foundry Products (Continued)**

Object Group Name	Object Identifier	Sections to Refer To
snL4GslbSiteRemoteServers	fdry.1.1.4.27	"GSLB Site Remote ServerIron Configuration Table" on page 21-36
snL4History	fdry.1.1.4.28	"Monitor Groups" on page 21-37
<b>router</b>	<b>fdry.1.2</b>	<b>All sections under the router branch</b>
snlpx	fdry.1.2.1	"IPX" on page 17-1
snlpxGen	fdry.1.2.1.1	"IPX General Objects" on page 17-1
snlpxCache	fdry.1.2.1.2	"IPX Cache Table" on page 17-4
snlpxRoute	fdry.1.2.1.3	"IPX Route Table" on page 17-5
snlpxServer	fdry.1.2.1.4	"IPX Server Table" on page 17-5
snlpxFwdFilter	fdry.1.2.1.5	"IPX Forward Filter Table" on page 17-6
snlpxRipFilter	fdry.1.2.1.6	"IPX RIP Filter Table" on page 17-8
snlpxSapFilter	fdry.1.2.1.7	"IPX SAP Filter Table" on page 17-9
snlpxIfFwdAccess	fdry.1.2.1.8	"IPX IF Forward Access Table" on page 17-10
snlpxIfRipAccess	fdry.1.2.1.9	"IPX IF RIP Access Table" on page 17-10
snlpxIfSapAccess	fdry.1.2.1.10	"IPX IF SAP Access Table" on page 17-11
snlpxPortAddr	fdry.1.2.1.11	"IPX Port Address Table" on page 17-12
snlpxPortCounters	fdry.1.2.1.12	"IPX Port Counters Tables" on page 17-13
snlpl	fdry.1.2.2	"Global Router and IP" on page 13-1
snRtlpGeneral	fdry.1.2.2.1	"Global Router and IP" on page 13-1
snAgAcl	fdry.1.2.2.15	"Filtering Traffic" on page 8-1
snlPAsPathAccessListStringTable	fdry.1.2.2.16	"IP AS-Path Access List Table" on page 13-22
snlPCommunityListStringTable	fdry.1.2.2.17	"IP Community List String Table" on page 6-7
snRtlpPortIfAddrTable	fdry.1.2.2.18	"IP Interface Port Address Table" on page 13-8
snRtlpPortIfAccessTable	fdry.1.2.2.19	"IP Interface Port Access Table" on page 13-9
snRip	fdry.1.2.3	"RIP" on page 14-1
snRtlpRipGeneral	fdry.1.2.3.1	"IP RIP General Group" on page 14-1
snOspf	fdry.1.2.4	"OSPF" on page 15-1
snOspfGen	fdry.1.2.4.1	"OSPF General Objects" on page 15-2
snOspfArea	fdry.1.2.4.2	"OSPF Area Table" on page 15-4
snOspfAddrRange	fdry.1.2.4.3	"Area Range Table" on page 15-5

**Table 2.1: Summary of MIB Objects Proprietary to Foundry Products (Continued)**

<b>Object Group Name</b>	<b>Object Identifier</b>	<b>Sections to Refer To</b>
snOspfIntf	fdry.1.2.4.4	"OSPF Interface Configuration Tables" on page 15-6
snOspfVirtIf	fdry.1.2.4.5	"OSPF Virtual Interface Table" on page 15-13
snOspfRedis	fdry.1.2.4.6	"OSPF Redistribution of Routes Table" on page 15-16
snOspfNbr	fdry.1.2.4.7	"OSPF Neighbor Table" on page 15-18
snOspfVirtNbr	fdry.1.2.4.8	"OSPF Virtual Neighbor Table" on page 15-21
snOspfLsdb	fdry.1.2.4.9	"OSPF Link-State Database" on page 15-23
snOspfExtLsdb	fdry.1.2.4.10	"OSPF Link State Database, External" on page 15-25
snOspfAreaStatus	fdry.1.2.4.11	"OSPF Area Status Table" on page 15-26
snOspfIfStatus	fdry.1.2.4.12	"OSPF Interface Status Table" on page 15-27
snOspfVirtIfStatus	fdry.1.2.4.13	"OSPF Virtual Interface Status Table" on page 15-31
snOspfRoutingInfo	fdry.1.2.4.14	"OSPF Routing Information Table" on page 15-34
snOspfTrapControl	fdry.1.2.4.15	"OSPF Traps" on page 23-20 section in the "Traps and Objects to Enable Traps" on page 23-1 chapter
snDvmrp	fdry.1.2.5	"DVMRP" on page 10-12
snDvmrpMIBObjects	fdry.1.2.5.1	
snIgmP	fdry.1.2.6	"IGMP" on page 10-1
snIgmPMIBObjects	fdry.1.2.6.1	
snFsrp	fdry.1.2.7	"FSRP Objects" on page 12-1
snFsrpGlobal	fdry.1.2.7.1	"FSRP Global Variables" on page 12-2
snFsrpIntf	fdry.1.2.7.2	"FSRP Interface Table" on page 12-2
snGblRt	fdry.1.2.8	"Global Router Objects" on page 13-1
snGblRtGeneral	fdry.1.2.8.1	
snPim	fdry.1.2.9	"PIM" on page 10-4
snPimMIBObjects	fdry.1.2.9.1	"Common PIM Objects" on page 10-4, "PIM Virtual Interface Table" on page 10-6, "PIM Neighbor Table" on page 10-7, and "PIM Virtual Interface Statistics Table" on page 10-8
snPimSMMIBObjects	fdry.1.2.9.2	"PIM-SM" on page 10-10

**Table 2.1: Summary of MIB Objects Proprietary to Foundry Products (Continued)**

<b>Object Group Name</b>	<b>Object Identifier</b>	<b>Sections to Refer To</b>
snAppleTalk	fdry.1.2.10	"AppleTalk" on page 18-1
snRtATGeneral	fdry.1.2.10.1	
snBgp4	fdry.1.2.11	"BGP4" on page 16-1
snBgp4Gen	fdry.1.2.11.1	"BGP4 General Variables" on page 16-2
snBgp4AddrFilter	fdry.1.2.11.2	"BGP4 Address Filter Table" on page 16-8
snBgp4AggregateAddr	fdry.1.2.11.3	"BGP4 Aggregate Address Table" on page 16-9
snBgp4AsPathFilter	fdry.1.2.11.4	"BGP4 AS-Path Filter Table" on page 16-12
snBgp4CommunityFilter	fdry.1.2.11.5	"BGP4 Community Filter Table" on page 16-13
snBgp4NeighGenCfg	fdry.1.2.11.6	"BGP4 Neighbor General Configuration Table" on page 16-24
snBgp4NeighDistGroup	fdry.1.2.11.7	"BGP4 Neighbor Distribute Group Table" on page 16-27
snBgp4NeighFilterGroup	fdry.1.2.11.8	"BGP4 Neighbor Filter Group Table" on page 16-29
snBgp4NeighRouteMap	fdry.1.2.11.9	"BGP4 Neighbor Route Map Table" on page 16-30
snBgp4Network	fdry.1.2.11.10	"BGP4 Network Table" on page 16-7
snBgp4Redis	fdry.1.2.11.11	"BGP4 Redistribution of Routes Table" on page 16-20
snBgp4RouteMapFilter	fdry.1.2.11.12	"BGP4 Route Map Filter Table" on page 16-14
snBgp4RouteMapMatch	fdry.1.2.11.13	"BGP4 Route Map Match Configuration Table" on page 16-15
snBgp4RouteMapSet	fdry.1.2.11.14	"BGP4 Route Map Set Configuration Table" on page 16-18
snBgp4NeighOperStatus	fdry.1.2.11.15	"BGP4 Neighbor Operational Status Table" on page 16-31
snBgp4NeighborSummary	fdry.1.2.11.17	"BGP4 Neighbor Summary Table" on page 16-33
snBgp4Attribute	fdry.1.2.11.18	"BGP4 Attribute Entries Table" on page 16-11
snBgp4ClearNeighborCmd	fdry.1.2.11.19	"BGP4 Clear Neighbor Command Table" on page 16-35
snBgp4NeighPrefixGroup	fdry.1.2.11.20	"BGP4 Neighbor Prefix Group Table" on page 16-35
snVrrp	fdry.1.2.12	"Router Redundancy Protocols" on page 12-1

**Table 2.1: Summary of MIB Objects Proprietary to Foundry Products (Continued)**

Object Group Name	Object Identifier	Sections to Refer To
snVrrpGlobal	fdry.1.2.12.1	“VRRP Global Variables” on page 12-4
snVrrpIf2Table	fdry.1.2.12..4.1	“VRRP and VRRPE Interface Table 2” on page 12-6
snVrrpVirRtr2Table	fdry.1.2.12.5.	“VRRP and VRRPE Parameter Table 2” on page 12-13
snLoopbackIf	fdry.1.2.13	“Loopback Interface Configuration Table” on page 7-32
snPOS	fdry.1.2.14	“Packet Port Information Table” on page 7-27
snPOSInfo	fdry.1.2.14.1	
<b>registration</b>	<b>fdry.1.3</b>	<b>Product identification</b>

## Structure of This Guide

All chapters in this guide contain details about the MIB objects that are in the Foundry MIB. Each object is presented with its object name and OID, the access type available for that object (for example, read-write or read only), and a description. Objects are grouped according to their function.

The chapter “Traps and Objects to Enable Traps” on page 23-1 contains both the objects used to enable a particular type of trap and the objects that are available for a trap type. For example, objects to enable Layer 4 traps as well as the Layer 4 trap objects are in the chapter.

## General Notes

SNMPv3 engine is supported in Foundry devices, beginning with IronWare release 07.5.01; however, there are no MIB objects specific to SNMPv3. The SNMPv3 engine can accept V1, V2c and V3 packet formats. IronWare releases prior to 07.5.01 support SNMP v1 and v2c engine. No V3 packet can be accepted by these engines.

Also, in IronWare releases earlier than 07.5.00, the SNMP agent does not check for type validity with the SNMP version. In IronWare release 07.5.00 and above, if the manager sends an SNMP request with a varbind of an invalid type for that version of SNMP, the SNMP agent sends a response with the error “noSuchName” for that varbind. For example, MIB objects of type Counter64 cannot be retrieved using a v1 packet, as Counter64 is a v2c and v3 type.



---

## Chapter 3 Registration

Registration objects identify the Foundry product that is being managed. The following table presents the objects for product registration. The sysOID will return one of these values:

<b>Object Name and Identifier</b>	<b>Description</b>
snFIWGSwitch fdry.1.3.1.1	Stackable FastIron Workgroup Switch
snFIBBSwitch fdry.1.3.1.2	Stackable FastIron Backbone Switch
snNIRouter fdry.1.3.2.1	Stackable NetIron Router
snSI fdry.1.3.3.1	Stackable ServerIron
snSIXL fdry.1.3.3.2	Stackable ServerIronXL
snSIXLTCS fdry.1.3.3.3	Stackable ServerIronXL TCS
snTISwitch fdry.1.3.4.1	Stackable Turbolron/8 Switch
snTIRouter fdry.1.3.4.2	Stackable Turbolron/8 Router
snT8Switch fdry.1.3.5.1	Stackable Turbolron/8 Switch
snT8Router fdry.1.3.5.2	Stackable Turbolron/8 Router

<b>Object Name and Identifier</b>	<b>Description</b>
snT8SI fdry.1.3.5.3	Stackable ServerIronXL
snT8SIXLG fdry.1.3.5.4	Stackable ServerIronXLG
snBI4000Switch fdry.1.3.6.1	BigIron 4000 Switch
snBI4000Router fdry.1.3.6.2	BigIron 4000 Router
snBI4000SI fdry.1.3.6.3	BigServerIron, 4-slot
snBI8000Switch fdry.1.3.7.1	BigIron 8000 Switch
snBI8000Router fdry.1.3.7.2	BigIron 8000 Router
snBI8000SI fdry.1.3.7.3	BigServerIron
snFI2Switch fdry.1.3.8.1	FastIron II Switch
snFI2Router fdry.1.3.8.2	FastIron II Router
snFI2PlusSwitch fdry.1.3.9.1	FastIron II Plus switch
snFI2PlusRouter fdry.1.3.9.2	FastIron II Plus router
snNI400Router fdry.1.3.10.1	NetIron Router
snNI800Router fdry.1.3.11.1	NetIron 800 Router
snFI2GCSwitch fdry.1.3.12.1	FastIron II GC switch
snFI2GCRouter fdry.1.3.12.2	FastIron II GC router
snFI2PlusGCSwitch fdry.1.3.13.1	FastIron II Plus GC switch



---

<b>Object Name and Identifier</b>	<b>Description</b>
snFI2PlusGCRouter fdry.1.3.13.2	FastIron II Plus GC router
snBigIron15000 fdry.1.3.14.1	BigIron 15000 Switch
snBI15000Router fdry.1.3.14.2	BigIron 15000 Router
snBI15000SI fdry.1.3.14.3	BigIron 15000 ServerIron for M2-M4 modules running the BS2 ServerIron code
snNI1500Router fdry.1.3.15.1	NetIron 1500 Router
snFI3Switch fdry.1.3.16.1	FastIron III Switch
snFI3Router fdry.1.3.16.2	FastIron III Router
snFI3GCSwitch fdry.1.3.17.1	FastIron III GC switch
snFI3GCRouter fdry.1.3.17.2	FastIron III GC router
snSI400Switch fdry.1.3.18.1	ServerIron 400 switch
snSI400Router fdry.1.3.18.2	ServerIron 400 router
snSI800Switch fdry.1.3.19.1	ServerIron 800 switch
snSI800Router fdry.1.3.19.2	ServerIron 800 router
snSI1500Switch fdry.1.3.20.1	ServerIron 1500 switch
snSI1500Router fdry.1.3.20.2	ServerIron 1500 router
sn4802Switch fdry.1.3.21.1	Stackable FastIron 4802 switch
sn4802Router fdry.1.3.21.2	Stackable FastIron 4802 router

---

<b>Object Name and Identifier</b>	<b>Description</b>
sn4802SI fdry.1.3.21.3	Stackable FastIron 4802 ServerIron
snFI400Switch fdry.1.3.22.1	FastIron 400 switch
snFI400Router fdry.1.3.22.2	FastIron 400 router
snFI800Switch fdry.1.3.23.1	FastIron 800 switch
snFI800Router fdry.1.3.23.2	FastIron 800 router
snFI1500Switch fdry.1.3.24.1	FastIron 1500 switch
snFI1500Router fdry.1.3.24.2	FastIron 1500 router
snFES2402Switch fdry.1.3.25.1	FastIron Edge Switch 2402 Switch
snFES2402Router fdry.1.3.25.1	FastIron Edge Switch 2402 Router
snFES4802Switch fdry.1.3.26.1	FastIron Edge Switch 4802 Switch
snFES4802Router fdry.1.3.26.2	FastIron Edge Switch 4802 Router
snFES9604Switch fdry.1.3.27.1	FastIron Edge Switch 9604 Switch
snFES9604Router fdry.1.3.27.2	FastIron Edge Switch 9604 Router
snFES12GCFSwitch fdry.1.3.28.1	FastIron Edge Switch 12GCF Switch
snFES12GCFRouter fdry.1.3.28.2	FastIron Edge Switch 12GCF Router
snFES2402POESwitch fdry.1.3.29.1	FastIron Edge Switch 2402 Power Over Ethernet Switch
snFES2402POERouter fdry.1.3.29.2	FastIron Edge Switch 2402 Power Over Ethernet Router

<b>Object Name and Identifier</b>	<b>Description</b>
snFES4802POESwitch fdry.1.3.30.1	FastIron Edge Switch 4802 Power Over Ethernet Switch
snFES4802POERouter fdry.1.3.30.2	FastIron Edge Switch 4802 Power Over Ethernet Router
snNI4802Switch fdry.1.3.31.1	NetIron 4802 Switch
snNI4802Router fdry.1.3.31.2	NetIron 4802 Router
snBIMG8Switch fdry.1.3.32.1	BigIron MG8 Switch
snBIMG8Router fdry.1.3.32.2	BigIron MG8 Router
snNetIron40GSwitch fdry.1.3.33.1	NetIron 40G Switch
snNI40GRouter fdry.1.3.33.2	NetIron 40G Router
snFESX424Switch fdry.1.3.34.1.1.1.1	FastIron Edge Switch X-Series 424 Switch
snFESX424Router fdry.1.3.34.1.1.1.2	FastIron Edge Switch X-Series 424 Router
snFESX424PremSwitch fdry.1.3.34.1.1.2.1	FastIron Edge Switch X-Series 424 Premium Switch
snFESX424PremRouter fdry.1.3.34.1.1.2.2	FastIron Edge Switch X-Series 424 Premium Router
snFESX424Plus1XGSwitch fdry.1.3.34.1.2.1.1	FastIron Edge Switch X-Series 424 Plus 1XG Switch
snFESX424Plus1XGRouter fdry.1.3.34.1.2.1.2	FastIron Edge Switch X-Series 424 Plus 1XG Router
snFESX424Plus1XGPremSwitch fdry.1.3.34.1.2.2.1	FastIron Edge Switch X-Series 424 Plus 1XG Premium Switch
snFESX424Plus1XGPremRouter fdry.1.3.34.1.2.2.2	FastIron Edge Switch X-Series 424 Plus 1XG Premium Router
snFESX424Plus2XGSwitch fdry.1.3.34.1.3.1.1	FastIron Edge Switch X-Series 424 Plus 2XG Switch

<b>Object Name and Identifier</b>	<b>Description</b>
snFESX424Plus2XGRouter fdry.1.3.34.1.3.1.2	FastIron Edge Switch X-Series 424 Plus 2XG Router
snFESX424Plus2XGPremSwitch fdry.1.3.34.1.3.2.1	FastIron Edge Switch X-Series 424 Plus 2XG Premium Switch
snFESX424Plus2XGPremRouter fdry.1.3.34.1.3.2.2	FastIron Edge Switch X-Series 424 Plus 2XG Premium Router
snFESX448Switch fdry.1.3.34.2.1.1.1	FastIron Edge Switch X-Series 448 Switch
snFESX448Router fdry.1.3.34.2.1.1.2	FastIron Edge Switch X-Series 448 Router
snFESX448PremSwitch fdry.1.3.34.2.1.2.1	FastIron Edge Switch X-Series 448 Premium Switch
snFESX448PremRouter fdry.1.3.34.2.1.2.2	FastIron Edge Switch X-Series 448 Premium Router
snFESX448Plus1XGSwitch fdry.1.3.34.2.2.1.1	FastIron Edge Switch X-Series 448 Plus 1XG Switch
snFESX448Plus1XGRouter fdry.1.3.34.2.2.1.2	FastIron Edge Switch X-Series 448 1XG Router
snFESX448Plus1XGPremSwitch fdry.1.3.34.2.2.2.1	FastIron Edge Switch X-Series 448 Plus 1XG Premium Switch
snFESX448Plus1XGPremRouter fdry.1.3.34.2.2.2.2	FastIron Edge Switch X-Series 448 Plus 1XG Premium Router
snFESX448Plus2XGSwitch fdry.1.3.34.2.3.1.1	FastIron Edge Switch X-Series 448 Plus 2XG Switch
snFESX448Plus2XGRouter fdry.1.3.34.2.3.1.2	FastIron Edge Switch X-Series 448 Plus 2XG Router
snFESX448Plus2XGPremSwitch fdry.1.3.34.2.3.2.1	FastIron Edge Switch X-Series 448 Plus 2XG Premium Switch
snFESX448Plus2XGPremRouter fdry.1.3.34.2.3.2.2	FastIron Edge Switch X-Series 448 Plus 2XG Premium Router
snFWSX424Switch fdry.1.3.35.1.1.1.1	FastIron Workgroup Switch X-Series (FWSX) 424 Switch
snFWSX424Plus1XGSwitch fdry.1.3.35.1.2.1.1	FastIron Workgroup Switch X-Series (FWSX) 424 plus 1 10-Gb port switch

<b>Object Name and Identifier</b>	<b>Description</b>
snFWSX424Plus2XGSwitch fdry.1.3.35.1.3.1.1	FastIron Workgroup Switch X-Series (FWSX) 424 Plus 2 10-Gb ports switch
snFWSX448Switch fdry.1.3.35.2.1.1.1	FastIron Workgroup Switch X-Series (FWSX) 448 switch
snFWSX448Plus1XGSwitch fdry.1.3.35.2.2.1.1	FastIron Workgroup Switch X-Series (FWSX) 448 switch plus 1 10-Gb port switch
snFWSX448Plus2XGSwitch fdry.1.3.35.2.3.1.1	FastIron Workgroup Switch X-Series (FWSX) 448 switch plus 2 10-Gb port switch
snFastIronSXFamly fdry.1.3.36	FastIron Super-X family
snFastIronSX1 fdry.1.3.36.1.	FastIron Super-X1
snFastIronSX1Switch fdry.1.3.36.1.1	FastIron SX1 Switch
snFastIronSX1Router fdry.1.3.36.1.2	FastIron SX1 Router
snFastIronSX1BaseL3Switch fdry.1.3.36.1.3	FastIron SX1 Base L3 Switch
snFastIronSuperXPrem fdry.1.3.36.2	FastIron SuperX Premium
snFastIronSuperXPremSwitch fdry.1.3.36.2.1	FastIron SuperX Premium Switch
snFastIronSuperXPremRouter fdry.1.3.36.2.2	FastIron SuperX Premium Router
snFastIronSuperXPremBaseL3S witch fdry.1.3.36.2.3	FastIron SuperX Premium Base Layer 3 Switch
snBigIronSuperXFamly fdry.1.3.37	BigIron SuperX Family
snBigIronSuperX fdry.1.3.37.1	BigIron SuperX
snBigIronSuperXSwitch fdry.1.3.37.1.1	BigIron SuperX Switch
snBigIronSuperXRouter fdry.1.3.37.1.2	BigIron SuperX Router

<b>Object Name and Identifier</b>	<b>Description</b>
snBigIronSuperXBaseL3Switch fdry.1.3.37.1.3	BigIron SuperX Base L3 Switch
snTurboIronSuperXFamily fdry.1.3.38	TurboIron SuperX Family
snTurboIronSuperX fdry.1.3.38.1	TurboIron SuperX
snTurboIronSuperXSwitch fdry.1.3.38.1.1	TurboIron SuperX Switch
snTurboIronSuperXRouter fdry.1.3.38.1.2	TurboIron SuperX Router
snTurboIronSuperXBaseL3Switch fdry.1.3.38.1.3	TurboIron SuperX Base L3 Switch
snTurboIronSuperXPrem fdry.1.3.38.2	TurboIron SuperX Premium
snTurboIronSuperXPremSwitch fdry.1.3.38.2.1	TurboIron SuperX Premium Switch
snTurboIronSuperXPremRouter fdry.1.3.38.2.2	TurboIron SuperX Premium Router
snTurboIronSuperXPremBaseL3Switch fdry.1.3.38.2.3	TurboIron SuperX Premium Base Layer 3 Switch
snIMRFamily fdry.1.3.39	IMR family
snNetIronIMR fdry.1.3.39.1	NetIron IMR 640 family
snNIIMRRouter fdry.1.3.39.2	NetIron IMR 640 router
edgelron fdry.1.4	Edgelron
edgelronMib fdry.1.4.1	Edgelron MIB
edgelronType2 fdry.1.5	Edgelron Type 2
edgelronType2Mib fdry.1.5.1	Edgelron Type 2 MIB

---

<b>Object Name and Identifier</b>	<b>Description</b>
wirelessAp fdry.1.6	IronPoint 200 Access Point
wirelessProbe fdry.1.7	IronPoint 200 Sensor
accessIron fdry.1.8	AccessIron
vendors fdry.2	
digitalChina fdry.2.1	Digital China
dcrs7504Switch fdry.2.1.1.1	DCRS 7504 switch
dcrs7504Router fdry.2.1.1.2	DCRS 7504 router
dcrs7508Switch fdry.2.1.2.1	DCRS 7508 switch
dcrs7508Router fdry.2.1.2.2	DCRS 7508 router
dcrs7515Switch fdry.2.1.3.1	DCRS 7508 switch
dcrs7515Router fdry.2.1.3.2	DCRS 7508 router

---





---

# Chapter 4

## Physical Properties of a Device

This chapter presents the global objects for the general management of a device's physical properties, such as the current status of the power supply, fan, and modules. This chapter contains the following sections:

- “Common Objects” on page 4-1
- “Stackable Products” on page 4-21
- “Chassis Products” on page 4-25

Refer to the *Foundry Switch and Router Installation and Basic Configuration Guide* and the *Foundry ServerIron Installation and Configuration Guide* for details on power supplies, fans, modules, and other features discussed in this chapter.

### Common Objects

The following sections contain objects that are common to most Foundry devices:

- “Power Supply” on page 4-2
- “Fan” on page 4-3
- “Boards” on page 4-4
- “Chassis Number” on page 4-7
- “Agent Board Table” on page 4-7
- “Agent Temperature Table (snAgentTemp Table)” on page 4-14
- “Configured Module Table” on page 4-15
- “Redundant Modules” on page 4-19

## Power Supply

The following object applies to all Foundry devices. Refer to the chapter, “Traps and Objects to Enable Traps” on page 23-1, for information on power supply traps.

Name, Identifier, and Syntax	Access	Description																														
snChasPwrSupplyStatus fdry.1.1.1.1.3 Syntax: Integer	Read only	<p>Shows the state of the power supply in Foundry products.</p> <p>This is a packed bit string. The power supply status are encoded into four bits. There are multiple power supplies per device.</p> <p>The following shows the meaning of each bit:</p> <table border="0"> <thead> <tr> <th data-bbox="789 596 922 623">Bit position</th> <th data-bbox="922 596 1016 623">Meaning</th> </tr> </thead> <tbody> <tr> <td data-bbox="789 638 862 665">16 – 31</td> <td data-bbox="862 638 964 665">reserved</td> </tr> <tr> <td data-bbox="789 680 829 707">15</td> <td data-bbox="829 680 1024 743">Power Supply 6 DC 0 – bad, 1 – good</td> </tr> <tr> <td data-bbox="789 758 829 785">14</td> <td data-bbox="829 758 1024 821">Power Supply 5 DC 0 – bad, 1 – good</td> </tr> <tr> <td data-bbox="789 835 829 863">13</td> <td data-bbox="829 835 1138 898">Power Supply 6 present status 0 – present, 1 – not present</td> </tr> <tr> <td data-bbox="789 913 829 940">12</td> <td data-bbox="829 913 1138 976">Power Supply 5 present status 0 – present, 1 – not present</td> </tr> <tr> <td data-bbox="789 991 829 1018">11</td> <td data-bbox="829 991 1024 1054">Power Supply 4 DC 0 – bad, 1 – good</td> </tr> <tr> <td data-bbox="789 1068 829 1096">10</td> <td data-bbox="829 1068 1024 1131">Power Supply 3 DC 0 – bad, 1 – good</td> </tr> <tr> <td data-bbox="789 1146 829 1173">9</td> <td data-bbox="829 1146 1127 1209">Power Supply 4 present status 0 – present, 1 – not present</td> </tr> <tr> <td data-bbox="789 1224 829 1251">8</td> <td data-bbox="829 1224 1127 1287">Power Supply 3 present status 0 – present, 1 – not present</td> </tr> <tr> <td data-bbox="789 1302 829 1329">4 – 7</td> <td data-bbox="829 1302 943 1329">Reserved.</td> </tr> <tr> <td data-bbox="789 1344 829 1371">3</td> <td data-bbox="829 1344 1078 1407">Power Supply 2 (DC +5 v) 0 – bad, 1 – good</td> </tr> <tr> <td data-bbox="789 1421 829 1449">2</td> <td data-bbox="829 1421 1078 1484">Power Supply 1 (DC +5 v) 0 – bad, 1 – good</td> </tr> <tr> <td data-bbox="789 1499 829 1526">1</td> <td data-bbox="829 1499 1127 1562">Power Supply 2 present status 0 – present, 1 – not present</td> </tr> <tr> <td data-bbox="789 1577 829 1604">0</td> <td data-bbox="829 1577 1127 1640">Power Supply 1 present status 0 – present, 1 – not present</td> </tr> </tbody> </table> <p>Bit 0 is the least significant bit.</p>	Bit position	Meaning	16 – 31	reserved	15	Power Supply 6 DC 0 – bad, 1 – good	14	Power Supply 5 DC 0 – bad, 1 – good	13	Power Supply 6 present status 0 – present, 1 – not present	12	Power Supply 5 present status 0 – present, 1 – not present	11	Power Supply 4 DC 0 – bad, 1 – good	10	Power Supply 3 DC 0 – bad, 1 – good	9	Power Supply 4 present status 0 – present, 1 – not present	8	Power Supply 3 present status 0 – present, 1 – not present	4 – 7	Reserved.	3	Power Supply 2 (DC +5 v) 0 – bad, 1 – good	2	Power Supply 1 (DC +5 v) 0 – bad, 1 – good	1	Power Supply 2 present status 0 – present, 1 – not present	0	Power Supply 1 present status 0 – present, 1 – not present
Bit position	Meaning																															
16 – 31	reserved																															
15	Power Supply 6 DC 0 – bad, 1 – good																															
14	Power Supply 5 DC 0 – bad, 1 – good																															
13	Power Supply 6 present status 0 – present, 1 – not present																															
12	Power Supply 5 present status 0 – present, 1 – not present																															
11	Power Supply 4 DC 0 – bad, 1 – good																															
10	Power Supply 3 DC 0 – bad, 1 – good																															
9	Power Supply 4 present status 0 – present, 1 – not present																															
8	Power Supply 3 present status 0 – present, 1 – not present																															
4 – 7	Reserved.																															
3	Power Supply 2 (DC +5 v) 0 – bad, 1 – good																															
2	Power Supply 1 (DC +5 v) 0 – bad, 1 – good																															
1	Power Supply 2 present status 0 – present, 1 – not present																															
0	Power Supply 1 present status 0 – present, 1 – not present																															

## Fan

The following object applies to all stackable Foundry devices. Refer to the chapter, “Traps and Objects to Enable Traps” on page 23-1, for information on traps for fans.

Name, Identifier, and Syntax	Access	Description																
snChasFanStatus fdry.1.1.1.1.4 Syntax: Integer	Read only	Shows the status of fans in stackable products. There are six fans per device.  This is a packed bit string. Each bit shows one of the following values: <ul style="list-style-type: none"> <li>• 0 – Fan failure.</li> <li>• 1 – Fan is operational</li> </ul> The following shows the meaning of each bit: <table border="0" style="margin-left: 40px;"> <thead> <tr> <th style="text-align: left;">Bit position</th> <th style="text-align: left;">Meaning</th> </tr> </thead> <tbody> <tr> <td>6 – 31</td> <td>reserved</td> </tr> <tr> <td>5</td> <td>Fan6 status</td> </tr> <tr> <td>4</td> <td>Fan5 status</td> </tr> <tr> <td>3</td> <td>Fan4 status</td> </tr> <tr> <td>2</td> <td>Fan3 status</td> </tr> <tr> <td>1</td> <td>Fan2 status</td> </tr> <tr> <td>0</td> <td>Fan1 status</td> </tr> </tbody> </table> (Bit 0 is the least significant bit.)	Bit position	Meaning	6 – 31	reserved	5	Fan6 status	4	Fan5 status	3	Fan4 status	2	Fan3 status	1	Fan2 status	0	Fan1 status
Bit position	Meaning																	
6 – 31	reserved																	
5	Fan6 status																	
4	Fan5 status																	
3	Fan4 status																	
2	Fan3 status																	
1	Fan2 status																	
0	Fan1 status																	

## Boards

Name, Identifier, and Syntax	Access	Description
snChasMainBrdd fdry.1.1.1.1.13 Syntax: Octet string	Read only	<p data-bbox="743 359 1406 436">Applies to all stackable Foundry products. It identifies the main board. This is an encoded octet string. Each octet provides the following information:</p> <p data-bbox="743 464 1260 487"><b>Octet 0</b> – Identifies the format of this octet string.</p> <p data-bbox="743 506 915 529"><b>Octets 1 and 2:</b></p> <p data-bbox="743 548 1102 571"><b>If the value of Octet 0 is 1, then:</b></p> <p data-bbox="743 598 992 621"><b>Octet 1</b> – Product type:</p> <ul data-bbox="743 640 943 890" style="list-style-type: none"> <li>• FIWG – 0x57</li> <li>• FIBB – 0x42</li> <li>• FIMLS – 0x4D</li> <li>• NI – 0x4E</li> <li>• TI – 0x54</li> <li>• TIRT – 0x52</li> </ul> <p data-bbox="743 909 974 932"><b>Octet 2</b> – Board type:</p> <ul data-bbox="743 951 951 1024" style="list-style-type: none"> <li>• POWERPC – 1</li> <li>• ALPHA – 2</li> </ul> <p data-bbox="743 1043 1110 1066">The length of the octet string is 27.</p> <hr/> <p data-bbox="743 1094 1102 1117"><b>If Octet 0 has a value of 2, then:</b></p> <p data-bbox="743 1144 992 1167"><b>Octet 1</b> – Product type:</p> <ul data-bbox="743 1186 951 1388" style="list-style-type: none"> <li>• BI_WG – 0x57</li> <li>• BI_BB – 0x42</li> <li>• BI_NI – 0x4E</li> <li>• NI_M4 – 0x4D</li> <li>• BI_SLB – 0x53</li> </ul> <p data-bbox="743 1415 987 1438"><b>Octet 2</b> – Module type:</p> <ul data-bbox="743 1457 1118 1749" style="list-style-type: none"> <li>• MASTER_FIBER_8G – 0x0</li> <li>• MASTER_FIBER_4G – 0x1</li> <li>• MASTER_COPPER_16 – 0x2</li> <li>• FI_MASTER_FIBER_2G – 0x4</li> <li>• FI_MASTER_FIBER_4G – 0x5</li> <li>• MASTER_COPPER_8G – 0x6</li> <li>• FI_MASTER_FIBER_8G – 0x7</li> </ul>

Name, Identifier, and Syntax	Access	Description
snChasMainBrdId (continued)		<p data-bbox="743 262 1117 289"><b>Octet 2</b> – Module type (continued):</p> <ul data-bbox="743 310 1166 787" style="list-style-type: none"> <li data-bbox="743 310 1133 338">• MASTER_COPPER_12_2 – 0x9</li> <li data-bbox="743 352 1101 380">• MASTER_FIBER_2G – 0x12</li> <li data-bbox="743 394 1101 422">• MASTER_FIBER_0G – 0x14</li> <li data-bbox="743 436 1166 464">• FI_MASTER_COPPER_8G – 0x1D</li> <li data-bbox="743 478 1166 506">• FI_MASTER_COPPER_4G – 0x1F</li> <li data-bbox="743 520 1166 548">• FI_MASTER_COPPER_2G – 0x20</li> <li data-bbox="743 562 1133 590">• MASTER_COPPER_4G – 0x21</li> <li data-bbox="743 604 1133 632">• MASTER_COPPER_2G – 0x22</li> <li data-bbox="743 646 1068 674">• MASTER_M4_8G – 0x23</li> <li data-bbox="743 688 1068 716">• MASTER_M4_4G – 0x24</li> <li data-bbox="743 730 1068 758">• MASTER_M4_0G – 0x26</li> </ul> <p data-bbox="743 800 1117 827">The length of the octet string is 28.</p> <hr/> <p data-bbox="743 848 1328 875"><b>Octet 3</b> – Processor type (both format version 1 and 2):</p> <ul data-bbox="743 896 987 1100" style="list-style-type: none"> <li data-bbox="743 896 954 924">• PVR_M603 – 3</li> <li data-bbox="743 938 954 966">• PVR_M604 – 4</li> <li data-bbox="743 980 971 1008">• PVR_M603E – 6</li> <li data-bbox="743 1022 987 1050">• PVR_M603EV – 7</li> <li data-bbox="743 1064 971 1092">• PVR_M604E – 9</li> </ul> <p data-bbox="743 1121 1365 1178"><b>Octet 4 to Octet 5</b> – Processor speed in MHz (both format version 1 and 2):</p> <p data-bbox="743 1199 964 1226"><b>Octet 6</b> – MAC type:</p> <ul data-bbox="743 1247 1068 1583" style="list-style-type: none"> <li data-bbox="743 1247 964 1274">• MAC_NONE – 0</li> <li data-bbox="743 1289 1052 1316">• MAC_SEEQ_10_100 – 1</li> <li data-bbox="743 1331 1040 1358">• MAC_DEC_10_100 – 2</li> <li data-bbox="743 1373 932 1400">• PHY_ICS – 3</li> <li data-bbox="743 1415 1068 1442">• MAC_XI0GMAC_1000 – 4</li> <li data-bbox="743 1457 1029 1484">• MAC_SEEQ_1000 – 5</li> <li data-bbox="743 1499 1029 1526">• MAC_GMAC_1000 – 6</li> <li data-bbox="743 1541 1013 1568">• MAC_VLSI_1000 – 7</li> </ul>

Name, Identifier, and Syntax	Access	Description
snChasMainBrdId (continued)		<p data-bbox="743 262 1273 289"><b>Octet 7</b> – PHY type (both format version 1 and 2):</p> <ul data-bbox="743 310 1036 646" style="list-style-type: none"> <li>PHY_NONE – 0</li> <li>PHY_QSI – 1</li> <li>PHY_BROADCOM – 2</li> <li>PHY_ICS – 3</li> <li>PHY_NATIONAL – 4</li> <li>PHY_LEVEL1 – 6</li> <li>PHY_LEVEL16 – 7</li> <li>PHY_LEVEL24 – 8</li> </ul> <p data-bbox="743 667 954 695"><b>Octet 8</b> – Port type:</p> <ul data-bbox="743 716 932 779" style="list-style-type: none"> <li>COPPER – 0</li> <li>FIBER – 1</li> </ul> <p data-bbox="743 800 1328 827"><b>Octet 9</b> – Fiber port type (both format version 1 and 2):</p> <ul data-bbox="743 848 992 1100" style="list-style-type: none"> <li>NONFIBER – 0</li> <li>SX_FIBER – 1</li> <li>LX_FIBER – 2</li> <li>LHX_FIBER – 3</li> <li>LX_SX_FIBER – 4</li> <li>LHB_FIBER – 5</li> </ul> <p data-bbox="743 1121 1360 1184"><b>Octet 10 to Octet 13</b> – DRAM size in KBytes (both format version 1 and 2)</p> <p data-bbox="743 1205 1398 1247"><b>Octet 14 to Octet 17</b> – Boot flash size in KBytes (both format version 1 and 2)</p> <p data-bbox="743 1268 1403 1331"><b>Octet 18 to Octet 21</b> – Code flash size in KBytes (both format version 1 and 2)</p> <p data-bbox="743 1352 1382 1394"><b>Octet 22 to Octet 27</b> – Serial number (both format version 1 and 2)</p> <p data-bbox="743 1415 1370 1442"><b>Octet 28</b> – Chassis backplane type (format version 1 only):</p> <p data-bbox="743 1463 1224 1491">This octet applies only if Octet 0 is equal to 1.</p> <ul data-bbox="743 1512 1062 1709" style="list-style-type: none"> <li>chassis4000 – 0x00</li> <li>chassis8000 – 0x04</li> <li>chassis15000 – 0x05</li> <li>Turbo8 – 0x07 (stack2)</li> <li>FastIron2 – 0x06 (stack1)</li> </ul>

## Chassis Number

Name, OID, and Syntax	Access	Description
snChasIdNumber fdry.1.1.1.1.17 Syntax: Display string	Read only	Shows the chassis identity number. This is used by inventory control. This not the number on the label of the device.  By default, this object displays a null string. It can have up to 64 characters.

## Agent Board Table

The Agent Board Table provides information about the boards. It contains the board ID, board status, LEDs, status, and other information of the main and expansion board. The table applies to all Foundry devices, except for the ServerIron products.

Name, OID, and Syntax	Access	Description
snAgentBrdTable fdry.1.1.2.2.1	None	A table of each physical board information.
snAgentBrdEntry fdry.1.1.2.2.1.1	None	A row in the Agent Board table.
snAgentBrdIndex fdry.1.1.2.2.1.1.1 Syntax: Integer	Read only	The index to the Agent Board Table.  Valid values: 1 – 32
snAgentBrdMainBrdDescription fdry.1.1.2.2.1.1.2 Syntax: Display string	Read only	Contains the main board description. This object can have up to 128 characters.
snAgentBrdMainBrdId fdry.1.1.2.2.1.1.3 Syntax: Octet string	Read only	Is the main board identifier, which can uniquely identify a board type. It is an encoded octet string. The octets in the string provide the following information:  <b>Octet 0</b> – Identifies the format of this object's octet string. This object has a value of 2  <b>Octet 1</b> – Product type: <ul style="list-style-type: none"> <li>• BI_WG – 0x57</li> <li>• BI_BB – 0x42</li> <li>• BI_NI – 0x4E</li> <li>• NI_M4 – 0x4D</li> <li>• BI_SLB – 0x53</li> </ul>

Name, OID, and Syntax	Access	Description
snAgentBrdMainBrdId (continued)		<p><b>Octet 2</b> – Module type:</p> <ul style="list-style-type: none"> <li>• MASTER_FIBER_8G – 0x0</li> <li>• MASTER_FIBER_4G – 0x1</li> <li>• MASTER_COPPER_16 – 0x2</li> <li>• SLAVE_FIBER_4G – 0x3</li> <li>• FI_MASTER_FIBER_2G – 0x4</li> <li>• FI_MASTER_FIBER_4G – 0x5</li> <li>• MASTER_COPPER_8G – 0x6</li> <li>• FI_MASTER_FIBER_8G – 0x7</li> <li>• SLAVE_FIBER_8G – 0x8</li> <li>• MASTER_COPPER_12_2 – 0x9</li> <li>• SLAVE_COPPER_24 – 0xA</li> <li>• FI_SLAVE_COPPER_24 – 0xB</li> <li>• SLAVE_100FX_16 – 0xC</li> <li>• SLAVE_100FX_8 – 0xD</li> <li>• SLAVE_COPPER_8G – 0xE</li> <li>• SLAVE_COPPER_16_2 – 0xF</li> <li>• STACK_FIBER_8G – 0x10</li> <li>• STACK_COPPER_8G – 0x11</li> <li>• MASTER_FIBER_2G – 0x12</li> <li>• SLAVE_100FX_24 – 0x13</li> <li>• MASTER_FIBER_0G – 0x14</li> <li>• POS_622M – 0x15</li> <li>• POS_155M – 0x16</li> <li>• SLAVE_FIBER_2G – 0x17</li> <li>• SLAVE_COPPER_2G – 0x18</li> <li>• FI_SLAVE_FIBER_2G – 0x19</li> <li>• FI_SLAVE_FIBER_4G – 0x1A</li> <li>• FI_SLAVE_FIBER_8G – 0x1B</li> <li>• FI_SLAVE_COPPER_8G – 0x1C</li> <li>• FI_MASTER_COPPER_8G – 0x1D</li> <li>• POS_155M2P – 0x1E</li> <li>• FI_MASTER_COPPER_4G – 0x1F</li> <li>• FI_MASTER_COPPER_2G – 0x20</li> <li>• MASTER_COPPER_4G – 0x21</li> </ul>



Name, OID, and Syntax	Access	Description
snAgentBrdMainBrdId (continued)		<p data-bbox="743 262 1117 289"><b>Octet 2</b> – Module type (continued):</p> <ul data-bbox="743 310 1138 1276" style="list-style-type: none"> <li data-bbox="743 310 1130 338">• MASTER_COPPER_2G – 0x22</li> <li data-bbox="743 352 1062 380">• MASTER_M4_8G – 0x23</li> <li data-bbox="743 394 1062 422">• MASTER_M4_4G – 0x24</li> <li data-bbox="743 436 1062 464">• MASTER_M4_2G – 0x25</li> <li data-bbox="743 478 1062 506">• MASTER_M4_0G – 0x26</li> <li data-bbox="743 520 1062 548">• MASTER_M5_0G – 0x27</li> <li data-bbox="743 562 1008 590">• POS_2488M – 0x28</li> <li data-bbox="743 604 1036 632">• SLAVE_M5_0G – 0x29</li> <li data-bbox="743 646 1024 674">• POS_N2488M – 0x2A</li> <li data-bbox="743 688 1068 716">• STACK_IPC_48_2 – 0x2B</li> <li data-bbox="743 730 1138 758">• SLAVE_NPA_FIBER_4G – 0x2C</li> <li data-bbox="743 772 1013 800">• ATM_2PORT – 0x2D</li> <li data-bbox="743 814 1013 842">• ATM_4PORT – 0x2E</li> <li data-bbox="743 856 1089 884">• SLAVE_FIBER_10G – 0x2F</li> <li data-bbox="743 898 1045 926">• SLAVE_JC_48E – 0xC3</li> <li data-bbox="743 940 1045 968">• SLAVE_JC_48T – 0xC4</li> <li data-bbox="743 982 1105 1010">• MASTER_JC_M4_8G – 0xC5</li> <li data-bbox="743 1024 1036 1052">• SLAVE_JC_8G – 0xC6</li> <li data-bbox="743 1066 1081 1094">• SLAVE_JC_B16GF – 0xC8</li> <li data-bbox="743 1108 1097 1136">• MASTER_JC_B2404 – 0xC9</li> <li data-bbox="743 1150 1084 1178">• SLAVE_JC_B16GC – 0xCA</li> <li data-bbox="743 1192 1081 1220">• SLAVE_JC_B24FX – 0xCE</li> </ul> <p data-bbox="743 1297 1019 1325"><b>Octet 3</b> – Processor type:</p> <ul data-bbox="743 1346 987 1591" style="list-style-type: none"> <li data-bbox="743 1346 954 1373">• PVR_M603 – 3</li> <li data-bbox="743 1388 954 1415">• PVR_M604 – 4</li> <li data-bbox="743 1430 971 1457">• PVR_M603E – 6</li> <li data-bbox="743 1472 987 1499">• PVR_M603EV – 7</li> <li data-bbox="743 1514 954 1541">• PVR_M750 – 8</li> <li data-bbox="743 1556 971 1583">• PVR_M604E – 9</li> </ul> <p data-bbox="743 1612 1230 1640"><b>Octet 4 to Octet 5</b> – Processor speed in MHz</p>

Name, OID, and Syntax	Access	Description
snAgentBrdMainBrdId (continued)		<p data-bbox="743 262 964 289"><b>Octet 6</b> – MAC type:</p> <ul style="list-style-type: none"> <li data-bbox="743 310 954 338">• MAC_None – 0</li> <li data-bbox="743 352 1052 380">• MAC_SEEQ_10_100 – 1</li> <li data-bbox="743 394 1040 422">• MAC_DEC_10_100 – 2</li> <li data-bbox="743 436 1057 464">• MAC_3COM_10_100 – 3</li> <li data-bbox="743 478 1089 506">• MAC_X10GMAC_10000 – 4</li> <li data-bbox="743 520 1029 548">• MAC_SEEQ_1000 – 5</li> <li data-bbox="743 562 1036 590">• MAC_GMAC_1000 – 6</li> <li data-bbox="743 604 1013 632">• MAC_VLSI_1000 – 7</li> <li data-bbox="743 646 997 674">• PHY_LEVEL24 – 8</li> </ul> <p data-bbox="743 709 959 737"><b>Octet 7</b> – PHY type:</p> <ul style="list-style-type: none"> <li data-bbox="743 758 964 785">• PHY_NONE – 0</li> <li data-bbox="743 800 932 827">• PHY_QSI – 1</li> <li data-bbox="743 842 1036 869">• PHY_BROADCOM – 2</li> <li data-bbox="743 884 932 911">• PHY_ICS – 3</li> <li data-bbox="743 926 1013 953">• PHY_NATIONAL – 4</li> <li data-bbox="743 968 980 995">• PHY_LEVEL1 – 6</li> <li data-bbox="743 1010 997 1037">• PHY_LEVEL16 – 7</li> <li data-bbox="743 1052 997 1079">• PHY_LEVEL24 – 8</li> <li data-bbox="743 1094 1110 1121">• PHY_BROADCOM_10000 – 9</li> </ul> <p data-bbox="743 1157 954 1184"><b>Octet 8</b> – Port type:</p> <ul style="list-style-type: none"> <li data-bbox="743 1205 932 1232">• COPPER – 0</li> <li data-bbox="743 1247 899 1274">• FIBER – 1</li> </ul> <p data-bbox="743 1289 1013 1316"><b>Octet 9</b> – Fiber port type:</p> <ul style="list-style-type: none"> <li data-bbox="743 1337 954 1365">• NONFIBER – 0</li> <li data-bbox="743 1379 948 1407">• SX_FIBER – 1</li> <li data-bbox="743 1421 948 1449">• LX_FIBER – 2</li> <li data-bbox="743 1463 964 1491">• LHX_FIBER – 3</li> </ul> <p data-bbox="743 1514 1252 1541"><b>Octet 10 to Octet 13</b> – Size of DRAM in KBytes</p> <p data-bbox="743 1556 1284 1583"><b>Octet 14 to Octet 17</b> – Size of boot flash in KBytes</p> <p data-bbox="743 1598 1289 1625"><b>Octet 18 to Octet 21</b> – Size of code flash in KBytes</p> <p data-bbox="743 1640 1143 1667"><b>Octet 22 to Octet 27</b> – Serial number</p>

Name, OID, and Syntax	Access	Description
snAgentBrdMainBrdId (continued)		<p><b>Octet 28</b> – Chassis backplane type.</p> <ul style="list-style-type: none"> <li>• chassis4000 – 0x00</li> <li>• chassis8000 – 0x04</li> <li>• chassis15000 – 0x05</li> <li>• Turbo8 – 0x07 (stack2)</li> <li>• FastIron2 – 0x06 (stack1)</li> </ul>
snAgentBrdMainPortTotal fdry.1.1.2.2.1.1.4 Syntax: Integer	Read only	Shows the total number of ports on the main board.
snAgentBrdExpBrdDescription fdry.1.1.2.2.1.1.5 Syntax: Display string	Read only	Contains the expansion board description string. Expansion board are those boards attaching on the main board. This object can have up to 128 characters.
snAgentBrdExpBrdId fdry.1.1.2.2.1.1.6 Syntax: Octet string	Read only	Is the expansion board identifier. Expansion board are those boards attaching on the main board. It is an encoded octet string with the following meaning: <p><b>Octet 0</b> – Identifies the format of this string. This octet has a value of 1.</p> <p><b>Octet 1</b> – Expansion board type:</p> <ul style="list-style-type: none"> <li>• HUNDRED_MEG_1PORT – 1</li> <li>• HUNDRED_MEG_2PORT – 2</li> <li>• HUNDRED_MEG_1PORT_COPPER – 3</li> <li>• HUNDRED_MEG_2PORT_COPPER – 4</li> <li>• HUNDRED_MEG_2PORT_LX – 5</li> <li>• GIGA_1PORT – 8</li> <li>• GIGA_2PORT – 9</li> </ul> <p><b>Octet 2</b> – Fiber port type:</p> <ul style="list-style-type: none"> <li>• NONFIBER – 0</li> <li>• SX_FIBER – 1</li> <li>• LX_FIBER – 2</li> <li>• LHX_FIBER – 3</li> <li>• LX_SX_FIBER – 4</li> </ul>
snAgentBrdExpPortTotal fdry.1.1.2.2.1.1.7 Syntax: Integer	Read only	Shows the total number of ports for the expansion board.

Name, OID, and Syntax	Access	Description
snAgentBrdStatusLeds fdry.1.1.2.2.1.1.8 Syntax: Integer	Read only	Applies to devices running IronWare release 07.1.00 and earlier. Refer to the “Bit Map of LEDs” in Figure 4.1 on page 4-23. It is replaced by the object snAgentBrdStatusLedString in Release 07.2. and later.  The value of this LED can be one of the following:  0 – Link off  1 – Link on
snAgentBrdTrafficLeds fdry.1.1.2.2.1.1.9 Syntax: Integer	Read only	Applies to devices running IronWare release 07.1.00 and earlier. Refer to the “Bit Map of LEDs” in Figure 4.1 on page 4-23. It is replaced by the object snAgentBrdTrafficLedString in Release 07.2. and later.  The value of this LED can be one of the following:  0 – No traffic.  1 – Traffic is flowing.
snAgentBrdMediaLeds fdry.1.1.2.2.1.1.10 Syntax: Integer	Read only	Applies to devices that have an LED for media type and are running IronWare release 07.1.00 and earlier. Refer to the “Bit Map of LEDs” in Figure 4.1 on page 4-23. It is replaced by the object snAgentBrdMediaLedString in Release 07.2. and later.  The value of this LED can be one of the following:  0 – Half duplex.  1 – Full duplex.
snAgentBrdSpeedLeds fdry.1.1.2.2.1.1.11 Syntax: Integer	Read only	Applies to devices that have an LED for board speed and are running IronWare release 07.1.00 and earlier. Refer to the “Bit Map of LEDs” in Figure 4.1 on page 4-23. It is replaced by the object snAgentBrdSpeedLedString in Release 07.2. and later.  The value of this LED can be one of the following:  0 – 10 Mbit  1 – 100Mbit
snAgentBrdModuleStatus fdry.1.1.2.2.1.1.12 Syntax: Integer	Read only	Shows the status of a module: <ul style="list-style-type: none"> <li>• notActivated(0) – The module is not activated.</li> <li>• moduleEmpty(0) – The slot of the chassis is empty.</li> <li>• moduleGoingDown(2) – The module is going down.</li> <li>• moduleRejected(3) – The module is being rejected due to a wrong configuration.</li> <li>• moduleBad(4) – The module hardware is bad.</li> <li>• moduleComingUp(9) – The module is in power-up cycle.</li> <li>• moduleRunning(10) – The module is running.</li> </ul> By default, this mode is set to notActivated(0).

Name, OID, and Syntax	Access	Description
snAgentBrdRedundantStatus fdry.1.1.2.2.1.1.13 Syntax: Integer	Read only	Shows the status of the redundant module. Non-management module always returns other(1). Management module returns the rest of the states: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• active(2)</li> <li>• standby(3)</li> <li>• crashed(4)</li> <li>• comingUp(5)</li> </ul>
snAgentBrdAlarmLeds fdry.1.1.2.2.1.1.14 Syntax: Integer	Read only	Applies to devices that have an LED for alarm and are running IronWare release 07.1.00 and earlier. Refer to the "Bit Map of LEDs" in Figure 4.1 on page 4-23. It is replaced by the object snAgentBrdAlarmLedString in Release 07.2. and later. The value of this LED can be one of the following: 0 – No alarm 1 – Alarm
snAgentBrdTxTrafficLeds fdry.1.1.2.2.1.1.15 Syntax: Integer	Read only	Applies only to POS modules that have an LED for transmit traffic and are running Release 07.1.00 and earlier. Refer to the "Bit Map of LEDs" in Figure 4.1 on page 4-23. It is replaced by the object snAgentBrdTxTrafficLedString in Release 07.2. and later. The value of this LED can be one of the following: 0 – No transmit traffic 1 – Transmit traffic
snAgentBrdRxTrafficLeds fdry.1.1.2.2.1.1.16 Syntax: Integer	Read only	Applies only to POS modules that have an LED for transmit traffic and are running Release 07.1.00 and earlier. Refer to the "Bit Map of LEDs" in Figure 4.1 on page 4-23. It is replaced by the object snAgentBrdRxTrafficLedString in Release 07.2. and later. The value of this LED can be one of the following: 0 – No receive traffic (off) 1 – Has receive traffic (on)
snAgentBrdStatusLedString fdry.1.1.2.2.1.1.17 Syntax: Octet string		Applies to devices IronWare release 07.2.00 and later. It contains an octet string that shows the value of the status of the link LED on the front panel. There are 64 bits per slot. The value of each bit can be one of the following: 0 – Link is off 1 – Link is on

Name, OID, and Syntax	Access	Description
snAgentBrdTrafficLedString fdry.1.1.2.2.1.1.18 Syntax: Octet string	Read only	Applies to devices running IronWare release 07.2.00 and later. It contains an octet string that shows the status of the traffic. There are 64 bits per slot. The value of each bit can be one of the following:  0 – No traffic 1 – Traffic is flowing
snAgentBrdMediaLedString fdry.1.1.2.2.1.1.19 Syntax: Octet string	Read only	Applies to devices with an LED for media type and are running Release 07.2.00 and later. It contains an octet string with 64 bits per slot. The value of each bit can be one of the following:  0 – Half duplex 1 – Full duplex
snAgentBrdSpeedLedString fdry.1.1.2.2.1.1.20 Syntax: Octet string	Read only	Applies to devices that have an LED for traffic speed and are running IronWare release 07.2.00 and later. It contains an octet string with 64 bits per slot. The value of each bit can be one of the following:  0 – 10 Mbit 1 – 100 Mbit
snAgentBrdAlarmLedString fdry.1.1.2.2.1.1.21 Syntax: Octet string	Read only	Applies to devices that have an LED for alarm and are running IronWare release 07.2.00 and later. It contains an octet string with 64 bits per slot. The value of each bit can be one of the following:  0 – No alarm 1 – Alarm
snAgentBrdTxTrafficLedString fdry.1.1.2.2.1.1.22 Syntax: Octet string	Read only	Applies only to POS modules running IronWare release 07.2.00 and later. It contains an octet string with 64 bits per slot. The value of each bit can be one of the following:  0 – No transmit traffic 1 – Has transmit traffic
snAgentBrdRxTrafficLedString fdry.1.1.2.2.1.1.23 Syntax: Octet string	Read only	Applies only to POS modules running IronWare release 07.2.00 and later. It contains an octet string with 64 bits per slot. The value of each bit can be one of the following:  0 – No receive traffic 1 – Has receive traffic

**NOTE:** The objects snAgentBrdStatusLedString, snAgentBrdTrafficLedString, snAgentBrdMediaLedString, snAgentBrdSpeedLedString, snAgentBrdAlarmLedString, snAgentBrdTxTrafficLedString, and snAgentBrdRxTrafficLedString provide information on the status LEDs on a device. However, some of these object apply only to POS modules.

### Agent Temperature Table (snAgentTemp Table)

This section displays the SNMP MIB objects for temperature readings on FESX and FWSX devices (software releases 02.2.00 and later).

The Agent Temperature table displays information about the temperature readings for each module's temperature sensor.

Name, OID, and Syntax	Access	Description
snAgentTempTable fdry.1.1.2.13.1	N/A	A table that displays the temperature reading for each module's temperature sensor. Note that temperature readings are displayed only for those modules that have temperature sensors.
snAgentTempEntry fdry.1.1.2.13.1.1	N/A	A row in the Agent Temperature table.
snAgentTempSlotNum fdry.1.1.2.13.1.1.1 Syntax: Integer	N/A	The slot number of the module to which the temperature sensor is attached.
snAgentTempSensorId fdry.1.1.2.13.1.1.2 Syntax: Integer	N/A	The identification number of the module's temperature sensor. The following applies to the Management module(s): <ul style="list-style-type: none"> <li>• Sensor 1 – the intake temperature</li> <li>• Sensor 2 – the exhaust-side temperature</li> </ul>
snAgentTempSensorDescr fdry.1.1.2.13.1.1.3 Syntax: Display string	Read only	A description of the temperature sensor.
snAgentTempValue fdry.1.1.2.13.1.1.4 Syntax: Integer	Read only	The temperature reading for the temperature sensor. This value is displayed in units of 0.5 degrees Celsius. Valid values: -110 – 250

## Configured Module Table

The Configured Module Table contains information about modules. It includes the object "snAgentConfigModuleSerialNumber", which contains the serial number of a device. These objects are available in all chassis devices:

- BigIron 4000, BigIron 8000, and BigIron 15000
- FastIron III
- FastIron 400, FastIron 800, and FastIron 1500
- NetIron 400, NetIron 800, and NetIron 1500

Name, OID, and Syntax	Access	Description
snAgentConfigModuleTable fdry.1.1.2.8.1	None	A table of each configured module information.

Name, OID, and Syntax	Access	Description
snAgentConfigModuleEntry fdry.1.1.2.8.1.1	None	A row in the Agent Configured Module table.
snAgentConfigModuleIndex fdry.1.1.2.8.1.1.1 Syntax: Integer	Read only	The index to the Agent Configured Module Table.  The modules configured are using the “#module“ command. The “show run” command may list these modules at the beginning of the list, but these modules may not really be existing in the system.



Name, OID, and Syntax	Access	Description
snAgentConfigModuleType fdry.1.1.2.8.1.1.2 Syntax: Integer	Read-write	The module type that has been configured for the device: <ul style="list-style-type: none"> <li>• bi8PortGigManagementModule(0)</li> <li>• bi4PortGigManagementModule(1)</li> <li>• bi16PortCopperManagementModule(2)</li> <li>• bi4PortGigModule(3)</li> <li>• fi2PortGigManagementModule(4)</li> <li>• fi4PortGigManagementModule(5)</li> <li>• bi8PortGigCopperManagementModule(6)</li> <li>• fi8PortGigManagementModule(7)</li> <li>• bi8PortGigModule(8)</li> <li>• bi24PortCopperModule(10)</li> <li>• fi24PortCopperModule(11)</li> <li>• bi16Port100FXModule(12)</li> <li>• bi8Port100FXModule(13)</li> <li>• bi8PortGigCopperModule(14)</li> <li>• bi2PortGigManagementModule(18)</li> <li>• bi24Port100FXModule(19)</li> <li>• bi0PortManagementModule(20)</li> <li>• pos622MbsModule(21)</li> <li>• pos155MbsModule(22)</li> <li>• bi2PortGigModule(23)</li> <li>• bi2PortGigCopperModule(24)</li> <li>• fi2PortGigModule(25)</li> <li>• fi4PortGigModule(26)</li> <li>• fi8PortGigModule(27)</li> <li>• fi8PortGigCopperModule(28)</li> <li>• fi8PortGigCopperManagementModule(29)</li> <li>• pos155Mbs2PModule(30)</li> <li>• fi4PortGigCopperManagementModule(31)</li> <li>• fi2PortGigCopperManagementModule(32)</li> <li>• bi4PortGigCopperManagementModule(33)</li> <li>• bi2PortGigCopperManagementModule(34)</li> </ul>

Name, OID, and Syntax	Access	Description
snAgentConfigModuleType (continued)		<ul style="list-style-type: none"> <li>• bi8PortGigM4ManagementModule(35)</li> <li>• bi4PortGigM4ManagementModule(36)</li> <li>• bi2PortGigM4ManagementModule(37)</li> <li>• bi0PortGigM4ManagementModule(38)</li> <li>• bi0PortWSMManagementModule(39)</li> <li>• biPos2Port2488MbsModule(40)</li> <li>• bi0PortWSMModule(41)</li> <li>• niPos2Port2488MbsModule(42)</li> <li>• ni4802(43)</li> <li>• bi4PortGigNPAModule(44)</li> <li>• biAtm2Port155MbsModule(45)</li> <li>• biAtm4Port155MbsModule(46)</li> <li>• bi1Port10GigModule(47)</li> <li>• bi4Port10GigModule(48)</li> <li>• bi32PortGigModule(49)</li> <li>• bi1Port100FXManagementModule(50)</li> <li>• biFiJc48ePort100fxlpcModule(195)</li> <li>• biFiJc48tPort100fxlpcModule(196)</li> <li>• biFiJc8PortGigM4ManagementModule(197)</li> <li>• biFiJc8PortGigIgcModule(198)</li> </ul>
snAgentConfigModuleRowStatus fdry.1.1.2.8.1.1.3 Syntax: Integer	Read-write	<p>To create or delete a configured module table entry.</p> <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> </ul>
snAgentConfigModuleDescription fdry.1.1.2.8.1.1.4 Syntax: Display string	Read only	A description of the configured module.
snAgentConfigModuleOperStatus fdry.1.1.2.8.1.1.5 Syntax: Display string	Read only	Module operational status. A blank indicates that the physical module has not been inserted to the chassis.

Name, OID, and Syntax	Access	Description
snAgentConfigModuleSerialNumber fdry.1.1.2.8.1.1.6 Syntax: Display string	Read only	Module serial number. A blank indicates that the serial number has not been programmed in the module's EEPROM or serial number is not supported in the module.  In IronWare releases before 07.5.0, this object returns a NULL string, indicating that it is a place holder for a serial number. Beginning with IronWare release 07.5.0 this object returns the device serial number.
snAgentConfigModuleNumberOfPorts fdry.1.1.2.8.1.1.7 Syntax: Integer,	Read only	The number of ports in the module.
snAgentConfigModuleManagementModuleType fdry.1.1.2.8.1.1.8 Syntax: Integer	Read only	The management module type: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• nonManagementModule(2)</li> <li>• unknownManagementModule(3)</li> <li>• m1ManagementModule(4)</li> <li>• m2ManagementModule(5)</li> <li>• m3ManagementModule(6)</li> <li>• m4ManagementModule(7)</li> <li>• m5ManagementModule(8)</li> <li>• jetcoreStackManagementModule(9)</li> <li>• muchoManagementModule(10)</li> </ul>
snAgentConfigModuleNumberOfCpus fdry.1.1.2.8.1.1.9 Syntax: Integer	Read only	The number of CPUs in the module.

## Redundant Modules

Use these objects to manage redundant management modules in all Foundry devices except for the ServerIron products. Refer to the chapter "Traps and Objects to Enable Traps" on page 23-1 for objects dealing with traps.

Name, OID, and Syntax	Access	Description
snAgentRedunActiveMgmtModule fdry.1.1.2.10.1.1 Syntax: Integer	Read-write	Shows the slot number of the active management module. Setting this object does not take effect immediately. You must save the configuration data to flash storage, then reboot the system before the new value takes effect. Setting a value of 0 requests the system to auto-select an active management module after power up.  Default: 0.

Name, OID, and Syntax	Access	Description
<p>snAgentRedunSyncConfig fdry.1.1.2.10.1.2 Syntax: Integer</p>	<p>Read-write</p>	<p>Shows how often the data in the active management module will be copied to the backup management module. The value for this object is in seconds.</p> <p>Setting this object to 0 disables the copy process. Setting it to a negative value starts the process immediately, but runs only once.</p> <p>Default: every 10 seconds</p>
<p>snAgentRedunBkupCopyBootCode fdry.1.1.2.10.1.3 Syntax: Integer</p>	<p>Read-write</p>	<p>If enabled, the backup management module copies the boot code of the active management module to its boot code flash storage after power up, and whenever the active management module's boot code is updated. The backup management module does not copy the boot code if is identical to what is already in its flash storage:</p> <ul style="list-style-type: none"> <li>• Disabled(0)</li> <li>• Enabled(1)</li> </ul> <p>Default: disabled(0)</p>
<p>snAgentRedunBkupBootLoad fdry.1.1.2.10.1.5 Syntax: Integer</p>	<p>Read-write</p>	<p>Downloads a new boot code from boot flash storage of the active management module to the backup management module.</p> <p>In a set operation, enter the value downloadBackup(20) to download the boot code from the active management module to the backup management module. A set operation is rejected during a download until error or normal state is reached.</p> <p>One of the following values are returned by a get operation:</p> <ul style="list-style-type: none"> <li>• normal(1) – no operation</li> <li>• operationError(17) – error codes</li> <li>• downloadbackup(20) – download boot code from active module to backup to the backup module</li> </ul>
<p>snAgentRedunSwitchOver fdry.1.1.2.10.1.6 Syntax: Integer</p>	<p>Read-write</p>	<p>Switches a backup management module to an active management module.</p> <ul style="list-style-type: none"> <li>• other(1)</li> <li>• reset(2) – Resets the backup module to active.</li> </ul>

## Stackable Products

The objects in this section are specific to Stackable devices, which include the following models:

- FastIron
- ServerIron
- NetIron

The objects for stackable devices are presented in the following sections:

- “Boards” on page 4-22
- “LEDs” on page 4-23

Refer to the “Agent Board Table” on page 4-7 for objects that apply to chassis devices.

---

**NOTE:** The MIB contains objects under the snStackGen (General Stackable Management Information) and snStackSecSwitchInfo (Stackable Management Secondary Switch Information Table) groups are not supported. They include the following objects:

snStackPriSwitchMode  
snStackMaxSecSwitch  
snStackTotalSecSwitch  
snStackSyncAllSecSwitch  
snStackSmSlotIndex  
snStackFmpSetProcess  
snStackSecSwitchTable  
snStackSecSwitchEntry  
snStackSecSwitchIndex  
snStackSecSwitchSlotId  
snStackSecSwitchPortCnts  
snStackSecSwitchEnabled  
snStackSecSwitchAck  
snStackSecSwitchMacAddr  
snStackSecSwitchSyncCmd  
snStackSecSwitchIpAddr  
snStackSecSwitchSubnetMask  
snStackSecSwitchCfgCmd

---

## Boards

The following objects apply only to stackable ServerIron products.

Name, Identifier, and Syntax	Access	Description
snChasMainBrdDescription fdry.1.1.1.1.5 Syntax: Display string	Read only	Shows the main board. This object can have up to 128 characters.
snChasMainPortTotal fdry.1.1.1.1.6 Syntax: Integer	Read only	Shows the total number of ports on the main board. Valid values: 1 – 24
snChasExpBrdDescription fdry.1.1.1.1.7 Syntax: Display string	Read only	Shows the description of the expansion board. This object can have up to 128 characters.
snChasExpPortTotal fdry.1.1.1.1.8 Syntax: Integer	Read only	Shows the total number of ports on the expansion board. Valid values: 1 – 24
snChasExpBrdId fdry.1.1.1.1.14 Syntax: Octet string	Read only	Applies only to stackable ServerIron products.  It identifies the expansion board, the board that attaches to the main board. It is an encoded octet string. The octets provide the following information:  <b>Octet 0</b> – Identifies the format of this octet string.  If Octet 0 has a value of 1, the value of the remaining octets are:  <b>Octet 1</b> – Expansion board type: <ul style="list-style-type: none"> <li>• HUNDRED_MEG_1PORT – 1</li> <li>• HUNDRED_MEG_2PORT – 2</li> <li>• HUNDRED_MEG_1PORT_COPPER – 3</li> <li>• HUNDRED_MEG_2PORT_COPPER – 4</li> <li>• HUNDRED_MEG_2PORT_LX – 5</li> <li>• GIGA_1PORT – 8, GIGA_2PORT – 9</li> </ul> <b>Octet 2</b> – Fiber port type: <ul style="list-style-type: none"> <li>• NONFIBER – 0</li> <li>• SX_FIBER – 1</li> <li>• LX_FIBER – 2</li> <li>• LHX_FIBER – 3</li> <li>• LX_SX_FIBER – 4</li> </ul>

## LEDs

This section presents the objects that apply to LEDs in stackable ServerIron devices. Figure 4.1 shows a bit map of LEDs in Foundry products. Some objects in the MIB refer to this bit map.

Figure 4.1 Bit Map of LEDs

	Port 1	Port 2	Port 3	Port 4	Port 5	Port 6	Port 7	Port 8
	Bit 0	Bit 1	Bit 2	Bit 3	Bit 4	Bit 5	Bit 6	Bit 7
Byte 1	LED 1	LED 2	LED 3	LED 4	LED 5	LED 6	LED 7	LED 8
Byte 2	LED 9	LED 10	LED 11	LED 12	LED 13	LED 14	LED 15	LED 16
Byte 3	LED 17	LED 18	LED 19	LED 20	LED 21	LED 22	LED 23	LED 24
...	...	...	...	...	...	...	...	...

Each LED contains one bit representing a switch port. Each bit shows the value of the LED. The expansion port number always begins from the last main port number.

Name, OID, and Syntax	Access	Description
snChasStatusLeds fdry.1.1.1.1.9 Syntax: Integer	Read only	Applies to devices running Release 07.1.00 and earlier. It is replaced by the object snAgentBrdStatusLedString in later releases.  This LED on the front panel of a device shows the status of the link. It is represented by one bit. There can be up to 32 bits per slot. Refer to the "Bit Map of LEDs" in Figure 4.1 on page 4-23. Status can be one of the following:  0 – Link off 1 – Link on
snChasTrafficLeds fdry.1.1.1.1.10 Syntax: Integer	Read only	Applies to devices running Release 07.1.00 and earlier. It is replaced by the object snAgentBrdTraficLedString in later releases.  This LED on the front panel of a device shows the traffic status. It is represented by one bit. There can be up to 32 bits per slot. Refer to the "Bit Map of LEDs" in Figure 4.1 on page 4-23. Status can be one of the following:  0 – No traffic 1 – Traffic is flowing
snChasMediaLeds fdry.1.1.1.1.11 Syntax: Integer	Read only	Applies to devices that have an LED for media type and are running Release 07.1.00 and earlier. It is replaced by the object snAgentBrdMediaLedString in later releases.  It is represented by one bit. There can be up to 32 bits per slot. Refer to the "Bit Map of LEDs" in Figure 4.1 on page 4-23. Status can be one of the following:  0 – Half duplex 1 – Full duplex

Name, OID, and Syntax	Access	Description
snChasSpeedLeds fdry.1.1.1.1.15 Syntax: Integer	Read only	Applies to devices that have an LED for media speed and are running Release 07.1.00 and earlier. It is replaced by the object snAgentBrdSpeedLedString in later releases.  It is represented by one bit. There can be up to 32 bits per slot. Refer to the "Bit Map of LEDs" in Figure 4.1 on page 4-23. Status can be one of the following:  0 – 10 Mbit 1 – 100 Mbit



## Chassis Products

The objects in this section apply to the following Foundry devices:

- BigIron 4000, BigIron 8000, and BigIron 15000
- FastIron 4802
- FastIron II, and FastIron III
- FastIron 400, FastIron 800, and FastIron 1500
- NetIron 400, NetIron 800, and NetIron 1500
- ServerIron 400 and ServerIron 800
- TurboIron/8

The objects for these devices are presented in the following sections:

- “General Chassis” on page 4-25
- “Power Supply Table” on page 4-26
- “Fan Table” on page 4-26
- “Temperature” on page 4-27
- “Flash Card” on page 4-28

### General Chassis

The following objects apply to all chassis-based Foundry devices.

Name, Identifier, and Syntax	Access	Description
snChasType fdry.1.1.1.1.1 Syntax: Display string	Read only	Shows the type of Foundry device being managed. This object can have up to 128 characters.  Possible value – 1
snChasSerNum fdry.1.1.1.1.2 Syntax: Display string	Read only	Shows the serial number of the chassis stored in the EEPROM of the device. This is not the serial number on the label of the device.  If the chassis serial number is available, it is the lowest three octets of the lowest MAC address in the device. For example, if the lowest MAC address is 00e0 52a9 2b20, then the serial number of the chassis is a92b20 .  If the serial number is unknown or unavailable, then the value is a null string.  This object can have up to 128 characters.

## Power Supply Table

The following table applies to the power supplies in chassis products

Name, OID, and Syntax	Access	Description
snChasPwrSupplyTable fdry.1.1.1.2.1	None	A table containing power supply information. Only installed power supplies appear in the table.
snChasPwrSupplyEntry fdry.1.1.1.2.1.1	None	A row in the power supply table. One row appears for each power supply.
snChasPwrSupplyIndex fdry.1.1.1.2.1.1.1 Syntax: Integer	Read only	The index to power supply table.
snChasPwrSupplyDescription fdry.1.1.1.2.1.1.2 Syntax: Display string	Read only	The power supply description. For example, you may see the description, "right side power supply". This object can have up to 128 characters.
snChasPwrSupplyOperStatus fdry.1.1.1.2.1.1.3 Syntax: Integer	Read only	Shows the status of the power supply: <ul style="list-style-type: none"> <li>• other(1) – Status is neither normal(2) or failure(3). This value is not used for stackables including FastIron 4802, BigIron 4000, BigIron 8000, and BigIron 15000.</li> <li>• normal(2)</li> <li>• failure(3)</li> </ul>

## Fan Table

The following table applies to fans in all chassis products.

Name, Identifier, and Syntax	Access	Description
snChasFanTable fdry.1.1.1.3.1	None	A table containing fan information. Only installed fans appear in the table.
snChasFanEntry fdry.1.1.1.3.1.1	None	A row in the fan table. One row appears for each installed fan.
snChasFanIndex fdry.1.1.1.3.1.1.1 Syntax: Integer	Read only	The index to the fan table.
snChasFanDescription fdry.1.1.1.3.1.1.2 Syntax: Display string	Read only	The fan description. For example, you may see the description "left side panel, back fan". This object can have up to 128 characters.

Name, Identifier, and Syntax	Access	Description
snChasFanOperStatus fdry.1.1.1.3.1.1.3 Syntax: Integer	Read only	Shows the status of the fan operation: <ul style="list-style-type: none"> <li>other(1) – Beginning with IronWare software release 7.6.01, this value means “not manageable” to refer to Fans 5 and 6 in the BigIron 15000. It has no meaning for other devices.</li> <li>normal(2)</li> <li>failure(3)</li> </ul>

## Temperature

The following objects manage temperature sensors in all Foundry devices, except the ServerIron products. Refer to the chapter “Traps and Objects to Enable Traps” on page 23-1 for objects dealing with traps.

Name, OID, and Syntax	Access	Description
snChasActualTemperature fdry.1.1.1.1.18 Syntax: Integer	Read only	Applies only to management modules with temperature sensors.  Shows the temperature of the chassis. Each unit is 0.5 degrees Celsius.  <b>NOTE:</b> If you are comparing this value to the value you get when you enter a show chassis command on the CLI, divide this value by 2. That would be the actual temperature you see in the CLI. This was done intentionally to represent tenth decimal value in SNMP, as SNMP can only report INTEGER values.  Valid values: 110 – 250
snChasWarningTemperature fdry.1.1.1.1.19 Syntax: Integer	Read-write	Applies only to management modules with temperature sensors.  Shows the threshold for the warning temperature. When the actual temperature exceeds this value the switch sends a temperature warning trap. Each unit is 0.5 degrees Celsius. This object applies only to management module built with temperature sensors.  Valid values: 0 – 250
snChasShutdownTemperature fdry.1.1.1.1.20 Syntax: Integer	Read-write	Applies only to management modules with temperature sensors.  Shows the temperature threshold that triggers the device to shut down. When the actual temperature exceeds this value the switch shuts down a portion of the hardware to cool down the device. Each unit is 0.5 degrees Celsius. This object applies only to management module built with temperature sensors.  Valid values: 0 – 250

**NOTE:** When performing an SNMP ISO MIB walk of the BigIron RX, increase the snmpwalk timeout to 10 seconds; otherwise, the MIB walk may time out before SNMP obtains the temperature values for the modules.

## Flash Card

The following objects manage the flash cards in all Foundry devices, except the ServerIron products.

Name, OID, and Syntax	Access	Description
snChasFlashCard fdry.1.1.1.1.22 Syntax: Integer	Read only	<p>Applies only to M4 management modules. This object is a bit array that contains the flash card status.</p> <p>This is a packed bit string. The status of each flash card is encoded into one bit. There can be up to two flash cards.</p> <p>The bits are:</p> <ul style="list-style-type: none"> <li>• 2 to 31 – Reserved</li> <li>• 1 – Flash card 2 status</li> <li>• 0 – Flash card 1 status</li> </ul> <p>(Bit 0 is the least significant bit.)</p> <p>Flash card status can be one of the following:</p> <ul style="list-style-type: none"> <li>• 0 – Flash card is absent</li> <li>• 1 – Flash card is present</li> </ul>
snChasFlashCardLeds fdry.1.1.1.1.23 Syntax: Integer	Read only	<p>Shows the status of LED on a flash card. This is a 32-bit integer type object. Each bit shows one of the following:</p> <ul style="list-style-type: none"> <li>• 0 – Flash card is off</li> <li>• 1 – Flash card is on</li> </ul>
snchasnumslots fdry.1.1.1.1.24 Syntax: Integer	Read only	Shows the number of slots in the chassis.
snchasarchitectureType fdry.1.1.1.1.25 Syntax: Integer	Read only	Shows the architecture type.
snchasProductType fdry.1.1.1.1.26 Syntax: Integer	Read only	Shows the product type.

---

# Chapter 5

## Basic Configuration and Management

This chapter contains objects to manage the software image and configuration in a device: It includes the following sections:

- “Software Image” on page 5-1
- “Software Configuration” on page 5-12
- “Error Management” on page 5-26
- “FDP and CDP” on page 5-26

Refer to the *Foundry Switch and Router Installation and Basic Configuration Guide* and the *Foundry ServerIron Installation and Configuration Guide* for detailed explanation on the features discussed in this chapter.

### Software Image

- “Reload” on page 5-2
- “NVRAM” on page 5-2
- “File Download and Upload” on page 5-4
- “Software Image Details” on page 5-8
- “Boot Sequence Table” on page 5-11

## Reload

The following object allows you to reload the agent.

Name, OID, and Syntax	Access	Description
snAgReload fdry.1.1.2.1.1 Syntax: Integer	Read-write	<p>Reboots the agent.</p> <p>The following value can be written:</p> <ul style="list-style-type: none"> <li>reset(3) – Do a hard reset</li> </ul> <p><b>NOTE:</b> To be able to use reset(3), make sure that either the “no snmp-server pw-check” CLI command has been configured in the device or the varbind, and snAgGblPassword, with the appropriate password has been added to the SetRequest PDU. The default value of snAgGblPassword is the “enable” super-user password. If the CLI command “aaa authentication snmp-server default ...” is configured, then the method list determines the value expected in the snAgGblPassword MIB object.</p> <p>The agent will return a response before the action occurs.</p> <p>The following values can only be read:</p> <ul style="list-style-type: none"> <li>other(1) – Agent is in unknown or other state</li> <li>running(2) – Agent is running</li> </ul>

## NVRAM

The objects in this section apply to all devices that use non-volatile random access memory (NVRAM), a type of memory that retains its contents when power is turned off. These objects are available in all Foundry devices.

Name, OID, and Syntax	Access	Description
snAgEraseNVRAM fdry.1.1.2.1.2 Syntax: Integer	Read-write	<p>Erases the NVRAM of the agent. This object can have one of the following values:</p> <ul style="list-style-type: none"> <li>normal(1) – NVRAM is not being erased.</li> <li>error(2) – Either the erase operation failed or the flash memory is bad</li> <li>erase(3) – NVRAM is set to be erased</li> <li>erasing(4) – NVRAM is being erased. Once the process starts, you cannot set this object to erase(3) until the process is finished and the value of this object is either normal(1) or error(2)</li> </ul>

Name, OID, and Syntax	Access	Description
snAgWriteNVRAM fdry.1.1.2.1.3 Syntax: Integer	Read-write	<p>Saves all configuration information to NVRAM of the agent. The following values can only be read:</p> <ul style="list-style-type: none"> <li>• normal(1)</li> <li>• error(2) – Operation failed or the flash is bad</li> <li>• writing(4) – Agent is writing NVRAM flash</li> </ul> <p>The following value can be written:</p> <ul style="list-style-type: none"> <li>• write(3) – Write operation</li> </ul> <p>The agent will return a response even before the write operation is complete. The read values will be written until write operation is finished. New write requests will be rejected until and error(2) or normal(1) value is obtained.</p> <p><b>NOTE:</b> To be able to use reset(3), make sure that either the “no snmp-server pw-check” CLI command has been configured in the device or the varbind and snAgGblPassword, with the appropriate password has been added to the SetRequest PDU. The default value of snAgGblPassword is the “enable” super-user password. If the CLI command “<b>aaa authentication snmp-server default ...</b>” is configured, then the method list determines the value expected in the snAgGblPassword MIB object.</p>
snAgConfigFromNVRAM fdry.1.1.2.1.4 Syntax: Integer	None	<p>Configures the switch from NVRAM of the agent.</p> <p>The following value can be written:</p> <ul style="list-style-type: none"> <li>• config(3) – Do configuration</li> </ul> <p>The following values can only be read:</p> <ul style="list-style-type: none"> <li>• normal(1)</li> <li>• error(2) – Operation failed or bad flash</li> <li>• configing(4) – Configuring from NVRAM flash is in process.</li> </ul> <p>The agent returns a response after configuration is done.</p>

### Configuration Notes on snAgEraseNVRAM and snAgWriteNVRAM

Refer to configuration notes for the snAgGblPassword object in the section “General Security Objects” on page 6-2 for more information on how to use snAgEraseNVRAM and snAgWriteNVRAM.

## File Download and Upload

The following objects manage file downloads and uploads. They are available in all Foundry devices.

---

**NOTE:** When uploading or downloading configuration files to and from the TFTP server using SNMP, check the following:

- If the SNMP password check is enabled on the device, the “snAgGlbPassword” on page 6-3 object must be sent with the following information in the same PDU as the TFTP objects:
    - If the AAA is used for SNMP authentication and the authentication method is enable or line, then the value of snAgGlbPassword must be in cleartext format.
    - If the AAA is used for SNMP authentication and the authentication method is local, RADIUS, TELNET, TACACS, or TACACS+, then the value of the snAgGlbPassword must be in the <user> <password> format. The space between <user> and <password> is the delimiter.
    - If AAA is not used for authentication, then the value of snAgGlbPassword for the enable password must be in cleartext format.
  - Make sure that user has administrative access (privilege=0) on the device; otherwise, the user will not be able to upload files to the TFTP server.
- 

---

**NOTE:** An atomic set of snAgImgLoad, snAgImgFname and snAgTftpServerIp is required for a successful download or upload.

---

Name, OID, and Syntax	Access	Description
snAgTftpServerIp fdry.1.1.2.1.5 Syntax: IpAddress	Read-write	Shows the IP address of the TFTP server that will be used for to download and upload image and configuration files.
snAgImgFname fdry.1.1.2.1.6 Syntax: Display string	Read-write	Shows the name of the image file, including path, that is currently associated with the system. When the object is not used, the value is blank. It can have up to 32 characters.



Name, OID, and Syntax	Access	Description
snAgImgLoad fdry.1.1.2.1.7 Syntax: Integer	Read-write	<p>Downloads or uploads a new software image to the agent. Use one of the following values in an SNMP set:</p> <ul style="list-style-type: none"> <li>• uploadMPPPrimary(19) – Uploads the primary image from the management processor flash memory to the TFTP server.</li> <li>• downloadMPPPrimary(20) – Downloads the primary image from the TFTP server to management processor flash.</li> <li>• uploadMPSecondary(21) – Uploads the secondary image from the management processor flash memory to the TFTP server.</li> <li>• downloadMPSecondary(22) – Downloads the secondary image from the TFTP server to management processor flash.</li> <li>• downloadSPPPrimary(24) – Downloads the secondary image from the TFTP server to secondary processor flash.</li> <li>• downloadSPSecondary(25) – Download the secondary image from the TFTP server to secondary processor flash.</li> </ul> <p>The following messages may be displayed:</p> <ul style="list-style-type: none"> <li>• normal(1)</li> <li>• flashPrepareReadFailure(2)</li> <li>• flashReadError(3)</li> <li>• flashPrepareWriteFailure(4)</li> <li>• flashWriteError(5)</li> <li>• tftpTimeoutError(6)</li> <li>• tftpOutOfBufferSpace(7)</li> <li>• tftpBusy(8)</li> <li>• tftpRemoteOtherErrors(9)</li> <li>• tftpRemoteNoFile(10)</li> <li>• tftpRemoteBadAccess(11)</li> <li>• tftpRemoteDiskFull(12)</li> <li>• tftpRemoteBadOperation(13)</li> <li>• tftpRemoteBadId(14)</li> <li>• tftpRemoteFileExists(15)</li> <li>• tftpRemoteNoUser(16)</li> <li>• operationError(17)</li> <li>• loading(18) – operation is in process</li> <li>• uploadMPPPrimary(19)</li> </ul>

Name, OID, and Syntax	Access	Description
snAgImgLoad (continued)		<ul style="list-style-type: none"> <li>• downloadMPPPrimary(20)</li> <li>• uploadMPSecondary(21)</li> <li>• downloadMPSecondary(22)</li> <li>• tftpWrongFileType(23)</li> <li>• downloadSPPPrimary(24)</li> <li>• downloadSPSecondary(25)</li> </ul>
snAgCfgFname fdry.1.1.2.1.8 Syntax: Display string	Read-write	Shows the name of the configuration file, including its path, that is currently associated with the system. If there are multiple configuration files, the names are separated by semicolons (;). This object can have up to 32 characters.

Name, OID, and Syntax	Access	Description
snAgCfgLoad fdry.1.1.2.1.9 Syntax: Integer	Read-write	<p>Downloads or uploads a configuration file to the agent. Use one of the following values for SNMP set:</p> <ul style="list-style-type: none"> <li>• uploadFromFlashToServer(20) – Uploads the configuration file from the flash to the TFTP server.</li> <li>• downloadToFlashFromServer(21) – Downloads the configuration file from the TFTP server to flash.</li> <li>• uploadFromDramToServer(22) – Uploads the configuration file from the DRAM to the TFTP server.</li> <li>• downloadToDramFromServer(23) – Downloads the configuration file from the TFTP server to DRAM.</li> <li>• uploadFromFlashToNMS(24) – Uploads the configuration file from flash to the network management system.</li> <li>• downloadToFlashFromNMS(25) – Downloads the configuration file from the network management system to flash.</li> <li>• uploadFromDramToNMS(26) – Uploads the configuration file from DRAM to a network management system.</li> <li>• downloadToDramFromNMS(27) – Downloads the configuration file from the network management system to DRAM.</li> </ul> <p>The following values may be read:</p> <ul style="list-style-type: none"> <li>• normal(1)</li> <li>• flashPrepareReadFailure(2)</li> <li>• flashReadError(3)</li> <li>• flashPrepareWriteFailure(4)</li> <li>• flashWriteError(5)</li> <li>• tftpTimeoutError(6)</li> <li>• tftpOutOfBufferSpace(7)</li> <li>• tftpBusy(8)</li> <li>• tftpRemoteOtherErrors(9)</li> <li>• tftpRemoteNoFile(10)</li> <li>• tftpRemoteBadAccess(11)</li> <li>• tftpRemoteDiskFull(12)</li> <li>• tftpRemoteBadOperation(13)</li> <li>• tftpRemoteBadId(14)</li> <li>• tftpRemoteFileExists(15)</li> <li>• tftpRemoteNoUser(16)</li> <li>• operationError(17)</li> <li>• loading(18)</li> <li>• tftpWrongFileType(29)</li> </ul>

Name, OID, and Syntax	Access	Description
snAgCfgLoad (continued)		<ul style="list-style-type: none"> <li>operationDoneWithNMS(28)</li> <li>tftpWrongFileType(29)</li> <li>downloadToDramFromServerOverwrite(30)</li> </ul> <p><b>NOTE:</b></p> <p>The objects "snAgCfgFname" and "snAgTftpServerIp" are required to allow the download or upload process to occur.</p> <p>No write requests will be allowed while a download or upload process is in progress.</p> <p>The snAgCfgEosTable objects must be sent along in one PDU for network management systems to recognize values from (24) to (27).</p> <p>A separate write memory using the CLI or an SNMP "set snAgWriteNVRAM" is required to save the configuration to NVRAM.</p>

In addition to the objects above, the following objects are available in all Foundry devices except in the ServerIron products.

Name, OID, and Syntax	Access	Description
snAgImgLoadSPModuleType fdry.1.1.2.1.56 Syntax: Integer	Read-write	Shows the switch processor module type that receives the downloaded image: <ul style="list-style-type: none"> <li>other(1)</li> <li>vm1(2)</li> <li>pos12(3)</li> <li>pos48(4)</li> <li>atm(5)</li> <li>gignpa(6)</li> </ul>
snAgImgLoadSPModuleNumber fdry.1.1.2.1.57	Read-write	Shows the slot number of a switch processor module that receives the downloaded image. Setting this object to 0 means that switch processor modules will receive the image.

### Software Image Details

The following objects show information about software images in a device. These objects are available in all Foundry devices.

Name, OID, and Syntax	Access	Description
snAgImgVer fdry.1.1.2.1.11 Syntax: Display string	Read only	Shows the version of the running software. The software image file name is displayed in the format: <code>major.minor.maintenance[letters]</code> . It can have up to 32 characters.

Name, OID, and Syntax	Access	Description
snAgFlashImgVer fdry.1.1.2.1.12 Syntax: Display string	Read only	Shows the version of the software image that has been saved in the local storage, such as the flash memory. The software image file name is displayed in the format: <code>major.minor.maintenance[letters]</code> It can have up to 32 characters. If this file is unknown or not available, then this object displays a null string.
snAgSoftwareFeature fdry.1.1.2.1.41 Syntax: Octet string	Read only	Contains a bit string representing the software feature of the running software image. Each bit can have one of the following values: <ul style="list-style-type: none"> <li>• 0 – The feature is available</li> <li>• 1 – The feature is available</li> </ul> Bit 0 is the least significant bit of an octet, and bit 7 is the most significant bit of an octet. <ul style="list-style-type: none"> <li>• Octet 0, bit 0 – RMON</li> <li>• Octet 0, bit 1 – IPX switching</li> <li>• Octet 0, bit 2 – Server Load Balancing</li> <li>• Octet 0, bit 3 – Layer 3 filter in switch</li> <li>• Octet 0, bit 4 – IPX routing</li> <li>• Octet 0, bit 5 – AppleTalk routing</li> <li>• Octet 0, bit 6 – IP multicast routing</li> <li>• Octet 0, bit 7 – Local access control</li> <li>• Octet 1, bit 0 – BGP routing</li> <li>• Octet 1, bit 1 – Loopback interface</li> <li>• Octet 1, bit 2 – BigIron multi-management module</li> <li>• Octet 1, bit 3 – BigIron SYSIF II</li> <li>• Octet 1, bit 4 – BigIron POS support</li> <li>• Octet 1, bit 5 – AppleTalk cable VLAN</li> <li>• Octet 1, bit 6 – 64 subnet</li> <li>• Octet 1, bit 7 – multi-slot trunk</li> <li>• Octet 2, bit 0 – TACACS</li> <li>• Octet 2, bit 1 – Gigabit Ethernet port auto-negotiation mode</li> <li>• Octet 2, bit 2 – FSRP</li> <li>• Octet 2, bit 3 – Exodus requested OSPF enhancement</li> <li>• Octet 2, bit 4 – OSPF NSSA</li> <li>• Octet 2, bit 5 – POS</li> <li>• Octet 2, bit 6 – QoS</li> <li>• Octet 2, bit 7 – Single Span</li> </ul>

Name, OID, and Syntax	Access	Description
snAgSoftwareFeature (continued)		<ul style="list-style-type: none"> <li>• Octet 3, bit 0 – Fast Span</li> <li>• Octet 3, bit 1 – Base L3</li> <li>• Octet 3, bit 2 – static log buffer</li> <li>• Octet 3, bit 3 – L2 POS</li> <li>• Octet 3, bit 4 – BI15K</li> <li>• Octet 3, bit 5 - L2 ATM</li> <li>• Octet 3, bit 6 - ATM</li> <li>• Octet 3, bit 7 - NETFLOW</li> <li>• Octet 4, bit 0 - SFLOW</li> <li>• Octet 4, bit 1 - GVRP</li> <li>• Octet 4, bit 2 - GARP</li> <li>• Octet 4, bit 3 - Dynamic trunk</li> <li>• Octet 4, bit 4 - IGC 8G</li> <li>• Octet 4, bit 5 - Rate limit</li> <li>• Octet 4, bit 6 - IPC rate limit</li> <li>• Octet 4, bit 7 - MPLS</li> <li>• Octet 5, bit 0 - ISIS</li> <li>• Octet 5, bit 1 - Link aggregation</li> <li>• Octet 5, bit 2 - Port dual mode</li> <li>• Octet 5, bit 3 - Private vlan</li> <li>• Octet 5, bit 4 - MBGP</li> <li>• Octet 5, bit 5 - IPV6 protocol vlan</li> <li>• Octet 5, bit 6 - X10G</li> <li>• Octet 5, bit 7 - FastIron Edge switch/router</li> <li>• Octet 6, bit 0 - FDP</li> <li>• Octet 6, bit 1 – port tag</li> </ul> <p>Bit 0 is the least significant bit of an octet; bit 7 is the most significant bit.</p> <p>Additional bits are added for new features. Check the MIB file for the software version you are running.</p>
snAgBuildDate fdry.1.1.2.1.47	Read only	Shows the date when the software was built. It can display up to 32 characters.
Syntax: Display string		
snAgBuildtime fdry.1.1.2.1.48	Read only	Shows the time when the software was built. It can display up to 32 characters.
Syntax: Display string		

Name, OID, and Syntax	Access	Description
snAgBuildVer fdry.1.1.2.1.49 Syntax: Display string	Read only	Shows the version of the software in the format: major.minor.maintenance[letters] It can display up to 32 characters.

## Boot Sequence Table

This table shows a list of software image loads. The images are in the sequence that will be used at boot up. When the device is booted up, the first image in the table will be loaded into the device. If that software image fails, the second image will be tried. The process continues until a successful load is completed.

This table is available in all Foundry devices. The combination of all the objects in this table must be unique. Duplicate instructions are rejected.

**NOTE:** Make sure that each entry is unique. It is possible to create entries with the same instructions by creating a new sequence index. Duplicate instructions may cause loops.

Name, OID, and Syntax	Access	Description
snAgBootSeqTable fdry.1.1.2.4.1	None	Identifies the Boot Sequence Table
snAgBootSeqEntry fdry.1.1.2.4.1.1	None	A row in the boot sequence table.
snAgBootSeqIndex fdry.1.1.2.4.1.1.1 Syntax: Integer	Read only	The index to the boot sequence table.
snAgBootSeqInstruction fdry.1.1.2.4.1.1.2 Syntax: Integer	Read-write	Shows from which image the device will boot. <ul style="list-style-type: none"> <li>fromPrimaryFlash(1)</li> <li>fromSecondaryFlash(2)</li> <li>fromTftpServer(3)</li> <li>fromBootpServer(4).</li> </ul>
snAgBootSeqIpAddr fdry.1.1.2.4.1.1.3 Syntax: IpAddress	Read-write	If the object "snAgBootSeqInstruction" is set to "fromTftpServer", this object shows the IP address of the TFTP server that contains the image that will be used in the boot.
snAgBootSeqFilename fdry.1.1.2.4.1.1.4 Syntax: Display string	Read-write	Shows the name of the image filename on the TFTP server that will be used in the boot. This object applies only if the object "snAgBootSeqInstruction" is set to "fromTftpServer". This object can have up to 32 characters.

Name, OID, and Syntax	Access	Description
snAgBootSeqRowStatus fdry.1.1.2.4.1.1.5 Syntax: Integer	Read-write	Creates or deletes an entry in the Boot Sequence Table: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> </ul>

## Software Configuration

The following sections control common configurations for devices:

- “Switch IP Configurations” on page 5-12
- “Agent System Parameters Configuration Table” on page 5-12
- “Switch Group Configuration” on page 5-14
- “Switch Configuration Summary Group” on page 5-19
- “DNS Group” on page 5-19
- “DHCP Gateway List Table” on page 5-20
- “NTP General Group” on page 5-21
- “NTP Server Table” on page 5-23
- “Banners” on page 5-24
- “Encoded Octet Strings Table” on page 5-24
- “Agent’s Global Group” on page 5-25

### Switch IP Configurations

Name, OID, and Syntax	Access	Description
snAgGblflpAddr fdry.1.1.2.1.13 Syntax: Integer	Read-write	Shows the IP address of the interface.
snAgGblflpMask fdry.1.1.2.1.14 Syntax: Integer	Read-write	Shows the IP address mask of the interface.
snAgDefGwaylp fdry.1.1.2.1.10 Syntax: Integer	Read-write	Shows the IP address of the default gateway router.

### Agent System Parameters Configuration Table

The Agent System Parameters Configuration Table presents the definition of the configuration system parameters. For example, the table may show the maximum number of VLANs a network can have.

The table is available in the following chassis devices:



- BigIron
- ServerIron 400
- ServerIron 800

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snAgentSysParaConfigTable fdry.1.1.2.7.1	None	A table of Agent of each board.
snAgentSysParaConfigEntry fdry.1.1.2.7.1.1	None	A row in the Agent System Parameters Configuration table.
snAgentSysParaConfigIndex fdry.1.1.2.7.1.1.1 Syntax: Integer	Read only	The index to the Agent System Parameters Configuration Table.
snAgentSysParaConfigDescription fdry.1.1.2.7.1.1.2 Syntax: Display string	Read only	The parameter description string. This object can have up to 32 characters.
snAgentSysParaConfigMin fdry.1.1.2.7.1.1.3 Syntax: Integer	Read only	The minimum value of this Agent System Parameter.
snAgentSysParaConfigMax fdry.1.1.2.7.1.1.4 Syntax: Integer	Read only	The maximum value of this Agent System Parameter.
snAgentSysParaConfigDefault fdry.1.1.2.7.1.1.5 Syntax: Integer	Read only	The default value of this Agent System Parameter.
snAgentSysParaConfigCurrent fdry.1.1.2.7.1.1.6 Syntax: Integer	Read-write	The current configured value of this Agent System Parameter.

## Switch Group Configuration

The objects in this group are available in BigIron and in ServerIron devices. Refer to the chapter “Traps and Objects to Enable Traps” on page 23-1 for switch group trap objects.

Name, OID, and Syntax	Access	Description
snSwGroupOperMode fdry.1.1.3.1.1 Syntax: Integer	Read-write	Indicates if switch ports have VLANs defined: <ul style="list-style-type: none"> <li>noVlan(1) – All switch ports with no port VLANs and no tag assigned.</li> <li>vlanByPort(2) – All switch ports with basic port-based VLANs.</li> </ul>
snSwGroupIpL3SwMode fdry.1.1.3.1.2 Syntax: Integer	Read-write	Indicates if the Layer 3 IP switch is enabled for the switch group. <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snSwGroupIpMcastMode fdry.1.1.3.1.3 Syntax: Integer	Read-write	Indicates if the IP multicast pruning mode is enabled for the switch group. <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snSwGroupDefaultCfgMode fdry.1.1.3.1.4 Syntax: Integer	Read-write	Indicates if the switch group contains a default configuration. If the default configuration is overwritten, the state will change to non-default. <ul style="list-style-type: none"> <li>default(1) – Has a default configuration</li> <li>nonDefault(2) – Has a non-default configuration</li> </ul>
snSwGroupSwitchAgeTime fdry.1.1.3.1.5 Syntax: Integer	Read-write	Sets the aging period for ports on the device, defining how long a port address remains active in the address table.  Valid values: 0 = no aging, or 67 – 65535 seconds  Default: 300 seconds
snVlanGroupVlanCurEntry fdry.1.1.3.1.6 Syntax: Integer	Read only	Shows the number of VLANs that are configured currently.
snVlanGroupSetAllVlan fdry.1.1.3.1.7 Syntax: Integer	Read-write	Shows the VlanIndex of a particular entry in snVlanByPortTable (snVlanByPortVlanIndex). All the attributes of that row except for PortMask will be used to set the same attributes for the entire VLAN group. VlanId and PortMask must be set for that particular entry prior to setting this object. Switch software will be based on that VLAN information to set the entire VLAN.  <b>NOTE:</b> All the intended attributes of the given row of the table (given VLAN) must be set prior setting this object. When this object is set, Set-All-VLAN action will take place simultaneously. The previous setting will be overwritten by the new one.

Name, OID, and Syntax	Access	Description
snSwPortSetAll fdry.1.1.3.1.8 Syntax: Integer	Read-write	<p>The value of this object is the index number of the snSwPortInfoTable (snSwPortInfoPortIndex). snSwPortInfoMonitorMode, snSwPortInfoTagType, snSwPortInfoChnMode, snSwPortInfoSpeed, snSwPortInfoAdminStatus are all the read-write attributes of that row of table. They will be used to set the same attributes for all the ports in the system.</p> <p><b>NOTE:</b> Before setting this object, all the intended attributes of the given row of the table must be set. Otherwise, the current data of the row will be used to set the entire port-table. The previous setting will be overwritten by the new one.</p>
snFdbTableCurEntry fdry.1.1.3.1.9 Syntax: Integer	Read only	Shows the total number of entries in the Filtering Database (FDB) that are configured currently.
snFdbTableStationFlush fdry.1.1.3.1.10 Syntax: Integer	Read-write	<p>Shows the state of the flush operation for the FDB table.</p> <p>The following value can be written:</p> <ul style="list-style-type: none"> <li>flush(3) – Perform the flush operation. Once the flush operation starts, any new flush requests will be rejected until the operation is complete or failed.</li> </ul> <p>The following values can only be read:</p> <ul style="list-style-type: none"> <li>normal(1) – Normal state</li> <li>error(2) – Operation failed</li> <li>flushing(4) – Operation is in process</li> </ul>
snPortStpSetAll fdry.1.1.3.1.11 Syntax: Integer	Read-write	<p>The value of this object is 1, which means that Port STP Set-all command is invoked. The snPortStpPriority and, snPortStpPathCost, which are the read-write STP related attributes of the first row of table, will be used to set the same attributes for all the ports in the system.</p> <p><b>NOTE:</b> Before setting this object, all the intended attributes of the given row of the table must be set. Otherwise, the current data of the row will be used to set the entire port-table. The previous setting will be overwritten by the new one.</p>
snSwProbePortNum fdry.1.1.3.1.12 Syntax: Integer	Read-write	<p>Indicates which chassis port is assigned as the chassis switch probe port. That port operates as a traffic analyzer port. Only one port in the chassis or stackable switch can be assigned as the traffic analyzer port. The value of this object represents the following:</p> <ul style="list-style-type: none"> <li>Bit 0 to bit 7 – Port number</li> <li>Bit 8 to bit 11 – Slot number</li> </ul>

Name, OID, and Syntax	Access	Description
snSw8021qTagMode fdry.1.1.3.1.13 Syntax: Integer	Read-write	Indicates whether or not IEEE802.1q has been enabled for the switch group. <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0)
snSwGlobalStpMode fdry.1.1.3.1.14 Syntax: Integer	Read-write	Indicates whether or not Spanning Tree System Global Mode has been enabled for the switch group. <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snSwIpmcastQuerierMode fdry.1.1.3.1.15 Syntax: Integer	Read-write	The IP Multicast pruning mode is configured either Non-Querier or Querier mode <ul style="list-style-type: none"> <li>• querier(1) – Send out host queries. (active)</li> <li>• nonQuerier(2) – Do not send out host queries.(passive)</li> </ul> Default: querier(1)
snSwViolatorPortNumber fdry.1.1.3.1.17 Syntax: Integer	Read only	Indicates the port number of the switch or router that receives the violator packet. This number is included in the locked address violation trap. The value of this object contains the following: <ul style="list-style-type: none"> <li>• Bit 0 to bit 7 – Port number</li> <li>• Bit 8 to bit 11 – Slot number (for chassis devices only)</li> </ul>
snSwViolatorMacAddress fdry.1.1.3.1.18 Syntax: MAC address	Read only	Indicates the source MAC address of the violator packet received by the switch or router. This number is included in the locked address violation trap.
snVlanGroupVlanMaxEntry fdry.1.1.3.1.19 Syntax: Integer	Read-write	Shows the maximum number of VLAN entries that can be configured.
snSwEosBufferSize fdry.1.1.3.1.20 Syntax: Integer	Read only	Specifies buffer size for all the different EOS buffers.
snVlanByPortEntrySize fdry.1.1.3.1.21 Syntax: Integer	Read only	Specifies the size of each VLAN table entry..
snSwPortEntrySize fdry.1.1.3.1.22 Syntax: Integer	Read only	Specifies the size of each port table entry..

Name, OID, and Syntax	Access	Description
snFdbStationEntrySize fdry.1.1.3.1.23 Syntax: Integer	Read only	Specifies the size of each FDB station table entry.
snPortStpEntrySize fdry.1.1.3.1.24 Syntax: Integer	Read only	Specifies the size of each port STP table entry..
snSwIpxL3SwMode fdry.1.1.3.1.28 Syntax: Integer	Read-write	Indicates whether or not Layer 3 IPX Switch mode is enabled. <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0)
snVlanByIpxSubnetMaxSubnets fdry.1.1.3.1.29 Syntax: Integer	Read only	Applies only to ServerIron products. Shows the maximum number of subnets for each IP VLAN.
snVlanByIpxNetMaxNetworks fdry.1.1.3.1.30 Syntax: Integer	Read only	Applies only to ServerIron products. Shows the maximum number of networks for each IPX VLAN.
snSwProtocolVlanMode fdry.1.1.3.1.31 Syntax: Integer	Read-write	Indicates whether or not protocol VLAN is enabled <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snMacStationVlanId fdry.1.1.3.1.32 Syntax: Integer	Read-write	Shows the MAC Station's VLAN ID index in the standard Forwarding Database for Transparent Bridge Table. (dot1dTpFdbTable). Since the dot1dTpFdbTable index is the MAC Address assigned to one of the ports in the bridge (VLAN) and each MAC address can be re-assigned to a different ports belonging to different bridges (VLANs), the snMacStationVlanId can be used by users to specify which bridge(VLAN) MAC Station information of the dot1dTpFdbTable users want to retrieve. If users do not specify the VLAN ID in this MIB, the default VLAN (bridge) ID will be used when dot1dTpFdbTable is retrieved. Valid values: 1 – 4095
snSwClearCounters fdry.1.1.3.1.33 Syntax: Integer	Read-write	Clears software counters: <ul style="list-style-type: none"> <li>valid(0) – an SNMP-GET of this MIB shows that it is valid command to use.</li> <li>clear(1) – Clear counter command of the following counters: Dot3, MIB2, IP and IPX counters for all ports.</li> </ul>
snSw8021qTagType fdry.1.1.3.1.34 Syntax: Integer	Read-write	Specifies the IEEE802.1q tag type that is embedded in the length/type field of an Ethernet packet. It specifies that the two octets after the length/type field in an Ethernet packet is the tag value. Default: 33024

Name, OID, and Syntax	Access	Description
snSwBroadcastLimit fdry.1.1.3.1.35 Syntax: Integer	Read-write	Specifies the number of broadcast packets per second. This number limits the number of broadcast packets to forward out of the switch ports. Setting this object to 0 disables the limitation check.  Default: 0
snSwMaxMacFilterPerSystem fdry.1.1.3.1.36 Syntax: Integer	Read only	Specifies the maximum number of MAC Filters per system in the MAC Filter table.
snSwMaxMacFilterPerPort fdry.1.1.3.1.37 Syntax: Integer	Read only	Specifies the maximum number of MAC Filters per port in the Port MAC Access Filter table.
snSwDefaultVlanId fdry.1.1.3.1.38 Syntax: Integer	Read-write	Shows the VLAN ID of the default port VLAN.  Valid values: 1 – 4095
snSwGlobalAutoNegotiate fdry.1.1.3.1.39 Syntax: Integer	Read-write	Applies only to Gigabit Ethernet ports.  Specifies the negotiation mode of the port: <ul style="list-style-type: none"> <li>• disable(0) – All Gigabit Ethernet ports are in non-negotiation mode.</li> <li>• enable(1) – All Gigabit Ethernet ports will start auto-negotiation indefinitely until they succeed.</li> <li>• negFullAuto(2) – All Gigabit Ethernet ports will start with auto-negotiation. If the negotiation fails, then they will automatically switch to non-negotiation mode. Gigabit Ethernet ports on all stackable products except for Turbolron/8 do not support negFullAuto(2).</li> </ul> <p>If the value of the object “snSwPortInfoAutoNegotiate” on page 7-8 is not set to “global”, then this global value for this object does not apply to the negotiation mode of that port.</p> <ul style="list-style-type: none"> <li>• other(3)</li> </ul> Default: negFullAuto(2)

The following objects apply only to all Foundry devices, except ServerIron products.

snSwQosMechanism fdry.1.1.3.1.40 Syntax: Integer	Read-write	Specifies the quality of service (QoS) mechanism: <ul style="list-style-type: none"> <li>• strict(0)</li> <li>• weighted(1)</li> </ul> Default: weighted(1)
--	------------	--

snSwSingleStpMode fdry.1.1.3.1.41 Syntax: Integer	Read-write	Specifies if the Single Spanning Tree System Mode in the Switch Group is enabled.  <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0)
snSwFastStpMode fdry.1.1.3.1.42 Syntax: Integer	Read-write	Indicates if Fast Spanning Tree System Mode in the Switch Group is enabled.  <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snSwViolatorIfIndex fdry.1.1.3.1.43 Syntax: Integer	Read only	The port number of the device that received a violator packet. This number is included in the locked address violator trap.

## Switch Configuration Summary Group

The following object applies to all Foundry devices.

Name, OID, and Syntax	Access	Description
snSwSummaryMode fdry.1.1.3.7.1 Syntax: Integer	Read-write	Indicates whether or not the Switch Configuration Summary is enabled.  <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0)

## DNS Group

The Domain Name Server (DNS) resolver feature lets you use a host name to perform Telnet, ping, and traceroute commands. You can also define a DNS domain on a Foundry Layer 2 Switch or Layer 3 Switch and thereby recognize all hosts within that domain. For more information on DNS in Foundry devices, refer to *Foundry Enterprise Configuration and Management Guide*.

The following objects provide information on DNS. They apply to all Foundry devices.

Name, OID, and Syntax	Access	Description
snDnsDomainName fdry.1.1.3.9.1 Syntax: Display string	Read-write	Shows the DNS Domain Name. This object can have up to 80 characters.
snDnsGatewayIpAddrList fdry.1.1.3.9.2 Syntax: Octet string	Read-write	Shows the DNS Gateway IP addresses. This list contains up to four IP addresses, represented by octet string. This object has 16 octets.

## DHCP Gateway List Table

The following objects provide information on DHCP gateways.

Name, OID, and Syntax	Access	Description
snDhcpGatewayListTable fdry.1.1.3.8.1	None	A table of DHCP gateway list of addresses.
snDhcpGatewayListEntry fdry.1.1.3.8.1.1	None	An entry in the IP Port Address table.
snDhcpGatewayListId fdry.1.1.3.8.1.1.1 Syntax: Integer	Read only	Shows the ID for a DHCP gateway. Valid values: 1 – 32.
snDhcpGatewayListAddrList fdry.1.1.3.8.1.1.2 Syntax: Octet string	Read-write	Lists the DHCP gateway addresses in each DHCP gateway list. This list contains 1 to 8 IP addresses represented by an octet string. This object can have 4 to 32 octets.
snDhcpGatewayListRowStatus fdry.1.1.3.8.1.1.3 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>



## NTP General Group

You can configure Layer 2 and Layer 3 Switches to consult Simple Network Time Protocol (SNTP) servers for the current system time and date. Since Foundry Layer 2 and Layer 3 switches do not retain time and date information across power cycles, using the SNTP feature alleviates administrators from reconfiguring time and date after system reset.

The following objects provide information on the network time processor (NTP) server. It applies to all Foundry devices.

Name, OID, and Syntax	Access	Description
snNTPGeneral fdry.1.1.3.11.1	None	Begins the NTP configuration objects.
snNTPPollInterval fdry.1.1.3.11.1.1 Syntax: Integer	Read- write	Specifies how often to poll the NTP server. Each unit is one second. Valid values: 1 – 65535 Default: 1800 seconds

Name, OID, and Syntax	Access	Description
snNTPTimeZone fdry.1.1.3.11.1.2 Syntax: Integer	Read- write	Time zone: <ul style="list-style-type: none"> <li>• alaska(0)</li> <li>• aleutian(1)</li> <li>• arizona(2)</li> <li>• central(3)</li> <li>• eastIndiana(4)</li> <li>• eastern(5)</li> <li>• hawaii(6)</li> <li>• michigan(7)</li> <li>• mountain(8)</li> <li>• pacific(9)</li> <li>• samoa(10)</li> <li>• gmtPlus12(11)</li> <li>• gmtPlus11(12)</li> <li>• gmtPlus10(13)</li> <li>• gmtPlus9(14)</li> <li>• gmtPlus8(15)</li> <li>• gmtPlus7(16)</li> <li>• gmtPlus6(17)</li> <li>• gmtPlus5(18)</li> <li>• gmtPlus4(19)</li> <li>• gmtPlus3(20)</li> <li>• gmtPlus2(21)</li> <li>• gmtPlus1(22)</li> <li>• gmt(23) – The default</li> <li>• gmtMinus1(24)</li> <li>• gmtMinus2(25)</li> <li>• gmtMinus3(26)</li> <li>• gmtMinus4(27)</li> <li>• gmtMinus5(28)</li> <li>• gmtMinus6(29)</li> </ul>

Name, OID, and Syntax	Access	Description
snNTPTimeZone (Continued)		<ul style="list-style-type: none"> <li>gmtMinus7(30)</li> <li>gmtMinus8(31)</li> <li>gmtMinus9(32)</li> <li>gmtMinus10(33)</li> <li>gmtMinus11(34)</li> <li>gmtMinus12(35)}</li> </ul>
snNTPSummerTimeEnable fdry.1.1.3.11.1.3 Syntax: Integer	Read-write	<p>Indicates if daylight savings time is enabled:</p> <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1) – Enables daylight saving time starting at 02:00:00 on the first Sunday in April and ending at 02:00:00 in last Sunday in October.</li> </ul> <p>Default: disabled(0)</p>
snNTPSystemClock fdry.1.1.3.11.1.4 Syntax: Octet string	Read-write	<p>Shows the format of the system clock:</p> <ul style="list-style-type: none"> <li>octet 0 – Seconds after the minute [0-60]</li> <li>octet 1 – Minutes after the hour [0-59]</li> <li>octet 2 – Hours since midnight [0-23]</li> <li>octet 3 – Day of the month [1-31]</li> <li>octet 4 – Months since January [0-11]</li> <li>octet 5 – Years since 1900</li> <li>octet 6 – Days since Sunday [0-6]</li> </ul> <p>Octets 0 to 5 must have valid values and Octet 6 must be set to 0. To disable the system clock set all octets to zero.</p>
snNTPSync fdry.1.1.3.11.1.5 Syntax: Integer	Read-write	<p>Initiates the time synchronization to the NTP servers.</p> <p>For set operation, only "synchronize(2)" is accepted.</p> <p>For get operation, always return "other(1)".</p>

## NTP Server Table

The following objects apply to all Foundry devices. They provide information on the NTP server.

Name, OID, and Syntax	Access	Description
snNTPServerTable fdry.1.1.3.11.2	None	NTP (Network Time Protocol) server table.
snNTPServerEntry fdry.1.1.3.11.2.1	None	An entry in the NTP server table.

Name, OID, and Syntax	Access	Description
snNTPServerIp fdry.1.1.3.11.2.1.1 Syntax: IpAddress	Read only	Shows the IP address of the NTP server.
snNTPServerVersion fdry.1.1.3.11.2.1.2 Syntax: Integer	Read-write	Shows the version in the NTP server. Default: 1
snNTPServerRowStatus fdry.1.1.3.11.2.1.3 Syntax: Integer	Read-write	Creates or deletes an NTP server table entry: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> </ul>

## Banners

Banners are messages that are displayed when a user logs into the device.

Name, OID, and Syntax	Access	Description
snAgGblBannerExec fdry.1.1.2.1.61 Syntax: Display string	Read-write	Enter a message that will be displayed when a user enters the Privileged EXEC CLI level of a device.  Enter up to 2048 characters for this banner. Use the character "\n" within the string to start a new line.  Leave this object blank if no message is to be displayed.
snAgGblBannerIncoming fdry.1.1.2.1.62 Syntax: Display string	Read-write	Enter a message that will be displayed on the Console when a user establishes a Telnet session. This message includes the location where the user is connecting from and displays a text message that can be configured.  Enter up to 2048 characters for this banner. Use the character "\n" within the string to start a new line.  Leave this object blank if no message is to be displayed.
snAgGblBannerMotd fdry.1.1.2.1.63 Syntax: Display string	Read-write	Enter the message of the day that will be displayed on a user's terminal when he or she establishes a Telnet CLI session.  Enter up to 2048 characters for this banner. Use the character "\n" within the string to start a new line.  Leave this object blank if no message is to be displayed.

## Encoded Octet Strings Table

Each row in the Encoded Octet Strings (EOS) Table represents a fragmented configuration file data packet, including its checksum. An SNMP SET represents a configuration file download process, while an SNMP GET represents a configuration file upload.

This action is only if the SNMP-SET of snAgCfgLoad command is sent along with this table consecutively. Consecutive SETs are performed until the network management system has no more packets to send. Likewise, consecutive GETs are done until the agent has no more packets to send.

The applicable snAgCfgLoad command value is as follows:

uploadFromFlashToNMS(23),  
downloadToFlashFromNMS(24),  
uploadFromDramToNMS(25),  
downloadToDramFromNMS(26)

The table is supported in all Foundry products.

Name, OID, and Syntax	Access	Description
snAgCfgEosTable fdry.1.1.2.5.1	None	The EOS table
snAgCfgEosEntry fdry.1.1.2.5.1.1	None	An EOS row in the table of encoded octet strings for table snAgCfgEosTable.
snAgCfgEosIndex fdry.1.1.2.5.1.1.1 Syntax: Integer	Read only	Each VLAN EOS Buffer Identifier have multiple VLAN table entries.
snAgCfgEosPacket fdry.1.1.2.5.1.1.2 Syntax: Octet string	Read-write	An encoded octet string. On reads it contains an integral number of configuration file data packets. The size of each encoded octet string is less than or equal to 1400 bytes. This object can contain up to 1000 octets.
snAgCfgEosChkSum fdry.1.1.2.5.1.1.3 Syntax: Integer	Read-write	A checksum of each configuration file data packet.

## Agent's Global Group

Name, OID, and Syntax	Access	Description
snAgGblDataRetrieveMode fdry.1.1.2.1.19 Syntax: Integer	Read-write	Retrieves the VLAN Table and Port-STP Table data as indicated by the selected mode. The mode can be one of the following: <ul style="list-style-type: none"> <li>nextbootCfg(0) – Retrieve the next boot configuration data</li> <li>operationalData(1) – Retrieve the current running data</li> </ul> Default: nextbootCfg(0).

## Error Management

The following objects are for general resource management in a device. They are available in all Foundry devices.

Name, OID, and Syntax	Access	Description
snAgGblQueueOverflow fdry.1.1.2.1.30 Syntax: Integer	Read only	The device queues are overflowing: <ul style="list-style-type: none"> <li>No(0)</li> <li>Yes(1)</li> </ul>
snAgGblBufferShortage fdry.1.1.2.1.31 Syntax: Integer	Read only	There is a shortage in the device buffers: <ul style="list-style-type: none"> <li>No(0)</li> <li>Yes(1)</li> </ul>
snAgGblDmaFailure fdry.1.1.2.1.32 Syntax: Integer	Read only	The device DMAs are in good condition <ul style="list-style-type: none"> <li>No(0)</li> <li>Yes(1)</li> </ul>
snAgGblResourceLowWarning fdry.1.1.2.1.33 Syntax: Integer	Read only	The device has low resources available: <ul style="list-style-type: none"> <li>No(0)</li> <li>Yes(1)</li> </ul>
snAgGblExcessiveErrorWarning fdry.1.1.2.1.34 Syntax: Integer	Read only	The device has excessive collision, FCS errors, alignment warnings, and other excessive warnings. <ul style="list-style-type: none"> <li>No(0)</li> <li>Yes(1)</li> </ul>

## FDP and CDP

This section presents the MIB objects and tables that can be used to manage FDP/CDP using SNMP.

- “FDP/CDP Global Configuration Objects” on page 5-27
- “FDP Interface Table” on page 5-27
- “FDP Cache Table” on page 5-28
- “FDP Cached Address Entry Table” on page 5-30

## FDP/CDP Global Configuration Objects

The following objects are used to configure FDP globally.

In FES devices, these objects supported in release 03.1.02 and later.

Name, OID, and Syntax	Access	Description
snFdpGlobalRun fdry.1.1.3.20.1.3.1 Syntax: Integer	Read-write	Indicates if the Foundry Discovery Protocol(FDP) is enabled: <ul style="list-style-type: none"> <li>false(0) – FDP is disabled. FDP entries in the snFdpCacheTable are deleted when FDP is disabled.</li> <li>true(1) – FDP is enabled. Enabling FDP automatically enables CDP globally.</li> </ul> Default: false(0)
snFdpGlobalMessageInterval fdry.1.1.3.20.1.3.2 Syntax: Integer	Read-write	Indicates the interval at which FDP messages are to be generated.  Valid values: 5 – 900 seconds  Default: 60 seconds
snFdpGlobalHoldTime fdry.1.1.3.20.1.3.3 Syntax: Integer	Read-write	Indicates how long the receiving device will hold FDP messages.  Valid values: 10 – 255 seconds  Default: 180 seconds
snFdpGlobalCdpRun fdry.1.1.3.20.1.3.4 Syntax: Integer	Read-write	Shows if the Cisco Discovery Protocol(CDP) is enabled: <ul style="list-style-type: none"> <li>false(0) – CDP is disabled. CDP entries in the snFdpCacheTable are deleted when FDP is disabled.</li> <li>true(1) – CDP is enabled. Enabling CDP does not automatically enable FDP globally.</li> </ul> Default: false (0)

## FDP Interface Table

The FDP Interface Table shows whether or not FDP is enabled on a physical interface. You can use this table to disable or enable FDP on individual interfaces.

**NOTE:** You cannot disable CDP on individual interfaces. Also, in FES devices, this table is supported in release 03.1.02 and later.

Name, OID, and Syntax	Access	Description
snFdpInterfaceTable fdry.1.1.3.20.1.1.1	None	The FDP Interface table
snFdpInterfaceIfIndex fdry.1.1.3.20.1.1.1.1	None	An entry in the FDP Cache Table, showing the ifIndex value of the local interface.

Name, OID, and Syntax	Access	Description
snFdpInterfaceEnable fdry.1.1.3.20.1.1.1.1.2 Syntax: Integer	Read-write	Determines if FDP is enabled on the interface: <ul style="list-style-type: none"> <li>false(0) – FDP is disabled.</li> <li>true(1) – FDP is enabled.</li> </ul> Default: true(1)
snFdpInterfaceCdpEnable fdry.1.1.3.20.1.1.1.1.3 Syntax: Integer	Read-write	Determines if CDP is enabled on the interface: <ul style="list-style-type: none"> <li>false(0) – CDP is disabled.</li> <li>true(1) – CDP is enabled.</li> </ul> Default: true(1) <p>This object is available beginning with IronWare software release 07.6.02.</p>

### FDP Cache Table

Each entry in the FDP Cache Table contains information received from FDP/CDP on one interface of one device. This table is available if FDP or CDP is enabled globally. Entries appear when an FDP/CDP advertisement is received from a neighbor device. Entries are deleted when FDP/CDP is disabled on an interface or globally.

In FES devices, this table is supported in release 03.1.02 and later.

Name, OID, and Syntax	Access	Description
snFdpCacheTable fdry.1.1.3.20.1.2.1	None	The FDP Cache Table
snFdpCacheEntry fdry.1.1.3.20.1.2.1.1	None	An entry in the FDP Cache Table.
snFdpCacheIfIndex fdry.1.1.3.20.1.2.1.1.1	None	An entry in the FDP Cache Table, showing the ifIndex value of the local interface.
snFdpCacheDeviceIndex fdry.1.1.3.20.1.2.1.1.2 Syntax: Integer	Read only	A unique value for each device from which FDP or CDP messages are being received. For example, you may see 1.
snFdpCacheDeviceId fdry.1.1.3.20.1.2.1.1.3 Syntax: Display string	Read only	Shows a description for the device as reported in the most recent FDP or CDP message. For example, you may see DeviceB.  A zero-length string indicates no Device-ID field (TLV) was reported in the most recent FDP or CDP message.
snFdpCacheAddressType fdry.1.1.3.20.1.2.1.1.4 Syntax: Integer	Read only	Indicates the type of address contained in the “snFdpCacheAddress” object for this entry: <ul style="list-style-type: none"> <li>ip(1)</li> <li>ipx(2)</li> <li>appletalk(3)</li> </ul>



Name, OID, and Syntax	Access	Description
snFdpCacheAddress fdry.1.1.3.20.1.2.1.1.5 Syntax: Octet string	Read only	Shows the network-layer address of the device's SNMP-agent, as reported in the most recent FDP or CDP message. A device may have more than one address. This object shows the first address on the device.  The format of this object depends on the value of the snFdpCacheAddressType object: <ul style="list-style-type: none"> <li>ip(1) – 4 octets</li> <li>ipx(2) – 10 octets: Octets 1 – 4: Network number Octets 5 – 10: Host number</li> <li>appletalk(3) – 3 octets: Octets 1 – 2: Network number Octet 3: Host number</li> </ul>
snFdpCacheVersion fdry.1.1.3.20.1.2.1.1.6 Syntax: Display string	Read only	Shows the software version running in the device as reported in the most recent FDP or CDP message. For example, you may see the following:  Foundry Networks, Inc. Router, IronWare Version 07.6.01b1T53 Compiled on Aug 28 2002 at 20:23:58 labeled as B2R07601
snFdpCacheDevicePort fdry.1.1.3.20.1.2.1.1.7 Syntax: Display string	Read only	Shows the port ID of the device as reported in the most recent FDP or CDP message. This will typically be the value of the ifName object. For example, you may see <code>Ethe 2/3</code> .  A zero-length string indicates no Port-ID field (TLV) was reported in the most recent FDP or CDP message.
snFdpCachePlatform fdry.1.1.3.20.1.2.1.1.8 Syntax: Display string	Read only	Shows the device's hardware platform as reported in the most recent FDP or CDP message. For example, you may see <code>BigIron Router</code> .  A zero-length string indicates that no Platform field (TLV) was reported in the most recent FDP or CDP message.
snFdpCacheCapabilities fdry.1.1.3.20.1.2.1.1.9 Syntax: Display string	Read only	Shows the device's functional capabilities as reported in the most recent FDP or CDP message. For example, you may see <code>Router</code> .
snFdpCacheVendorId fdry.1.1.3.20.1.2.1.1.10 Syntax: Integer	Read only	Indicates if FDP or CDP received the entry: <ul style="list-style-type: none"> <li>fdp(1)</li> <li>cdp(2)</li> </ul>
snFdpCachelsAggregateVlan fdry.1.1.3.20.1.2.1.1.11 Syntax: Integer	Read only	Indicates if this entry is from a neighbor device that is in an aggregated VLAN: <ul style="list-style-type: none"> <li>false(0) – It is not in an aggregated VLAN</li> <li>true(1) – It is in an aggregate VLAN</li> </ul>

Name, OID, and Syntax	Access	Description
snFdpCacheDeviceTagType fdry.1.1.3.20.1.2.1.1.12 Syntax: Integer	Read only	Shows the tag type of the neighbor device that sent this entry. For example, you may see 0x8100.
snFdpCacheDevicePortVlanMask fdry.1.1.3.20.1.2.1.1.13 Syntax: Octet string	Read only	Shows the port VLAN masks, in 512-byte octet string, of the neighbor that sent this entry.
snFdpCachePortTagMode fdry.1.1.3.20.1.2.1.1.14 Syntax: Integer	Read only	Shows the port tag mode on the neighbor device: <ul style="list-style-type: none"> <li>untagged(1)</li> <li>tagged(2)</li> <li>dual(3)</li> </ul>
snFdpCacheDefaultTrafficVlanIdForDualMode fdry.1.1.3.20.1.2.1.1.15 Syntax: Integer	Read only	Shows the default traffic vlan ID for neighbor devices that have dual-mode ports.

### FDP Cached Address Entry Table

The FDP Cached Address Entry Table shows all the cached addresses from which FDP or CDP messages are being received. This table is available if FDP or CDP is enabled globally.

Also, in FES devices, this table is supported in release 03.1.02 and later.

Name, OID, and Syntax	Access	Description
snFdpCachedAddressTable fdry.1.1.3.20.1.4.1	None	The FDP Cached Address Entry Table
snFdpCachedAddressEntry fdry.1.1.3.20.1.4.1.1	None	An entry in the FDP Cached Address Table.
snFdpCachedAddrIfIndex fdry.1.1.3.20.1.4.1.1.1 Syntax: Integer	None	Shows the ifIndex value of the local interface.
snFdpCachedAddrDeviceIndex fdry.1.1.3.20.1.4.1.1.2 Syntax: Integer	Read only	Shows a unique value for each device from which FDP or CDP messages are being received.
snFdpCachedAddrDeviceAddrEntryIndex fdry.1.1.3.20.1.4.1.1.3 Syntax: Integer	Read only	Shows a unique value for each address on the device from which FDP or CDP messages are being received. A device may have several addresses. There will be one entry for each address.

---

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snFdpCachedAddrType fdry.1.1.3.20.1.4.1.1.4 Syntax: Integer	Read only	Indicates the type of address contained in the “snFdpCachedAddrValue” object for this entry: <ul style="list-style-type: none"><li>• ip(1)</li><li>• ipx(2)</li><li>• appletalk(3)</li></ul>
snFdpCachedAddrValue fdry.1.1.3.20.1.4.1.1.5 Syntax: Octet string	Read only	Indicates the network-layer address of the device’s SNMP-agent as reported in the most recent FDP or CDP message.  The format of this object depends on the value of the snFdpCachedAddrValue object: <ul style="list-style-type: none"><li>• ip(1) – 4 octets</li><li>• ipx(2) – 10 octets: Octets 1 – 4: Network number Octets 5 – 10: Host number</li><li>• appletalk(3) – 3 octets: Octets 1 – 2: Network number Octet 3: Host number</li></ul>

---



---

# Chapter 6

## User Access

This chapter presents the objects used to control user access to devices. It contains the following sections:

- “Agent User Access Group” on page 6-1
- “Agent User Account Table” on page 6-2
- “General Security Objects” on page 6-2
- “IP Community List Table” on page 6-6
- “IP Community List String Table” on page 6-7
- “Authorization and Accounting” on page 6-8
- “RADIUS General Group” on page 6-10
- “RADIUS Server Table” on page 6-13
- “TACACS General Objects” on page 6-14
- “TACACS Server Table” on page 6-15

Refer to the *Foundry Security Guide* for detailed explanation on the features discussed in this chapter.

### Agent User Access Group

The objects in this section apply to user accounts in all Foundry devices.

Name, OID, and Syntax	Access	Description
snAgentUserMaxAcct fdry.1.1.2.9.1.1 Syntax: Integer	Read only	Shows the maximum number of user accounts that can be configured on the device.
snAgWebMgmtServerTcpPort fdry.1.1.2.1.63 Syntax: Integer	Read-write	This object allows you to specify which TCP port will be used for the Web management interface. Also, Element Manager of IronView Network Manager will query the device for this port number before it sends HTTP packets to the device.  Enter a number from 1 – 65535.

## Agent User Account Table

The objects in this table provide information about user accounts. They apply to all Foundry devices.

Name, OID, and Syntax	Access	Description
snAgentUserAcntTable fdry.1.1.2.9.2	None	A table of user account information.
snAgentUserAcntEntry fdry.1.1.2.9.2.1	None	Represents a row in the Agent User table.
snAgentUserAcntName fdry.1.1.2.9.2.1.1 Syntax: Display string	Read only	Displays the user name. This object can have up to 48 characters
snAgentUserAcntPassword fdry.1.1.2.9.2.1.2 Syntax: Display string	Read-write	Contains the user password. Valid values: Up to 48 characters
snAgentUserAcntEncryptCode fdry.1.1.2.9.2.1.3 Syntax: Integer	Read-write	States the password encryption method code. <ul style="list-style-type: none"><li>• 0 – no encryption</li><li>• 1 – simple encryption</li><li>• 7– MD5 encryption</li></ul>
snAgentUserAcntPrivilege fdry.1.1.2.9.2.1.4 Syntax: Integer	Read-write	Shows the user's privilege. <ul style="list-style-type: none"><li>• 0 – administration</li><li>• 4 – Port configuration</li><li>• 5 – Read only</li></ul>
snAgentUserAcntRowStatus fdry.1.1.2.9.2.1.5 Syntax: Integer	Read-write	Creates, modifies, or deletes a user account table entry: <ul style="list-style-type: none"><li>• other(1)</li><li>• valid(2)</li><li>• delete(3)</li><li>• create(4)</li><li>• modify(5)</li></ul>

## General Security Objects

The following objects are used to manage general security functions in all Foundry devices.

snAgGblPassword fdry.1.1.2.1.15	Read- write	<p>Shows the system security access password, which is used only for an SNMP-Set. An SNMP-Get will return a zero string.</p> <p>If the <b>password-change any</b> command (the default) is configured on the device, then this object needs to be part of the SNMP Set operation on some critical SNMP objects.</p> <p>The value of this object depends on the authentication method for SNMP operation:</p> <ul style="list-style-type: none"> <li>• If there is no AAA authentication configuration for SNMP, then this object will have the enable superuser password.</li> <li>• If AAA authentication for SNMP is configured and has the leading method as “enable” or “line”, this object will have the corresponding “enable” or “line” password.</li> <li>• If the switch has AAA authentication for SNMP operation, and the method specified is one of local, TACACS+, or RADIUS, this object will have &lt;username&gt; &lt;password&gt; format. Note: one space character in between &lt;username&gt; and &lt;password&gt;.</li> </ul> <p>The maximum size allows concatenation of max 48 octets of username and 48 octets of password, with one blank character</p> <p>Refer to “Configuration Notes” on page 6-5 for more details.</p> <p>Valid values: Up 48 octets.</p>
snAgGblSecurityLevelSet fdry.1.1.2.1.28	Read- write	<p>Shows the security level required to set an “enable” password. This security level can be from 0 to 5.</p>
snAgGblPasswordChangeMode fdry.1.1.2.1.24	Read only	<p>Specifies which management entity is allowed to change the “enable” password for the device. For security reasons, this object can only be modified using the device’s CLI.</p> <p>Valid values:</p> <ul style="list-style-type: none"> <li>• anyMgmtEntity(1) – Any SNMP management station, console command line interface or Telnet command line interface can be used to change the password.</li> <li>• consoleAndTelnet(2) – The password can be changed using the console command line interface or the Telnet command line interface</li> <li>• consoleOnly(3) – Only the console command line interface can be used</li> <li>• telnetOnly(4) – Only telnet command line interface can be used.</li> </ul> <p>Default: consoleAndTelnet(2)</p>
snAgGblLevelPasswordsMask fdry.1.1.2.1.29	Read only	<p>Shows the bitmap of level passwords which were successfully assigned to the system.</p> <ul style="list-style-type: none"> <li>• Bit 0 – Level 0 = admin</li> <li>• Bit 4 – Level 4 = port configuration</li> <li>• Bit 5 – Level 5 = read only</li> </ul>

snAgGblReadOnlyCommunity fdry.1.1.2.1.25 Syntax: Display string	Read-write	Allows you to configure SNMP read-only community strings for the device. This object can be used in an SNMP-Set, but not SNMP-Get. Get will return a blank.  Valid values: Up to 32 characters.  <b>NOTE:</b> To use this object, make sure that " <b>password-change any</b> " has been configured in the device, to allow passwords to be updated from SNMP or any method
snAgGblReadWriteCommunity fdry.1.1.2.1.26 Syntax: Display string	Read-write	Allows you to configure SNMP read-write community strings for the device. This object can be used in an SNMP-Set, but not SNMP-Get. Get will return a blank.  Valid values: Up to 32 characters.  <b>NOTE:</b> To use this object, make sure that " <b>password-change any</b> " has been configured in the device, to allow passwords to be updated from SNMP or any method
snAgGblCurrentSecurityLevel fdry.1.1.2.1.27 Syntax: Integer	Read only	Represents the current login security level (0 to 5). Each level of security requires a password to permit users for different system configurations. Levels are defined in the "snAgGblLevelPasswordsMask" object.
snAgSystemLog fdry.1.1.2.1.20 Syntax: Octet string	Read-write	Indicates whether any network management system has login privileges. The agent allows only one network management to be logged in.  The value of this object consists of an octet string, with the first byte representing the value described below. The following four bytes contain a secret code.  The value of the first byte can be one of the following: <ul style="list-style-type: none"> <li>• login(1) – Login for a network management system.</li> <li>• heartbeat(2) – a value for the login NMS periodically to check in; Otherwise, the Agent will automatically set this object to logout(3) after a timeout period.</li> <li>• logout(3) – a value for a NMS to logout.</li> <li>• changePassword(4) – a value for the login NMS to change password, only if snAgGblPasswordChangeMode was configured to "anyMgmtEntity".</li> <li>• changeReadOnlyCommunity(5) – a value for the login NMS to change the read-only community string, only if snAgGblPasswordChangeMode was configured to "anyMgmtEntity".</li> <li>• changeReadWriteCommunity(6) – a value for the login NMS to change the read-write community string, only if snAgGblPasswordChangeMode was configured to "anyMgmtEntity".</li> </ul>
snAgGblTelnetTimeout fdry.1.1.2.1.37 Syntax: Integer	Read-write	Shows how many minutes a Telnet session can remain idle before it times out. The value of this object can be up to 240 minutes. A value of 0 means that the Telnet session never times out.



snAgGblEnableWebMgmt fdry.1.1.2.1.38 Syntax: Integer	Read-write	Enables or disables access to the device from the Web management interface: <ul style="list-style-type: none"> <li>• disable(0)</li> <li>• enable(1)</li> </ul>
snAgGblSecurityLevelBinding fdry.1.1.2.1.39 Syntax: Integer	Read only	After a network management system logs in to a device with a user ID and password, the privilege level assigned to that system is saved in this object. Privilege level can be one of the following: <ul style="list-style-type: none"> <li>• 0 – Administration</li> <li>• 4 – Port configuration</li> <li>• 5 – Read only</li> <li>• 255 – Invalid binding</li> </ul>
snAgGblEnableSLB fdry.1.1.2.1.40 Syntax: Integer	Read only	Enables or disables Server Load Balancing: <ul style="list-style-type: none"> <li>• disable(0)</li> <li>• enable(1)</li> </ul>
snAgGblEnableTelnetServer fdry.1.1.2.1.45 Syntax: Integer	Read-write	Enables or disables the Telnet server in a device: <ul style="list-style-type: none"> <li>• Disable(0)</li> <li>• Enable(1)</li> </ul> Default: enable(1)
snAgGblTelnetPassword fdry.1.1.2.1.46 Syntax: Display string	Read-write	Contains the Telnet access password, which is only used with SNMP Set. An SNMP-Get produces a zero string. This object can have 48 characters.
snAgGblTelnetLoginTimeout fdry.1.1.2.1.60 Syntax: Integer	Read-write	Indicates how many minutes you have to log in before Telnet is disconnected.  Valid values: 1 – 10 minutes.  Default: 1 minute

## Configuration Notes

When using the snAgGblPassword object in a Set operation, keep the following in mind:

The device will always insist on a password to be part of object snAgGblPassword. You can override this requirement by entering a **no snmp-server pw-check** command on the device's CLI.

By default, the object uses the value of the is the **enable super-user** password configured on the device as the default password. To allow device to use other authentication schemes, use one of the following commands:

- `aaa authen snmp default enable | local | none`

Using **enable** tells the device to use the configured enable super-user password, If the enable super-user password is missing, then the device checks if implicit TACACS+ enable password is known by the device. The device will store a previous (unrelated to SNMP) implicit enable operation results, and remember the enable password that was approved by TACACS+. You can enter the following command to use this method:

```
SnmpSet (snAgGblPassword.0="<enable-password>", snAgEraseNVRAM.0=3)
```

Using **local** instructs the device to use a configured local username and password value. You can enter the following SNMP command to use this method:

```
SnmpSet (snAgGblPassword.0="<username> <password>", snAgEraseNVRAM.0=3)
```

Using **none** tells the device to ignore the value of snAgGblPassword and authentication check will always pass. You can enter the following SNMP command to use this method:

```
SnmpSet ( snAgGblPassword.0=" <anything here> " , snAgEraseNVRAM.0=3 )
```

- aaa authentication login default TACACS+
- aaa authentication enable default TACACS+
- aaa authentication enable implicit-user

## IP Community List Table

This table has been deprecated in IronWare software release 07.5.00 and is no longer supported. It has been replaced by the "IP Community List String Table" on page 6-7.

Name, OID, and Syntax	Access	Description
snIpCommunityListTable	None	IP Community List Table.
snIpCommunityListEntry	None	An entry in the IP Community List Table.
snIpCommunityListIndex	Read only	An index for an entry in the table.
Syntax: Integer		
snIpCommunityListSequence	Read only	Identifies the sequence of this entry in this table.
Syntax: Integer		
snIpCommunityListAction	Read-write	Determines what action to take if the address in the packet matches this filter: <ul style="list-style-type: none"> <li>• deny(0)</li> <li>• permit(1)</li> </ul>
Syntax: Integer		
snIpCommunityListCommNum	Read-write	Specifies the community number. This is a number from 1 to 0xFFFFFFFF. There are 20 of them. The number is represented by four octets.
Syntax: Octet string		
snIpCommunityListInternet	Read-write	Indicates if the community is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
Syntax: Integer		
snIpCommunityListNoAdvertise	Read-write	Indicates if routes will not be advertised to any internal or external peer: <ul style="list-style-type: none"> <li>• false(0)</li> <li>• true(1)</li> </ul>
Syntax: Integer		

Name, OID, and Syntax	Access	Description
snIpCommunityListNoExport  Syntax: Integer	Read-write	Determines if the route will not be advertised to an EBGp peer: <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>
snIpCommunityListRowStatus  Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snIpCommunityListLocalAs  Syntax: Integer	Read-write	Indicates if this route will be sent to peers (advertised) in other sub-autonomous systems within the local confederation: <ul style="list-style-type: none"> <li>false(0) – Do not advertise this route to an external system.</li> <li>true(1) – Advertise this route.</li> </ul>

## IP Community List String Table

This table contains the list of community strings used.

Beginning with IronWare software release 07.5.00, this table replaces the "IP Community List String Table" on page 6-7.

Name, OID, and Syntax	Access	Description
snIpCommunityListStringTable fdry.1.2.2.17	None	IP Community ListString Table.
snIpCommunityListStringEntry fdry.1.2.2.17.1	None	An entry in the IP Community ListString Table.
snIpCommunityListStringName fdry.1.2.2.17.1.1 Syntax: Octet string	Read only	An index for an entry in the table.  This object can have up to 32 octets.
snIpCommunityListStringSequence fdry.1.2.2.17.1. Syntax: Integer	Read only	Indicates the sequence of this entry in the table.

Name, OID, and Syntax	Access	Description
snIpcCommunityListStringAction fdry.1.2.2.17.1.3 Syntax: Integer	Read-write	Indicates the action to take if the community string on the packet matches this filter: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snIpcCommunityListStringCommN um fdry.1.2.2.17.1.4 Syntax: Integer	Read-write	Shows the community string's number, represented by four octets. This number can be from 1 to 0xFFFFFFFF.  There can be up to 20 community string numbers.
snIpcCommunityListStringInternet fdry.1.2.2.17.1.5 Syntax: Integer	Read-write	Indicates if the community is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snIpcCommunityListStringNoAdver tise fdry.1.2.2.17.1.6 Syntax: Integer	Read-write	Indicates the community string will not be advertised to any internal or external peers: <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>
snIpcCommunityListStringNoExpor t fdry.1.2.2.17.1.7 Syntax: Integer	Read-write	Indicates if this route is not advertised as an EBGp peer: <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>
snIpcCommunityListStringRowStat us fdry.1.2.2.17.1.8 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snIpcCommunityListStringLocalAs fdry.1.2.2.17.1.9	Read-write	Determines if this route will be sent to peers in other sub autonomous systems within the local confederation. Do not advertise this route to an external system.

## Authorization and Accounting

The following objects are for authorization, and accounting functions. They are available in all Foundry devices.

In releases prior to 07.1.00, a user logging into the device using Telnet or SSH would first enter the User EXEC level. The user could then enter the **enable** command to get to the Privileged EXEC level. Starting with Release 07.1.00, a user who is successfully authenticated by a RADIUS or TACACS+ server is automatically placed at the Privileged EXEC level after login. For more information on the AAA functions, refer to the *Foundry Security Guide*.

Name, OID, and Syntax	Access	Description
snAuthorizationCommand Methods fdry.1.1.3.15.2.1 Syntax: Octet string	Read-write	Specifies the sequence of authorization methods. This object can have zero to three octets. Each octet represents a method to authorize the user command. Each octet has the following value: <ul style="list-style-type: none"> <li>radius(2) – Authorize by the requesting RADIUS server</li> <li>tacplus(5) – Authorize by requesting TACACS server</li> <li>none(6) – Skip authorization</li> </ul> Setting a zero length octet string invalidates all previous authorization methods.
snAuthorizationCommandLevel fdry.1.1.3.15.2.2 Syntax: IpAddress	Read-write	Specifies the commands that need to be authorized. Any command that is equal to or less than the selected level will be authorized: <ul style="list-style-type: none"> <li>level(0) – Privilege level 0</li> <li>level(4) – Privilege level 4</li> <li>level(5) – Privilege level 5</li> </ul>
snAuthorizationExec fdry.1.1.3.15.2.3 Syntax: Octet string	Read-write	Shows the sequence of authorization methods for exec programs. This object can have zero to three octets. Each octet represents a method for Telnet or SSH login authorization. Each octet can have one of the following value: <ul style="list-style-type: none"> <li>radius(2) – Send EXEC authorization request to RADIUS server</li> <li>tacplus(5) – Send EXEC authorization request to TACACS+ server</li> <li>none(6) – No EXEC authorization method</li> </ul> Setting a zero length octet string invalidates all authorization methods.

Name, OID, and Syntax	Access	Description
snAccountingCommandMethods fdry.1.1.3.15.3.1 Syntax: Octet string	Read-write	Shows a sequence of accounting methods.  This object can have zero to three octets. Each octet represents an accounting method. Each octet can have one of the following value: <ul style="list-style-type: none"> <li>• radius(2) – Send accounting information to RADIUS server</li> <li>• tacplus(5) – Send accounting information to TACACS+ server</li> <li>• none(6) – No accounting method</li> </ul> Setting a zero length octet string invalidates all authorization methods.
snAccountingCommandLevel fdry.1.1.3.15.3.2 Syntax: Integer	Read-write	Specifies the commands that need to be accounted for. Any command that is equal to or less than the selected level will be accounted for: <ul style="list-style-type: none"> <li>• level(0) – Privilege level 0</li> <li>• level(4) – Privilege level 4</li> <li>• level(5) – Privilege level 5.</li> </ul>
snAccountingExec fdry.1.1.3.15.3.3 Syntax: Octet string	Read-write	Shows the sequence of accounting methods for exec programs.  This object can have zero to three octets. Each octet represents a method for Telnet or SSH login authorization. Each octet can have one of the following value: <ul style="list-style-type: none"> <li>• radius(2) – Send accounting information to the RADIUS server</li> <li>• tacplus(5) – Send accounting information to the TACACS+ server</li> <li>• none(6) – No accounting method</li> </ul> Setting a zero length octet string invalidates all authorization methods.
snAccountingSystem fdry.1.1.3.15.3.4 Syntax: Octet string	Read-write	A sequence of accounting methods.  This object can have zero to three octets. Each octet represents a method to account for the system related events. Each octet has the following enumeration value: <ul style="list-style-type: none"> <li>• radius(2) – send accounting information to the RADIUS server</li> <li>• tacplus(5) – send accounting information to the TACACS+ server</li> <li>• none(6) – skip accounting</li> </ul> Setting a zero length octet string invalidates all previous accounting methods.

## RADIUS General Group

You can use a Remote Authentication Dial In User Service (RADIUS) server to secure the following types of access to the Foundry switch or router:

- Telnet access
- SSH access
- Web management access
- Access to the Privileged EXEC level and CONFIG levels of the CLI

The following objects provide information on RADIUS authentication. They apply to all Foundry devices.

Name, OID, and Syntax	Access	Description
snRadiusGeneral fdry.1.1.3.12.1		
snRadiusSNMPAccess fdry.1.1.3.12.1.1 Syntax: Integer	Read only	Indicates if the RADIUS group MIB objects can be accessed by an SNMP manager: <ul style="list-style-type: none"> <li>• disabled(0) – All RADIUS group MIB objects return a “general error”</li> <li>• enabled(1)</li> </ul> Default: disabled
snRadiusEnableTelnetAuth fdry.1.1.3.12.1.2 Syntax: Integer	Read-write	Indicates if Telnet authentication as specified by the object “snRadiusLoginMethod” is enabled. <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled
snRadiusRetransmit fdry.1.1.3.12.1.3 Syntax: Integer	Read-write	Indicates the number of authentication query retransmissions that can be sent to the RADIUS server. <p>Valid values: 0 – 5</p> Default: 3
snRadiusTimeOut fdry.1.1.3.12.1.4 Syntax: Integer	Read-write	Specifies the number of seconds to wait for authentication reply from the RADIUS server. <p>Valid values: 0 – 15</p> Default: 3
snRadiusDeadTime fdry.1.1.3.12.1.5 Syntax: Integer	Read-write	Specifies the RADIUS server dead time, each unit is one minute. <p>Valid values: 0 – 5</p> Default: 3
snRadiusKey fdry.1.1.3.12.1.6 Syntax: Display string	Read-write	Shows the authentication key as encrypted text. <p>This object can have up to 32 characters.</p>

Name, OID, and Syntax	Access	Description
snRadiusLoginMethod fdry.1.1.3.12.1.7 Syntax: Octet string	Read- write	Shows the sequence of authentication methods for the RADIUS server. Each octet represents a method for authenticating the user at login. Each octet can have one of the following values: <ul style="list-style-type: none"> <li>• enable(1) – Authenticate by the “Enable” password for the command line interface</li> <li>• radius(2) – Authenticate by requesting the RADIUS server</li> <li>• local(3) – Authenticate by local user account table</li> <li>• line(4) – Authenticate by the Telnet password</li> <li>• tacplus(5) – Authenticate by requesting TACACS Plus server</li> <li>• none(6) – Do not authenticate</li> <li>• tacacs(7) – Authenticate by requesting TACACS server</li> </ul> Setting a zero length octet string invalidates all previous authentication methods.
snRadiusEnableMethod fdry.1.1.3.12.1.8 Syntax: Octet string	Read- write	Shows the sequence of authentication methods for the RADIUS server. Each octet represents a method for authenticating the user after login, as the user enters the privilege mode of the command line interface. Each octet can have one of the following values: <ul style="list-style-type: none"> <li>• enable(1) – Authenticate by the “Enable” password for the command line interface</li> <li>• radius(2) – Authenticate by requesting the RADIUS server</li> <li>• local(3) – Authenticate by local user account table</li> <li>• line(4) – Authenticate by the Telnet password</li> <li>• tacplus(5) – Authenticate by requesting TACACS Plus server</li> <li>• none(6) – Do not authenticate</li> <li>• tacacs(7) – Authenticate by requesting TACACS server</li> </ul> Setting a zero length octet string invalidates all previous authentication methods.



Name, OID, and Syntax	Access	Description
snRadiusWebServerMethod fdry.1.1.3.12.1.9 Syntax: Octet string	Read-write	<p>Shows the sequence of authentication methods. Each octet represents a method for authenticating the user who is accessing the Web-server. Each octet can have one of the following values:</p> <ul style="list-style-type: none"> <li>enable(1) – Authenticate by the “Enable” password for the command line interface</li> <li>radius(2) – Authenticate by requesting the RADIUS server</li> <li>local(3) – Authenticate by local user account table</li> <li>line(4) – Authenticate by the Telnet password</li> <li>tacplus(5) – Authenticate by requesting TACACS Plus server</li> <li>none(6) – Do not authenticate</li> <li>tacacs(7) – Authenticate by requesting TACACS server</li> </ul> <p>Setting a zero length octet string invalidates all previous authentication methods.</p>
snRadiusSNMPServerMethod fdry.1.1.3.12.1.10 Syntax: Octet string	Read-write	<p>Shows the sequence of authentication methods. Each octet represents a method to authenticate the user who is accessing the SNMP server. Each octet can have one of the following values:</p> <ul style="list-style-type: none"> <li>enable(1) – Authenticate by the “Enable” password for the command line interface</li> <li>radius(2) – Authenticate by requesting the RADIUS server</li> <li>local(3) – Authenticate by local user account table</li> <li>line(4) – Authenticate by the Telnet password</li> <li>tacplus(5) – Authenticate by requesting TACACS Plus server</li> <li>none(6) – Do not authenticate</li> <li>tacacs(7) – Authenticate by requesting TACACS server</li> </ul> <p>Setting a zero length octet string invalidates all previous authentication methods..</p>

## RADIUS Server Table

The following objects provide information on the RADIUS server. They apply to all Foundry devices.

Name, OID, and Syntax	Access	Description
snRadiusServerTable fdry.1.1.3.12.2	None	RADIUS server table.
snRadiusServerEntry fdry.1.1.3.12.2.1	None	An entry in the RADIUS server table.

Name, OID, and Syntax	Access	Description
snRadiusServerIp fdry.1.1.3.12.2.1.1 Syntax: IpAddress	Read only	Shows the RADIUS server IP address.
snRadiusServerAuthPort fdry.1.1.3.12.2.1.2 Syntax: Integer	Read-write	Shows the UDP port number for authentication. Default: 1645
snRadiusServerAcctPort fdry.1.1.3.12.2.1.3 Syntax: Integer	Read-write	Shows the UDP port number used for accounting. Default: 1646
snRadiusServerRowStatus fdry.1.1.3.12.2.1.4 Syntax: Integer	Read-write	Creates or deletes a RADIUS server table entry: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> </ul>
snRadiusServerRowKey fdry.1.1.3.12.2.1.5 Syntax: Display string	Read-write	Shows the authentication key, which is displayed as encrypted text. Valid values: Up to 32 characters.
snRadiusServerUsage fdry.1.1.3.12.2.1.6 Syntax: Integer	Read-write	Allows this server to be dedicated for a particular AAA activity: <ul style="list-style-type: none"> <li>• default(1)</li> <li>• authentication-only(2)</li> <li>• authorization-only(3)</li> <li>• accounting-only(4)</li> </ul>

## TACACS General Objects

The Terminal Access Controller Access Control System (TACACS) or security protocols can be used to authenticate the following types of access to Foundry devices:

- Telnet access
- SSH access
- Securing Access to Management Functions
- Web management access
- Access to the Privileged EXEC level and CONFIG levels of the CLI

The TACACS and protocols define how authentication, authorization, and accounting information is sent between a Foundry device and an authentication database on a TACACS server.

The following objects provide information on TACACS authentication. They apply to all Foundry devices. Refer to the *Foundry Security Guide* for more information on TACACS.

Name, OID, and Syntax	Access	Description
snTacacsGeneral fdry.1.1.3.13.1		
snTacacsRetransmit fdry.1.1.3.13.1.1 Syntax: Integer	Read-write	Shows the number of authentication query retransmissions to the TACACS server.  Valid values: 0 – 5. Default: 3
snTacacsTimeOut fdry.1.1.3.13.1.2 Syntax: Integer	Read-write	Specifies how many seconds to wait for authentication reply from the TACACS server.  Valid values: 0 – 15 Default: 3 seconds
snTacacsDeadTime fdry.1.1.3.13.1.3 Syntax: Integer	Read-write	Specifies the TACACS server dead time in minutes.  Valid values: 0 – 5 Default: 3 minutes
snTacacsKey fdry.1.1.3.13.1.4 Syntax: Display string	Read-write	Authentication key displayed as encrypted text.  Valid values: Up to 32 characters.
snTacacsSNMPAccess fdry.1.1.3.13.1.5 Syntax: Integer	Read only	Indicates whether the TACACS group MIB objects can be accessed by an SNMP manager. <ul style="list-style-type: none"> <li>disabled(0) – All TACACS group MIB objects return "general error"</li> <li>enabled(1)</li> </ul> Default: disabled(0)

## TACACS Server Table

The following objects provide information on the TACACS server. They apply to all Foundry devices.

Name, OID, and Syntax	Access	Description
snTacacsServerTable fdry.1.1.3.13.2	None	TACACS server table.
snTacacsServerEntry fdry.1.1.3.13.2.1	None	An entry in the TACACS server table.

Name, OID, and Syntax	Access	Description
snTacacsServerIp fdry.1.1.3.13.2.1.1 Syntax: IpAddress	Read only	Shows the TACACS server IP address.
snTacacsServerAuthPort fdry.1.1.3.13.2.1.2 Syntax: Integer	Read-write	Specifies the UDP port used for authentication. Default: 49
snTacacsServerRowStatus fdry.1.1.3.13.2.1.3 Syntax: Integer	Read-write	Creates or deletes a TACACS server table entry: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> </ul>
snTacacsServerRowKey fdry.1.1.3.13.2.1.4 Syntax: Display string	Read-write	Authentication key displayed as encrypted text. Valid values: Up to 32 characters.
snTacacsServerUsage fdry.1.1.3.13.2.1.5 Syntax: Integer	Read-write	Allows this server to be dedicated to a particular AAA activity: <ul style="list-style-type: none"> <li>• default(1) – All AAA functions</li> <li>• authentication-only(2)</li> <li>• authorization-only(3)</li> <li>• accounting-only(4)</li> </ul>

This chapter presents the objects used to define interfaces on a device. It contains the following sections:

- “Switch Port Information Table” on page 7-1
- “Interface ID Lookup Table” on page 7-23
- “Interface Index Lookup Table” on page 7-25
- “Trunk Port Configuration Group” on page 7-26
- “Multi-Slot Trunk Port Table” on page 7-26
- “Packet Port Information Table” on page 7-27
- “Loopback Interface Configuration Table” on page 7-32
- “Port STP Configuration Groups” on page 7-34
- “Port Monitor Table” on page 7-40

Refer to the *Foundry Switch and Router Installation and Basic Configuration Guide* for details on the features discussed in this chapter.

## Switch Port Information

The following table contains information about the switch port groups.

### Switch Port Information Table

The snSwPortInfoTable contains information about the switch port groups.

---

**NOTE:** BigIron MG8 and NetIron 40G use the snSwIfInfoTable instead of this table. Refer to “Switch Port Information Group” on page 7-14.

---

---

Name, OID, and Syntax	Access	Description
snSwPortInfoTable	None	The Switch Port Information Table.
fdry.1.1.3.3.1		

---

Name, OID, and Syntax	Access	Description
snSwPortInfoEntry fdry.1.1.3.3.1.1	None	An entry in the snSwPortInfo table indicates the configuration for a specified port. An SNMP SET PDU for a row of the snSwPortInfoTable requires the entire sequence of the MIB Objects in each snSwPortInfoEntry stored in one PDU. Otherwise, GENERR return-value will be returned.
snSwPortInfoPortNum fdry.1.1.3.3.1.1.1 Syntax: Integer	Read only	Shows the port index: <ul style="list-style-type: none"> <li>• Bit 0 to bit 7 – Port number</li> <li>• Bit 8 to bit 11 – Slot number (for slot chassis only).</li> </ul>
snSwPortInfoMonitorMode fdry.1.1.3.3.1.1.2 Syntax: Integer <b>NOTE:</b> In FES software release 03.2.00 and later, this object has been deprecated and was replaced with “snSwPortInfoMirrorMode”	Read-write	Indicates the method used to monitor traffic on a port: <ul style="list-style-type: none"> <li>• disabled(0) – No traffic monitoring.</li> <li>• input(1) – Traffic monitoring is activated on packets received</li> <li>• output(2) – Traffic monitoring is activated on packets transmitted</li> <li>• both(3) – Traffic monitoring is activated on packets received and transmitted.</li> </ul> Default: disabled(0)
snSwPortInfoTagType fdry.1.1.3.3.1.1.3 Syntax: Integer	Read-write	Indicates if the port has an 802.1q tag: <ul style="list-style-type: none"> <li>• tagged(1) – Ports can have multiple VLAN IDs since these ports can be members of more than one VLAN.</li> <li>• untagged(2) – There is only one VLAN ID per port.</li> <li>• auto(3) – There is only one VLAN ID per port.</li> <li>• disabled(4)</li> </ul>
snSwPortInfoChnMode fdry.1.1.3.3.1.1.4 Syntax: Integer	Read-write	Indicates if the port operates in half- or full-duplex mode: <ul style="list-style-type: none"> <li>• halfDuplex(1) – Half duplex mode. Available only for 10/100 Mbps ports.</li> <li>• fullDuplex(2) – Full duplex mode. 100BaseFx, 1000BaseSx, and 1000BaseLx ports operate only at fullDuplex(2).</li> </ul> The read-back channel status from hardware can be: <ul style="list-style-type: none"> <li>• none(0) – Link down or port disabled.</li> <li>• halfDuplex(1) – Half duplex mode.</li> <li>• fullDuplex(2) – Full duplex mode.</li> </ul> The port media type (expansion or regular) and port link type (trunk or feeder) determine the value of this object. The port cannot be set to half duplex mode if the port connect mode is m200e(4). However, the value of this parameter may be automatically set whenever the expansion port is connected, for example, in the case of cascade connecting device.

Name, OID, and Syntax	Access	Description
snSwPortInfoSpeed fdry.1.1.3.3.1.1.5 Syntax: Integer	Read- write	<p>Indicates the speed configuration for a port:</p> <ul style="list-style-type: none"> <li>• none(0) – Link down or no traffic.</li> <li>• sAutoSense(1) – Auto-sensing 10 or 100Mbits.</li> <li>• s10M(2) – 10Mbits per second.</li> <li>• s100M(3) – 100Mbits per second.</li> <li>• s1G(4) – 1Gbits per second.</li> <li>• s45M(5) – 45Mbits per second (T3) (for expansion board only).</li> <li>• s155M(6) – 155Mbits per second (ATM) (for expansion board only).</li> <li>• s10G(7) – 10Gbits per second.</li> </ul> <p>The read-back hardware status are the following:</p> <ul style="list-style-type: none"> <li>• none(0) – Link down or no traffic.</li> <li>• s10M(2) – 10Mbits per second.</li> <li>• s100M(3) – 100Mbits per second.</li> <li>• s1G(4) – 1Gbits per second.</li> <li>• s45M(5) – 45Mbits per second (T3) (for expansion board only).</li> <li>• s155M(6) – 155Mbits per second (ATM) (for expansion board only).</li> <li>• s10G(7) – 10Gbits per second.</li> </ul> <p>The port media type (expansion or regular) and port link type (trunk or feeder) determine whether this object can be written and the valid values for this object. It is not allowed to change speed for trunks ports. For expansion ports, all of the above speeds can be set; however, the value of this parameter may be automatically set whenever the expansion port is connected, for example, in the case of cascade connecting device.</p>

Name, OID, and Syntax	Access	Description
snSwPortInfoMediaType fdry.1.1.3.3.1.1.6 Syntax: Integer	Read only	Shows the media type for the port: <ul style="list-style-type: none"> <li>• other(1) – other or unknown media.</li> <li>• m100BaseTX(2) – 100Mbps per second copper.</li> <li>• m100BaseFX(3) – 100Mbps per second fiber.</li> <li>• m1000BaseFX(4) – 1Gbits per second fiber.</li> <li>• mT3(5) – 45Mbps per second (T3).</li> <li>• m155ATM(6) – 155Mbps per second (ATM).</li> <li>• m1000BaseTX(7) – 1Gbits per second copper.</li> <li>• m622ATM(8) – 622Mbps per second (ATM).</li> <li>• m155POS(9) – 155Mbps per second (POS).</li> <li>• m622POS(10) – 622Mbps per second (POS).</li> <li>• m2488POS(11) – 2488Mbps per second (POS).</li> <li>• m10000BaseFX(12) – 10Gbits per second fiber.</li> </ul>
snSwPortInfoConnectorType fdry.1.1.3.3.1.1.7 Syntax: Integer	Read only	Shows the type of connector that the port offers: <ul style="list-style-type: none"> <li>• other(1) – Other or unknown connector</li> <li>• copper(2) – Copper connector</li> <li>• fiber(3) – Fiber connector This describes the physical connector type</li> </ul>
snSwPortInfoAdminStatus fdry.1.1.3.3.1.1.8 Syntax: Integer	Read-write	Shows the desired state of all ports. <ul style="list-style-type: none"> <li>• up(1) – Ready to pass packets</li> <li>• down(2)</li> <li>• testing(3) – No operational packets can be passed (same as ifAdminStatus in MIB-II)</li> </ul>
snSwPortInfoLinkStatus fdry.1.1.3.3.1.1.9 Syntax: Integer	Read only	Shows the current operational state of the interface. <ul style="list-style-type: none"> <li>• up(1) – Ready to pass packets</li> <li>• down(2)</li> <li>• testing(3) – No operational packets can be passed (same as ifAdminStatus in MIB-II)</li> </ul>



Name, OID, and Syntax	Access	Description
snSwPortInfoPortQos fdry.1.1.3.3.1.1.10 Syntax: Integer	Read- write	Indicates the quality of service level selected for the port. For stackable devices, the QoS can be one of the following: <ul style="list-style-type: none"> <li>• low(0) – low priority</li> <li>• high(1) – high priority.</li> </ul> For chassis devices, the values can be: <ul style="list-style-type: none"> <li>• level0(0)</li> <li>• level1(1)</li> <li>• level2(2)</li> <li>• level3(3)</li> <li>• level4(4)</li> <li>• level5(5)</li> <li>• level6(6)</li> <li>• level7(7)</li> </ul>
snSwPortInfoPhysAddress fdry.1.1.3.3.1.1.11 Syntax: Physical address	Read only	Shows the port's physical address.
snSwPortStatsInFrames fdry.1.1.3.3.1.1.12 Syntax: Counter	Read only	Shows the total number of packets received on the interface.
snSwPortStatsOutFrames fdry.1.1.3.3.1.1.13 Syntax: Counter	Read only	Shows the total number of packets transmitted out of the interface.
snSwPortStatsAlignErrors fdry.1.1.3.3.1.1.14 Syntax: Counter	Read only	Shows the number of dot3StatsAlignmentErrors, which consists of frames received on a particular interface that are not an integral number of octets in length and do not pass the FCS check.  The count represented by an instance of this object is incremented when the alignmentError status is returned by the MAC service to the LLC (or other MAC user). According to the conventions of IEEE 802.3 Layer Management, received frames for which multiple error conditions are obtain are counted exclusively according to the error status presented to the LLC.

Name, OID, and Syntax	Access	Description
<p>snSwPortStatsFCSErrors fdry.1.1.3.3.1.1.15 Syntax: Counter</p>	Read only	<p>Shows the number of dot3StatsFCSErrors, which consists of frames received on a particular interface that are an integral number of octets in length but do not pass the FCS check.</p> <p>The count represented by an instance of this object is incremented when the frameCheckError status is returned by the MAC service to the LLC (or other MAC user). According to the conventions of IEEE 802.3 Layer Management, received frames for which multiple error conditions are obtain are counted exclusively according to the error status presented to the LLC</p>
<p>snSwPortStatsMultiColliFrames fdry.1.1.3.3.1.1.16 Syntax: Counter</p>	Read only	<p>Shows the number of dot3StatsMultipleCollisionFrames, which consists of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision.</p> <p>A frame that is counted by an instance of this object is also counted by the corresponding instance of either the ifOutUcastPkts, ifOutMulticastPkts, or ifOutBroadcastPkts and is not counted by the corresponding instance of the dot3StatsSingleCollisionFrames object.</p>
<p>snSwPortStatsFrameTooLongs fdry.1.1.3.3.1.1.17 Syntax: Counter</p>	Read only	<p>Shows the number of dot3StatsFrameTooLongs, which consists of frames received on a particular interface that exceed the maximum permitted frame size.</p> <p>The count represented by an instance of this object is incremented when the frameTooLong status is returned by the MAC service to the LLC (or other MAC user). According to the conventions of IEEE 802.3 Layer Management, received frames for which multiple error conditions are obtain are, counted exclusively according to the error status presented to the LLC</p>
<p>snSwPortStatsTxColliFrames fdry.1.1.3.3.1.1.18 Syntax: Counter</p>	Read only	<p>Shows the number of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision. This count is a combination of the dot3StatsSingleCollisionFrames and dot3StatsMultipleCollisionFrames objects.</p>
<p>snSwPortStatsRxColliFrames fdry.1.1.3.3.1.1.19 Syntax: Counter</p>	Read only	<p>Shows the number of successfully received frames on a particular interface for which transmission is inhibited by more than one collision. This object is not specified in dot3 but it has the same functionality as the object "snSwPortStatsTxColliFrames".</p>
<p>snSwPortStatsFrameTooShorts fdry.1.1.3.3.1.1.20 Syntax: Counter</p>	Read only	<p>Shows the number frames received on a particular interface that are below the minimum permitted frame size.</p>
<p>snSwPortLockAddressCount fdry.1.1.3.3.1.1.21 Syntax: Integer</p>	Read-write	<p>Indicates the number of source MAC addresses that are allowed for a port. Writing 0 to this object will allow any number of addresses.</p> <p>Valid values: 0 to 2048.</p> <p>Default: 8</p>

Name, OID, and Syntax	Access	Description
snSwPortStpPortEnable fdry.1.1.3.3.1.1.22 Syntax: Integer	Read-write	Indicates if STP is enabled for the port: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Refer to the document IEEE 802.1D-1990: Section 4.5.5.2, dot1dStpPortEnable.
snSwPortDhcpGateListId fdry.1.1.3.3.1.1.23 Syntax: Integer	Read-write	Specifies the ID for a DHCP gateway list entry relative to this switch port.  Valid values: 0 – 32. A value of 0 means that the ID is unassigned.
snSwPortName fdry.1.1.3.3.1.1.24 Syntax: Display string	Read-write	Indicates the port name or description. This description may have been entered using the CLI.  Valid values: Up to 255 characters.
snSwPortStatsInBcastFrames fdry.1.1.3.3.1.1.25 Syntax: Counter	Read-write	Shows the total number of broadcast packets received on the interface.
snSwPortStatsOutBcastFrames fdry.1.1.3.3.1.1.26 Syntax: Counter	Read only	Shows the total number of broadcast packets transmitted out of the interface.
snSwPortStatsInMcastFrames fdry.1.1.3.3.1.1.27 Syntax: Counter	Read only	Shows the total number of multicast packets received on the interface.
snSwPortStatsOutMcastFrames fdry.1.1.3.3.1.1.28 Syntax: Counter	Read only	Shows the total number of multicast packets transmitted out of the interface.
snSwPortStatsInDiscard fdry.1.1.3.3.1.1.29 Syntax: Counter	Read only	Shows the number of inbound packets that will be discarded even though they have no errors. These packets will be discarded to prevent them from being deliverable to a higher-layer protocol. For example, packets may be discarded to free up buffer space.
snSwPortStatsOutDiscard fdry.1.1.3.3.1.1.30 Syntax: Counter	Read only	Shows the number of outbound packets that will be discarded even though they contain no errors. For example, packets may be discarded to free up buffer space.
snSwPortStatsMacStations fdry.1.1.3.3.1.1.31 Syntax: Integer	Read only	Shows the total number of MAC Stations connected to the interface.

Name, OID, and Syntax	Access	Description
snSwPortCacheGroupld fdry.1.1.3.3.1.1.32 Syntax: Integer	Read-write	Applies only to ServerIron products. Indicates the cache Group ID for the interface.
snSwPortTransGroupld fdry.1.1.3.3.1.1.33 Syntax: Integer	Read-write	Applies only to ServerIron products. Indicates the transparent Group ID for the interface.
snSwPortInfoAutoNegotiate fdry.1.1.3.3.1.1.34 Syntax: Integer	Read-write	Applies only to Gigabit Ethernet ports. Indicates if auto-negotiation mode is enabled on the port. <ul style="list-style-type: none"> <li>• disable(0) – The port will be placed in non-negotiation mode.</li> <li>• enable(1) – The port will start auto-negotiation indefinitely until it succeeds.</li> <li>• negFullAuto(2) – The port will start with auto-negotiation. If the negotiation fails, then it will automatically switch to non-negotiation mode. This option is not supported in stackable products Gigabit Ethernet ports, except for TurboIron/8.</li> <li>• global(3) – The port negotiation mode follows the value of snSwGlobalAutoNegotiate.</li> <li>• other(4) – Non-Gigabit Ethernet.</li> </ul> Default: global(3)
snSwPortInfoFlowControl fdry.1.1.3.3.1.1.35 Syntax: Integer	Read-write	Indicates if port flow control is enabled: <ul style="list-style-type: none"> <li>• disable(0)</li> <li>• enable(1)</li> </ul> Default: enabled(1)

Name, OID, and Syntax	Access	Description
snSwPortInfoGigType	Read only	Applies only to Gigabit Ethernet ports.
fdry.1.1.3.3.1.1.36		Shows the media type for the port:
Syntax: Integer		<ul style="list-style-type: none"> <li>• m1000BaseSX(0) – 1-Gbps fiber, with a short wavelength transceiver</li> <li>• m1000BaseLX(1) – 1-Gbps fiber, with a long wavelength transceiver (3km)</li> <li>• m1000BaseLH(2) – 1-Gbps fiber, with a special wavelength transceiver (50km)</li> <li>• m1000BaseLHB(4) – 1-Gbps fiber, with a special wavelength transceiver (150km).</li> <li>• m1000BaseTX(5) – 1-Gbps copper (100meter).</li> <li>• m10000BaseSR(6) – 10-Gbps fiber, with a short range wavelength transceiver (100m).</li> <li>• m10000BaseLR(7) – 10-Gbps fiber, with a long range wavelength transceiver (10km).</li> <li>• m10000BaseER(8) – 10-Gbps fiber, with a extended range wavelength transceiver (40km).</li> <li>• notApplicable(255) – a non-gigabit port.</li> <li>• m1000BaseSX(0) – 1Gbits per second fiber, with a short wavelength transceiver.</li> <li>• m1000BaseLX(1) – 1Gbits per second fiber, with a long wavelength transceiver (3km).</li> <li>• m1000BaseLH(2) – 1Gbits per second fiber, with a special wavelength transceiver (50km).Obsoleted.</li> <li>• m1000BaseLHA(3) – 1Gbits per second fiber, with a special wavelength transceiver (70km).</li> <li>• m1000BaseLHB(4) – 1Gbits per second fiber, with a special wavelength transceiver (150km).</li> <li>• m1000BaseTX(5) – 1Gbits per second copper (100meter).</li> <li>• m10000BaseSR(6) – 10Gbits per second fiber, with a short range wavelength transceiver (100m)</li> <li>• m10000BaseLR(7) – 10Gbits per second fiber, with a long range wavelength transceiver (10km).</li> <li>• m10000BaseER(8) – 10Gbits per second fiber, with a extended range wavelength transceiver (40km).</li> <li>• sfpCWDM1470nm80Km(9) – 1Gbits per second CWDM fiber, with a wavelength 1470nm, reach 80 kms.</li> <li>• sfpCWDM1490nm80Km(10) – 1Gbits per second CWDM fiber, with a wavelength 1490nm, reach 80 kms.</li> <li>• sfpCWDM1510nm80Km(11) – 1Gbits per second CWDM fiber, with a wavelength 1510nm, reach 80 kms.</li> </ul>

Name, OID, and Syntax	Access	Description
snSwPortInfoGigType (continued)		<ul style="list-style-type: none"> <li>• sfpCWDM1530nm80Km(12) – 1Gbits per second CWDM fiber, with a wavelength 1530nm, reach 80 kms.</li> <li>• sfpCWDM1550nm80Km(13) – 1Gbits per second CWDM fiber, with a wavelength 1550nm, reach 80 kms.</li> <li>• sfpCWDM1570nm80Km(14) – 1Gbits per second CWDM fiber, with a wavelength 1570nm, reach 80 kms.</li> <li>• sfpCWDM1590nm80Km(15) – 1Gbits per second CWDM fiber, with a wavelength 1590nm, reach 80 kms.</li> <li>• sfpCWDM1610nm80Km(16) – 1Gbits per second CWDM fiber, with a wavelength 1610nm, reach 80 kms.</li> <li>• sfpCWDM1470nm100Km(17) – 1Gbits per second CWDM fiber, with a wavelength 1470nm, reach 100 kms.</li> <li>• sfpCWDM1490nm100Km(18) – 1Gbits per second CWDM fiber, with a wavelength 1490nm, reach 100 kms.</li> <li>• sfpCWDM1510nm100Km(19) – 1Gbits per second CWDM fiber, with a wavelength 1510nm, reach 100 kms.</li> <li>• sfpCWDM1530nm100Km(20) – 1Gbits per second CWDM fiber, with a wavelength 1530nm, reach 100 kms.</li> <li>• sfpCWDM1550nm100Km(21) – 1Gbits per second CWDM fiber, with a wavelength 1550nm, reach 100 kms.</li> <li>• sfpCWDM1570nm100Km(22) – 1Gbits per second CWDM fiber, with a wavelength 1570nm, reach 100 kms.</li> <li>• sfpCWDM1590nm100Km(23) – 1Gbits per second CWDM fiber, with a wavelength 1590nm, reach 100 kms.</li> <li>• sfpCWDM1610nm100Km(24) – 1Gbits per second CWDM fiber, with a wavelength 1610nm, reach 100 kms.</li> <li>• notApplicable(255) – a non-gigabit port.</li> </ul>
snSwPortStatsLinkChange fdry.1.1.3.3.1.1.37 Syntax: Counter	Read only	Shows the total number of link state changes on the interface.
snSwPortIfIndex fdry.1.1.3.3.1.1.38 Syntax: Integer	Read only	Identifies the instance of the ifIndex object in order to identify a particular interface, as defined in RFC 1213 and RFC 1573.
snSwPortDescr fdry.1.1.3.3.1.1.39 Syntax: Display string	Read only	Shows the slot/port information.
snSwPortInOctets fdry.1.1.3.3.1.1.40 Syntax: Octet string	Read only	Shows the total number of octets received on the interface, including framing characters. This object is a 64-bit counter of the ifInOctets object defined in RFC 1213. The octet string is in big-endian byte order.  This object has eight octets.

Name, OID, and Syntax	Access	Description
snSwPortOutOctets fdry.1.1.3.3.1.1.41 Syntax: Octet string	Read only	Shows the total number of octets transmitted out of the interface, including framing characters. This object is a 64-bit counter of the ifOutOctets object, defined in RFC 1213. The octet string is in big-endian byte order.  This object has eight octets.
snSwPortStatsInBitsPerSec fdry.1.1.3.3.1.1.42 Syntax: Gauge	Read only	Shows the number of bits per second received on the interface over a five-minute interval.
snSwPortStatsOutBitsPerSec fdry.1.1.3.3.1.1.43 Syntax: Gauge	Read only	Shows the number of bits per second transmitted out of the interface over a five-minute interval.
snSwPortStatsInPktsPerSec fdry.1.1.3.3.1.1.44 Syntax: Gauge	Read only	Shows the number of packets per second received on the interface over a five-minute interval.
snSwPortStatsOutPktsPerSec fdry.1.1.3.3.1.1.45 Syntax: Gauge	Read only	Shows the number of packets per second transmitted out of the interface over a five-minute interval.
snSwPortStatsInUtilization fdry.1.1.3.3.1.1.46 Syntax: Integer	Read only	Identifies the input network utilization in hundredths of a percent over a five-minute interval.  Valid values: 0 – 10000.
snSwPortStatsOutUtilization fdry.1.1.3.3.1.1.47 Syntax: Integer	Read only	Shows the output network utilization in hundredths of a percent over a five-minute interval.  Valid values: 0 – 10000.
<p><b>NOTE:</b> Ethernet devices must allow a minimum idle period between transmission of frames known as interframe gap (IFG) or interpacket gap (IPG). The gap provides a brief recovery time between frames to allow devices to prepare to receive the next frame. The minimum IFG is 96 bit times, which is 9.6 microseconds for 10 Mbps Ethernet, 960 nanoseconds for 100 Mbps Ethernet, and 96 nanoseconds for 1 Gbps Ethernet. In addition, to account for the bit rate on the port, port utilization should also account for the IFG, which normally is filtered by the packet synchronization circuitry.</p> <p>Refer to the etherHistoryUtilization objects in the <i>RFC 1757: Remote Network Monitoring Management Information Base</i> for details.</p>		
snSwPortFastSpanPortEnable fdry.1.1.3.3.1.1.48 Syntax: Integer	Read-write	Indicates if fast span is enabled on the port. <ul style="list-style-type: none"> <li>• disable(0)</li> <li>• enable(1)</li> </ul>
snSwPortFastSpanUplinkEnable fdry.1.1.3.3.1.1.49 Syntax: Integer	Read-write	Indicates if fast span uplink is enabled on the port. <ul style="list-style-type: none"> <li>• disable(0)</li> <li>• enable(1)</li> </ul>

Name, OID, and Syntax	Access	Description
snSwPortVlanId fdry.1.1.3.3.1.1.50 Syntax: Integer	Read only	Shows the ID of a VLAN of which this port is a member. Port must be untagged.  Valid values: 0 – 4095; where 0 means an invalid VLAN ID value, which is returned for tagged ports.
snSwPortRouteOnly fdry.1.1.3.3.1.1.51 Syntax: Integer	Read-write	Indicates if Layer 2 switching is enabled on a routing switch port. <ul style="list-style-type: none"> <li>disable(0) – Instructs the routing switch to perform routing first. If that fails, it performs switching.</li> <li>enable(1) – Instructs the routing switch to perform routing only.</li> </ul> <p>For a Layer 2 switching only product, reading this object always returns "disabled". Writing "enabled" to this object takes no effect.</p> <p>Default: disabled(0)</p>
snSwPortPresent fdry.1.1.3.3.1.1.52 Syntax: Integer	Read only	Applies only to M4 modules.  Indicates if the port is absent or present. <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>
snSwPortGBICStatus fdry.1.1.3.3.1.1.53 Syntax: Integer	Read only	Indicates if the Gigabit port has a GBIC or miniGBIC port: <ul style="list-style-type: none"> <li>GBIC(1) – GBIC</li> <li>miniGBIC(2) – MiniGBIC</li> <li>empty(3) – GBIC is missing</li> <li>other(4) – Not a removable Gigabit port</li> </ul>
snSwPortStatsInKiloBitsPerSec fdry.1.1.3.3.1.1.54 Syntax: Unsigned32	Read-only	Shows the bit rate, in kilobits per second, received on a 10 Gigabit or faster interface within a five minute interval.
snSwPortStatsOutKiloBitsPerSec fdry.1.1.3.3.1.1.55 Syntax: Unsigned32	Read-only	Shows the bit rate, in kilobits per second, transmitted from a 10 Gigabit or faster interface within a five minute interval.
snSwPortLoadInterval fdry.1.1.3.3.1.1.56 Syntax: Integer	Read-write	Shows the number of seconds for which average port utilization should be calculated.  Valid values: 30 to 300, in 30 second increments.  Default: 300 seconds  <b>NOTE:</b> This object is implemented in IronWare Release 07.5.04 and TrafficWorks release 8.x.



Name, OID, and Syntax	Access	Description
snSwPortInLinePowerControl fdry.1.1.3.3.1.1.58 Syntax: Integer	Read-write	<p>This object is available in FastIron Edge Switch devices that support power over Ethernet beginning with software release 03.1.00.</p> <p>Controls inline power on/off to a port.</p> <p>Valid values:</p> <ul style="list-style-type: none"> <li>other(1) – The port does not have inline power capability,</li> <li>disable(2) – The device is a 802.3af-compliant device and the inline power capability on this port is disabled.</li> <li>enable(3) – The device is a 802.3af-compliant device and the inline power capability on this port is enabled.</li> <li>enableLegacyDevice(4) – This device is non-802.3af-compliant and the inline power capability on this port is enabled.</li> </ul>
snSwPortInLinePowerWattage fdry.1.1.3.3.1.1.59 Syntax: Integer	Read-write	<p>This object is available in FastIron Edge Switch devices that support power over Ethernet beginning with software release 03.1.00.</p> <p>Adjust the inline power wattage. Each unit is milliwatts. This object can only be set after snSwPortInLinePowerControl object has been set to enable(3) or enableLegacyDevice(4). If a port does not have inline power capability, reading this object returns undefined value.</p> <p>Valid values: 1000 – 15400 milliwatts</p>
snSwPortInLinePowerClass fdry.1.1.3.3.1.1.60 Syntax: Integer	Read-write	<p>This object is available in FastIron Edge Switch devices that support power over Ethernet beginning with software release 03.1.00.</p> <p>Adjust the inline power class. This object can only be set after snSwPortInLinePowerControl has been set to 'enable(3)' or 'enableLegacyDevice(4)'. If a port does not have inline power capability, reading this object returns undefined value.</p> <p>Valid values:</p> <ul style="list-style-type: none"> <li>0 – 15.4</li> <li>1 – 4</li> <li>2 – 7</li> <li>3 – 15.4</li> </ul> <p>Default: 0</p>
snSwPortInfoMirrorMode fdry.1.1.3.3.1.1.62 Syntax: Integer	Read-write	<p>This object enables or disables port mirroring on the interface:</p> <ul style="list-style-type: none"> <li>disable(0)</li> <li>enable(1)</li> </ul> <p><b>NOTE:</b> In FES software release 03.2.00 and later, this object replaces the "snSwIfInfoMonitorMode"</p>

## Switch Port Information Group

The snSwIfInfoTable contains information about the switch port groups on BigIron MG8 and NetIron 40G devices. Other Foundry devices use the snSwPortInfoTable (refer to “Switch Port Information Table” on page 7-1).

Name, OID, and Syntax	Access	Description
snSwIfInfoTable fdry.1.1.3.3.5	None	The Switch Port Information Table.
snSwIfInfoEntry fdry.1.1.3.3.5.1	None	An entry in the snSwIfInfo table indicates the configuration for a specified port. An SNMP SET PDU for a row of the snSwPortInfoTable requires the entire sequence of the MIB Objects in each snSwPortInfoEntry stored in one PDU. Otherwise, GENERR return-value will be returned.
snSwIfInfoPortNum fdry.1.1.3.3.5.1.1 Syntax: InterfaceIndex	Read only	Shows the port or interface index.
snSwIfInfoMonitorMode fdry.1.1.3.3.5.1.2 Syntax: Integer	Read-write	Indicates the method used to monitor traffic on a port: <ul style="list-style-type: none"> <li>disabled(0) – No traffic monitoring.</li> <li>input(1) – Traffic monitoring is activated on packets received</li> <li>output(2) – Traffic monitoring is activated on packets transmitted</li> <li>both(3) – Traffic monitoring is activated on packets received and transmitted.</li> </ul> Default: disabled(0)
snSwIfInfoMirrorPorts fdry.1.1.3.3.5.1.3 Syntax: Integer	Read-write	Contains a list of port or interface indexes (ifindex) that mirror this interface when monitoring is enabled.
snSwIfInfoTagMode fdry.1.1.3.3.5.1.4 Syntax: Integer	Read-write	Indicates if the port has an 802.1q tag: <ul style="list-style-type: none"> <li>tagged(1) – Ports can have multiple VLAN IDs since these ports can be members of more than one VLAN.</li> <li>untagged(2) – There is only one VLAN ID per port.</li> </ul>
snSwIfInfoTagMode fdry.1.1.3.3.5.1.5 Syntax: Integer	Read-write	Indicated the interface's IEEE802.1q tag type. The tag type is embedded in the two octets in the length/type field of an Ethernet packet.

---

Name, OID, and Syntax	Access	Description
snSwlInfoChnMode fdry.1.1.3.3.5.1.6 Syntax: Integer	Read- write	<p data-bbox="743 262 1341 289">Indicates if the port operates in half- or full-duplex mode:</p> <ul data-bbox="743 306 1414 468" style="list-style-type: none"><li data-bbox="743 306 1414 363">• halfDuplex(1) – Half duplex mode. Available only for 10/100 Mbps ports.</li><li data-bbox="743 380 1414 468">• fullDuplex(2) – Full duplex mode. 100BaseFx, 1000BaseSx, and 1000BaseLx ports operate only at fullDuplex(2).</li></ul> <p data-bbox="743 485 1305 512">The read-back channel status from hardware can be:</p> <ul data-bbox="743 529 1187 648" style="list-style-type: none"><li data-bbox="743 529 1187 556">• none(0) – Link down or port disabled.</li><li data-bbox="743 573 1154 600">• halfDuplex(1) – Half duplex mode.</li><li data-bbox="743 617 1138 644">• fullDuplex(2) – Full duplex mode.</li></ul> <p data-bbox="743 661 1414 835">The port media type (expansion or regular) and port link type (trunk or feeder) determine the value of this object. The port cannot be set to half duplex mode if the port connect mode is m200e(4). However, the value of this parameter may be automatically set whenever the expansion port is connected, for example, in the case of cascade connecting device.</p>

---

Name, OID, and Syntax	Access	Description
snSwlInfoSpeed fdry.1.1.3.3.5.1.7 Syntax: Integer	Read- write	<p>Indicates the speed configuration for a port:</p> <ul style="list-style-type: none"> <li>• none(0) – Link down or no traffic.</li> <li>• sAutoSense(1) – Auto-sensing 10 or 100Mbps.</li> <li>• s10M(2) – 10Mbps per second.</li> <li>• s100M(3) – 100Mbps per second.</li> <li>• s1G(4) – 1Gbps per second.</li> <li>• s45M(5) – 45Mbps per second (T3) (for expansion board only).</li> <li>• s155M(6) – 155Mbps per second (ATM) (for expansion board only).</li> <li>• s10G(7) – 10Gbps per second.</li> </ul> <p>The read-back hardware status are the following:</p> <ul style="list-style-type: none"> <li>• none(0) – Link down or no traffic.</li> <li>• s10M(2) – 10Mbps per second.</li> <li>• s100M(3) – 100Mbps per second.</li> <li>• s1G(4) – 1Gbps per second.</li> <li>• s45M(5) – 45Mbps per second (T3) (for expansion board only).</li> <li>• s155M(6) – 155Mbps per second (ATM) (for expansion board only).</li> <li>• s10G(7) – 10Gbps per second.</li> </ul> <p>The port media type (expansion or regular) and port link type (trunk or feeder) determine whether this object can be written and the valid values for this object. It is not allowed to change speed for trunks ports. For expansion ports, all of the above speeds can be set; however, the value of this parameter may be automatically set whenever the expansion port is connected, for example, in the case of cascade connecting device.</p>

Name, OID, and Syntax	Access	Description
snSwlflInfoMediaType fdry.1.1.3.3.5.1.8 Syntax: Integer	Read only	Shows the media type for the port: <ul style="list-style-type: none"> <li>• other(1) – other or unknown media.</li> <li>• m100BaseTX(2) – 100Mbps per second copper.</li> <li>• m100BaseFX(3) – 100Mbps per second fiber.</li> <li>• m1000BaseFX(4) – 1Gbps per second fiber.</li> <li>• mT3(5) – 45Mbps per second (T3).</li> <li>• m155ATM(6) – 155Mbps per second (ATM).</li> <li>• m1000BaseTX(7) – 1Gbps per second copper.</li> <li>• m622ATM(8) – 622Mbps per second (ATM).</li> <li>• m155POS(9) – 155Mbps per second (POS).</li> <li>• m622POS(10) – 622Mbps per second (POS).</li> <li>• m2488POS(11) – 2488Mbps per second (POS).</li> <li>• m10000BaseFX(12) – 10Gbps per second fiber.</li> </ul>
snSwlflInfoConnectorType fdry.1.1.3.3.5.1.9 Syntax: Integer	Read only	Shows the type of connector that the port offers: <ul style="list-style-type: none"> <li>• other(1) – Other or unknown connector</li> <li>• copper(2) – Copper connector</li> <li>• fiber(3) – Fiber connector This describes the physical connector type</li> </ul>
snSwlflInfoAdminStatus fdry.1.1.3.3.5.1.10 Syntax: Integer	Read-write	Shows the desired state of all ports. <ul style="list-style-type: none"> <li>• up(1) – Ready to pass packets</li> <li>• down(2)</li> <li>• testing(3) – No operational packets can be passed (same as ifAdminStatus in MIB-II)</li> </ul>
snSwlflInfoLinkStatus fdry.1.1.3.3.5.1.11 Syntax: Integer	Read only	Shows the current operational state of the interface. <ul style="list-style-type: none"> <li>• up(1) – Ready to pass packets</li> <li>• down(2)</li> <li>• testing(3) – No operational packets can be passed (same as ifAdminStatus in MIB-II)</li> </ul>

Name, OID, and Syntax	Access	Description
snSwlInfoPortQos fdry.1.1.3.3.5.1.12 Syntax: Integer	Read-write	Indicates the quality of service level selected for the port. For stackable devices, the QoS can be one of the following: <ul style="list-style-type: none"> <li>• low(0) – low priority</li> <li>• high(1) – high priority.</li> </ul> For chassis devices, the values can be: <ul style="list-style-type: none"> <li>• level0(0)</li> <li>• level1(1)</li> <li>• level2(2)</li> <li>• level3(3)</li> <li>• level4(4)</li> <li>• level5(5)</li> <li>• level6(6)</li> <li>• level7(7)</li> </ul>
snSwlInfoPhysAddress fdry.1.1.3.3.5.1.13 Syntax: Physical address	Read only	Shows the port's physical address.
snSwlLockAddressCount fdry.1.1.3.3.5.1.14 Syntax: Integer	Read-write	Indicates the number of source MAC addresses that are allowed on the interface. Valid values: 0 – 2048. If you enter 0 allow an unlimited number of addresses. Default: 8
snSwlStpPortEnable fdry.1.1.3.3.5.1.15 Syntax: Integer	Read-write	Indicates if STP is enabled for the port: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Refer to the document IEEE 802.1D-1990: Section 4.5.5.2, dot1dStpPortEnable.
snSwlDhcpGateListId fdry.1.1.3.3.5.1.16 Syntax: Integer	Read-write	Specifies the ID for a DHCP gateway list entry relative to this switch port. Valid values: 0 – 32. A value of 0 means that the ID is unassigned.
snSwlName fdry.1.1.3.3.5.1.17 Syntax: Display string	Read-write	Indicates the port name or description. This description may have been entered using the CLI. Valid values: Up to 32 characters for most devices. Up to 255 characters for NetIron XMR.
snSwlDescr dry.1.1.3.3.5.1.18 Syntax: Display string	Read-write	The name of the interface.

Name, OID, and Syntax	Access	Description
snSwlInfoAutoNegotiate fdry.1.1.3.3.5.1.19 Syntax: Integer	Read-write	<p>Applies only to Gigabit Ethernet ports.</p> <p>Indicates if auto-negotiation mode is enabled on the port.</p> <ul style="list-style-type: none"> <li>disable(0) – The port will be placed in non-negotiation mode.</li> <li>enable(1) – The port will start auto-negotiation indefinitely until it succeeds.</li> <li>negFullAuto(2) – The port will start with auto-negotiation. If the negotiation fails, then it will automatically switch to non-negotiation mode. This option is not supported in stackable products Gigabit Ethernet ports, except for Turbolron/8.</li> <li>global(3) – The port negotiation mode follows the value of snSwGlobalAutoNegotiate.</li> <li>other(4) – Non-Gigabit Ethernet.</li> </ul> <p>Default: global(3)</p>
snSwlInfoFlowControl fdry.1.1.3.3.5.1.20 Syntax: Integer	Read-write	<p>Indicates if port flow control is enabled:</p> <ul style="list-style-type: none"> <li>disable(0)</li> <li>enable(1)</li> </ul> <p>Default: enabled(1)</p>
snSwlInfoGigType fdry.1.1.3.3.5.1.21 Syntax: Integer	Read only	<p>Applies only to Gigabit Ethernet ports.</p> <p>Shows the media type for the port:</p> <ul style="list-style-type: none"> <li>m1000BaseSX(0) – 1-Gbps fiber, with a short wavelength transceiver</li> <li>m1000BaseLX(1) – 1-Gbps fiber, with a long wavelength transceiver (3km)</li> <li>m1000BaseLH(2) – 1-Gbps fiber, with a special wavelength transceiver (50km)</li> <li>m1000BaseLHB(4) – 1-Gbps fiber, with a special wavelength transceiver (150km).</li> <li>m1000BaseTX(5) – 1-Gbps copper (100meter).</li> <li>m10000BaseSR(6) – 10-Gbps fiber, with a short range wavelength transceiver (100m).</li> <li>m10000BaseLR(7) – 10-Gbps fiber, with a long range wavelength transceiver (10km).</li> <li>m10000BaseER(8) – 10-Gbps fiber, with a extended range wavelength transceiver (40km).</li> <li>notApplicable(255) – a non-gigabit port.</li> </ul>
snSwlFastSpanPortEnable fdry.1.1.3.3.5.1.22 Syntax: Integer	Read-write	<p>Indicates if fast span is enabled on the port.</p> <ul style="list-style-type: none"> <li>disable(0)</li> <li>enable(1)</li> </ul>

Name, OID, and Syntax	Access	Description
snSwlfFastSpanUplinkEnable fdry.1.1.3.3.5.1.23 Syntax: Integer	Read-write	Indicates if fast span uplink is enabled on the port. <ul style="list-style-type: none"> <li>disable(0)</li> <li>enable(1)</li> </ul>
snSwlfVlanId fdry.1.1.3.3.5.1.24 Syntax: Integer	Read only	Shows the ID of a VLAN of which this port is a member. Port must be untagged.  Valid values: 0 – 4095; where 0 means an invalid VLAN ID value, which is returned for tagged ports.
snSwlfRouteOnly fdry.1.1.3.3.5.1.25 Syntax: Integer	Read-write	Indicates if Layer 2 switching is enabled on a routing switch port. <ul style="list-style-type: none"> <li>disable(0) – Instructs the routing switch to perform routing first. If that fails, it performs switching.</li> <li>enable(1) – Instructs the routing switch to perform routing only.</li> </ul> <p>For a Layer 2 switching only product, reading this object always returns "disabled". Writing "enabled" to this object takes no effect.</p> <p>Default: disabled(0)</p>
snSwlfPresent fdry.1.1.3.3.5.1.26 Syntax: Integer	Read only	Applies only to M4 modules.  Indicates if the port is absent or present. <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>
snSwlfGBICStatus fdry.1.1.3.3.5.1.27 Syntax: Integer	Read only	Indicates if the Gigabit port has a GBIC or miniGBIC port: <ul style="list-style-type: none"> <li>GBIC(1) – GBIC</li> <li>miniGBIC(2) – MiniGBIC</li> <li>empty(3) – GBIC is missing</li> <li>other(4) – Not a removable Gigabit port</li> </ul>
snSwlfLoadInterval fdry.1.1.3.3.5.1.28 Syntax: Integer	Read-write	Shows the number of seconds for which average port utilization should be calculated.  Valid values: 30 – 300, in 30 second increments.  Default: 300 seconds  <b>NOTE:</b> This object is implemented in IronWare Release 07.5.04 and TrafficWorks release 8.x.
snSwlfStatsInFrames fdry.1.1.3.3.5.1.29 Syntax: Counter	Read only	Shows the total number of packets received on the interface.
snSwlfStatsOutFrames fdry.1.1.3.3.5.1.30 Syntax: Counter	Read only	Shows the total number of packets transmitted out of the interface.



Name, OID, and Syntax	Access	Description
snSwlfStatsAlignErrors fdry.1.1.3.3.5.1.31 Syntax: Counter	Read only	Shows the number of dot3StatsAlignmentErrors, which consists of frames received on a particular interface that are not an integral number of octets in length and do not pass the FCS check.  The count represented by an instance of this object is incremented when the alignmentError status is returned by the MAC service to the LLC (or other MAC user). According to the conventions of IEEE 802.3 Layer Management, received frames for which multiple error conditions are obtain are counted exclusively according to the error status presented to the LLC.
snSwlfStatsFCSErrors fdry.1.1.3.3.5.1.32 Syntax: Counter	Read only	Shows the number of dot3StatsFCSErrors, which consists of frames received on a particular interface that are an integral number of octets in length but do not pass the FCS check.  The count represented by an instance of this object is incremented when the frameCheckError status is returned by the MAC service to the LLC (or other MAC user). According to the conventions of IEEE 802.3 Layer Management, received frames for which multiple error conditions are obtain are counted exclusively according to the error status presented to the LLC
snSwlfStatsMultiColliFrames fdry.1.1.3.3.5.1.33 Syntax: Counter	Read only	Shows the number of dot3StatsMultipleCollisionFrames, which consists of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision.  A frame that is counted by an instance of this object is also counted by the corresponding instance of either the ifOutUcastPkts, ifOutMulticastPkts, or ifOutBroadcastPkts and is not counted by the corresponding instance of the dot3StatsSingleCollisionFrames object.
snSwlfStatsTxColliFrames fdry.1.1.3.3.5.1.34 Syntax: Counter	Read only	Shows the number of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision. This count is a combination of the dot3StatsSingleCollisionFrames and dot3StatsMultipleCollisionFrames objects.
snSwlfStatsRxColliFrames fdry.1.1.3.3.5.1.35 Syntax: Counter	Read only	Shows the number of successfully received frames on a particular interface for which transmission is inhibited by more than one collision. This object is not specified in dot3 but it has the same functionality as the object "snSwPortStatsTxColliFrames".
snSwlfStatsFrameTooLongs fdry.1.1.3.3.5.1.36 Syntax: Counter	Read only	Shows the number of dot3StatsFrameTooLongs, which consists of frames received on a particular interface that exceed the maximum permitted frame size.  The count represented by an instance of this object is incremented when the frameTooLong status is returned by the MAC service to the LLC (or other MAC user). According to the conventions of IEEE 802.3 Layer Management, received frames for which multiple error conditions are obtain are, counted exclusively according to the error status presented to the LLC

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snSwlfStatsFrameTooShorts fdry.1.1.3.3.5.1.37 Syntax: Counter	Read only	Shows the number frames received on a particular interface that are below the minimum permitted frame size.
snSwlfStatsInBcastFrames fdry.1.1.3.3.5.1.38 Syntax: Counter	Read-write	Shows the total number of broadcast packets received on the interface.
snSwlfStatsOutBcastFrames fdry.1.1.3.3.5.1.39 Syntax: Counter	Read only	Shows the total number of broadcast packets transmitted out of the interface.
snSwlfStatsInMcastFrames fdry.1.1.3.3.5.1.40 Syntax: Counter	Read only	Shows the total number of multicast packets received on the interface.
snSwlfStatsOutMcastFrames fdry.1.1.3.3.5.1.41 Syntax: Counter	Read only	Shows the total number of multicast packets transmitted out of the interface.
snSwlfStatsInDiscard fdry.1.1.3.3.5.1.42 Syntax: Counter	Read only	Shows the number of inbound packets that will be discarded even though they have no errors. These packets will be discarded to prevent them from being deliverable to a higher-layer protocol. For example, packets may be discarded to free up buffer space.
snSwlfStatsOutDiscard fdry.1.1.3.3.5.1.43 Syntax: Counter	Read only	Shows the number of outbound packets that will be discarded even though they contain no errors. For example, packets may be discarded to free up buffer space.
snSwlfStatsMacStations fdry.1.1.3.3.5.1.44 Syntax: Integer	Read only	Shows the total number of MAC Stations connected to the interface.
snSwlfStatsLinkChange fdry.1.1.3.3.5.1.45 Syntax: Counter	Read only	Shows the total number of link state changes on the interface.
snSwlfInOctets fdry.1.1.3.3.5.1.46 Syntax: Octet string	Read only	Shows the total number of octets received on the interface, including framing characters. This object is a 64-bit counter of the ifInOctets object defined in RFC 1213. The octet string is in big-endian byte order.  This object has eight octets.
snSwlfOutOctets fdry.1.1.3.3.5.1.47 Syntax: Octet string	Read only	Shows the total number of octets transmitted out of the interface, including framing characters. This object is a 64-bit counter of the ifOutOctets object, defined in RFC 1213. The octet string is in big-endian byte order.  This object has eight octets.

Name, OID, and Syntax	Access	Description
snSwlfStatsInBitsPerSec fdry.1.1.3.3.5.1.48 Syntax: Gauge	Read only	Shows the number of bits per second received on the interface over a five-minute interval.
snSwlfStatsOutBitsPerSec fdry.1.1.3.3.5.1.49 Syntax: Gauge	Read only	Shows the number of bits per second transmitted out of the interface over a five-minute interval.
snSwlfStatsInPktsPerSec fdry.1.1.3.3.5.1.50 Syntax: Gauge	Read only	Shows the number of packets per second received on the interface over a five-minute interval.
snSwlfStatsOutPktsPerSec fdry.1.1.3.3.5.1.51 Syntax: Gauge	Read only	Shows the number of packets per second transmitted out of the interface over a five-minute interval.
snSwlfStatsInUtilization fdry.1.1.3.3.5.1.52 Syntax: Integer	Read only	Identifies the input network utilization in hundredths of a percent over a five-minute interval. Valid values: 0 – 10000.
snSwlfStatsOutUtilization fdry.1.1.3.3.5.1.53 Syntax: Integer	Read only	Shows the output network utilization in hundredths of a percent over a five-minute interval. Valid values: 0 – 10000.
<p><b>NOTE:</b> Ethernet devices must allow a minimum idle period between transmission of frames known as interframe gap (IFG) or interpacket gap (IPG). The gap provides a brief recovery time between frames to allow devices to prepare to receive the next frame. The minimum IFG is 96 bit times, which is 9.6 microseconds for 10 Mbps Ethernet, 960 nanoseconds for 100 Mbps Ethernet, and 96 nanoseconds for 1 Gbps Ethernet. In addition, to account for the bit rate on the port, port utilization should also account for the IFG, which normally is filtered by the packet synchronization circuitry.</p> <p>Refer to the etherHistoryUtilization objects in the <i>RFC 1757: Remote Network Monitoring Management Information Base</i> for details.</p>		
snSwlfStatsInKiloBitsPerSec fdry.1.1.3.3.5.1.54 Syntax: Unsigned32	Read-only	Shows the bit rate, in kilobits per second, received on a 10 Gigabit or faster interface within a five minute interval.
snSwlfStatsOutKiloBitsPerSec fdry.1.1.3.3.5.1.55 Syntax: Unsigned32	Read-only	Shows the bit rate, in kilobits per second, transmitted from a 10 Gigabit or faster interface within a five minute interval.

## Interface ID Lookup Table

The Interface ID Lookup Table maps interface ID to the InterfaceIndex (ifIndex) Lookup Table. Given an interface ID, this table returns the ifIndex value. The table is useful for mapping a known interface to the corresponding ifIndex value.

**NOTE:** The contents of the table can only be accessed using Get operations. Unlike other SNMP tables, this table does not support GetNext operations. If you try to walk the table using GetNext, no rows will be returned.

---

Name, OID, and Syntax	Access	Description
snInterfaceLookupTable fdry.1.1.3.3.3	None	The Interface Lookup Table
snInterfaceLookupEntry fdry.1.1.3.3.3.1	None	An entry in the Interface Lookup Table
snInterfaceLookupInterfaceId fdry.1.1.3.3.3.1.1 Syntax: InterfaceId	Read only	<p>Shows the interface ID which consists of the following:</p> <p><b>Octet 0</b> – Port type, which can be one of the following:</p> <ul style="list-style-type: none"> <li>• 1 – Ethernet</li> <li>• 2 – POS</li> <li>• 3 – ATM</li> <li>• 4 – Virtual</li> <li>• 5 – Loopback</li> <li>• 6 – GRE Tunnel</li> <li>• 7 – ATM Subif</li> <li>• 8 – MPLS Tunnel</li> <li>• 9 – ATM PVC</li> </ul> <p><b>Octet 1</b></p> <ul style="list-style-type: none"> <li>• If the value of Octet 0 is 1,2,3,7 or 9, then this octet shows the device's slot number.</li> <li>• If the value of Octet 0 is 6 or 8, then this octet shows the tunnel ID.</li> <li>• If the value of Octet 0 is 5, then this octet shows the loopback ID.</li> <li>• If the value of Octet 0 is 4, then this octet shows a virtual ID.</li> </ul> <p><b>Octet 2</b> – If the value of Octet 0 is 1,2,3,7 or 9, then this octet shows the port number</p> <p><b>Octet 3</b> – If the value of Octet 0 is 7 Or 9, then this octet shows the ATM Subif number)</p> <p><b>Octet 4</b> – If the value of Octet 0 is 9, then this octet shows the ATM VPI number.</p> <p><b>Octet 5</b> – If the value of Octet 0 is 9, then this octet shows the ATM VCI number.</p>
snInterfaceLookupIfIndex fdry.1.1.3.3.3.1.2 Syntax: Integer	Read only	Shows the interface in the ifIndex format.

## Interface Index Lookup Table

The Interface Index Lookup Table maps ifindex values to Interface ID Lookup Table. Given an ifIndex, this table returns the interface ID value.

Name, OID, and Syntax	Access	Description
snIfIndexLookupTable fdry.1.1.3.3.4	None	The IF Index Lookup Table
snIfIndexLookupEntry fdry.1.1.3.3.4.1	None	An entry in the IF Index Lookup Table
snIfIndexLookupIfIndex fdry.1.1.3.3.4.1.1 Syntax: Integer	Read only	Shows the interface in the ifIndex format.
snIfIndexLookupInterfaceId fdry.1.1.3.3.4.1.2 Syntax: InterfaceId	Read only	<p><b>Octet 0</b> – Port type, which can be one of the following:</p> <ul style="list-style-type: none"> <li>• 1 – Ethernet</li> <li>• 2 – POS</li> <li>• 3 – ATM</li> <li>• 4 – Virtual</li> <li>• 5 – Loopback</li> <li>• 6 – GRE Tunnel</li> <li>• 7 – ATM Subif</li> <li>• 8 – MPLS Tunnel</li> <li>• 9 – ATM PVC</li> </ul> <p><b>Octet 1</b></p> <ul style="list-style-type: none"> <li>• If the value of Octet 0 is 1,2,3,7 or 9, then this octet shows the device's slot number.</li> <li>• If the value of Octet 0 is 6 or 8, then this octet shows the tunnel ID.</li> <li>• If the value of Octet 0 is 5, then this octet shows the loopback ID.</li> <li>• If the value of Octet 0 is 4, then this octet shows a virtual ID.</li> </ul> <p><b>Octet 2</b> – If the value of Octet 0 is 1,2,3,7 or 9, then this octet shows the port number</p> <p><b>Octet 3</b> – If the value of Octet 0 is 7 Or 9, then this octet shows the ATM Subif number)</p> <p><b>Octet 4</b> – If the value of Octet 0 is 9, then this octet shows the ATM VPI number.</p> <p><b>Octet 5</b> – If the value of Octet 0 is 9, then this octet shows the ATM VCI number.</p>

## Trunk Port Configuration Group

The Trunk Group feature allows you to manually configure multiple high-speed, load-sharing links between two Foundry switches or routers or between a Foundry switch and router and a server. Details on trunk group configuration are discussed in the *Foundry Switch and Router Installation and Basic Configuration Guide*.

The following objects contain configuration of trunk port memberships and apply to all Foundry devices.

Name, OID, and Syntax	Access	Description
snTrunkTable fdry.1.1.3.6.1	None	The Trunk Port Table. A specific snTrunkTable consists of a number of Trunk port-mask.
snTrunkEntry fdry.1.1.3.6.1.1	None	An entry in the trunk Port Table.
snTrunkIndex fdry.1.1.3.6.1.1.1 Syntax: Integer	Read only	Shows the number of the trunk port entries that can be configured.  Valid values: 1 – 64.
snTrunkPortMask fdry.1.1.3.6.1.1.2 Syntax: PortMask	Read-write	Shows the trunk port membership of the switch.
snTrunkType fdry.1.1.3.6.1.1.3 Syntax: Integer	Read-write	Indicates if the trunk port is connected to a switch or a server: <ul style="list-style-type: none"> <li>• switch(1)</li> <li>• server(2).</li> </ul>

## Multi-Slot Trunk Port Table

The following table applies to multi-slot trunk ports. They show the ports that are members of a trunk group. They apply to all Foundry devices unless otherwise specified in their descriptions.

Name, OID, and Syntax	Access	Description
snMSTrunkTable fdry.1.1.3.6.2	None	The Multi-slot Trunk Port Configuration Table.
snMSTrunkEntry fdry.1.1.3.6.2.1	None	An entry of the Multi-slot Trunk Port Configuration Table.
snMSTrunkPortIndex fdry.1.1.3.6.2.1.1 Syntax: Integer	Read only	Identifies the port that is the primary port of a trunk group.  For module with Gigabit ports, the primary port is port 1, 3, 5, or 7.  For module with 10/100 ports, the primary port is port 1, 5, 9, 13, 17, or 21.

Name, OID, and Syntax	Access	Description
snMSTrunkPortList fdry.1.1.3.6.2.1.2 Syntax: Octet string	Read-write	Contains a list of port indices that are members of a trunk group. Each port index is a 16-bit integer in big endian order. The first port index must be the index of the primary port.
snMSTrunkType fdry.1.1.3.6.2.1.3 Syntax: Integer	Read-write	Specifies if the ports are connected to a switch or a server: <ul style="list-style-type: none"> <li>switch(1)</li> <li>server(2)</li> </ul>
snMSTrunkRowStatus fdry.1.1.3.6.2.1.4 Syntax: Integer	Read-write	Applies to all Foundry devices, except for ServerIron products. Creates, deletes, or modifies an entry in this table: <ul style="list-style-type: none"> <li>invalid(1)</li> <li>valid(2)</li> <li>delete(3)</li> <li>create(4)</li> <li>modify(5)</li> </ul>

## Packet Port Information Table

Foundry's Packet over SONET (POS) is the serial transmission of data over SONET frames through the use of Point-to-Point Protocol (PPP). The Foundry POS modules allow direct connection to interfaces within SONET. POS is a transport technology that encapsulates packet data such as an IP datagram directly into SONET.

The POS modules are available on NetIron Internet Backbone routers and BigIron Layer 3 Switches with redundant management modules.

The following table presents information about POS ports.

Name, OID, and Syntax	Access	Description
snPOSInfoTable fdry.1.2.14.1.1	None	POS Port Information table.
snPOSInfoEntry fdry.1.2.14.1.1.1	None	An entry in the POS Port Information table.
snPOSInfoPortNum fdry.1.2.14.1.1.1.1 Syntax: Integer	Read only	The chassis slot and port number. <ul style="list-style-type: none"> <li>Bit 0 to bit 7 – port number.</li> <li>Bit 8 to bit 11 – slot number (for chassis devices only).</li> </ul>
snPOSIfIndex fdry.1.2.14.1.1.1.2 Syntax: Integer	Read only	Identifies the instance of the ifIndex object as defined in RFC 1213 and RFC 1573.
snPOSDescr fdry.1.2.14.1.1.1.3 Syntax: Display string	Read only	Description of the chassis slot and port.

Name, OID, and Syntax	Access	Description
snPOSName fdry.1.2.14.1.1.1.4 Syntax: Display string	Read- write	Name of the port. Valid values: Up to 255 characters.
snPOSInfoSpeed fdry.1.2.14.1.1.1.5 Syntax: Integer	Read- write	The bandwidth of the interface, which can be one of the following: <ul style="list-style-type: none"> <li>• s155000(1) bps</li> <li>• s622000(2) bps</li> <li>• other(3)</li> <li>• s2488000(4) bps</li> </ul>
snPOSInfoAdminStatus fdry.1.2.14.1.1.1.6 Syntax: Integer	Read- write	The desired state of the interface, which can be one of the following: <ul style="list-style-type: none"> <li>• up(1) – The port is ready to pass packets.</li> <li>• down(2) – The port is not ready to pass packets.</li> <li>• testing(3) – The port is in test mode. No packets can be passed.</li> </ul>
snPOSInfoLinkStatus fdry.1.2.14.1.1.1.7 Syntax: Integer	Read only	The current operational state of the link, which can be one of the following: <ul style="list-style-type: none"> <li>• up(1) – The port is ready to pass packets.</li> <li>• down(2) – The port is not ready to pass packets.</li> <li>• testing(3) – The port is in test mode. No packets can be passed.</li> </ul>
snPOSInfoClock fdry.1.2.14.1.1.1.8 Syntax: Integer	Read- write	The clock source, which can be one of the following: <ul style="list-style-type: none"> <li>• internal(1) – The interface is using the clock on the POS module.</li> <li>• line(2) – The interface is using the clock source supplied on the network.</li> </ul> Default: internal(1)
snPOSInfoLoopBack fdry.1.2.14.1.1.1.9 Syntax: Integer	Read- write	The loopback state of the interface. The loopback state can be one of the following: <ul style="list-style-type: none"> <li>• line(1) – The loopback path consists of both this POS interface and the POS interface at the remote end of the link. Use this mode to check the POS interface along the link.</li> <li>• internal(2) – The loopback path consists only of the POS circuitry on this interface. Use this mode to check the POS circuitry.</li> <li>• none(3) – The interface is not operating in loopback mode.</li> </ul>



Name, OID, and Syntax	Access	Description
snPOSInfoScrambleATM fdry.1.2.14.1.1.1.10 Syntax: Integer	Read-write	The state of the ATM scramble mode, which can be one of the following: <ul style="list-style-type: none"> <li>disabled(0) – Scrambling is disabled.</li> <li>enabled(1) – Scrambling of the Synchronous Payload Envelope (SPE) is enabled. Data in the SONET packet is scrambled for security.</li> </ul> Default: disabled(0)
snPOSInfoFraming fdry.1.2.14.1.1.1.11 Syntax: Integer	Read-write	The frame type used on the interface. The frame type can be one of the following: <ul style="list-style-type: none"> <li>sonet(1) – Synchronous Optical Network.</li> <li>sdh(2) – Synchronous Digital Hierarchy.</li> </ul> Default: sonet(1)
snPOSInfoCRC fdry.1.2.14.1.1.1.12 Syntax: Integer	Read-write	The length of the CRC field in packets transmitted on the interface. The length can be one of the following: <ul style="list-style-type: none"> <li>crc32bits(1) – The field is 8 bits long.</li> <li>crc16bits(2) – The field is 16 bits long.</li> </ul> Default: crc32bits(1)
snPOSInfoKeepAlive fdry.1.2.14.1.1.1.13 Syntax: Integer	Read-write	The time interval when keepalive messages are sent. Default: 10 seconds
snPOSInfoFlagC2 fdry.1.2.14.1.1.1.14 Syntax: Integer	Read-write	The value of the c2 flag in the SONET headers of packets transmitted by the interface. The c2 flag identifies the payload type of the packets transmitted on this interface. Default: 0xcf, which means that the payload is SONET or SDH.
snPOSInfoFlagJ0 fdry.1.2.14.1.1.1.15 Syntax: Integer	Read-write	The value of the j0 flag in the SONET headers of packets transmitted by the interface. This flag sets the trace byte, which is used to trace the origin of an STS-1 frame on a SONET network. Default: 0xcc
snPOSInfoFlagH1 fdry.1.2.14.1.1.1.16 Syntax: Integer	Read-write	The value of the h1 flag in the SONET headers of packets transmitted by the interface. This flag sets the H1 pointer, which is used to indicate where the SPE (Synchronous Payload Envelope) starts within the packet. The SPE contains the packet's payload: <ul style="list-style-type: none"> <li>0x00 – The pointer for SONET frames.</li> <li>0x02 – The pointer for SDH frames.</li> </ul> Default: 0x00
snPOSStatsInFrames fdry.1.2.14.1.1.1.17 Syntax: Counter	Read only	The total number of packets received on the interface.

Name, OID, and Syntax	Access	Description
snPOSStatsOutFrames fdry.1.2.14.1.1.1.18 Syntax: Counter	Read only	The total number of packets transmitted out of the interface.
snPOSStatsAlignErrors fdry.1.2.14.1.1.1.19 Syntax: Counter	Read only	The number of packets that contained frame alignment errors.
snPOSStatsFCSErrors fdry.1.2.14.1.1.1.20 Syntax: Counter	Read only	The number of packets that contained Frame Check Sequence errors.
snPOSStatsFrameTooLongs fdry.1.2.14.1.1.1.21 Syntax: Counter	Read only	The number of packets that were longer than the configured MTU.
snPOSStatsFrameTooShorts fdry.1.2.14.1.1.1.22 Syntax: Counter	Read only	The number of packets that were shorter than the minimum valid length.
snPOSStatsInDiscard fdry.1.2.14.1.1.1.23 Syntax: Counter	Read only	The number of inbound packets that were discarded to prevent them from being delivered to a higher-layer protocol, even though no errors had been detected. For example, a packet may be discarded to free up buffer space.
snPOSStatsOutDiscard fdry.1.2.14.1.1.1.24 Syntax: Counter	Read only	The number of outbound packets that were discarded to prevent them from being transmitted, even though they contain no errors. For example, a packet may be discarded to free up buffer space.
snPOSInOctets fdry.1.2.14.1.1.1.25 Syntax: Octet string	Read only	The total number of packets in octets that were received on the interface, including framing characters.  This object is a 64-bit counter of the ifInOctets object, defined in RFC 1213. The octet string is in big-endian byte order.
snPOSOutOctets fdry.1.2.14.1.1.1.26 Syntax: Octet string	Read only	The total number of packets in octets that were transmitted out of the interface, including framing characters.  This object is a 64-bit counter of the ifOutOctets object, defined in RFC 1213. The octet string is in big-endian byte order.
snPOSStatsInBitsPerSec fdry.1.2.14.1.1.1.27 Syntax: Gauge	Read only	The number of bits per second received on the interface over a five-minute interval.
snPOSStatsOutBitsPerSec fdry.1.2.14.1.1.1.28 Syntax: Gauge	Read only	The number of bits per second transmitted out of the interface over a five-minute interval.

Name, OID, and Syntax	Access	Description
snPOSStatsInPktsPerSec fdry.1.2.14.1.1.1.29 Syntax: Gauge	Read only	The number of packets per second received on the interface over a five-minute interval.
snPOSStatsOutPktsPerSec fdry.1.2.14.1.1.1.30 Syntax: Gauge	Read only	The number of packets per second transmitted out of the interface over a five minute interval.
snPOSStatsInUtilization fdry.1.2.14.1.1.1.31 Syntax: Integer	Read only	The network utilization by incoming traffic in hundredths of a percent over a five-minute interval. <b>NOTE:</b> This object is not supported.
snPOSStatsOutUtilization fdry.1.2.14.1.1.1.32 Syntax: Integer	Read only	The network utilization by outgoing traffic in hundredths of a percent over a five-minute interval. <b>NOTE:</b> This object is not supported.
snPOSTagType fdry.1.2.14.1.1.1.33 Syntax: Integer	Read only	Shows whether or not the port has a VLAN tag: <ul style="list-style-type: none"> <li>tagged(1) – The port has a VLAN tag. This port can have multiple VLANs.</li> <li>untagged(2) – The port is not tagged.</li> </ul>

## POS Alarms and Error Conditions

The following MIB objects belong to the snPOSInfoTable. They allow you to collect errors for POS SONET links. SONET equipment detects alarms and error conditions from the three layers of the SONET protocol: section, line, and path. Other devices on the network are notified of these events. Use the MIB objects below to determine if alarms or error conditions have been reported for POS. The information is also available when you enter the **show controllers pos** CLI command.

Name, OID, and Syntax	Access	Description
snPOSStatsB1 fdry.1.2.14.1.1.1.34 Syntax: Counter	Read only	Shows the number of received frames that have parity errors at the section layer of the SONET link.
snPOSStatsB2 fdry.1.2.14.1.1.1.35 Syntax: Counter	Read only	Shows the number of received frames that have parity errors at the line layer of the SONET link.
snPOSStatsB3 fdry.1.2.14.1.1.1.36 Syntax: Counter	Read only	Shows the number of received frames that have parity errors at the path layer of the SONET link.
snPOSStatsAIS fdry.1.2.14.1.1.1.37 Syntax: Counter	Read only	Shows the number of Alarm Indicator Signals (AIS) that were received by the interface.

Name, OID, and Syntax	Access	Description
snPOSStatsRDI fdry.1.2.14.1.1.1.38 Syntax: Counter	Read only	Shows the number of Remote Defect Indicator (RDI) signals that were received by the interface.
snPOSStatsLOP fdry.1.2.14.1.1.1.39 Syntax: Counter	Read only	Indicates a loss of pointer (LOP) that results from an invalid path pointer or if an excessive number of new data flag have been enabled.
snPOSStatsLOF fdry.1.2.14.1.1.1.40 Syntax: Counter	Read only	Shows how many times the interface experienced out of frame alignment problems, which is also called a loss of frame (LOF) condition.
snPOSStatsLOS fdry.1.2.14.1.1.1.41 Syntax: Counter	Read only	Indicates the number of times the interface experienced a loss of signal (LOS). With LOS, incoming signals are all zeros during a 100 microsecond period.

## Loopback Interface Configuration Table

The following objects apply to all Foundry devices, except ServerIron products.

Name, OID, and Syntax	Access	Description
snLoopbackIntfConfigTable fdry.1.2.13.1	None	The Loopback Interface Configuration table.
snLoopbackIntfConfigEntry fdry.1.2.13.1.1	None	An entry in the Loopback Interface Configuration table.
snLoopbackIntfConfigPortIndex fdry.1.2.13.1.1.1 Syntax: Integer	Read only	Shows the port index for loopback interface configuration entry. There can be up to eight entries in this table.
snLoopbackIntfMode fdry.1.2.13.1.1.2 Syntax: Integer	Read-write	Indicates if loopback interface is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>

---

Name, OID, and Syntax	Access	Description
snLoopbackIntfRowStatus fdry.1.2.13.1.1.3 Syntax: Integer	Read- write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"><li>• delete(3) – Delete the row</li><li>• create(4) – Create a new row</li><li>• modify(5) – Modify an existing row</li></ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"><li>• noSuch(0) – No such row</li><li>• invalid(1) – Row is inoperative</li><li>• valid(2) – Row exists and is valid</li></ul>

---

## Port STP Configuration Groups

The Spanning Tree Protocol (STP) eliminates Layer 2 loops in networks, by selectively blocking some ports and allowing other ports to forward traffic, based on global (bridge) and local (port) parameters you can configure.

The tables in this section contain information about the ports on which STP is enabled.

### Port STP Configuration Groups (snPortStpTable)

This table applies to all Foundry devices, except the FastIron X-Series devices, BigIron MG8, and NetIron 40G. These devices use the snIfStpTable. Refer to the “Port STP Configuration Group (snIfStpTable)” on page 7-37

Name, OID, and Syntax	Access	Description
snPortStpTable fdry.1.1.3.5.1	None	A specific snPortStpTable consists of a number of switch ports. This table only exists if “snVlanByPortTable” on page 11-1 exists and “snVlanByPortStpMode” on page 11-2 is enabled for each VLAN.
snPortStpEntry fdry.1.1.3.5.1.1	None	An entry in this table shows information about the configuration of a specified port.  An SNMP SET PDU for a row in this table requires the entire sequence of the MIB objects in each snPortStpEntry to be stored in one PDU. Otherwise, GENERR return-value will be returned.
snPortStpVlanId fdry.1.1.3.5.1.1.1 Syntax: Integer	Read only	Shows the VLAN ID of the VLAN switch community.  Valid values: 1 – 65535.
snPortStpPortNum fdry.1.1.3.5.1.1.2 Syntax: Integer	Read only	Shows the port number of the Switch: <ul style="list-style-type: none"> <li>• Bit 0 to bit 7 – Port number.</li> <li>• Bit 8 to bit 11 – Slot number (slot for chassis only).</li> </ul>
snPortStpPortPriority fdry.1.1.3.5.1.1.3 Syntax: Integer	Read-write	Shows the value of the priority field, which is contained in the first (in network byte order) octet of the Port ID. The second octet of the Port ID is given by the value of dot1dStpPort. The two octets combine to form the identity of the root bridge in a spanning tree (instance of STP). The bridge with the lowest value has the highest priority and is the root.  Valid values: 8 – 255

Name, OID, and Syntax	Access	Description
snPortStpPathCost fdry.1.1.3.5.1.1.4 Syntax: Integer	Read-write	<p>Shows the value of the dot1dStpPortPathCost, which is the port's path cost to reach the root bridge. When selecting among multiple links to the root bridge, STP chooses the link with the lowest path cost and blocks the other paths.</p> <p>IEEE 802.1D-1990 recommends that the default value of this parameter be in inverse proportion to the speed of the attached LAN.</p> <p>Writing a value of zero to this object sets the path cost to a default value which automatically changes according to port speed.</p> <p>Reading a value of zero indicates an unknown path cost because the port speed cannot be determined due to the speed auto sense that is currently in progress.</p> <p>Each port type has its own default STP path cost.</p> <ul style="list-style-type: none"> <li>• 10 Mbps – 100</li> <li>• 100 Mbps – 19</li> <li>• Gigabit – 4</li> </ul> <p>Valid values: 0 – 65535</p>
snPortStpOperState fdry.1.1.3.5.1.1.5 Syntax: Integer	Read only	<p>Indicates if the port STP entry is activated and is in running mode.</p> <ul style="list-style-type: none"> <li>• notActivated(0)</li> <li>• activated(1)</li> </ul> <p>Default: notActivated(0)</p>
snPortStpPortEnable fdry.1.1.3.5.1.1.6 Syntax: Integer	None	<p>Indicates whether or not the port is enabled:</p> <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snPortStpPortForwardTransitions fdry.1.1.3.5.1.1.7 Syntax: Integer	None	<p>Shows the number of times this port has transitional from the Learning state to the Forwarding state.</p>

Name, OID, and Syntax	Access	Description
snPortStpPortState fdry.1.1.3.5.1.1.8 Syntax: Integer	Read only	<p>Shows the port's current state as defined by application of the Spanning Tree Protocol. This state controls what action a port takes when it receives a frame.</p> <ul style="list-style-type: none"> <li>• disabled(1) – The port is not participating in STP. This can occur when the port is disconnected or STP is disabled on the port.</li> <li>• blocking(2) – STP has blocked Layer 2 traffic on this port to prevent a loop. The device or VLAN can reach the root bridge using another port, whose state is forwarding(5). When a port is in this state, the port does not transmit or receive user frames, but the port does continue to receive STP BPDUs.</li> <li>• listening(3) – STP is responding to a topology change and this port is listening for a BPDU from neighboring bridge(s) in order to determine the new topology. No user frames are transmitted or received during this state.</li> <li>• learning(4) – The port has passed the listening state and will change to the blocking or forwarding state, depending on the results of STP's reconvergence. The port does not transmit or receive user frames during this state. However, the device can learn the MAC addresses of frames that the port receives during this state and make corresponding entries in the MAC table.</li> <li>• forwarding(5) – STP is allowing the port to send and receive frames.</li> <li>• broken(6) – Ports that are malfunctioning are placed into this state by the bridge.</li> </ul>
snPortStpPortDesignatedCost fdry.1.1.3.5.1.1.9 Syntax: Integer	Read only	<p>The cost to the root bridge as advertised by the designated bridge that is connected to this port. If the designated bridge is the root bridge itself, then the cost is 0. The identity of the designated bridge is shown in the Design Bridge field.</p> <p>This value is compared to the Root Path Cost field in the receivedbridge PDUs.</p>
snPortStpPortDesignatedRoot fdry.1.1.3.5.1.1.10 Syntax: Bridgeld	Read only	<p>The root bridge as recognized on this port. The value is the same as the root bridge ID listed in the Root ID field.</p> <p>Shows the unique ID of the root bridge. The root bridge is recorded as the root in the configuration BPDUs, which are transmitted by the designated bridge for the segment to which the port is attached.</p>
snPortStpPortDesignatedBridge fdry.1.1.3.5.1.1.11 Syntax: Bridgeld	Read only	<p>Shows the ID of the designated bridge. The designated bridge is the device that connects the network segment to the root bridge.</p>
snPortStpPortDesignatedPort fdry.1.1.3.5.1.1.12 Syntax: Octet string	Read only	<p>Shows the ID of the port on the designated bridge that connects to the root bridge on the network.</p> <p>This object has two octets.</p>



## Port STP Configuration Group (snIfStpTable)

The snIfStpTable contains information about ports where STP is enabled on FastIron X-Series devices, BigIron MG8, and NetIron 40G. Other Foundry devices use the snPortStpTable (refer to “Port STP Configuration Groups (snPortStpTable)” on page 7-34).

Name, OID, and Syntax	Access	Description
snIfStpTable fdry.1.1.3.5.2	None	A specific snIfStpTable consists of a number of switch ports. This table only exists if “snVlanByPortTable” on page 11-1 exists and “snVlanByPortStpMode” on page 11-2 is enabled for each VLAN.
snIfStpEntry fdry.1.1.3.5.2.1	None	An entry in this table shows information about the configuration of a specified port.  An SNMP SET PDU for a row in this table requires the entire sequence of the MIB objects in each snIfStpEntry to be stored in one PDU. Otherwise, GENERR return-value will be returned.
snIfStpVlanId fdry.1.1.3.5.2.1.1 Syntax: Integer	Read only	Shows the VLAN ID of the VLAN switch community.  Valid values: 1 – 65535.
snIfStpPortNum fdry.1.1.3.5.2.1.2 Syntax: Integer	Read only	Shows the port number of the Switch: <ul style="list-style-type: none"> <li>• Bit 0 to bit 7 – Port number.</li> <li>• Bit 8 to bit 11 – Slot number (slot for chassis only).</li> </ul>
snIfStpPortPriority fdry.1.1.3.5.2.1.3 Syntax: Integer	Read-write	Shows the value of the priority field, which is contained in the first (in network byte order) octet of the Port ID. The second octet of the Port ID is given by the value of dot1dStpPort. The two octets combine to form the identity of the root bridge in a spanning tree (instance of STP or RSTP). The bridge with the lowest value has the highest priority and is the root.  Valid values: 8 – 255

Name, OID, and Syntax	Access	Description
<p>snIfStpPathCost fdry.1.1.3.5.2.1.4 Syntax: Integer</p>	<p>Read- write</p>	<p>Shows the value of the dot1dStpPortPathCost, which is the port's path cost to reach the root bridge. When selecting among multiple links to the root bridge, STP or RSTP chooses the link with the lowest path cost and blocks the other paths.</p> <p>IEEE 802.1D-1990 recommends that the default value of this parameter be in inverse proportion to the speed of the attached LAN.</p> <p>Writing a value of zero to this object sets the path cost to a default value which automatically changes according to port speed.</p> <p>Reading a value of zero indicates an unknown path cost because the port speed cannot be determined due to the speed auto sense that is currently in progress.</p> <p>Each port type has its own default STP path cost.</p> <ul style="list-style-type: none"> <li>• 10 Mbps – 100</li> <li>• 100 Mbps – 19</li> <li>• Gigabit – 4</li> </ul> <p>Valid values: 0 – 65535</p>
<p>snIfStpCfgPathCost fdry.1.1.3.5.2.1.4 Syntax: Integer</p>	<p>Read- write</p>	<p>This MIB object replaces the MIB object snIfStpPathCost.</p> <p>Shows the value of the dot1dStpPortPathCost, which is the port's path cost to reach the root bridge. When selecting among multiple links to the root bridge, STP or RSTP chooses the link with the lowest path cost and blocks the other paths.</p> <p>IEEE 802.1D-1990 recommends that the default value of this parameter be in inverse proportion to the speed of the attached LAN.</p> <p>Writing a value of zero to this object sets the path cost to a default value which automatically changes according to port speed.</p> <p>Reading a value of zero indicates an unknown path cost because the port speed cannot be determined due to the speed auto sense that is currently in progress.</p> <p>Each port type has its own default STP or RSTP path cost.</p> <ul style="list-style-type: none"> <li>• 10 Mbps – 100</li> <li>• 100 Mbps – 19</li> <li>• Gigabit – 4</li> </ul> <p>Valid values: 0 – 65535</p>
<p>snIfStpOperState fdry.1.1.3.5.2.1.5 Syntax: Integer</p>	<p>Read only</p>	<p>Indicates if the port STP entry is activated and is in running mode.</p> <ul style="list-style-type: none"> <li>• notActivated(0)</li> <li>• activated(1)</li> </ul> <p>Default: notActivated(0)</p>

Name, OID, and Syntax	Access	Description
snIfStpPortState fdry.1.1.3.5.2.1.8 Syntax: Integer	Read only	<p>Shows the port's current state as defined by application of the Spanning Tree Protocol. This state controls what action a port takes when it receives a frame.</p> <ul style="list-style-type: none"> <li>disabled(1) – The port is not participating in STP. This can occur when the port is disconnected or STP is disabled on the port.</li> <li>blocking(2) – STP has blocked Layer 2 traffic on this port to prevent a loop. The device or VLAN can reach the root bridge using another port, whose state is forwarding(5). When a port is in this state, the port does not transmit or receive user frames, but the port does continue to receive STP BPDUs.</li> <li>listening(3) – STP is responding to a topology change and this port is listening for a BPDU from neighboring bridge(s) in order to determine the new topology. No user frames are transmitted or received during this state.</li> <li>learning(4) – The port has passed the listening state and will change to the blocking or forwarding state, depending on the results of STP's reconvergence. The port does not transmit or receive user frames during this state. However, the device can learn the MAC addresses of frames that the port receives during this state and make corresponding entries in the MAC table.</li> <li>forwarding(5) – STP is allowing the port to send and receive frames.</li> <li>broken(6) – Ports that are malfunctioning are placed into this state by the bridge.</li> <li>preforwarding(7) – The port is in an RSTP pre-forwarding mode.</li> </ul>
snIfStpPortDesignatedCost fdry.1.1.3.5.2.1.9 Syntax: Integer	Read only	<p>The cost to the root bridge as advertised by the designated bridge that is connected to this port. If the designated bridge is the root bridge itself, then the cost is 0. The identity of the designated bridge is shown in the Design Bridge field.</p> <p>This value is compared to the Root Path Cost field in the receivedbridge PDUs.</p>
snIfStpPortDesignatedRoot fdry.1.1.3.5.2.1.10 Syntax: Bridgeld	Read only	<p>The root bridge as recognized on this port. The value is the same as the root bridge ID listed in the Root ID field.</p> <p>Shows the unique ID of the root bridge. The root bridge is recorded as the root in the configuration BPDUs, which are transmitted by the designated bridge for the segment to which the port is attached.</p>
snIfStpPortDesignatedBridge fdry.1.1.3.5.2.1.11 Syntax: Bridgeld	Read only	<p>Shows the ID of the designated bridge. The designated bridge is the device that connects the network segment to the root bridge.</p>

Name, OID, and Syntax	Access	Description
snIfStpPortDesignatedPort fdry.1.1.3.5.2.1.12 Syntax: Octet string	Read only	Shows the ID of the port on the designated bridge that connects to the root bridge on the network.  This object has two octets.
snIfStpPortAdminRstp fdry.1.1.3.5.2.1.13 Syntax: Integer	Read-write	Enables or disables RSTP on a port that is a member of a VLAN: <ul style="list-style-type: none"> <li>true(1) – RSTP is enabled</li> <li>false(2) – RSTP is not enabled; therefore, this object is not writable.</li> </ul>
snIfStpPortProtocolMigration fdry.1.1.3.5.2.1.14 Syntax: Integer	Read-write	This value can be one of the following: <ul style="list-style-type: none"> <li>true(1) – The port is operating in RSTP version 2 mode. It will transmit RSTP BPDUs.</li> <li>false(2) – The port is not operating in RSTP version 2 mode.</li> </ul>
snIfStpPortAdminEdgePort fdry.1.1.3.5.2.1.15 Syntax: Integer	Read-write	Indicates if the port is an edge or non-edge port: <ul style="list-style-type: none"> <li>true(1) – Assumed this port is an edge-port</li> <li>false(2) – Assume this port is a non-edge-port</li> </ul>
snIfStpPortAdminPointToPoint fdry.1.1.3.5.2.1.16 Syntax: Integer	Read-write	Indicates the administrative point-to-point status of the LAN segment attached to this port. <ul style="list-style-type: none"> <li>true(1) – This port should always be treated as if it is connected to a point-to-point link.</li> <li>false(2) – This port should be treated as having a shared media connection.</li> </ul>

## Port Monitor Table

The Port Monitor Table shows the status of port monitoring on an interface.

Name, OID, and Syntax	Access	Description
snPortMonitorTable fdry.1.1.3.25.1.	N/A	The Port Monitor Table
snPortMonitorEntry fdry.1.1.3.25.1.1.	N/A	An entry in the Port Monitor Table
snPortMonitorIfIndex fdry.1.1.3.25.1.1.1	N/A	ID of the port in the table

---

Name, OID, and Syntax	Access	Description
snPortMonitorMirrorList fdry.1.1.3.25.1.1.2 Syntax: Display string	Read-write	Lists the monitoring status of each port.  The values in this object are space delimited. They consist of a sequence of a port's ifIndex followed by the port's monitoring mode. Port monitoring mode can be one of the following: <ul style="list-style-type: none"><li>• 0 – Monitoring is off</li><li>• 1 – The port will monitor input traffic</li><li>• 2 – The port will monitor output traffic</li><li>• 3 – The port will monitor both input and output traffic</li></ul> For example, you may see the following values:  65 2 66 1  "65" may represent port 2/1 and "66" port 2/2.  The entry means that port 2/1 is monitoring output traffic. Port 2/2 will monitor input traffic.

---



---

# Chapter 8

## Filtering Traffic

The objects in this chapter present filters that can be used to control incoming or outgoing traffic. They include the following:

- “MAC Filters” on page 8-1
- “ACLs” on page 8-7

Refer to the *Foundry Switch and Router Installation and Basic Configuration Guide* for details on the features discussed in this chapter.

### MAC Filters

MAC layer filtering enables you to build access lists based on MAC layer headers in the Ethernet/IEEE 802.3 frame. You can filter on the source and destination MAC addresses as well as other information such as the EtherType, LLC1 DSAP or SSAP numbers, and a SNAP EtherType. The filters apply to incoming traffic only.

For more information on MAC Layer filtering, refer to the *Foundry Switch and Router Installation and Basic Configuration Guide* and the *Foundry Enterprise Configuration and Management Guide*.

Objects available for MAC filtering are presented in the following sections:

- “MAC Filter Table” on page 8-2
- “MAC Filter Port Access Tables” on page 8-3
- “Forwarding Database Static Table Information” on page 8-4

## MAC Filter Table

The objects in this table provide information on MAC filters. They apply to all Foundry devices

Name, OID, and Syntax	Access	Description
snMacFilterTable fdry.1.1.3.10.1	None	The MAC filter table.
snMacFilterEntry fdry.1.1.3.10.1.1	None	An entry in the MAC filter table.
snMacFilterIndex fdry.1.1.3.10.1.1.1 Syntax: Integer	Read only	The table index for a filter entry.
snMacFilterAction fdry.1.1.3.10.1.1.2 Syntax: Integer	Read-write	Indicates what action is to be taken if the MAC packet matches this filter: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snMacFilterSourceMac fdry.1.1.3.10.1.1.3 Syntax: MAC address	Read-write	Shows the source MAC address.
snMacFilterSourceMask fdry.1.1.3.10.1.1.4 Syntax: MAC address	Read-write	Shows the source MAC subnet mask.
snMacFilterDestMac fdry.1.1.3.10.1.1.5 Syntax: MAC address	Read-write	Shows the destination MAC address.
snMacFilterDestMask fdry.1.1.3.10.1.1.6 Syntax: MAC address	Read-write	Shows the destination MAC subnet mask.
snMacFilterOperator fdry.1.1.3.10.1.1.7 Syntax: Integer	Read-write	Indicates the type of comparison to perform: <ul style="list-style-type: none"> <li>equal(0)</li> <li>notEqual(1)</li> <li>less(2)</li> <li>greater(3)</li> </ul>



Name, OID, and Syntax	Access	Description
snMacFilterFrameType fdry.1.1.3.10.1.1.8 Syntax: Integer	Read-write	Indicates the frame type: <ul style="list-style-type: none"> <li>notUsed(0)</li> <li>ethernet(1)</li> <li>LLC(2)</li> <li>snap(3)</li> </ul>
snMacFilterFrameTypeNum fdry.1.1.3.10.1.1.9 Syntax: Integer	Read-write	Shows the frame type number. Valid values: 0 – 65535, where 0 means that this object is not applicable.
snMacFilterRowStatus fdry.1.1.3.10.1.1.10 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## MAC Filter Port Access Tables

The tables show information about the MAC Filter Port Access.

Name, OID, and Syntax	Access	Description
snMacFilterPortAccessTable fdry.1.1.3.10.2	None	MAC Filter Port Access table.
snMacFilterPortAccessEntry fdry.1.1.3.10.2.1	None	An entry in the MAC Filter Port Access Table.

Name, OID, and Syntax	Access	Description
snMacFilterPortAccessPortIndex fdry.1.1.3.10.2.1.1 Syntax: Integer	Read only	<p>The port index.</p> <p>For FastIron and NetIron products, port index value is from 1 – 42.</p> <p>For BigIron products, port index is an encoded number:</p> <ul style="list-style-type: none"> <li>• Bit 0 to bit 7– Port number</li> <li>• Bit 8 to bit 11 – Slot number</li> </ul> <p>For virtual router interfaces:</p> <ul style="list-style-type: none"> <li>• 15 – Slot number</li> <li>• 1 to 60 – Virtual router port, which is the port number.</li> </ul> <p>Therefore, port index value for BigIron is from 257 to 3900.</p>
snMacFilterPortAccessFilters fdry.1.1.3.10.2.1.2 Syntax: Octet string	Read-write	<p>Shows the filter numbers of the ports. The first octet correspond to the first filter number, the second octet, to the second filter number, and so on.</p>
snMacFilterPortAccessRowStatus fdry.1.1.3.10.2.1.3 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>• delete(3) – Delete the row</li> <li>• create(4) – Create a new row</li> <li>• modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row</li> <li>• invalid(1) – Row is inoperative</li> <li>• valid(2) – Row exists and is valid</li> </ul>

### Forwarding Database Static Table Information

This table contains Forwarding Database information for each station known to the system. There is one entry per station. This table applies to all Foundry devices.

Name, OID, and Syntax	Access	Description
snFdbTable fdry.1.1.3.4.1	None	The Forwarding Database Static Table.
snFdbEntry fdry.1.1.3.4.1.1	None	Each entry represents the information of a static MAC station.

Name, OID, and Syntax	Access	Description
snFdbStationIndex fdry.1.1.3.4.1.1.1 Syntax: Integer	Read only	Shows the FDB Station index to the Fdb Station Table.
snFdbStationAddr fdry.1.1.3.4.1.1.2 Syntax: Integer	Read-write	Shows the snFdb's physical address. The physical address represents a MAC Station.
snFdbStationPort fdry.1.1.3.4.1.1.3 Syntax: Integer	Read-write	Indicates the station slot/port number: <ul style="list-style-type: none"> <li>• Bit 0 to bit 7 – Port number</li> <li>• Bit 8 to bit 11 – Slot number (slot for chassis only).</li> </ul>
snFdbVlanId fdry.1.1.3.4.1.1.4 Syntax: Integer	Read-write	Indicates the Station VLAN ID.
snFdbStationQos fdry.1.1.3.4.1.1.5 Syntax: Integer	Read-write	Shows the quality of service values for the station: For stackable stations, the values can be: <ul style="list-style-type: none"> <li>• low(0) – low priority</li> <li>• high(1) – high priority.</li> </ul> For chassis stations, the values can be <ul style="list-style-type: none"> <li>• level0(0)</li> <li>• level1(1)</li> <li>• level2(2)</li> <li>• level3(3)</li> <li>• level4(4)</li> <li>• level5(5)</li> <li>• level6(6)</li> <li>• level7(7)</li> </ul>
snFdbStationType fdry.1.1.3.4.1.1.6 Syntax: Integer	Read-write	Show the station type: <ul style="list-style-type: none"> <li>• notSupported(0) – a read value only: this product does not support multilayer Switching.</li> <li>• host(1) – any MAC station.</li> <li>• router(2) – a router-typed station.</li> </ul>

Name, OID, and Syntax	Access	Description
snFdbRowStatus fdry.1.1.3.4.1.1.7 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snFdbStationIfIndex fdry.1.1.3.4.1.1.8 Syntax: InterfaceIndex	Read-write	Station interface index number.

## MAC Port Security Table

The MAC Port Security table shows the same information as the **show port security mac** CLI command.

Name, Identifier, and Syntax	Access	Description
snPortMacSecurityTable fdry.1.1.3.24.1.1.1	N/A	The MAC Port Security table.
snPortMacSecurityEntry fdry.1.1.3.24.1.1.1.1	N/A	An entry in the MAC Port Security table.
snPortMacSecurityIfIndex fdry.1.1.3.24.1.1.1.1.1 Syntax: Unsigned32	Read only	The ifIndex value (ID) of the Ethernet interface on which MAC port security is enabled.
snPortMacSecurityResource fdry.1.1.3.24.1.1.1.1.2 Syntax: Integer	Read only	<p>Indicates how the MAC addresses on an interface are secured:</p> <p>local(1) – Local resource was used. The interface secures at least one secure MAC address entry. Each interface can store up to 64 local resources.</p> <p>shared(2) – Shared resource was used. When an interface has secured enough MAC addresses to reach its limit for local resources, it can secure additional MAC addresses by using global or shared resources.</p>

snPortMacSecurityQueryIndex fdry.1.1.3.24.1.1.1.1.3 Syntax: Unsigned32	Read only	An index for a MAC address entry that was secured for this interface.
snPortMacSecurityMAC fdry.1.1.3.24.1.1.1.1.4 Syntax: Integer	Read only	The secured MAC address.
snPortMacSecurityAgeLeft fdry.1.1.3.24.1.1.1.1.5 Syntax: Unsigned32	Read only	The number of minutes the MAC address will remain secure.
snPortMacSecurityShutdownStatus fdry.1.1.3.24.1.1.1.1.6 Syntax: Integer	Read only	Indicates if the interface has been shut down due to a security violation. <ul style="list-style-type: none"> <li>up(1) – The port is up.</li> <li>down(2) – The port has been shut down.</li> </ul>
snPortMacSecurityShutdownTimeLeft fdry.1.1.3.24.1.1.1.1.7 Syntax: Unsigned32	Read only	If the value of the snPortMacSecurityShutdownStatus is down(2), this object shows the number of seconds before it is enabled again. If the value is up(1), this object shows 0.
snPortMacSecurityVlanId fdry.1.1.3.24.1.1.1.1.8 Syntax: Unsigned32	Read only	Shows the VLAN membership of this interface. This object shows a value from 1 – 65535.

## ACLs

Access Control Lists (ACL) can be used to permit or deny packets from entering or leaving a Foundry device. For additional information on ACLs in Foundry devices, refer to the *Foundry Enterprise Configuration and Management Guide*.

This chapter contains the following sections:

- “Global ACL” on page 8-7
- “ACL Table” on page 8-8
- “ACL Bind to Port Table (snAgAcIBindToPortTable)” on page 8-15

### Global ACL

The following objects are global to ACLs.

Name, OID, and Syntax	Access	Description
snAgAcIGblCurRowIndex fdry.1.2.2.15.1.1 Syntax: Integer	Read only	Shows the number of entries in the ACL table.

## ACL Table

The ACL Table contains the ACLs defined for the device. The snAgAclGblCurRowIndex object determines the number of ACLs that can be added to this table.

Use this table to create ACLs. Apply the ACLs to interfaces using the snAgAclBindToPortTable.

---

**NOTE:** BigIron MG8 and NetIron 40G use the snAgAclIfBindTable (refer to “ACL Port Table (snAgAclIfBindTable)” on page 8-17).

---

Name, OID, and Syntax	Access	Description
snAgAclTable fdry.1.2.2.15.2	None	Access Control List Table
snAgAclEntry fdry.1.2.2.15.2.1	None	An entry in the Access Control List Table
snAgAclIndex fdry.1.2.2.15.2.1.1 Syntax: Integer	Read only	Shows the index for an ACL entry that is associated with this ACL.  This number must be unique among all the entries, even though the value of other objects for an entry maybe the same those of another entry.
snAgAclNumber fdry.1.2.2.15.2.1.2 Syntax: AclNumber	Read-write	The access control list number for an entry: <ul style="list-style-type: none"> <li>1 to 99 – Standard access list</li> <li>100 to 199 – Extended access list</li> </ul>
snAgAclName fdry.1.2.2.15.2.1.3 Syntax: Display string	Read-write	Shows the ACL name.
snAgAclAction fdry.1.2.2.15.2.1.4 Syntax: Integer	Read-write	Indicates if IP packets that matched this access control list are permitted or denied: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul> <p>The default action when no ACLs are configured on a device is to permit all traffic. However, once you configure an ACL and apply it to a port, the default action for that port is to deny all traffic that is not explicitly permitted on the port. Therefore:</p> <ul style="list-style-type: none"> <li>If you want to tightly control access, configure ACLs consisting of permit entries for the access you want to permit. The ACLs implicitly deny all other access.</li> <li>If you want to secure access in environments with many users, you might want to configure ACLs that consist of explicit deny entries, then add an entry to permit all access to the end of each ACL. The software permits packets that are not denied by the deny entries.</li> </ul>

Name, OID, and Syntax	Access	Description
snAgAclProtocol fdry.1.2.2.15.2.1.5 Syntax: IPProtocol	Read-write	<p>Indicates the protocol denied or permitted by the extended ACL.</p> <p>The IP protocol can be one of the following well-known names or any IP protocol number from 0 to 255:</p> <ul style="list-style-type: none"> <li>• Internet Control Message Protocol (ICMP)</li> <li>• Internet Group Management Protocol (IGMP)</li> <li>• Internet Gateway Routing Protocol (IGRP)</li> <li>• Internet Protocol (IP)</li> <li>• Open Shortest Path First (OSPF)</li> <li>• Transmission Control Protocol (TCP)</li> <li>• User Datagram Protocol (UDP)</li> </ul> <p>Entering "0" indicates any protocol.</p>
snAgAclSourceIp fdry.1.2.2.15.2.1.6 Syntax: IpAddress	Read-write	<p>Applies only to extended ACLs.</p> <p>Identifies the source IP address of the packet that will either be permitted or denied.</p>
snAgAclSourceMask fdry.1.2.2.15.2.1.7 Syntax: IpAddress	Read-write	<p>Applies only to extended ACLs.</p> <p>Identifies the source IP subnet mask of the packet that will either be permitted or denied.</p>
snAgAclSourceOperator fdry.1.2.2.15.2.1.8 Syntax: Operator	Read-write	<p>Applies only to TCP or UDP ports in extended ACLs.</p> <p>Indicates how the policy will be compared to the ports specified in the "snAgAclSourceOperand1" and "snAgAclSourceOperand2" objects:</p> <ul style="list-style-type: none"> <li>• eq(0) – The policy applies only to packets whose source port number matches the port number specified in the objects.</li> <li>• neq(1) – The policy applies only to packets whose source port numbers are not included in the specified range.</li> <li>• lt(2) – The policy applies only to packets whose source port numbers are less than those in the specified range.</li> <li>• gt(3) – The policy applies only to packets whose source port numbers are greater than those in the specified range.</li> <li>• range(4) – The policy applies to packets whose source port numbers fall within the specified range.</li> <li>• undefined(7)</li> </ul>
snAgAclSourceOperand1 fdry.1.2.2.15.2.1.9 Syntax: Integer	Read-write	<p>Applies only to TCP or UDP ports in extended ACLs.</p> <p>Shows the source port number to be matched. If used with the "snAgAclSourceOperand2" object, it defines the start of the range of source port numbers to be matched.</p> <p>Valid values: 0 – 65535. A value of 0 means that this object is not applicable.</p>

Name, OID, and Syntax	Access	Description
<p>snAgAclSourceOperand2 fdry.1.2.2.15.2.1.10 Syntax: Integer</p>	<p>Read- write</p>	<p>Applies only to TCP or UDP ports in extended ACLs.</p> <p>Used with the “snAgAclSourceOperand1” object, it defines the end of the range of source port numbers to be matched.</p> <p>Valid values: 0 – 65535. A value of 0 means that this object is not applicable.</p> <p>On devices running Enterprise IronWare Release 07.8.00 and later, this object filters traffic containing ICMP packets based on the type number and the code number of the ICMP packets. Use this object to identify the ICMP message type number. Make sure you indicate a code number in the “snAgAclIcmpCode” object.</p> <p>Valid values for ICMP type number are:</p> <ul style="list-style-type: none"> <li>• 0 = not applicable</li> <li>• 1 = Echo reply</li> <li>• 4 = Destination unreachable</li> <li>• 5 = Source quench</li> <li>• 6 = Redirect</li> <li>• 9 = Echo request</li> <li>• 10 = Router advertisement</li> <li>• 11 = Router solicitation</li> <li>• 12 = Time exceeded</li> <li>• 13 = Parameter problem</li> <li>• 14 = Timestamp request</li> <li>• 15 = Timestamp reply</li> <li>• 16 = Information request</li> <li>• 17 = Information reply</li> <li>• 18 = Address mask request</li> <li>• 19 = Address mask reply</li> </ul>
<p>snAgAclDestinationIp fdry.1.2.2.15.2.1.11 Syntax: IpAddress</p>	<p>Read- write</p>	<p>Applies only to extended ACLs.</p> <p>Identifies the destination IP address of the packet that will either be permitted or denied.</p>
<p>snAgAclDestinationMask fdry.1.2.2.15.2.1.12 Syntax: IpAddress</p>	<p>Read- write</p>	<p>Applies only to extended ACLs.</p> <p>Identifies the destination subnet mask of the packet that will either be permitted or denied.</p>



Name, OID, and Syntax	Access	Description
snAgAclDestinationOperator fdry.1.2.2.15.2.1.13 Syntax: Operator	Read-write	Applies only to TCP or UDP ports in extended ACLs. Indicates how the policy will be compared to the ports specified in the “snAgAclDestinationOperand1” and “snAgAclDestinationOperand2” objects: <ul style="list-style-type: none"> <li>• eq(0) – The policy applies only to packets whose destination port number matches the port number specified in the objects.</li> <li>• neq(1) – The policy applies only to packets whose destination port numbers are not included in the specified range.</li> <li>• lt(2) – The policy applies only to packets whose destination port numbers are less than those in the specified range.</li> <li>• gt(3) – The policy applies only to packets whose destination port numbers are greater than those in the specified range.</li> <li>• range(4) – The policy applies to packets whose destination port numbers fall within the specified range.</li> <li>• undefined(7).</li> </ul>
snAgAclDestinationOperand1 fdry.1.2.2.15.2.1.14 Syntax: Integer	Read-write	Applies only to TCP or UDP ports in extended ACLs. Shows the destination port number to be matched. If used with the “snAgAclDestinationOperand2” object, it defines the start of the range of destination port numbers to be matched. Valid values: 0 – 65535. A value of 0 means that this object is not applicable.
snAgAclDestinationOperand2 fdry.1.2.2.15.2.1.15 Syntax: Integer	Read-write	Applies only to TCP or UDP ports in extended ACLs. Used with the “snAgAclDestinationOperand1” object, it defines the end of the range of destination port numbers to be matched. Valid values: 0 – 65535. A value of 0 means that this object is not applicable.
snAgAclPrecedence fdry.1.2.2.15.2.1.16 Syntax: PrecedenceValue	Read-write	Applies only to extended ACLs. Indicates the IP precedence value that a packet must have to be permitted or denied. <ul style="list-style-type: none"> <li>• routine(0)</li> <li>• priority(1)</li> <li>• immediate(2)</li> <li>• flash(3)</li> <li>• flash-override(4)</li> <li>• critical(5)</li> <li>• internet(6)</li> <li>• network(7)</li> </ul> The following priorities specify a hardware forwarding queue: routine(0), priority(1), immediate(2), flash(3)

Name, OID, and Syntax	Access	Description
snAgAclTos fdry.1.2.2.15.2.1.17 Syntax: TosValue	Read- write	Applies only to extended ACLs. Indicates the type of service a packet must have to be denied or permitted: <ul style="list-style-type: none"> <li>• normal(0) – The ACL matches packets that have the normal TOS. If TOS is not defined, packets are matched to this value.</li> <li>• minMonetaryCost(1) – The ACL matches packets that have the minimum monetary cost TOS.</li> <li>• maxReliability(2) – The ACL matches packets that have the maximum reliability TOS.</li> <li>• maxThroughput(4) – The ACL matches packets that have the maximum throughput TOS.</li> <li>• minDelay(8) – The ACL matches packets that have the minimum delay TOS.</li> </ul>
snAgAclEstablished fdry.1.2.2.15.2.1.18 Syntax: Integer	Read- write	Applies only to extended ACLs. Enables or disables the filtering of established TCP packets that have the ACK or RESET flag turned on. This additional filter only applies to TCP transport protocol. <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snAgAclLogOption fdry.1.2.2.15.2.1.19 Syntax: TruthVal	Read- write	Determines if ACL matches are logged: <ul style="list-style-type: none"> <li>• false(0) – Do not log ACL matches</li> <li>• true(1) – Log ACL matches</li> </ul>
snAgAclStandardFlag fdry.1.2.2.15.2.1.20 Syntax: TruthVal	Read- write	Indicates if this is a standard ACL: <ul style="list-style-type: none"> <li>• false(0) – The ACL is an extended ACL</li> <li>• true(1) – The ACL is a standard ACL</li> </ul>
snAgAclRowStatus fdry.1.2.2.15.2.1.21 Syntax: SnRowStatus	Read- write	Creates or deletes an ACL entry. <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> </ul>
snAgAclFlowCounter fdry.1.2.2.15.2.1.22 Syntax: Counter64	Read only	Shows an approximate count of flows that match the individual ACL entry.
snAgAclPacketCounter fdry.1.2.2.15.2.1.23 Syntax: Counter64	Read only	Shows the number of packets that matched the ACL entry.

Name, OID, and Syntax	Access	Description
snAgAclComments fdry.1.2.2.15.2.1.24 Syntax: Display string	Read-write	Indicates the description of an individual ACL entry.
snAgAclIpPriority fdry.1.2.2.15.2.1.25 Syntax: Integer	Read-write	Indicates the QoS priority option for this ACL. This priority assigns traffic that matches the ACL to a hardware forwarding queue. In addition to changing the internal forwarding priority, if the outgoing interface is an 802.1Q interface, this option maps the specified priority to its equivalent 802.1p (CoS) priority and marks the packet with the new 802.1p priority.  <b>NOTE:</b> This option is available in IronWare software release 07.6.01 and later, and applies only to JetCore devices and 10 Gigabit Ethernet modules.
snAgAclPriorityForce fdry.1.2.2.15.2.1.26 Syntax: Integer	Read-write	Indicates priority that is being forced on the outgoing packet. This parameter allows you assign packets of outgoing traffic that match the ACL to a specific hardware forwarding queue, even though the incoming packet may be assigned to another queue.  Valid values: <ul style="list-style-type: none"> <li>• qosp0(0)</li> <li>• qosp1(1)</li> <li>• qosp2(2)</li> <li>• qosp3(3)</li> <li>• Not defined(4)</li> </ul> Default: Not defined(4).  <b>NOTE:</b> This option is available in IronWare software release 07.6.01 and later, and applies only to JetCore devices and 10 Gigabit Ethernet modules.
snAgAclPriorityMapping fdry.1.2.2.15.2.1.27 Syntax: Integer	Read-write	Indicates the priority of the incoming packet to be matched. This option maps the packet's 802.1p value. It does not change the packet's forwarding priority through the device nor does it mark the packet.  Valid values: 0 – 8 Default: Not defined(8)  <b>NOTE:</b> This option is available in IronWare software release 07.6.01 and later, and applies only to JetCore devices.
snAgAclDscpMarking fdry.1.2.2.15.2.1.28 Syntax: Integer	Read-write	Indicates the DSCP marking of a packet that will be matched.  Valid values: 0 – 64 Default: Not defined(64)  <b>NOTE:</b> This option is available in IronWare software release 07.6.01 and later, and applies only to JetCore devices and 10 Gigabit Ethernet modules.

Name, OID, and Syntax	Access	Description
snAgAclDscpMapping fdry.1.2.2.15.2.1.29 Syntax: Integer	Read- write	Indicates the DCSP value of the incoming packet value to be matched.  Valid values: 0 – 64  Default: Not defined(64)  <b>NOTE:</b> This option is available in IronWare software release 07.6.01 and later, and applies only to JetCore devices and 10 Gigabit Ethernet modules.
snAgAclIcmpCode fdry.1.2.2.15.2.1.30 Syntax: Integer	Read write	If you entered a value for ICMP message type number in the “snAgAclSourceOperand2” object, enter the code number in this object.  <b>Valid value for type code 1, Echo reply</b> <ul style="list-style-type: none"> <li>• 1 = Echo reply</li> </ul> <b>Valid values for type code4, Destination unreachable</b> <ul style="list-style-type: none"> <li>• 1 = Network unreachable</li> <li>• 2 = Host unreachable</li> <li>• 3 = Protocol unreachable</li> <li>• 4 = Port unreachable</li> <li>• 5 = Fragmentation needed by don't fragment bit set</li> <li>• 6 = Source route failed</li> <li>• 7 = Destination network unknown</li> <li>• 8 = Destination host unknown</li> <li>• 9 = Source host isolated</li> <li>• 10 = Destination network administratively prohibited</li> <li>• 11 = Destination host administratively prohibited</li> <li>• 12 = Network unreachable for TOS</li> <li>• 13 = Host unreachable for TOS</li> <li>• 14 = Communication administratively prohibited by filter</li> <li>• 15 = Host precedence violation</li> <li>• 16 = Precedence cutoff in effect</li> </ul> <b>Valid value for type code 5, Source quench</b> <ul style="list-style-type: none"> <li>• 1 = Source quench</li> </ul> <b>Valid values for type code 6, Redirect</b> <ul style="list-style-type: none"> <li>• 1 = Redirect for network</li> <li>• 2 = Redirect for host</li> <li>• 3 = Redirect for TOS and network</li> <li>• 4 = Redirect for TOS and host</li> </ul>

Name, OID, and Syntax	Access	Description
snAgAclIcmpCode (continued)		<p><b>Valid value for type code 9, Echo request</b></p> <ul style="list-style-type: none"> <li>1 = Echo request</li> </ul> <p><b>Valid value for type code 10, Router advertisement</b></p> <ul style="list-style-type: none"> <li>1 = Router advertisement</li> </ul> <p><b>Valid value for type code 11, Router solicitation</b></p> <ul style="list-style-type: none"> <li>1 = Router solicitation</li> </ul> <p><b>Valid values for type code 12, Time exceeded</b></p> <ul style="list-style-type: none"> <li>1 = Time to live equals 0 during transmit</li> <li>2 = Time to live equals 0 during reassembly</li> </ul> <p><b>Valid values for type code 13, Parameter problem</b></p> <ul style="list-style-type: none"> <li>1 = IP header bad (catchall error)</li> <li>2 = Required option missing</li> </ul> <p><b>Valid value for type code 14, Timestamp request</b></p> <ul style="list-style-type: none"> <li>1 = Timestamp request</li> </ul> <p><b>Valid value for type code 15, Timestamp reply</b></p> <ul style="list-style-type: none"> <li>1 = Timestamp reply</li> </ul> <p><b>Valid value for type code 16, Information request</b></p> <ul style="list-style-type: none"> <li>1 = Information request</li> </ul> <p><b>Valid value for type code 17 Information reply</b></p> <ul style="list-style-type: none"> <li>1 = Information reply</li> </ul> <p><b>Valid value for type code 18 Address mask request</b></p> <ul style="list-style-type: none"> <li>1 = Address mask request</li> </ul> <p><b>Valid value for type code 19 Address mask reply</b></p> <ul style="list-style-type: none"> <li>1 = Address mask reply</li> </ul>

### ACL Bind to Port Table (snAgAclBindToPortTable)

The ACL Bind to Port Table contains ACL port bindings for a Layer 3 Switch. Port numbers and bind direction are used to index entries.

This table has been deprecated.

Name, OID, and Syntax	Access	Description
snAgAclBindToPortTable fdry.1.2.2.15.3	None	The ACL Bind to Port Table
snAgAclBindToPortEntry fdry.1.2.2.15.3.1	None	An entry in the ACL Bind to Port table

Name, OID, and Syntax	Access	Description
snAgAclPortNum fdry.1.2.2.15.3.1.1 Syntax: Integer	Read only	Shows the format of port number.. <ul style="list-style-type: none"> <li>• LS octet – port number (max 255)</li> <li>• Next octet – slot number (max 255)</li> <li>• MS Octet:                             <ul style="list-style-type: none"> <li>0 (phy) – 0000 to 0FFFF</li> <li>1 (ve) – 10000 to 1FFFF</li> </ul> </li> </ul>
snAgAclPortBindDirection fdry.1.2.2.15.3.1.2 Syntax: Direction	Read only	Shows the traffic direction to which the ACL will be applied: <ul style="list-style-type: none"> <li>• inbound(0)</li> <li>• outbound(1)</li> </ul>
snAgAclNum fdry.1.2.2.15.3.1.3 Syntax: Integer	Read-write	Shows the defined ACL number that will be bound to the port.
snAgAclNameString fdry.1.2.2.15.3.1.4 Syntax: Display string	Read-write	Shows the defined ACL name that will be bound to the port.
snAgBindPortListInVirtualInterface fdry.1.2.2.15.3.1.5 Syntax: Octet string	Read-write	Contains a list of ports for binding virtual interface
snAgAclPortRowStatus fdry.1.2.2.15.3.1.6 Syntax: SnRowStatus	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>• delete(3) – Delete the row</li> <li>• create(4) – Create a new row</li> <li>• modify(5) – Modify an existing row</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row</li> <li>• invalid(1) – Row is inoperative</li> <li>• valid(2) – Row exists and is valid</li> </ul>

## ACL Port Table (snAgAclIfBindTable)

The snAgAclIfBindTable contains the ACLs defined for the BigIron MG8 and NetIron 40G. Other devices use the snAgAclTable (refer to “ACL Table” on page 8-8).

Name, OID, and Syntax	Access	Description
snAgAclIfBindTable fdry.1.2.2.15.4	None	The ACL Bind to Port Table
snAgAclIfBindEntry fdry.1.2.2.15.4.1	None	An entry in the ACL Bind to Port table
snAgAclIfBindIndex fdry.1.2.2.15.4.1.1 Syntax: InterfaceIndex	Read only	The number of the virtual or physical interface to which this ACL is bound.
snAgAclIfBindDirection fdry.1.2.2.15.4.1.2 Syntax: Direction	Read only	Shows the traffic direction to which the ACL will be applied: <ul style="list-style-type: none"> <li>inbound(0)</li> <li>outbound(1)</li> </ul>
snAgAclIfBindNum fdry.1.2.2.15.4.1.3 Syntax: Integer	Read-write	Shows the defined ACL number that will be bound to the port.
snAgAclIfBindNameString fdry.1.2.2.15.4.1.4 Syntax: Display string	Read-write	Shows the defined ACL name that will be bound to the port.
snAgAclIfBindVifPortList fdry.1.2.2.15.4.1.5 Syntax: Octet string	Read-write	Contains a list of ports for binding virtual interface. Each port index is an ifIndex. If there are four or more consecutive ifIndexes then, they will be encoded. Encoding and decoding scheme is range based. Each range prefix with 0000 (2 octets) where 0000 is not a valid ifIndex. The next 2 octets indicates lower range ifIndex, followed by 2 octets of higher range ifIndex. Individual(non-range) ones will be displayed as is.  For example:  Port list: 0001..0005 0015 0032..0047  Port list in PDU: 0000 0001 0005 000f 0000 0020 002f

Name, OID, and Syntax	Access	Description
snAgAclIfRowStatus fdry.1.2.2.15.4.1.6 Syntax: SnRowStatus	Read- write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>• delete(3) – Delete the row</li> <li>• create(4) – Create a new row</li> <li>• modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row</li> <li>• invalid(1) – Row is inoperative</li> <li>• valid(2) – Row exists and is valid</li> </ul>



---

# Chapter 9

## Traffic Control and Prioritization

This chapter presents the objects that can be used to prioritize traffic. It presents objects for the following features:

- “Quality of Service” on page 9-1
- “CAR” on page 9-2

### Quality of Service

Quality of Service (QoS) provides guaranteed bandwidth for certain traffic flows, by assigning priorities to queues that will be used by the traffic. For more information on QoS, refer to the *Foundry Enterprise Configuration and Management Guide*.

The following tables are available to configure QoS:

- “QoS Profile Table” on page 9-1
- “QoS Bind Table” on page 9-2

### QoS Profile Table

The following table contains the configuration of QoS profile groups.

Name, OID, and Syntax	Access	Description
snQosProfileTable fdry.1.1.3.14.1	None	The QoS Profile Table.
snQosProfileEntry fdry.1.1.3.14.1.1	None	An entry of the QoS Profile Table. Each entry represents a queue profile.
snQosProfileIndex fdry.1.1.3.14.1.1.1 Syntax: Integer	Read only	The table index of QoS Profile. There can be up to four profiles in this table.

Name, OID, and Syntax	Access	Description
snQosProfileName fdry.1.1.3.14.1.1.2 Syntax: Display string	Read-write	Shows the name of the QoS profile. Valid values: Up to 32 characters.
snQosProfileRequestedBandwidth fdry.1.1.3.14.1.1.3 Syntax: Integer	Read-write	Shows the requested bandwidth for the QoS profile.
snQosProfileCalculatedBandwidth fdry.1.1.3.14.1.1.4 Syntax: Integer	Read only	Shows the calculated bandwidth of the QoS profile.

## QoS Bind Table

The following table binds 802.1p tags to the entries in the “QoS Profile Table” on page 9-1.

Name, OID, and Syntax	Access	Description
snQosBindTable fdry.1.1.3.14.2	None	The QoS Bind Table.
snQosBindEntry fdry.1.1.3.14.2.1	None	An entry of the snQosBindTable.
snQosBindIndex fdry.1.1.3.14.2.1.1 Syntax: Integer	Read only	The table index of QoS Bind.
snQosBindPriority fdry.1.1.3.14.2.1.2 Syntax: Integer	Read only	Shows the QoS bind priority.
snQosBindProfileIndex fdry.1.1.3.14.2.1.3 Syntax: Integer	Read-write	Is an index that serves as a pointer to the index of the “snQosProfileTable”.

## CAR

This section presents the objects for Committed Access Rate (CAR), a Rate Limiting feature. Rate Limiting is a method of traffic control. You can configure a set of fixed or adaptive rate limits to regulate network traffic flow on an interface. The objects in this section are for the Fixed Rate Limiting feature.

The following tables are available to configure CAR:

- “CAR Port Table” on page 9-3
- “VLAN CAR Objects” on page 9-5

## CAR Port Table

The CAR Port Table shows the definitions of CAR objects. This table is indexed by the “snPortCARifIndex”, “snPortCARDirection”, and “snPortCARRowIndex” objects.

Name, OID, and Syntax	Access	Description
snPortCARTable fdry.1.1.3.16.1.1	None	The CAR Port Table
snPortCAREntry fdry.1.1.3.16.1.1.1	None	An entry in the CAR Port Table
snPortCARifIndex fdry.1.1.3.16.1.1.1.1 Syntax: Integer	Read only	Shows the ifIndex value for this rate limit entry.
snPortCARDirection fdry.1.1.3.16.1.1.1.2 Syntax: Integer	Read only	Specifies the transmission direction of the Rate-Limit object. <ul style="list-style-type: none"> <li>input(0) – for inbound traffic</li> <li>output(1) – for outbound traffic</li> </ul>
snPortCARRowIndex fdry.1.1.3.16.1.1.1.3 Syntax: Integer	Read only	Shows the table index for rate limit objects. Rows are numbered in sequential order. When a row is added, it is assigned the next sequential number. When a row is deleted, the row is skipped.
snPortCARType fdry.1.1.3.16.1.1.1.4 Syntax: RateLimitType	Read only	Shows the type of traffic to which the rate limit is applied. <ul style="list-style-type: none"> <li>all(3) – all traffic.</li> <li>standardAcc(1) – traffic matches standard access list.</li> <li>quickAcc(2) – traffic matches rate-limit’s access list.</li> </ul>
snPortCARAcclDx fdry.1.1.3.16.1.1.1.5 Syntax: Integer	Read only	Indicates the index to the access list if rate limit type is one of the following: <ul style="list-style-type: none"> <li>standardAcc(1) – traffic matches standard access list.</li> <li>quickAcc(2) – traffic matches rate-limit’s access list.</li> </ul>
snPortCARRate fdry.1.1.3.16.1.1.1.6 Syntax: Integer	Read only	Shows the committed access rate for the long term average transmission rate in bits per second. Traffic that falls under this rate always conforms to this rate.
snPortCARLimit fdry.1.1.3.16.1.1.1.7 Syntax: Integer	Read only	Shows the normal burst size in bytes. Normal burst size is the number of bytes that are guaranteed to be transported by the network at the average rate under normal conditions during the committed time interval.
snPortCARExtLimit fdry.1.1.3.16.1.1.1.8 Syntax: Integer	Read only	Shows the extended burst limit in bytes. The extended burst limit determines how large traffic bursts can be before all the traffic exceeds the rate limit.

Name, OID, and Syntax	Access	Description
snPortCARConformAction fdry.1.1.3.16.1.1.1.9 Syntax: Integer	Read only	Indicates what happens to packets when the traffic is within the Rate Limit. <ul style="list-style-type: none"> <li>• continue(1) – Continue to evaluate the subsequent rate limits.</li> <li>• drop(2) – Drop the packet.</li> <li>• precedCont(3) – Rewrite the IP precedence and transmit the packet.</li> <li>• precedXmit(4) – Rewrite the IP precedence and transmit the packet.</li> <li>• xmit(5) – Transmit the packet.</li> </ul>
snPortCARExceedAction fdry.1.1.3.16.1.1.1.10 Syntax: Integer	Read only	Indicates what happens to packets when the traffic exceeds the Rate Limit. <ul style="list-style-type: none"> <li>• continue(1) – Continue to evaluate the subsequent rate limits.</li> <li>• drop(2) – Drop the packet.</li> <li>• precedCont(3) – Rewrite the IP precedence and transmit the packet.</li> <li>• precedXmit(4) – Rewrite the IP precedence and transmit the packet.</li> <li>• xmit(5) – Transmit the packet.</li> </ul>
snPortCARStatSwitchedPkts fdry.1.1.3.16.1.1.1.11 Syntax: Counter64	Read only	Indicates the number of packets permitted by this rate limit.
snPortCARStatSwitchedBytes fdry.1.1.3.16.1.1.1.12 Syntax: Counter64	Read only	Indicates the number of bytes permitted by this interface.
snPortCARStatFilteredPkts fdry.1.1.3.16.1.1.1.13 Syntax: Counter64	Read only	Indicates the number of packets which exceeded this rate limit.
snPortCARStatFilteredBytes fdry.1.1.3.16.1.1.1.14 Syntax: Counter64	Read only	Indicates the number of bytes which exceeded this rate limit.
snPortCARStatCurBurst fdry.1.1.3.16.1.1.1.15 Syntax: Gauge	Read only	Shows the current burst size of received.

## VLAN CAR Objects

The objects in the following table contain the rate limit configuration for VLANs. This table is indexed by the “snVlanCARVlanId”, “snVlanCARDirection”, and “snVlanCARRowIndex” objects.

Name, OID, and Syntax	Access	Description
snVlanCARTable fdry.1.1.3.17.1.1	None	The VLAN rate limit table.
snVlanCAREntry fdry.1.1.3.17.1.1.1	None	An entry in the VLAN CAR Table.
snVlanCARVlanId fdry.1.1.3.17.1.1.1.1 Syntax: Integer	Read only	Shows the VLAN ID. VLAN ID is one of the indices of this table. Each VLAN ID can have a membership of multiple ports. Valid values: 1 – 4095
snVlanCARDirection fdry.1.1.3.17.1.1.1.2 Syntax: Integer	Read only	Specifies the transmission direction of the Rate-Limit object. <ul style="list-style-type: none"> <li>input(0) – for inbound traffic</li> <li>output(1) – for outbound traffic</li> </ul>
snVlanCARRowIndex fdry.1.1.3.17.1.1.1.3 Syntax: Integer	Read only	Shows the table index for rate limit objects for the VLAN. Rows are numbered in sequential order. When a row is added, it is assigned the next sequential number. When a row is deleted, the row is skipped.
snVlanCARType fdry.1.1.3.17.1.1.1.4 Syntax: Integer	Read only	Shows the type of traffic to which the rate limit is applied. <ul style="list-style-type: none"> <li>all(3) – all traffic.</li> <li>standardAcc(1) – traffic matches standard access list.</li> <li>quickAcc(2) – traffic matches rate-limit’s access list.</li> </ul>
snVlanCARAccIdx fdry.1.1.3.17.1.1.1.5 Syntax: Integer	Read only	Indicates the index to the access list if rate limit type is one of the following: <ul style="list-style-type: none"> <li>standardAcc(1) – traffic matches standard access list.</li> <li>quickAcc(2) – traffic matches rate-limit’s access list.</li> </ul>
snVlanCARRate fdry.1.1.3.17.1.1.1.6	Read only	Shows the committed access rate for long term average transmission for this VLAN. This rate is in bits per second. Traffic that falls under this rate always conforms to this rate.
snVlanCARLimit fdry.1.1.3.17.1.1.1.7 Syntax: Integer	Read only	Shows the normal burst size in bytes. Normal burst size is the number of bytes that are guaranteed to be transported by the network at the average rate under normal conditions during the committed time interval.
snVlanCARExtLimit fdry.1.1.3.17.1.1.1.8 Syntax: Integer	Read only	Shows the extended burst limit in bytes. The extended burst limit determines how large traffic bursts can be before all the traffic exceeds the rate limit.

Name, OID, and Syntax	Access	Description
snVlanCARConformAction fdry.1.1.3.17.1.1.1.9 Syntax: Integer	Read only	<p>Indicates what happens to packets when the traffic is within the Rate Limit.</p> <ul style="list-style-type: none"> <li>• continue(1) – Continue to evaluate the subsequent rate limits.</li> <li>• drop(2) – Drop the packet.</li> <li>• precedCont(3) – Rewrite the IP precedence and transmit the packet.</li> <li>• precedXmit(4) – Rewrite the IP precedence and transmit the packet.</li> <li>• xmit(5) – Transmit the packet.</li> </ul>
snVlanCARExceedAction fdry.1.1.3.17.1.1.1.10 Syntax: Integer	Read only	<p>Indicates what happens to packets when the traffic exceeds the Rate Limit.</p> <ul style="list-style-type: none"> <li>• continue(1) – Continue to evaluate the subsequent rate limits.</li> <li>• drop(2) – Drop the packet.</li> <li>• precedCont(3) – Rewrite the IP precedence and transmit the packet.</li> <li>• precedXmit(4) – Rewrite the IP precedence and transmit the packet.</li> <li>• xmit(5) – Transmit the packet.</li> </ul>
snVlanCARStatSwitchedPkts fdry.1.1.3.17.1.1.1.11 Syntax: Counter64	Read only	<p>Indicates the number of packets permitted by this rate limit.</p>
snVlanCARStatSwitchedBytes fdry.1.1.3.17.1.1.1.12 Syntax: Counter64	Read only	<p>Indicates the number of bytes permitted by this interface.</p>
snVlanCARStatFilteredPkts fdry.1.1.3.17.1.1.1.13 Syntax: Counter64	Read only	<p>Indicates the number of packets which exceeded this rate limit.</p>
snVlanCARStatFilteredBytes fdry.1.1.3.17.1.1.1.14 Syntax: Counter64	Read only	<p>Indicates the number of bytes which exceeded this rate limit.</p>
snVlanCARStatCurBurst fdry.1.1.3.17.1.1.1.15 Syntax: Gauge	Read only	<p>Shows the current burst size of received packets.</p>

---

# Chapter 10

## Multicast

The multicast feature allows packets to be simultaneously transmitted to a selected set of destinations, such one or more multicast groups.

This chapter presents objects for multicasting protocols in the following sections:

- “IGMP” on page 10-1
- “PIM” on page 10-4
- “DVMRP” on page 10-12

Refer to the *Foundry Enterprise Configuration and Management Guide* for details on the features discussed in this chapter.

### IGMP

The Internet Group Membership Protocol (IGMP) allows Foundry Layer 3 Switches to limit the multicast of IGMP packets to only those ports on the Layer 3 Switch that are identified as IP Multicast members. Foundry devices support IGMP versions 1 and 2. The Layer 3 Switch actively sends out host queries to identify IP Multicast groups on the network, inserts the group information in an IGMP packet, and forwards the packet to IP Multicast neighbors.

Objects for IGMP are presented in the following sections:

- “General IGMP Objects” on page 10-2
- “IGMP Interface Table” on page 10-2
- “IGMP Static Group MIB Table” on page 10-3

## General IGMP Objects

The following general IGMP objects are available in all Foundry devices.

Object Name and Number	Access	Description
snIgmPQueryInterval fdry.1.2.6.1.1 Syntax: Integer	Read-write	Specifies how often the Layer 3 Switch sends out IGMP host query packets to query an interface for group membership.  Valid values: 1 – 3600 seconds.  Default: 60 seconds  For a Layer 3 Switch, the object “snDvmrpEnable” must have been set to “enabled(1)” before this object can be written.  For a Layer 2 Switch, the object “snSwGroupIpMcastMode” must have been set to “enabled(1)” and the object “snSwIpMcastQuerierMode” must have been set to “querier(1)” before this object can be written.
snIgmPGroupMembershipTime fdry.1.2.6.1.2 Syntax: Integer	Read-write	Specifies how many seconds an IP Multicast group can remain on a Layer 3 Switch interface in the absence of a group report.  Valid values: 1 – 7200 seconds.  Default: 60 seconds  For a Layer 3 Switch, the object “snDvmrpEnable” must have been set to “enabled(1)” before this object can be written.  For a Layer 2 Switch, the object “snSwGroupIpMcastMode” must have been set to “enabled(1)” before this object can be written.

## IGMP Interface Table

The IGMP Interface Table contains the group membership information of a port.

Object Name and Number	Access	Description
snIgmPlfTable fdry.1.2.6.1.3	None	The IGMP Interface Table.
snIgmPlfEntry fdry.1.2.6.1.3.1	None	An entry in the IGMP Interface Table.
snIgmPlfEntryIndex fdry.1.2.6.1.3.1.1 Syntax: Integer	Read only	The table entry index.
snIgmPlfPortNumber fdry.1.2.6.1.3.1.2 Syntax: Integer	Read only	Shows the port number (interface) on which the group was learned.



Object Name and Number	Access	Description
snIgmplfGroupAddress fdry.1.2.6.1.3.1.3 Syntax: IpAddress	Read only	Shows the group's IP address learned from the interface.
snIgmplfGroupAge fdry.1.2.6.1.3.1.4 Syntax: Integer	Read only	Specifies how many seconds the Layer 3 Switch will wait for an IGMP response from an interface before concluding that the group member on that interface is down. The switch will then begin to remove the interface from the group.  Valid values: 1 – 10 seconds Default: 5 seconds

### IGMP Static Group MIB Table

The IGMP Static Group MIB table is available beginning with IronWare software release 07.6.02.

The table contains a list of IGMP static group entries. This table is available when IP Multicast Traffic Reduction is enabled on a Layer 2 Switch. The snSwGroupIpMcastMode MIB object enables or disables IP Multicast using SNMP.

By default, Foundry Layer 2 Switches forward all IP multicast traffic out of all ports except the port on which the traffic was received. To reduce multicast traffic through the Layer 2 Switch, you can enable IP Multicast Traffic Reduction. This feature configures the Layer 2 Switch to forward multicast traffic only on the ports attached to multicast group members. The Layer 2 Switch determines the ports that are attached to multicast group members based on entries in the IGMP table. Each entry in the table consists of an IP multicast group address and the Foundry Layer 2 Switch ports from which the Layer 2 Switch has received Group Membership reports for that group.

After you enable IP Multicast Traffic Reduction, when the Layer 2 Switch receives traffic for an IP multicast group, the Layer 2 Switch looks in the IGMP table for an entry for that group. If the Layer 2 Switch finds an entry, the Layer 2 Switch forwards the group traffic out the ports listed in the group entry. If the table does not contain an entry for the group, the Layer 2 Switch broadcasts the traffic.

The IGMP table is populated by receipt of Group Membership messages from IP multicast group members. Each Group Membership message contains the member's IP address and the group address.

Name, OID, and Syntax	Access	Description
snIgmplfStaticGroupTable fdry.1.2.6.1.4	None	The IGMP Static Group Table
snIgmplfStaticGroupEntry fdry.1.2.6.1.4.1	None	An entry in the IGMP static group. Each entry contains membership information.
snIgmplfStaticGroupIfIndex fdry.1.2.6.1.4.1.1 Syntax: Integer	Read only	Shows the interface for which the group was configured.
snIgmplfStaticGroupAddress fdry.1.2.6.1.4.1.2 Syntax: IpAddress	Read only	Shows the IP address for the group.

snIcmpStaticGroupPortList fdry.1.2.6.1.4.1.3 Syntax: Octet string	Read-write	Contains a list of ports that are members of the static group. Each port contains a 16-bit integer ifIndex.
snIcmpStaticGroupRowStatus fdry.1.2.6.1.4.1.4 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>other(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## PIM

Protocol-Independent Multicast (PIM) protocol is one of the multicast routing protocol supported in Foundry Layer 3 Switches such as Foundry's BigIron products. For detailed explanation on PIM, refer to the *Foundry Enterprise Configuration and Management Guide*.

The objects for PIM are presented in the following sections:

- "Common PIM Objects" on page 10-4
- "PIM Virtual Interface Table" on page 10-6
- "PIM Neighbor Table" on page 10-7
- "PIM Virtual Interface Statistics Table" on page 10-8
- "PIM-SM" on page 10-10

### Common PIM Objects

The following table presents objects that are common to all PIM interfaces.

Name, OID, and Syntax	Access	Description
snPimEnable fdry.1.2.9.1.1 Syntax: Integer	Read-write	<p>Determines if PIM is enabled on this Layer 3 Switch:</p> <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> <p>Default: disabled(0)</p> <p>The remaining object applies only if this object is set to enabled(1).</p>

Name, OID, and Syntax	Access	Description
snPimNeighborRouterTimeout fdry.1.2.9.1.2 Syntax: Integer	Read- write	Specifies the number of seconds the PIM Layer 3 Switch waits before it considers a neighbor to be absent. Absence of PIM hello messages from a neighboring Layer 3 Switch indicates that a neighbor is not present.  Valid values: 60 – 8000 seconds Default: 180 seconds
snPimHelloTime fdry.1.2.9.1.3 Syntax: Integer	Read- write	Specifies the number of seconds that periodic hellos are sent out on PIM interfaces. Layer 3 Switches use hello messages to inform neighboring Layer 3 Switches of their presence.  Valid values: 10 – 3600 seconds Default: 60 seconds
snPimPruneTime fdry.1.2.9.1.4 Syntax: Integer	Read- write	Specifies the number of seconds that a Foundry PIM Layer 3 Switch will maintain a prune state for a forwarding entry.  The first multicast that the Layer 3 Switch receives from an interface is forwarded to all other PIM interfaces on the Layer 3 Switch. If there is no presence of groups on that interface, the leaf node sends a prune message upstream and stores a prune state. This prune state travels up the tree and installs a prune state.  A prune state is maintained until the prune timer expires or a graft message is received for the forwarding entry.  Valid values: 10 – 3600 seconds Default: 180 seconds
snPimGraftRetransmitTime fdry.1.2.9.1.5 Syntax: Integer	Read- write	Defines the number of seconds between the transmission of graft messages.  A graft message is sent by a Layer 3 Switch to cancel a prune state. When a Layer 3 Switch receives a graft message, the Layer 3 Switch responds with a Graft ACK (acknowledge) message. If this Graft ACK message is lost, the Layer 3 Switch that sent the graft message will resend it.  Valid values: 10 – 3600 seconds Default: 180 seconds
snPimInactivityTime fdry.1.2.9.1.6 Syntax: Integer	Read- write	Defines how long a forwarding entry can remain unused before the Layer 3 Switch deletes it. The Layer 3 Switch deletes a forwarding entry if the entry is not used to send multicast packets.  This object is used only to keep the forwarding entries for the active sessions.  Valid values: 10 – 3600 seconds Default: 180 seconds

## PIM Virtual Interface Table

The PIM Virtual Interface Table lists the PIM virtual interfaces on a Layer 3 Switch.

Name, OID, and Syntax	Access	Description
snPimVInterfaceTable fdry.1.2.9.1.7	None	The PIM Virtual Interface Table.
snPimVInterfaceEntry fdry.1.2.9.1.7.1	None	An entry in the PIM Virtual Interface Table.
snPimVInterfaceVifIndex fdry.1.2.9.1.7.1.1 Syntax: Integer	Read only	The ifIndex value of this PIM virtual interface. There can be up to 48 entries.
snPimVInterfaceType fdry.1.2.9.1.7.1.2 Syntax: Integer	Read-write	Indicates the type of PIM virtual interface the row represents: <ul style="list-style-type: none"> <li>tunnel(1)</li> <li>subnet(2) or a physical interface</li> </ul>
snPimVInterfaceLocalAddress fdry.1.2.9.1.7.1.3 Syntax: IpAddress	Read-write	Indicates the IP address of the local end of the interface being configured.  IP tunneling must also be enabled and defined on the destination Layer 3 Switch interface as well..
snPimVInterfaceLocalSubnetMask fdry.1.2.9.1.7.1.4 Syntax: IpAddress	Read only	Shows the network mask for the IP address of the PIM virtual interface. For a tunnel, this should be 0.0.0.0.
snPimVInterfaceRemoteAddress fdry.1.2.9.1.7.1.5 Syntax: IpAddress	Read-write	Shows the IP address of the remote end of this PIM virtual interface.
snPimVInterfaceDR fdry.1.2.9.1.7.1.6 Syntax: IpAddress	Read only	Defines the designated Layer 3 Switch on this PIM virtual interface. For point-to-point interfaces, this object has the value 0.0.0.0.
snPimVInterfaceTtlThreshold fdry.1.2.9.1.7.1.7 Syntax: Integer	Read-write	Determines the minimum time-to-live value to forward the packets out of this interface.  Valid values: 1 – 31  Default: 1

Name, OID, and Syntax	Access	Description
snPimVInterfaceStatus fdry.1.2.9.1.7.1.8 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snPimVInterfaceMode fdry.1.2.9.1.7.1.9 Syntax: Integer	Read-write	<p>Shows the configured mode of this PIM interface:</p> <ul style="list-style-type: none"> <li>dense(1) – Traffic is initially flooded to all PIM interface neighbors. Branches that do not want the data are pruned.</li> <li>sparse(2) – PIM interface neighbors must join the multicast group if they want to receive the traffic.</li> </ul>

## PIM Neighbor Table

The PIM Neighbor Table is a conceptual table that lists the Layer 3 Switch's PIM neighbors.

Name, OID, and Syntax	Access	Description
snPimNeighborTable fdry.1.2.9.1.8	None	The PIM Neighbor Table
snPimNeighborEntry fdry.1.2.9.1.8.1	None	An entry in the PIM Neighbor Table
snPimNeighborEntryIndex fdry.1.2.9.1.8.1.1 Syntax: Integer	Read only	The table entry index.
snPimNeighborVifIndex fdry.1.2.9.1.8.1.2 Syntax: Integer	Read only	Shows the value of VifIndex for the virtual interface used to reach this PIM neighbor.
snPimNeighborAddress fdry.1.2.9.1.8.1.3 Syntax: IpAddress	Read only	Shows the IP address of the this PIM neighbor.

Name, OID, and Syntax	Access	Description
snPimNeighborUpTime fdry.1.2.9.1.8.1.4 Syntax: Time ticks	Read only	Indicates the last time when this PIM neighbor became a neighbor of the local Layer 3 Switch.
snPimNeighborExpiryTime fdry.1.2.9.1.8.1.5 Syntax: Time ticks	Read only	Displays the time remaining before this PIM neighbor will be aged out.

### PIM Virtual Interface Statistics Table

The PIM Virtual Interface Statistics table lists the Layer 3 Switch's PIM virtual interface statistical counters.

Name, OID, and Syntax	Access	Description
snPimVifStatTable fdry.1.2.9.1.9	None	The PIM Virtual Interface Statistics Table.
snPimVifStatEntry fdry.1.2.9.1.9.1	None	An entry in the PIM Virtual Interface Statistics Table.
snPimVifStatVifIndex fdry.1.2.9.1.9.1.1 Syntax: Integer	Read only	The ifIndex value of this PIM virtual interface. There can be up – 32 entries.
snPimVifStatInJoinPkts fdry.1.2.9.1.9.1.2 Syntax: Counter	Read only	Shows the number of Join/Prune messages sent or received on the interface. <b>NOTE:</b> Unlike PIM dense, PIM Sparse uses the same messages for Joins and Prunes.T
snPimVifStatOutJoinPkts fdry.1.2.9.1.9.1.3 Syntax: Counter	Read only	Indicates the number of join packets that have been sent on the PIM virtual interface.
snPimVifStatDiscardJoinPkts fdry.1.2.9.1.9.1.4 Syntax: Counter	Read only	Shows the number of join packets that have been discarded by the PIM virtual interface.
snPimVifStatInPrunePkts fdry.1.2.9.1.9.1.5 Syntax: Counter	Read only	Shows the number of prune packets that have arrived on the PIM virtual interface.
snPimVifStatOutPrunePkts fdry.1.2.9.1.9.1.6 Syntax: Counter	Read only	Shows the number of prune packets that have been sent on the PIM virtual interface.

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snPimVifStatDiscardPrunePkts fdry.1.2.9.1.9.1.7 Syntax: Counter	Read only	Shows the number of prune packets that have been discarded by the PIM virtual interface.
snPimVifStatInAssertPkts fdry.1.2.9.1.9.1.8 Syntax: Counter	Read only	Shows the number of assert packets that have arrived on the PIM virtual interface.
snPimVifStatOutAssertPkts fdry.1.2.9.1.9.1.9 Syntax: Counter	Read only	Shows the number of assert packets that have been sent on the PIM virtual interface.
snPimVifStatDiscardAssertPkts fdry.1.2.9.1.9.1.10 Syntax: Counter	Read only	Shows the number of assert packets that have been discarded by the PIM virtual interface.
snPimVifStatInHelloPkts fdry.1.2.9.1.9.1.11 Syntax: Counter	Read only	Shows the number of hello packets that have arrived on the PIM virtual interface.
snPimVifStatOutHelloPkts fdry.1.2.9.1.9.1.12 Syntax: Counter	Read only	Shows the number of hello packets that have been sent on the PIM virtual interface.
snPimVifStatDiscardHelloPkts fdry.1.2.9.1.9.1.13 Syntax: Counter	Read only	Shows the number of hello packets that have been discarded by the PIM virtual interface.
snPimVifStatInGraftPkts fdry.1.2.9.1.9.1.14 Syntax: Counter	Read only	Shows the number of graft packets that have arrived on the PIM virtual interface.
snPimVifStatOutGraftPkts fdry.1.2.9.1.9.1.15 Syntax: Counter	Read only	Shows the number of graft packets that have been sent on the PIM virtual interface.
snPimVifStatDiscardGraftPkts fdry.1.2.9.1.9.1.16 Syntax: Counter	Read only	Shows the number of graft packets that have been discarded by the PIM virtual interface.
snPimVifStatInGraftAckPkts fdry.1.2.9.1.9.1.17 Syntax: Counter	Read only	Shows the number of graft acknowledge packets that have arrived on the PIM virtual interface.

Name, OID, and Syntax	Access	Description
snPimVifStatOutGraftAckPkts fdry.1.2.9.1.9.1.18 Syntax: Counter	Read only	Shows the number of graft acknowledge packets that have been sent on the PIM virtual interface.
snPimVifStatDiscardGraftAckPkts fdry.1.2.9.1.9.1.19 Syntax: Counter	Read only	Shows the number of graft acknowledge packets that have been discarded by the PIM virtual interface.

## PIM-SM

The following tables are available for the PIM Sparse feature.

- “PIM Sparse: Candidate BSR Table” on page 10-10
- “PIM RP Set Table” on page 10-11
- “PIM RP Candidate Table” on page 10-12

Name, OID, and Syntax	Access	Description
snPimJoinPruneInterval fdry.1.2.9.2.1 Syntax: Integer	Read-write	Determines the the number of seconds when periodic PIM Spare Join/Prune messages are to be sent. These messages inform other PIM Sparse Layer 3 Switches about clients who want to become receivers (Join) or stop being receivers (Prune) for PIM Sparse groups.  Valid values: 10 – 3600 seconds Default: 60 seconds

## PIM Sparse: Candidate BSR Table

The Candidate Bootstrap Router (BSR) Table contains information about BSRs that can are candidates to be the active BSR for the domain. The Bootstrap Router (BSR) distributes Rendezvous Point (RP) information to the other PIM Sparse routers within the domain. Each PIM Sparse domain has one active BSR. For redundancy, you can configure ports on multiple routers as candidate BSRs. The PIM Sparse protocol uses an election process to select one of the candidate BSRs as the active BSR for the domain. The BSR with the highest BSR priority is elected. If the priorities result in a tie, then the candidate BSR interface with the highest IP address is elected.

Name, OID, and Syntax	Access	Description
snPimCandidateBSRTTable fdry.1.2.9.2.2	None	The Candidate Bootstrap Router Table.
snPimCandidateBSREntry fdry.1.2.9.2.2.1	None	An entry in the Candidate Bootstrap Router Table.
snPimCandidateBSRPortID fdry.1.2.9.2.2.1.1 Syntax: Integer	Read-write	Identifies the IP address of the PIM interface: <ul style="list-style-type: none"> <li>• Bit 0 to bit 7 – Port number.</li> <li>• Bit 8 to bit 11– Slot number.</li> </ul>



Name, OID, and Syntax	Access	Description
snPimCandidateBSRIPAddress fdry.1.2.9.2.2.1.2 Syntax: IpAddress	Read only	Shows the unicast address of the candidate BSR. Valid values: 1 – 32.
snPimCandidateBSRHashMaskLen fdry.1.2.9.2.2.1.3 Syntax: Integer	Read-write	Indicates the hash mask value for this Layer 3 Switch as a candidate bootstrap router.
snPimCandidateBSRPreference fdry.1.2.9.2.2.1.4 Syntax: Integer	Read-write	Indicates the preference value for this Layer 3 Switch as a candidate bootstrap router. Valid values: 0 – 255 Default: 100

### PIM RP Set Table

The PIM RP Set Table contains information about candidate Rendezvous Points (RPs) for IP multicast groups. When the local Layer 3 Switch is the BSR, this information is obtained from the advertisements received from the Candidate-RP. When the local Layer 3 Switch is not the BSR, this information is obtained from the received RP-Set messages.

Name, OID, and Syntax	Access	Description
snPimRPSetTable fdry.1.2.9.2.3	None	The PIM RP Set Table
snPimRPSetEntry fdry.1.2.9.2.3.1	None	An entry in the PIM RP Set Table
snPimRPSetGroupAddress fdry.1.2.9.2.3.1.1 Syntax: IpAddress	Read only	Shows the IP multicast group address. This object plus the snPimRPSetGroupMask, form the group prefix for the Candidate-RP.
snPimRPSetMask fdry.1.2.9.2.3.1.2 Syntax: IpAddress	Read only	Shows the IP multicast group address. This object plus the “snPimRPSetGroupAddress” object form the group prefix for the Candidate-RP.
snPimRPSetIPAddress fdry.1.2.9.2.3.1.3 Syntax: IpAddress	Read only	Shows the IP address of the Candidate-RP.
snPimRPSetHoldTime fdry.1.2.9.2.3.1.4 Syntax: Integer	Read only	Shows the holdtime, in seconds, of a Candidate-RP. If the local router is not the BSR, this value is 0.

### PIM RP Candidate Table

The PIM Rendezvous Point Table listing the IP multicast groups for which the local router is to advertise itself as a Candidate-RP. If this table is empty, then the local router will advertise itself as a Candidate-RP for all groups snPimEnable must be "enabled" before this table is read or written.

Name, OID, and Syntax	Access	Description
snPimCandidateRPTable fdry.1.2.9.2.4	None	The PIM RP Candidate Table
snPimCandidateRPEntry fdry.1.2.9.2.4.1	None	An entry the PIM RP Candidate Table
snPimCandidateRPGroupAddresses fdry.1.2.9.2.4.1.1 Syntax: IpAddress	Read only	Shows the IP multicast group address. This object combined with the snPimCandidateRPGroupMask object forms the group prefix for which the local router will advertise itself as a Candidate-RP.
snPimCandidateRPMask fdry.1.2.9.2.4.1.2 Syntax: IpAddress	Read only	Shows the multicast group address mask. This object combined with snPimCandidateRPGroupMask forms the group prefix for which the local router will advertise itself as a Candidate-RP.
snPimCandidateRPIPAddress fdry.1.2.9.2.4.1.3 Syntax: IpAddress	Read-write	Indicates the unicast IP address of the interface that will be advertised as a Candidate-RP.
snPimCandidateRPRowStatus fdry.1.2.9.2.4.1.4 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

### DVMRP

Distance Vector Multicast Routing Protocol (DVMRP) is one of the multicast routing protocol supported in Foundry's Layer 3 Switches, such as the BigIron products.

The objects in this section apply to the DVMRP feature, if that feature is enabled in the Layer 3 Switch. For additional information on DVMRP, refer to the *Foundry Enterprise Configuration and Management Guide*.

The following sections present the objects and tables for configuring DVMRP:

- “Global DVMRP Objects” on page 10-13
- “DVMRP Virtual Interface Table” on page 10-14
- “DVMRP Neighbor Table” on page 10-16
- “DVMRP Route Table” on page 10-17
- “DVMRP Routing Next Hop Table” on page 10-18
- “DVMRP Virtual Interface Statistics Table” on page 10-19

## Global DVMRP Objects

Name, OID, and Syntax	Access	Description
snDvmrpVersion fdry.1.2.5.1.1 Syntax: Display string	Read only	Shows the DVMRP version in the Layer 3 Switch. There can be up to 255 characters in this object.
snDvmrpEnable fdry.1.2.5.1.2 Syntax: Integer	Read-write	Indicates if DVMRP is enabled on this Layer 3 Switch: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0)
snDvmrpGenerationId fdry.1.2.5.1.3 Syntax: Integer	Read only	Shows the generation identifier for the routing process. This is used by neighboring Layer 3 Switches to determine if pruning information should be resent.
snDvmrpProbeInterval fdry.1.2.5.1.4 Syntax: Integer	Read-write	Defines how often neighbor probe messages are sent to the ALL-DVMRP-ROUTERS IP multicast group address. A Layer 3 Switch’s probe message lists those neighbor DVMRP routers from which it has received probes.  Valid values: 5 – 30 seconds Default: 10 seconds
snDvmrpReportInterval fdry.1.2.5.1.5 Syntax: Integer	Read-write	Defines how often Layer 3 Switches propagate their complete routing tables to other DVMRP neighbor routers.  Valid values: 10 –2000 seconds Default: 60 seconds
snDvmrpTriggerInterval fdry.1.2.5.1.6 Syntax: Integer	Read-write	Defines how often trigger updates, which reflect changes in the network topology, are sent. For example, changes in a network topology, including router up or down, or changes in the metric, would cause trigger updates to be sent.  Valid values: 5 –30 seconds Default: 5 seconds
snDvmrpNeighborRouterTimeout fdry.1.2.5.1.7 Syntax: Integer	Read-write	Specifies the how long a router waits before it determines that an attached DVMRP neighbor router as down.  Valid values: 40 – 8000 seconds Default: 180 seconds

Name, OID, and Syntax	Access	Description
snDvmrpRouteExpireTime fdry.1.2.5.1.8 Syntax: Integer	Read-write	Defines how long a route is considered valid in the absence of the next route update.  Valid values: 20 – 4000 seconds Default: 200 seconds
snDvmrpRouteDiscardTime fdry.1.2.5.1.9 Syntax: Integer	Read-write	Defines how long a router waits before it deletes a route.  Valid values: 40 – 8000 seconds Default: 340 seconds
snDvmrpPruneAge fdry.1.2.5.1.10 Syntax: Integer	Read-write	Defines how long a prune state will remain in effect for a source-routed multicast tree. After the prune age period expires, flooding will resume.  Valid values: 20 – 3600 seconds Default: 180 seconds
snDvmrpGraftRetransmitTime fdry.1.2.5.1.11 Syntax: Integer	Read-write	Defines how long a router that is sending a graft message will wait for a the first graft acknowledgement from an upstream router before re-transmitting that message. Subsequent retransmissions are sent at an interval twice that of the preceding interval.  Valid values: 5 – 3600 seconds Default: 10 seconds
snDvmrpDefaultRoute fdry.1.2.5.1.12 Syntax: IpAddress	Read-write	This is the IP address of a router that is connected to one of the directly attached subnet. If a multicast route is not present on the local router, this default route will be used for multicast forwarding. “snDvmrpEnable” must be set to “enabled” before this object can be written.

### DVMRP Virtual Interface Table

The DVMRP Virtual Interface Table contains the router’s DVMRP virtual interfaces.

Name, OID, and Syntax	Access	Description
snDvmrpVInterfaceTable fdry.1.2.5.1.13	None	The DVMRP Virtual Interface Table
snDvmrpVInterfaceEntry fdry.1.2.5.1.13.1	None	An entry in the The DVMRP Virtual Interface Table.  This row augments ipMRouteInterfaceEntry in the IP Multicast MIB, where the threshold object resides.
snDvmrpVInterfaceVifIndex fdry.1.2.5.1.13.1.1 Syntax: Integer	Read only	The ifIndex value of this DVMRP virtual interface.

Name, OID, and Syntax	Access	Description
snDvmpVInterfaceType fdry.1.2.5.1.13.1.2 Syntax: Integer	Read-write	Indicates the type of this DVMRP virtual interface: <ul style="list-style-type: none"> <li>tunnel(1) – Tunnel interface, for which the interface is a querier.</li> <li>subnet(3) – Physical interface, for which the interface is not a querier.</li> </ul>
snDvmpVInterfaceOperState fdry.1.2.5.1.13.1.3 Syntax: Integer	Read only	Shows the current state of this DVMRP virtual interface: <ul style="list-style-type: none"> <li>up(1)</li> <li>down(2)</li> </ul>
snDvmpVInterfaceLocalAddress fdry.1.2.5.1.13.1.4 Syntax: IpAddress	Read-write	Shows the IP address of the local end of this DVMRP virtual interface.
snDvmpVInterfaceRemoteAddress fdry.1.2.5.1.13.1.5 Syntax: IpAddress	Read-write	Shows the IP address of the remote end of this DVMRP virtual interface.  For a tunnel, enter the IP address of the neighboring router.  For a subnet, enter the subnet address.
snDvmpVInterfaceRemoteSubnetMask fdry.1.2.5.1.13.1.6 Syntax: IpAddress	Read only	Shows the subnet mask for a directly connected subnet. For a tunnel, this should be 0.0.0.0.
snDvmpVInterfaceMetric fdry.1.2.5.1.13.1.7 Syntax: Integer	Read-write	Defines the distance metric for this DVMRP virtual interface. The router uses the metric when establishing reverse paths to some networks on directly attached interfaces.  Valid values: 1 – 31 hops  Default: 1
snDvmpVInterfaceTtlThreshold fdry.1.2.5.1.13.1.8 Syntax: Integer	Read-write	Defines the minimum value required in a packet in order for the packet to be forwarded out of the interface. For example, if the TTL for an interface is set at 10, then only those packets with a TTL value of 10 or more are forwarded. Likewise, if an interface is configured with a TTL Threshold value of 1, all packets received on that interface are forwarded.  Valid values: 1 – 64  Default: 1
snDvmpVInterfaceAdvertiseLocal fdry.1.2.5.1.13.1.9 Syntax: Integer	Read-write	Determines if advertising of this local route is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: enabled(1)

Name, OID, and Syntax	Access	Description
snDvmrpVInterfaceEncapsulation fdry.1.2.5.1.13.1.10 Syntax: Integer	Read-write	Indicates if the encapsulation of the DVMRP control packets when using IPINIP encapsulation is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0)
snDvmrpVInterfaceStatus fdry.1.2.5.1.13.1.11 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

### DVMRP Neighbor Table

The DVMRP Neighbor Table lists the router's DVMRP neighbors, as discovered by the receiving Neighbor Probe messages.

Name, OID, and Syntax	Access	Description
snDvmrpNeighborTable fdry.1.2.5.1.14	None	The DVMRP Neighbor Table.
snDvmrpNeighborEntry fdry.1.2.5.1.14.1	None	An entry in the DVMRP Neighbor Table.
snDvmrpNeighborEntryIndex fdry.1.2.5.1.14.1.1 Syntax: Integer	Read only	The table entry index.
snDvmrpNeighborVifIndex fdry.1.2.5.1.14.1.2 Syntax: Integer	Read only	The value of VifIndex for the virtual interface used to reach this DVMRP neighbor.
snDvmrpNeighborAddress fdry.1.2.5.1.14.1.3 Syntax: IpAddress	Read only	Shows the IP address of the DVMRP neighbor for which this entry contains information.

Name, OID, and Syntax	Access	Description
snDvmpNeighborUpTime fdry.1.2.5.1.14.1.4 Syntax: Time ticks	Read only	Shows the last time since this DVMRP neighbor became a neighbor of the local router.
snDvmpNeighborExpiryTime fdry.1.2.5.1.14.1.5 Syntax: Time ticks	Read only	Shows the number of seconds remaining before this DVMRP neighbor will be aged out.
snDvmpNeighborGenerationId fdry.1.2.5.1.14.1.6 Syntax: Integer	Read only	Shows the neighboring router's generation identifier.
snDvmpNeighborMajorVersion fdry.1.2.5.1.14.1.7 Syntax: Integer	Read only	Shows the neighboring router's major DVMRP version number. Valid values: 0 – 255
snDvmpNeighborMinorVersion fdry.1.2.5.1.14.1.8 Syntax: Integer	Read only	Shows the neighboring router's minor DVMRP version number. Valid values: 0 – 255
snDvmpNeighborCapabilities fdry.1.2.5.1.14.1.9 Syntax: Integer	Read only	Describes the neighboring router's capabilities. The following shows the position of each bit:  <b>Bit position</b> <b>Meaning</b> 3mtrace bit. If on, neighbor can handle mtrace requests 2generationID bit. If on, the neighbor sends its generationID in Probe messages 1prune bit. If on, the neighbor supports pruning 0leaf bit. If on, the neighbor has only one interface with other neighbors

## DVMRP Route Table

DVMRP uses a routing table instead of the unicast routing table. The DVMRP Route Table contains information on the DVMRP source and destination routes.

Name, OID, and Syntax	Access	Description
snDvmpRouteTable fdry.1.2.5.1.15	None	The DVMRP Route Table
snDvmpRouteEntry fdry.1.2.5.1.15.1	None	An entry in the DVMRP Route Table

Name, OID, and Syntax	Access	Description
snDvmrpRouteEntryIndex fdry.1.2.5.1.15.1.1 Syntax: Integer	Read only	The table entry index.
snDvmrpRouteSource fdry.1.2.5.1.15.1.2 Syntax: IpAddress	Read only	Shows the network address of the source. This object plus the value of the "snDvmrpRouteSourceMask" object identifies the sources of this entry.
snDvmrpRouteSourceMask fdry.1.2.5.1.15.1.3 Syntax: IpAddress	Read only	Shows the network mask of the source. This object plus the value of the "snDvmrpRouteSource" object identifies the sources of this entry.
snDvmrpRouteUpstreamNeighbor fdry.1.2.5.1.15.1.4 Syntax: IpAddress	Read only	Shows the address of the upstream neighbor (for example, RPF neighbor) from which IP datagrams were received.
snDvmrpRouteVifIndex fdry.1.2.5.1.15.1.5 Syntax: Integer	Read only	The value of snDvmrpVInterfaceVifIndex for the virtual interface on which IP datagrams sent by these sources are received.
snDvmrpRouteMetric fdry.1.2.5.1.15.1.6 Syntax: Integer	Read only	Shows the number of hops to the source subnet.
snDvmrpRouteExpiryTime fdry.1.2.5.1.15.1.7 Syntax: Time ticks	Read only	Shows the amount of time remaining before this entry will be aged out.

### DVMRP Routing Next Hop Table

The DVMRP Routing Next Hop Table contains information on the nex hop for routing IP multicast datagrams.

Name, OID, and Syntax	Access	Description
snDvmrpRouteNextHopTable fdry.1.2.5.1.16	None	The DVMRP Routing Next Hop Table
snDvmrpRouteNextHopEntry fdry.1.2.5.1.16.1	None	An entry the DVMRP Routing Next Hop Table.
snDvmrpRouteNextHopSource fdry.1.2.5.1.16.1.1 Syntax: IpAddress	Read only	Shows the network mask of the source. This object plus the "snDvmrpRouteNextHopSourceMask" object identify the source of the next hop.



Name, OID, and Syntax	Access	Description
snDvmrpRouteNextHopSourceMask fdry.1.2.5.1.16.1.2 Syntax: IpAddress	Read only	Shows the network mask of the source. This object plus the “snDvmrpRouteNextHopSource” object identify the sources of the next hop.
snDvmrpRouteNextHopVifIndex fdry.1.2.5.1.16.1.3 Syntax: Integer	Read only	The snDvmrpVInterfaceVifIndex value of the virtual interface for the outgoing interface for this next hop.
snDvmrpRouteNextHopType fdry.1.2.5.1.16.1.4 Syntax: Integer	Read only	Identifies the type of router for the next hop: <ul style="list-style-type: none"> <li>leaf(1) – There are no neighbors at the next hop</li> <li>branch(2) – Neighbors are attached to the next hop</li> </ul>

### DVMRP Virtual Interface Statistics Table

The DVMRP Virtual Interface Statistics Table provides information about the DVMRP routes.

Name, OID, and Syntax	Access	Description
snDvmrpVifStatTable fdry.1.2.5.1.17	None	The DVMRP Virtual Interface Statistics Table
snDvmrpVifStatEntry fdry.1.2.5.1.17.1	None	An entry in the DVMRP Virtual Interface Statistics Table
snDvmrpVifStatVifIndex fdry.1.2.5.1.17.1.1 Syntax: Integer	Read only	The ifIndex value of this DVMRP virtual interface.
snDvmrpVifStatInPkts fdry.1.2.5.1.17.1.2 Syntax: Counter	Read only	Shows the number of packets that have arrived on the DVMRP virtual interface.
snDvmrpVifStatOutPkts fdry.1.2.5.1.17.1.3 Syntax: Counter	Read only	Shows the number of packets that have been sent on the DVMRP virtual interface.
snDvmrpVifStatInOctets fdry.1.2.5.1.17.1.4 Syntax: Counter	Read only	Shows the number of octets that have arrived on the DVMRP virtual interface.
snDvmrpVifStatOutOctets fdry.1.2.5.1.17.1.5 Syntax: Counter	Read only	Shows the number of octets that have been sent on the DVMRP virtual interface.

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snDvmrpVifStatInProbePkts fdry.1.2.5.1.17.1.6 Syntax: Counter	Read only	Shows the number of probe packets that have arrived on the DVMRP virtual interface.
snDvmrpVifStatOutProbePkts fdry.1.2.5.1.17.1.7 Syntax: Counter	Read only	Shows the number of probe packets that have been sent on the DVMRP virtual interface.
snDvmrpVifStatDiscardProbePkts fdry.1.2.5.1.17.1.8 Syntax: Counter	Read only	Shows the number of probe packets that have been discarded by the DVMRP virtual interface.
snDvmrpVifStatInRtUpdatePkts fdry.1.2.5.1.17.1.9 Syntax: Counter	Read only	Shows the number of route update packets that have arrived on the DVMRP virtual interface.
snDvmrpVifStatOutRtUpdatePkts fdry.1.2.5.1.17.1.10	Read only	Shows the number of route update packets that have been sent on the DVMRP virtual interface.
snDvmrpVifStatDiscardRtUpdatePkts fdry.1.2.5.1.17.1.11 Syntax: Counter	Read only	Shows the number of route update packets that have been discarded by the DVMRP virtual interface.
snDvmrpVifStatInGraftPkts fdry.1.2.5.1.17.1.12 Syntax: Counter	Read only	Shows the number of graft packets that have arrived on the DVMRP virtual interface.
snDvmrpVifStatOutGraftPkts fdry.1.2.5.1.17.1.13 Syntax: Counter	Read only	Shows the number of graft packets that have been sent on the DVMRP virtual interface.
snDvmrpVifStatDiscardGraftPkts fdry.1.2.5.1.17.1.14 Syntax: Counter	Read only	Shows the number of graft packets that have been discarded by the DVMRP virtual interface.
snDvmrpVifStatInGraftAckPkts fdry.1.2.5.1.17.1.15 Syntax: Counter	Read only	Shows the number of graft acknowledge packets that have arrived on the DVMRP virtual interface.
snDvmrpVifStatOutGraftAckPkts fdry.1.2.5.1.17.1.16 Syntax: Counter	Read only	Shows the number of graft acknowledge packets that have been sent on the DVMRP virtual interface.

---

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snDvmpVifStatDiscardGraftAckPkts fdry.1.2.5.1.17.1.17 Syntax: Counter	Read only	Shows the number of graft acknowledge packets that have been discarded by the DVMRP virtual interface.
snDvmpVifStatInPrunePkts fdry.1.2.5.1.17.1.18 Syntax: Counter	Read only	Shows the number of prune packets that have arrived on the DVMRP virtual interface.
snDvmpVifStatOutPrunePkts fdry.1.2.5.1.17.1.19 Syntax: Counter	Read only	Shows the number of prune packets that have been sent on the DVMRP virtual interface.
snDvmpVifStatDiscardPrunePkts fdry.1.2.5.1.17.1.20 Syntax: Counter	Read only	Shows the number of prune packets that have been discarded by the DVMRP virtual interface.

---



---

# Chapter 11

## VLANs

Refer to the following sections to determine what MIB objects are available for VLANs:

- “VLAN By Port Information Table” on page 11-1
- “VLAN by Port Membership Table” on page 11-6
- “Port VLAN Configuration Table” on page 11-7
- “VLAN by Protocol Configuration Table” on page 11-12
- “VLAN by IP Subnet Configuration Table” on page 11-14
- “VLAN by IPX Network Configuration Table” on page 11-17
- “VLAN by AppleTalk Cable Configuration Table” on page 11-19

Refer to the *Foundry Switch and Router Installation and Basic Configuration Guide* for details on the features discussed in this chapter.

### VLAN By Port Information Table

This table applies to a Layer 2 device if the object “snSwGroupOperMode” on page 5-14 is configured with a value of vlanByPort(2), allowing switch ports to be configured with a VLAN ID. Each VLAN switch port could have a number of VLAN IDs. Unless indicated below, the objects in this table apply to all Foundry devices.

Name, OID, and Syntax	Access	Description
snVlanByPortTable fdry.1.1.3.2.1	None	The VLAN by Port Information Table for Layer 2 switches.
snVlanByPortEntry fdry.1.1.3.2.1.1	None	An entry in the VLAN By Port Information table.
snVlanByPortVlanIndex fdry.1.1.3.2.1.1.1 Syntax: Integer	Read only	Shows the index to this table.  The VLAN ID number must not be greater than the value of the object “snVlanGroupVlanMaxEntry” on page 5-16. Each VLAN Identifier can be a member of multiple ports.

Name, OID, and Syntax	Access	Description
snVlanByPortVlanId fdry.1.1.3.2.1.1.2	Read-write	The VLAN ID index to the this table. Each VLAN Identifier can be a member of multiple ports.  Valid values: 1 – 4095.
snVlanByPortPortMask fdry.1.1.3.2.1.1.3 Syntax: PortMask	Read-write	Applies only to ServerIron stackable devices.  Shows the standalone switch VLAN port membership. This object was obsoleted for Chassis devices.
snVlanByPortQos fdry.1.1.3.2.1.1.4 Syntax: Integer	Read-write	Shows the QoS settings for the devices.  For Stackable device, the values can be one of the following: <ul style="list-style-type: none"> <li>• low(0) – low priority</li> <li>• high(1) – high priority</li> </ul> The Chassis devices, the value can be one of the following: <ul style="list-style-type: none"> <li>• level0(0)</li> <li>• level1(1)</li> <li>• level2(2)</li> <li>• level3(3)</li> <li>• level4(4)</li> <li>• level5(5)</li> <li>• level6(6)</li> <li>• level7(7)</li> </ul>
snVlanByPortStpMode fdry.1.1.3.2.1.1.5 Syntax: Integer	Read-write	Indicates whether or not Spanning Tree Protocol (STP) is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snVlanByPortStpPriority fdry.1.1.3.2.1.1.6 Syntax: Integer	Read-write	Shows the value of the dot1dStpPriority, which is the first two octets of the STP bridge ID. The STP bridge ID is eight octets long. This object contains the writable portion of the bridge ID.  The last six octets are contained in the dot1dBaseBridgeAddress of the object “snVlanByPortBaseBridgeAddress”.  Valid values: 1 – 65535.

Name, OID, and Syntax	Access	Description
snVlanByPortStpGroupMaxAge fdry.1.1.3.2.1.1.7 Syntax: Integer	Read-write	<p>Shows the value of dot1dStpBridgeMaxAge, which is the last six octets or the STP bridge ID. All bridges use this object for MaxAge when this bridge is acting as the root.</p> <p><b>NOTE:</b> 802.1D-1990 specifies that the range for this parameter is related to the value of dot1dStpBridgeHelloTime in the object “snVlanByPortStpGroupHelloTime” .</p> <p>The granularity of this timer is specified by 802.1D-1990 to be one second. An agent may return a badValue error if a set is attempted to a value which is not a whole number of seconds.</p> <p>(Refer to RFC 1493 Bridge MIB.)</p> <p>Valid values: 6 – 40.</p>
snVlanByPortStpGroupHelloTime fdry.1.1.3.2.1.1.8 Syntax: Integer	Read-write	<p>Shows the value of the dot1dStpBridgeHelloTime, which is the value used by all bridges HelloTime when this bridge is acting as the root.</p> <p>The granularity of this timer is specified by 802.1D-1990 to be one second. An agent may return a badValue error if a set is attempted to a value which is not a whole number of seconds.</p> <p>(Refer to RFC1493 Bridge MIB).</p> <p>Valid values: 1 – 10</p>
snVlanByPortStpGroupForwardDelay fdry.1.1.3.2.1.1.9 Syntax: Integer	Read-write	<p>Shows the value of dot1dStpBridgeForwardDelay, which is the value used by all bridges for ForwardDelay when this bridge is acting as the root.</p> <p><b>NOTE:</b> 802.1D-1990 specifies that the range for this parameter is related to the value of dot1dStpBridgeMaxAge, which is in the object “snVlanByPortStpGroupMaxAge”.</p> <p>The granularity of this timer is specified by 802.1D-1990 to be one second. An agent may return a badValue error if a set is attempted to a value which is not a whole number of seconds.</p> <p>(Refer to RFC1493 Bridge MIB).</p> <p>Valid values: 2 –30.</p>

Name, OID, and Syntax	Access	Description
snVlanByPortRowStatus fdry.1.1.3.2.1.1.10 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>• delete(3) – Delete the row</li> <li>• create(4) – Create a new row</li> <li>• modify(5) – Modify an existing row</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row</li> <li>• invalid(1) – Row is inoperative</li> <li>• valid(2) – Row exists and is valid</li> </ul>
snVlanByPortOperState fdry.1.1.3.2.1.1.11 Syntax: Integer	Read only	Activates the VLAN entry and sets it to running mode. <ul style="list-style-type: none"> <li>• notActivated(0) – The VLAN entry is not activated and not in running mode</li> <li>• activated(1) – The VLAN entry is activated and in running mode</li> </ul> Default: notActivated(0)
snVlanByPortBaseNumPorts fdry.1.1.3.2.1.1.12 Syntax: Integer	Read only	Indicates the number of ports controlled by this bridging entity.
snVlanByPortBaseType fdry.1.1.3.2.1.1.13 Syntax: Integer	Read only	Indicates what type of bridging this bridge can perform. If a bridge is actually performing a certain type of bridging this will be indicated by entries in the port table for the given type. <ul style="list-style-type: none"> <li>• unknown(1)</li> <li>• transparent-only(2)</li> <li>• sourceroute-only(3)</li> <li>• srt(4)</li> </ul>
snVlanByPortStpProtocolSpecific fdry.1.1.3.2.1.1.14 Syntax: Integer	Read only	Shows what version of STP is being run: <ul style="list-style-type: none"> <li>• unknown(1)</li> <li>• decLb100(2) – Indicates the DEC LANbridge 100 Spanning Tree protocol</li> <li>• ieee8021d(3) – Returns "ieee8021d(3)". If future versions of the IEEE Spanning Tree Protocol are released that are incompatible with the current version, a new value will be defined</li> </ul>



Name, OID, and Syntax	Access	Description
snVlanByPortStpMaxAge fdry.1.1.3.2.1.1.15 Syntax: Integer	Read only	Shows the value of dot1dStpMaxAge, which is the maximum age that the STP information can exist before it is discarded. The STP information is the information learned from the network. The value of this object is in hundredths of a second, and is the actual value that this bridge is currently using.  (Refer to RFC1493 Bridge MIB.)
snVlanByPortStpHelloTime fdry.1.1.3.2.1.1.16 Syntax: Timeout	Read only	Shows the value of dot1dStpHelloTime, which is the interval between the transmission of Configuration bridge PDUs by this node. This value applies to any port when it is the root of the spanning tree or is trying to become the root. This is the actual value that this bridge is currently using.  This value is in hundredths of a second.  (Refer to RFC1493 Bridge MIB.)
snVlanByPortStpHoldTime fdry.1.1.3.2.1.1.17 Syntax: Integer	Read only	Shows the value of dot1dStpHoldTime, which is the interval when no more than two Configuration bridge PDUs shall be transmitted by this node. The interval is in units of hundredths of a second.  (Refer to RFC1493 Bridge MIB.)
snVlanByPortStpForwardDelay fdry.1.1.3.2.1.1.18 Syntax: Timeout	Read only	Shows the value of dot1dStpForwardDelay, which is the time that controls how long a port stays in the listening and learning states as its spanning state moves towards the Forwarding state.  This value is also used when a topology change has been detected and is underway. The value is used to age all dynamic entries in the Forwarding Database.  This value is the one that this bridge is currently using, in contrast to dot1dStpBridgeForwardDelay in the object "snVlanByPortStpGroupForwardDelay", which is the value that this bridge and all others would start using when this bridge becomes the root.  This time value is in hundredths of a second,  (Refer to RFC1493 Bridge MIB.)
snVlanByPortStpTimeSinceTopologyChange fdry.1.1.3.2.1.1.19 Syntax: Time ticks	Read only	Shows the time since the last time the bridge detected a topology change. This time is in hundredths of a second.
snVlanByPortStpTopChanges fdry.1.1.3.2.1.1.20 Syntax: Counter	Read only	Shows the total number of topology changes detected by this bridge since the management entity was last reset or initialized.
snVlanByPortStpRootCost fdry.1.1.3.2.1.1.21 Syntax: Integer	Read only	Shows the value of dot1dStpRootCost, which is the cost of the path to the root as seen from this bridge.  (Refer to RFC1493 Bridge MIB.)

Name, OID, and Syntax	Access	Description
snVlanByPortStpRootPort fdry.1.1.3.2.1.1.22 Syntax: Integer	Read only	Shows the value of dot1dStpRootPort, which is the number of the port that offers the lowest cost path from this bridge to the root bridge. (Refer to RFC1493 Bridge MIB.)
snVlanByPortStpDesignatedRoot fdry.1.1.3.2.1.1.23 Syntax: Bridgeld	Read only	Shows the value of dot1dStpDesignatedRoot, which is the bridge ID of the root of the spanning tree as determined by STP as executed by this node. This value is used as the Root Identifier parameter in all Configuration Bridge PDUs originated by this node.  (Refer to RFC1493 Bridge MIB.)
snVlanByPortBaseBridgeAddresses fdry.1.1.3.2.1.1.24 Syntax: Bridgeld	Read only	Indicates the value of the dot1dBaseBridgeAddress, which is the MAC address used by this bridge when it must be referred to in a unique fashion.  It is recommended that this is the smallest MAC address of all ports that belong to this bridge; however it must be unique. When concatenated with dot1dStpPriority a unique Bridgeldentifier is formed which is used in the STP.
snVlanByPortVlanName fdry.1.1.3.2.1.1.25 Syntax: Display string	Read-write	Indicates the name of the community string that is allowed to access the VLAN.  Valid values: Up to 32 characters.
snVlanByPortRouterIntf fdry.1.1.3.2.1.1.26 Syntax: Integer	Read-write	Is optional and applies only to routers.  It shows the ID of the virtual interface of a router to the VLAN.  If an SNMP-Get value is zero, then this object was not configured.  Valid values: 1 – 60.
snVlanByPortChassisPortMask fdry.1.1.3.2.1.1.27 Syntax: Octet string	Read-write	Applies only to devices running Release 07.1.00 and earlier. It is replaced by “snVlanByPortPortList” for later releases.  It shows the VLAN switch port membership.  This object has 32 octets.
snVlanByPortPortList fdry.1.1.3.2.1.1.28 Syntax: Octet string	Read-write	Applies to all Foundry devices, except ServerIron products.  It lists the membership of a VLAN By Port. Each port index is a 16-bit integer in big endian order. The first 8-bit is the slot number, the other 8-bit is the port number.

## VLAN by Port Membership Table

The following table is the Port VLAN (Layer 2 VLAN) port membership table.

Name, OID, and Syntax	Access	Description
snVlanByPortMemberTable fdry.1.1.3.2.6	None	This table is used to create or delete a port VLAN (Layer 2 VLAN) entry.

Name, OID, and Syntax	Access	Description
snVlanByPortMemberEntry fdry.1.1.3.2.6.1	None	An entry in the Port VLAN Port Membership table.
snVlanByPortMemberVlanId fdry.1.1.3.2.6.1.1 Syntax: Integer	Read only	The VLAN identifier (VLAN ID). Valid values: 1 – 4095 VLAN IDs.
snVlanByPortMemberPortId fdry.1.1.3.2.6.1.2 Syntax: Integer	Read only	The ifIndex which is a member of the port VLAN.
snVlanByPortMemberRowStatus fdry.1.1.3.2.6.1.3 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>other(1) – Some other case</li> <li>valid(2) – Row exists and is valid</li> </ul>

**EXAMPLE:**

If you want to delete port 11/14 (untagged) from VLAN 1964, then add it to VLAN 104, enter the following lines:

```
/* 654=ifIndex of 11/14 (64*10+14), value 3=delete*/
SetRequest(snVlanByPortMemberRowStatus.1964.654=3)

/* 654=ifIndex of 11/14 (64*10+14), value 4=create*/
SetRequest(snVlanByPortMemberRowStatus.104.654=4)
```

The first line deletes port 11/14 from VLAN 1964. The second line adds port 11/14 to VLAN 104.

## Port VLAN Configuration Table

Name, OID, and Syntax	Access	Description
snVlanByPortCfgTable fdry.1.1.3.2.7	None	The Port VLAN (Layer 2 VLAN) configuration table.
snVlanByPortCfgEntry fdry.1.1.3.2.7.1	None	An entry of the port VLAN configuration table.

Name, OID, and Syntax	Access	Description
snVlanByPortCfgVlanId fdry.1.1.3.2.7.1.1 Syntax: Integer	Read-write	The VLAN ID index to this table. Each VLAN Identifier can be a member of multiple ports.  Valid values: 1 – 4095.
snVlanByPortCfgQos fdry.1.1.3.2.7.1.2 Syntax: Integer	Read-write	Shows the quality of service settings for the devices.  For Stackable device, the values can be one of the following: <ul style="list-style-type: none"> <li>• low(0) – low priority</li> <li>• high(1) – high priority</li> </ul> The Chassis devices, the value can be one of the following: <ul style="list-style-type: none"> <li>• level0(0)</li> <li>• level1(1)</li> <li>• level2(2)</li> <li>• level3(3)</li> <li>• level4(4)</li> <li>• level5(5)</li> <li>• level6(6)</li> <li>• level7(7)</li> </ul>
snVlanByPortCfgStpMode fdry.1.1.3.2.7.1.3 Syntax: Integer	Read-write	Indicates whether or not Spanning Tree Protocol (STP) is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> The following values are supported on FES, FWSX, and FastIron SuperX software releases 02.2.00 and later <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enableStp(1)</li> <li>• enableRstp(2)</li> </ul>
snVlanByPortCfgStpPriority fdry.1.1.3.2.7.1.4 Syntax: Integer	Read-write	Shows the value of the dot1dStpPriority, which is the first two octets of the STP or RSTP bridge ID. The STP and RSTP bridge ID are eight octets long. This object contains the the writable portion of the bridge ID.  The last six octets are contained in the dot1dBaseBridgeAddress of the object “snVlanByPortBaseBridgeAddress”.  Valid values: 1 – 65535.

Name, OID, and Syntax	Access	Description
snVlanByPortCfgStpGroupMaxAge fdry.1.1.3.2.7.1.5 Syntax: Integer	Read-write	Shows the value of dot1dStpBridgeMaxAge, which is the last six octets or the STP or RSTP bridge ID. All bridges use this object for MaxAge when this bridge is acting as the root.  <b>NOTE:</b> 802.1D-1990 specifies that the range for this parameter is related to the value of dot1dStpBridgeHelloTime in the object "snVlanByPortStpGroupHelloTime".  The granularity of this timer is specified by 802.1D-1990 to be one second. An agent may return a badValue error if a set is attempted to a value which is not a whole number of seconds.  (Refer to RFC 1493 Bridge MIB.) Valid values: 6 – 40.
snVlanByPortCfgStpGroupHelloTime fdry.1.1.3.2.7.1.6 Syntax: Integer	Read-write	Shows the value of the dot1dStpBridgeHelloTime, which is the value used by all bridges HelloTime when this bridge is acting as the root.  The granularity of this timer is specified by 802.1D-1990 to be one second. An agent may return a badValue error if a set is attempted to a value which is not a whole number of seconds.  (Refer to RFC1493 Bridge MIB). Valid values: 1 – 10
snVlanByPortCfgStpGroupForwardDelay fdry.1.1.3.2.7.1.7 Syntax: Integer	Read-write	Shows the value of dot1dStpBridgeForwardDelay, which is the value used by all bridges for ForwardDelay when this bridge is acting as the root.  <b>NOTE:</b> 802.1D-1990 specifies that the range for this parameter is related to the value of dot1dStpBridgeMaxAge, which is in the object "snVlanByPortStpGroupMaxAge".  The granularity of this timer is specified by 802.1D-1990 to be one second. An agent may return a badValue error if a set is attempted to a value which is not a whole number of seconds.  (Refer to RFC1493 Bridge MIB). Valid values: 2 – 30.
snVlanByPortCfgBaseNumPorts fdry.1.1.3.2.7.1.8 Syntax: Integer	Read only	The number of ports controlled by this bridging entity.

Name, OID, and Syntax	Access	Description
snVlanByPortCfgBaseType fdry.1.1.3.2.7.1.9 Syntax: Integer	Read only	Indicates what type of bridging this bridge can perform. If a bridge is actually performing a certain type of bridging this will be indicated by entries in the port table for the given type. <ul style="list-style-type: none"> <li>• unknown(1)</li> <li>• transparent-only(2)</li> <li>• sourceroute-only(3)</li> <li>• srt(4)</li> </ul>
snVlanByPortCfgStpProtocolSpecification fdry.1.1.3.2.7.1.10 Syntax: Integer	Read only	Shows what version of STP is being run: <ul style="list-style-type: none"> <li>• unknown(1)</li> <li>• decLb100(2) – Indicates the DEC LANbridge 100 Spanning Tree protocol</li> <li>• ieee8021d(3) – Return "ieee8021d(3)". If future versions of the IEEE Spanning Tree Protocol are released that are incompatible with the current version, a new value will be defined</li> </ul>
snVlanByPortCfgStpMaxAge fdry.1.1.3.2.7.1.11 Syntax: Integer	Read only	Shows the value of dot1dStpMaxAge, which is the maximum age that the STP information can exist before it is discarded. The STP information is the information learned from the network. The value of this object is in hundredths of a second, and is the actual value that this bridge is currently using.  (Refer to RFC1493 Bridge MIB.)
snVlanByPortCfgStpHelloTime fdry.1.1.3.2.7.1.12 Syntax: Timeout	Read only	Shows the value of dot1dStpHelloTime, which is the interval between the transmission of Configuration bridge PDUs by this node. This value applies to any port when it is the root of the spanning tree or is trying to become the root. This is the actual value that this bridge is currently using.  This value is in hundredths of a second.  (Refer to RFC1493 Bridge MIB.)
snVlanByPortCfgStpHoldTime fdry.1.1.3.2.7.1.13 Syntax: Integer	Read only	Shows the value of dot1dStpHoldTime, which is the interval when no more than two Configuration bridge PDUs shall be transmitted by this node. The interval is in units of hundredths of a second.  (Refer to RFC1493 Bridge MIB.)

Name, OID, and Syntax	Access	Description
snVlanByPortCfgStpForwardDelay fdry.1.1.3.2.7.1.14 Syntax: Timeout	Read only	Shows the value of dot1dStpForwardDelay, which controls how fast a port changes its spanning state when moving towards the forwarding state. The value determines how long the port stays in each of the listening and learning states, which precede the forwarding state. This value is also used, when a topology change has been detected and is underway, to age all dynamic entries in the forwarding database.  <b>NOTE:</b> This value is the one that this bridge is currently using in contrast to dot1dStpBridgeForwardDelay, which is the value that this bridge and all others would start using when this bridge were to become the root.  This time value is measured in hundredths of a second.  (Refer to RFC1493 Bridge MIB.)
snVlanByPortCfgStpTimeSinceTopologyChange fdry.1.1.3.2.7.1.15 Syntax: Time ticks	Read only	Shows the time since the last time a topology change was detected by the bridge entity. This time is in hundredths of a second.
snVlanByPortCfgStpTopChanges fdry.1.1.3.2.7.1.16 Syntax: Counter	Read only	Shows the total number of topology changes detected by this bridge since the management entity was last reset or initialized.
snVlanByPortCfgStpRootCost fdry.1.1.3.2.7.1.17 Syntax: Integer	Read only	Shows the value of dot1dStpRootCost, which is the cost of the path to the root as seen from this bridge.  (Refer to RFC1493 Bridge MIB.)
snVlanByPortCfgStpRootPort fdry.1.1.3.2.7.1.18 Syntax: Integer	Read only	Shows the value of dot1dStpRootPort, which is the port number of the port which offers the lowest cost path from this bridge to the root bridge.  (Refer to RFC1493 Bridge MIB.)
snVlanByPortCfgStpDesignatedRoot fdry.1.1.3.2.7.1.19 Syntax: Bridgeld	Read only	Shows the dot1dStpDesignatedRoot, which is the bridge identifier of the root of the spanning tree as determined by the Spanning Tree Protocol as executed by this node. This value is used as the root identifier parameter in all configuration bridge PDUs originated by this node.  (Refer to RFC1493 Bridge MIB.)
snVlanByPortCfgBaseBridgeAddress fdry.1.1.3.2.7.1.20 Syntax: MAC address	Read only	Shows the MAC address used by this bridge when it must be referred to in a unique fashion. It is recommended that this be the numerically smallest MAC address of all ports that belong to this bridge.; however, it is only required to be unique. When concatenated with dot1dStpPriority a unique bridge identifier is formed which is used in the Spanning Tree Protocol.
snVlanByPortCfgVlanName fdry.1.1.3.2.7.1.21 Syntax: Display string	Read-write	Shows the name of the VLAN community string.  Valid values: Up to 32 characters.

Name, OID, and Syntax	Access	Description
snVlanByPortCfgRouterIntf fdry.1.1.3.2.7.1.22 Syntax: Integer	Read-write	This object is optional. It identifies the virtual interface for the router to the VLAN, and applies only to the router. If an SNMP-Get value is zero, that means this object was not configured.
snVlanByPortCfgRowStatus fdry.1.1.3.2.7.1.23 Syntax: Integer	Read-write	Determines whether or not the VLAN will be deleted: <ul style="list-style-type: none"> <li>other(1)</li> <li>valid(2)</li> <li>delete(3)</li> </ul>
snVlanByPortCfgStpVersion fdry.1.1.3.2.7.1.24 Syntax: Integer Supported on FES, FWSX, and FastIron SuperX software releases 02.2.00 and later	Read-write	Shows the version of Spanning Tree Protocol the bridge is currently running. <ul style="list-style-type: none"> <li>stpCompatible(0) – STP (IEEE 802.1D)</li> <li>rstp(2) – RSTP (IEEE 802.1w)</li> </ul>

## VLAN by Protocol Configuration Table

The following table applies to protocol VLANs. Unless otherwise specified in the description for an object, all objects in the table applies to all Foundry devices.

Name, OID, and Syntax	Access	Description
snVlanByProtocolTable fdry.1.1.3.2.2	None	The VLAN by Protocol Configuration Table.
snVlanByProtocolEntry fdry.1.1.3.2.2.1	None	An entry in the VLAN By Protocol Configuration Table.
snVlanByProtocolVlanId fdry.1.1.3.2.2.1.1	Read only	Shows the VLAN ID index to both the VLAN By Port Info Table and this table.
snVlanByProtocolIndex fdry.1.1.3.2.2.1.2 Syntax: Integer	Read only	Shows the protocol used by this VLAN.  The following IP/IPX protocols are used by VLANs in Layer 3 VLAN: <ul style="list-style-type: none"> <li>IP(1)</li> <li>IPX(2)</li> </ul> The following protocols are used in Layer 2 bridging: <ul style="list-style-type: none"> <li>appleTalk(3)</li> <li>decNet(4)</li> <li>netBios(5)</li> <li>others(6) – other protocols which are defined here.</li> </ul>



Name, OID, and Syntax	Access	Description
snVlanByProtocolDynamic fdry.1.1.3.2.2.1.3 Syntax: Integer	Read-write	Applies to only to switches. Indicates whether or not dynamic port inclusion is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snVlanByProtocolStaticMask fdry.1.1.3.2.2.1.4 Syntax: PortMask	Read-write	Applies to ServerIron stackable devices. It indicates the Standalone switch Protocol VLAN port membership (portmask) applied in static mode.
snVlanByProtocolExcludeMask fdry.1.1.3.2.2.1.5 Syntax: PortMask	Read-write	Applies to ServerIron stackable devices. It indicates the Standalone switch Protocol VLAN port membership (portmask) applied in exclusive mode.
snVlanByProtocolRouterIntf fdry.1.1.3.2.2.1.6 Syntax: Integer	Read-write	Applies to routers only and is optional. It shows the virtual interface of a router to the VLAN This object is not configured if an SNMP-Get is equal to zero
snVlanByProtocolRowStatus fdry.1.1.3.2.2.1.7 Syntax: Integer	Read-write	Applies to all Foundry devices, except for ServerIron products. Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snVlanByProtocolDynamicMask fdry.1.1.3.2.2.1.8 Syntax: PortMask	Read only	Applies only to stackable ServerIron products. It shows the portmask, which is the Standalone switch Protocol VLAN active port membership. This object was obsoleted for Chassis devices.
snVlanByProtocolChassisStaticMask fdry.1.1.3.2.2.1.9 Syntax: Octet string	Read-write	Applies to all Foundry devices, except for ServerIron products. This object has 32 octets. It has been obsoleted after Release 07.1.00 and replaced by the object "snVlanByProtocolStaticPortList". For Release 07.1.00 and earlier, this object shows the Chassis Protocol VLAN port membership applied in static mode.

Name, OID, and Syntax	Access	Description
snVlanByProtocolChassisExcludeMask fdry.1.1.3.2.2.1.10 Syntax: Octet string	Read-write	Applies to all Foundry devices, except for ServerIron products. This object has 32 octets. It has been obsoleted after Release 07.1.00 and replaced by the object "snVlanByProtocolExcludePortList". For Release 07.1.00 and earlier, this object shows the Chassis Protocol VLAN port membership applied in exclusive mode.
snVlanByProtocolChassisDynamicMask fdry.1.1.3.2.2.1.11 Syntax: Octet string	Read-write	Applies to all Foundry devices, except for ServerIron products. This object has 32 octets. It has been obsoleted after Release 07.1.00 and replaced by the object "snVlanByProtocolDynamicPortList". For Release 07.1.00 and earlier, this object shows the Chassis Protocol VLAN active port membership.
snVlanByProtocolVlanName fdry.1.1.3.2.2.1.12 Syntax: Display string	Read-write	Shows the name of the community string that is allowed to access the VLAN. Valid values: Up to 32 characters.
snVlanByProtocolStaticPortList fdry.1.1.3.2.2.1.13 Syntax: Octet string	Read-write	Applies to all Foundry devices, except for ServerIron products. This object is an index of ports that are the configured to be members of the Protocol VLAN. Each port index is a 16-bit integer in big endian order. The first 8-bits show the slot number; the other 8-bit form the port number.
snVlanByProtocolExcludePortList fdry.1.1.3.2.2.1.14 Syntax: Octet string	Read-write	Applies to all Foundry devices, except for ServerIron products. This object is an index of ports that are excluded from port membership of the Protocol VLAN. Each port index is a 16-bit integer in big endian order. The first 8-bits show the slot number; the other 8-bit form the port number.
snVlanByProtocolDynamicPortList fdry.1.1.3.2.2.1.15 Syntax: Octet string	Read only	Applies to all Foundry devices, except for ServerIron products. This object is an index of ports that can dynamically join the port membership of the Protocol VLAN. Each port index is a 16-bit integer in big endian order. The first 8-bits show the slot number; the other 8-bit form the port number.

## VLAN by IP Subnet Configuration Table

The following table applies to protocol VLANs that use the IP routing protocol. Unless otherwise stated in the object description, all objects in this table apply to all Foundry devices.

The remaining objects for IP are presented in the chapter "Global Router and IP" on page 13-1.

Name, OID, and Syntax	Access	Description
snVlanByIpSubnetTable fdry.1.1.3.2.3	None	The VLAN by IP Subnet Configuration Table.

Name, OID, and Syntax	Access	Description
snVlanByIpSubnetEntry fdry.1.1.3.2.3.1	None	An entry in the VLAN By IP Subnet Configuration table.
snVlanByIpSubnetVlanId fdry.1.1.3.2.3.1.1 Syntax: Integer	Read only	Shows the VLAN ID index to both of the VLAN By Port Info Table and this table. Valid values: 1 – 4095.
snVlanByIpSubnetIpAddress fdry.1.1.3.2.3.1.2 Syntax: IpAddress	Read only	Shows the IP address for the subnet of the protocol-based IP VLAN.
snVlanByIpSubnetSubnetMask fdry.1.1.3.2.3.1.3 Syntax: IpAddress	Read only	Subnet mask associated with the subnet IP address.
snVlanByIpSubnetDynamic fdry.1.1.3.2.3.1.4 Syntax: Integer	Read-write	Applies only to switches. Indicates whether or not dynamic port inclusion is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snVlanByIpSubnetStaticMask fdry.1.1.3.2.3.1.5 Syntax: PortMask	Read-write	Applies only to stackable ServerIron products. It shows the port membership of the standalone switch VLAN by Subnet in static mode.
snVlanByIpSubnetExcludeMask fdry.1.1.3.2.3.1.6 Syntax: PortMask	Read-write	Applies only to stackable ServerIron products. It shows the port membership of the standalone switch VLAN by Subnet in exclusive mode.
snVlanByIpSubnetRouterIntf fdry.1.1.3.2.3.1.7 Syntax: Integer	Read-write	Applies only to routers and is optional. It shows the virtual interface of a router to the VLAN. Valid values: 0 – 60. It is not configured if an SNMP-Get is equal to zero.
snVlanByIpSubnetRowStatus fdry.1.1.3.2.3.1.8 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

Name, OID, and Syntax	Access	Description
snVlanByIpSubnetDynamicMask fdry.1.1.3.2.3.1.9 Syntax: PortMask	Read only	Applies only to ServerIron stackable products.  It shows the standalone switch VLAN by Subnet active port membership.
snVlanByIpSubnetChassisStaticMask fdry.1.1.3.2.3.1.10 Syntax: Octet string	Read-write	Applies to all Foundry devices, except ServerIron products, running Release 07.1.00. This object has 32 octets.  It is replaced by the object “snVlanByIpSubnetStaticPortList” in later releases.  It shows the chassis VLAN by Subnet port membership applied in static mode.
snVlanByIpSubnetChassisExcludeMask fdry.1.1.3.2.3.1.11 Syntax: Octet string	Read-write	Applies to all Foundry devices, except ServerIron products, running Release 07.1.00. This object has 32 octets.  It is replaced by the object “snVlanByIpSubnetExcludePortList” in later releases.  It shows the chassis VLAN by Subnet port membership applied in exclusive mode.
snVlanByIpSubnetChassisDynamicMask fdry.1.1.3.2.3.1.12 Syntax: Octet string	Read-write	Applies to all Foundry devices, except ServerIron products, running Release 07.1.00. This object has 32 octets.  It is replaced by the object “snVlanByIpSubnetDynamicPortList” in later releases.  It shows the chassis VLAN by Subnet port membership applied in exclusive mode.
snVlanByIpSubnetVlanName fdry.1.1.3.2.3.1.13 Syntax: Display string	Read-write	Shows the name of the community string that is allowed to access the VLAN.  Valid values: Up to 32 characters.
snVlanByIpSubnetStaticPortList fdry.1.1.3.2.3.1.14 Syntax: Octet string	Read-write	Applies to all Foundry devices, except for ServerIron products.  This object is an index of ports that are the configured to be members of the VLAN by IP Subnet. Each port index is a 16-bit integer in big endian order. The first 8-bits show the slot number; the other 8-bit form the port number.
snVlanByIpSubnetExcludePortList fdry.1.1.3.2.3.1.15 Syntax: Octet string	Read-write	Applies to all Foundry devices, except for ServerIron products.  This object is an index of ports that are excluded from port membership of the VLAN by IP Subnet. Each port index is a 16-bit integer in big endian order. The first 8-bits show the slot number; the other 8-bit form the port number.
snVlanByIpSubnetDynamicPortList fdry.1.1.3.2.3.1.16 Syntax: Octet string	Read only	Applies to all Foundry devices, except for ServerIron products.  This object is an index of ports that can dynamically join the port membership of the VLAN By IP Subnet. Each port index is a 16-bit integer in big endian order. The first 8-bits show the slot number; the other 8-bit form the port number.

## VLAN by IPX Network Configuration Table

The following table applies to protocol VLANs that use the IPX routing protocol. Unless otherwise stated in the object description, all objects in this table apply to all Foundry devices.

The remaining objects for IP are presented in the chapter “IPX” on page 17-1.

Name, OID, and Syntax	Access	Description
snVlanByIpxNetTable fdry.1.1.3.2.4	None	An entry of the VLAN By IPX Network Number Table.
snVlanByIpxNetEntry fdry.1.1.3.2.4.1	None	An entry in the VLAN by IPX Network Configuration table.
snVlanByIpxNetVlanId fdry.1.1.3.2.4.1.1 Syntax: Integer	Read only	The VLAN ID index to both of the VLAN By Port Info Table and this table. Valid values: 1 – 4095.
snVlanByIpxNetNetworkNum fdry.1.1.3.2.4.1.2 Syntax: Octet string	Read only	Shows the IPX Network Number. This object has four octets.
snVlanByIpxNetFrameType fdry.1.1.3.2.4.1.3 Syntax: Integer	Read only	Shows the frame type for the Layer 3 VLAN: <ul style="list-style-type: none"> <li>notApplicable(0) – If none of the options below is selected.</li> <li>ipxEthernet8022(1)</li> <li>ipxEthernet8023(2)</li> <li>ipxEthernetII(3)</li> <li>ipxEthernetSnap(4)</li> </ul> Each IPX Network Number must be assigned with one unique Frame type; otherwise an SNMP-SET error will be returned.
snVlanByIpxNetDynamic fdry.1.1.3.2.4.1.4 Syntax: Integer	Read-write	Applies only to switches. It indicates whether or not dynamic port inclusion is enabled. <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snVlanByIpxNetStaticMask fdry.1.1.3.2.4.1.5 Syntax: PortMask	Read-write	Applies only to stackable ServerIron products. It shows the VLAN by IPX network port membership applied in static mode.
snVlanByIpxNetExcludeMask fdry.1.1.3.2.4.1.6 Syntax: PortMask	Read-write	Applies only to stackable ServerIron products. It shows the VLAN by IPX network port membership applied in exclusive mode.

Name, OID, and Syntax	Access	Description
<p>snVlanByIpxNetRouterIntf fdry.1.1.3.2.4.1.7 Syntax: Integer</p>	<p>Read-write</p>	<p>Applies only to routers and is optional. It shows the virtual interface of a router to the VLAN. Valid values: 0 – 60; however, if this object is not configured if an SNMP-Get is equal to zero.</p>
<p>snVlanByIpxNetRowStatus fdry.1.1.3.2.4.1.8 Syntax: Integer</p>	<p>Read-write</p>	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>• delete(3) – Delete the row</li> <li>• create(4) – Create a new row</li> <li>• modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row</li> <li>• invalid(1) – Row is inoperative</li> <li>• valid(2) – Row exists and is valid</li> </ul>
<p>snVlanByIpxNetDynamicMask fdry.1.1.3.2.4.1.9 Syntax: PortMask</p>	<p>Read only</p>	<p>Applies only to stackable ServerIron products. It shows the VLAN By IPX network active port membership.</p>
<p>snVlanByIpxNetChassisStaticMask fdry.1.1.3.2.4.1.10 Syntax: Octet string</p>	<p>Read-write</p>	<p>Applies to all Foundry devices running Release 07.1.00 and earlier, except for ServerIron products. This object has 32 octets. It is replaced by snVlanByIpxNetStaticPortList in later releases. It shows the chassis VLAN by IPX network port membership applied in static mode.</p>
<p>snVlanByIpxNetChassisExcludeMask fdry.1.1.3.2.4.1.11 Syntax: Octet string</p>	<p>Read-write</p>	<p>Applies to all Foundry devices running Release 07.1.00 and earlier, except for ServerIron products. This object has 32 octets. It is replaced by snVlanByIpxNetExcludePortList in later releases. It shows the chassis VLAN by IPX network port membership applied in exclusive mode.</p>
<p>snVlanByIpxNetChassisDynamicMask fdry.1.1.3.2.4.1.12 Syntax: Octet string</p>	<p>Read only</p>	<p>Applies to all Foundry devices running Release 07.1.00 and earlier, except for ServerIron products. This object has 32 octets. It is replaced by snVlanByIpxNetDynamicPortList in later releases. It shows the chassis VLAN by IPX network port membership.</p>

Name, OID, and Syntax	Access	Description
snVlanByIpxNetVlanName fdry.1.1.3.2.4.1.13 Syntax: Display string	Read-write	Applies to all Foundry devices except for ServerIron products. It shows the name of the community string that can access this VLAN. Valid values: Up to 32 characters.
snVlanByIpxNetStaticPortList fdry.1.1.3.2.4.1.14 Syntax: Octet string	Read-write	Applies to all Foundry devices, except ServerIron products. It lists the membership of a VLAN By IPX network. Each port index is a 16-bit integer in big endian order. The first 8-bit is the slot number, the other 8-bit is the port number.
snVlanByIpxNetExcludePortList fdry.1.1.3.2.4.1.15 Syntax: Octet string	Read-write	Applies to all Foundry devices, except ServerIron products. It lists the ports that are excluded from the VLAN by IPX network membership. Each port index is a 16-bit integer in big endian order. The first 8-bit is the slot number, the other 8-bit is the port number.
snVlanByIpxNetDynamicPortList fdry.1.1.3.2.4.1.16 Syntax: Octet string	Read only	Applies to all Foundry devices, except ServerIron products. It lists the ports that can dynamically join the membership of the VLAN by IPX network. Each port index is a 16-bit integer in big endian order. 8-bit is the slot number, the other 8-bit is the port number.

## VLAN by AppleTalk Cable Configuration Table

The following table applies to protocol VLANs that use AppleTalk the routing protocol. Objects in this table apply to all Foundry devices, except ServerIron products.

The remaining objects for IP are presented in the chapter “AppleTalk” on page 18-1.

Name, OID, and Syntax	Access	Description
snVlanByATCableTable fdry.1.1.3.2.5	None	A table Of VLAN by AppleTalk Network Number.
snVlanByATCableEntry fdry.1.1.3.2.5.1	None	An entry of the AppleTalk Cable VLAN table.
snVlanByATCableVlanId fdry.1.1.3.2.5.1.1 Syntax: Integer	Read only	The VLAN ID of a port VLAN to which the AppleTalk Cable VLAN attaches. Valid values: 1 – 4095.
snVlanByATCableIndex fdry.1.1.3.2.5.1.2 Syntax: Integer	Read only	AppleTalk Cable VLAN index number.

Name, OID, and Syntax	Access	Description
snVlanByATCableRouterIntf fdry.1.1.3.2.5.1.3 Syntax: Integer	Read-write	It shows the virtual interface of a router to the AppleTalk CABLE VLAN  Valid values: 0 – 60; however, an SNMP-Get will equal to zero if this object is not configured. Only router products accept the SNMP-SET operation.
snVlanByATCableRowStatus fdry.1.1.3.2.5.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>• delete(3) – Delete the row</li> <li>• create(4) – Create a new row</li> <li>• modify(5) – Modify an existing row</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.  The following values can be returned on reads: <ul style="list-style-type: none"> <li>• noSuch(0) – No such row</li> <li>• invalid(1) – Row is inoperative</li> <li>• valid(2) – Row exists and is valid</li> </ul>
snVlanByATCableChassisStaticMask fdry.1.1.3.2.5.1.5 Syntax: Octet string	Read-write	Applies only to Foundry devices running Release 07.1.00 and earlier. It is replaced in earlier releases by the object snVlanByATCableStaticPortList.  Shows a list of ports that are statically configured to become port members of a VLAN.  It has 32 octets.
snVlanByATCableVlanName fdry.1.1.3.2.5.1.6 Syntax: Display string	Read-write	Shows the community string that can access this VLAN.  Valid values: Up to 32 characters.
snVlanByATCableStaticPortList fdry.1.1.3.2.5.1.7 Syntax: Octet string	Read-write	Shows a list of port indices that configured to be membership of the AppleTalk Cable VLAN. Each port index is a 16-bit integer in big endian order. The first 8-bits contain the slot number, the other 8-bits contain the port number.



---

# Chapter 12

## Router Redundancy Protocols

The objects in this chapter are for the following protocols:

- Foundry Standby Routing Protocol (FSRP) allows alternate paths to be provided to a host using a virtual router. FSRP is a proprietary router redundancy protocol that was available in Foundry devices before the other router redundancy protocols. The protocol has been retired in B2R flash images, starting with IronWare release 07.6.01. (Refer to “FSRP Objects” on page 12-1.)
- Virtual Router Redundancy Protocol (VRRP) is a standard router redundancy protocol described in RFC 2338. VRRP is a protocol that provides redundancy to routers within a LAN. VRRP allows you to provide alternate router paths for a host without changing the IP address or MAC address by which the host knows its gateway. The VRRP feature is available in Foundry Layer 3 Switches. (Refer to the sections “VRRP Global Variables” on page 12-4, “VRRP Interface Tables” on page 12-5, and “VRRP Virtual Router Parameters Tables” on page 12-7.)
- VRRP Extended (VRRPE) is an enhanced version of VRRP that overcomes limitations in the standard protocol. The VRRPE feature is also available in Foundry Layer 3 Switches. (Refer to the sections “VRRP Global Variables” on page 12-4, “VRRP Interface Tables” on page 12-5, and “VRRP Virtual Router Parameters Tables” on page 12-7.)
- Virtual Switch Redundancy Protocol (VSRP), which is a Foundry proprietary protocol that provides redundancy and sub-second failover in Layer 2 and Layer 3 mesh topologies. Based on the Foundry Virtual Router Redundancy Protocol Extended (VRRPE), VSRP provides one or more backups for a Layer 2 Switch or Layer 3 Switch. If the active Layer 2 Switch or Layer 3 Switch becomes unavailable, one of the backups takes over as the active device and continues forwarding traffic for the network. (Refer to “VSRP” on page 12-18.)

---

**NOTE:** VRRP, VRRPE, and VSRP are separate protocols. You cannot use them together.

---

This chapter presents the objects for the protocols. Traps for FSRP and VRRP are discussed in the section “Traps and Objects to Enable Traps” on page 23-1.

Refer to the *Foundry Enterprise Configuration and Management Guide* for details on the features discussed in this chapter.

### FSRP Objects

The Foundry Standby Routing Protocol (FSRP) allows alternate paths to be provided to a host. To provide path redundancy between given hosts, a virtual router is created. To create a virtual router, unique IP addresses are assigned to ports on existing routers in the network—routers that could provide a path between the given hosts.

For more information on FSRP, refer to the *Foundry Enterprise Configuration and Management Guide*. This chapter presents the objects for FSRP. They are available in Foundry devices that support. You must determine if you device supports FSRP before using the MIB objects for FSRP traps.

For objects referring to FSRP traps, refer to the chapter “Traps and Objects to Enable Traps” on page 23-1.

This section presents the following objects:

- “FSRP Global Variables” on page 12-2
- “FSRP Interface Table” on page 12-2

## FSRP Global Variables

The following object applies to all FSRP interfaces.

Name, OID, and Syntax	Access	Description
snFsrpGroupOperMode fdry.1.2.7.1.1 Syntax: Integer	Read-write	Indicates if FSRP is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> <p><b>NOTE:</b> Do not enable both FSRP and VRRP. Foundry Networks recommends that you use only one of these router redundancy protocols on a Layer 3 Switch. Default: disabled(0)</p>

## FSRP Interface Table

The FSRP Interface Table describes the configuration of FSRP interfaces.

Name, OID, and Syntax	Access	Description
snFsrplfTable fdry.1.2.7.2.1	None	The FSRP Interface Table.
snFsrplfEntry fdry.1.2.7.2.1.1	None	An entry in the FSRP Interface Table.
snFsrplfPort fdry.1.2.7.2.1.1.1 Syntax: Integer	Read only	Identifies the physical router port number of this FSRP interface.
snFsrplfIpAddress fdry.1.2.7.2.1.1.2 Syntax: IpAddress	Read only	Identifies the IP address of the physical router port of this interface.
snFsrplfVirRtrIpAddr fdry.1.2.7.2.1.1.3 Syntax: IpAddress	Read-write	Identifies the IP address of the virtual router for the interface. The Virtual Router IP address needs to be configured on the interface before the Redundant Router Function can operate on the interface. This address has to be same on all the routers that are going to participate in the Redundant Router Function on a given subnet.

Name, OID, and Syntax	Access	Description
snFsrplfOtherRtrIpAddr fdry.1.2.7.2.1.1.4 Syntax: IpAddress	Read-write	Identifies the IP address of the other router on this IP subnet. The other router is the router that operates FSRP and to which the keep alive message needs to be sent by this router. This object must be configured in order for FSRP to work correctly
snFsrplfPreferLevel fdry.1.2.7.2.1.1.5 Syntax: Integer	Read-write	Decides which router should become the active router for the interface. The active router is the one with the higher priority. A higher number indicates a higher priority.  Valid values: 1 – 255  Default: 100
snFsrplfTrackPortMask  Syntax: PortMask	Read-write	This object is not supported in Foundry devices.
snFsrplfRowStatus fdry.1.2.7.2.1.1.7 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snFsrplfState fdry.1.2.7.2.1.1.8 Syntax: Integer	Read only	Specifies the state of the FSRP Router interface: <ul style="list-style-type: none"> <li>init(0) – initialization state</li> <li>negotiating(1) – negotiating state</li> <li>standby(2) – standby state</li> <li>active(3) – active state</li> </ul>
snFsrplfKeepAliveTime fdry.1.2.7.2.1.1.9 Syntax: Integer	Read-write	Defines the heartbeat of the interface.  Valid values: 1 – 120 seconds.  Default: 3 seconds
snFsrplfRouterDeadTime fdry.1.2.7.2.1.1.10 Syntax: Integer	Read-write	Defines the hold time of the FSRP router.  Valid values: 3 – 255 seconds  Default: nine seconds

Name, OID, and Syntax	Access	Description
snFsrplfChassisTrackPortMask fdry.1.2.7.2.1.1.11 Syntax: Octet string	Read-write	<p>Applies only to chassis products running Release 07.1.00 software.</p> <p>This object is replaced by the “snFsrplfTrackPortList” object in later releases.</p> <p>For chassis products running Release 07.1.00, this object shows the chassis router FSRP Track port membership.</p> <p>It specifies the identity of the physical port whose state is to be monitored. Each bit is a port of the system.</p> <p>Valid values: Up to 32 octets</p> <p>Default: 0</p> <p>If this object is configured, then the preference level of this interface will be adjusted dynamically, depending on the state of the track port. The preference level is configured in the “snFsrplfPreferLevel” object. The interface’s preference level is reduced by the value of the preference level parameter when the track port states first changes from UP to DOWN. When the track port comes up, the interface’s preference level is increased by the amount specified by the preference level.</p>
snFsrplfTrackPortList fdry.1.2.7.2.1.1.12 Syntax: Octet string	Read-write	<p>Shows the router FSRP physical track port membership.</p> <p>It specifies the identity of the physical port whose state is to be monitored. Each port index is a 16-bit integer in big endian order. 8-bit is the slot number, the other 8-bit is the port number.</p> <p>Default: 0 length octet string</p> <p>If this object is configured, then the preference level of this interface will be adjusted dynamically, depending on the state of the track port. The preference level is configured in the “snFsrplfPreferLevel” object. The interface’s preference level is reduced by the value of the preference level parameter when the track port states first changes from UP to DOWN. When the track port comes up, the interface’s preference level is increased by the amount specified by the preference level.</p>

## VRRP Global Variables

The following table contains the global objects that applies to VRRP, VRRPE, and VSRP protocol.

Name, OID, and Syntax	Access	Description
snVrrpGroupOperMode fdry.1.2.12.1.1 Syntax: Integer	Read-write	<p>Indicates if VRRP is enabled for this system:</p> <ul style="list-style-type: none"> <li>disabled(0) – Disable VRRP</li> <li>enabled(1) – Activate VRRP</li> </ul> <p>Default: disabled(0)</p>

Name, OID, and Syntax	Access	Description
snVrrplfMaxNumVridPerIntf fdry.1.2.12.1.3 Syntax: Integer	Read only	Indicates the maximum number of Virtual Router ID (VRID) that can be configured per interface.
snVrrplfMaxNumVridPerSystem fdry.1.2.12.1.4 Syntax: Integer	Read only	Indicates the maximum number of VRID per system.
snVrrpClearVrrpStat fdry.1.2.12.1.5 Syntax: Integer	Read-write	Indicates if the system has been configured to clear VRRP statistics: <ul style="list-style-type: none"> <li>normal(0)</li> <li>clear(1)</li> </ul>
snVrrpGroupOperModeVrrpextended fdry.1.2.12.1.6 Syntax: Integer	Read-write	Indicates if VRRP extended (VRRPE) protocol is enabled on this device: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0).

## VRRP Interface Tables

This section presents:

- “VRRP Interface Table” on page 12-5
- “VRRP and VRRPE Interface Table 2” on page 12-6

### VRRP Interface Table

The objects in this section apply to VRRP, VRRPE, and VSRP, depending on which protocol is enabled in the device. This table has been replaced by the “snVrrplf2Table” table, which is presented in the “VRRP and VRRPE Interface Table 2” on page 12-6

This table has been deprecated.

Name, OID, and Syntax	Access	Description
snVrrplfTable fdry.1.2.12.2.1	None	The VRRP Interface Table.
snVrrplfEntry fdry.1.2.12.2.1.1	None	An entry in the VRRP Interface Table.
snVrrplfPort fdry.1.2.12.2.1.1.1 snVrrplfPort	Read only	Shows the IP port of this VRRP interface.

Name, OID, and Syntax	Access	Description
snVrrplfAuthType fdry.1.2.12.2.1.1.2 snVrrplfPort	Read-write	Indicates the authentication type of this interface. <ul style="list-style-type: none"> <li>noAuth(0)</li> <li>simpleTextPasswd(1)</li> <li>ipAuthHeader(2)</li> </ul>
snVrrplfAuthPassword fdry.1.2.12.2.1.1.3 Syntax: Octet string	Read-write	Shows the simple text password for this interface. You can use a simple text password if the object "snVrrplfAuthType" object is set to simpleTextPasswd(1).
snVrrplfRxHeaderErrCnts fdry.1.2.12.2.1.1.4 Syntax: Counter	Read only	Shows the number of VRRP or VRRPE packets received by the interface that had a header error.
snVrrplfRxAuthTypeErrCnts fdry.1.2.12.2.1.1.5 Syntax: Counter	Read only	Shows the number of VRRP or VRRPE packets received by the interface that had an authentication error.
snVrrplfRxAuthPwdMismatchErrCnts fdry.1.2.12.2.1.1.6 Syntax: Counter	Read only	Shows the number of VRRP or VRRPE packets received by the interface that had a password value that does not match the password used by the interface for authentication.
snVrrplfRxVridErrCnts fdry.1.2.12.2.1.1.7 Syntax: Counter	Read only	Shows the number of VRRP or VRRPE packets received by the interface that contained a VRID that is not configured on this interface.

## VRRP and VRRPE Interface Table 2

The following table replaces the "snVrrplfTable" (presented in the section "VRRP Interface Table" on page 12-5), which uses the slot/port number to index an entry. This new table uses the ifindex to present the configuration and statistics of VRRP and VRRPE interfaces. Each entry in the table describes one VRRP or VRRPE interface.

Name, OID, and Syntax	Access	Description
snVrrplf2Table fdry.1.2.12.4.1	None	The VRRP and VRRPE table 2 for interfaces, using the ifindex
snVrrplf2Entry fdry.1.2.12.4.1.1	None	An entry in the table
snVrrplf2AuthType fdry.1.2.12.4.1.1.1 Syntax: Integer	Read-write	The authentication type of the interface: <ul style="list-style-type: none"> <li>noAuth(0)</li> <li>simpleTextPasswd(1)</li> <li>ipAuthHeader(2)</li> </ul>

Name, OID, and Syntax	Access	Description
snVrrplf2AuthPassword fdry.1.2.12.4.1.1.2 Syntax: Octet string	Read-write	Password for the interface if the snVrrplf2AuthType type is set to simpleTextPasswd(1).
snVrrplf2RxHeaderErrCnts fdry.1.2.12.4.1.1.3 Syntax: Counter	Read only	The number of packets received by the interface that had a header error.
snVrrplf2RxAuthTypeErrCnts fdry.1.2.12.4.1.1.4 Syntax: Counter	Read only	The number of packets received by the interface that had an authentication error.
snVrrplf2RxAuthPwdMismatchErr Cnts fdry.1.2.12.4.1.1.5 Syntax: Counter	Read only	The number of packets received by the interface that had a password value that does not match the password used by the interface for authentication.
snVrrplf2RxVridErrCnts fdry.1.2.12.4.1.1.6 Syntax: Counter	Read only	The number of packets received by the interface that contained a VRID that is not configured on this interface.

## VRRP Virtual Router Parameters Tables

There are two types of VRRP Virtual Router Parameters Table:

- “VRRP Virtual Router Table” on page 12-7
- “VRRP and VRRPE Parameter Table 2” on page 12-13

### VRRP Virtual Router Table

This table has been replaced by the “snVrrpVirRtr2Table” in IronWare release 07.6.01. The new table is presented in the section “VRRP and VRRPE Parameter Table 2” on page 12-13.

Name, OID, and Syntax	Access	Description
snVrrpVirRtrTable fdry.1.2.12.3.1	None	The VRRP Virtual Router Table
snVrrpVirRtrEntry fdry.1.2.12.3.1.1	None	An entry in the VRRP Virtual Router Table.
snVrrpVirRtrPort fdry.1.2.12.3.1.1.1 Syntax: Integer	Read only	Shows the port number of this VRRP interface.

Name, OID, and Syntax	Access	Description
snVrrpVirRtrId fdry.1.2.12.3.1.1.2 Syntax: Integer	Read only	Shows the VRID that has been configured on this interface. If multiple VRIDs are configured, there is an entry for each VRID.
snVrrpVirRtrOwnership fdry.1.2.12.3.1.1.3 Syntax: Integer	Read-write	Indicates the owner of the router interface. The owner or master router owns the IP addresses associated with the VRID: <ul style="list-style-type: none"> <li>• incomplete(0) – no IP address has been assigned to this VRRP router interface.</li> <li>• owner(1) – The owner or the master router is the owner of the VRRP router interface.</li> <li>• backup(2) – The backup router is the owner of the interface.</li> </ul>
snVrrpVirRtrCfgPriority fdry.1.2.12.3.1.1.4 Syntax: Integer	Read-write	Applies only if the object “snVrrpVirRtrOwnership” is set to backup(2).  It indicates the backup router’s preferability to becoming the active router for the interface. The higher the number, the higher the priority. If two or more devices are tied with the highest priority, the Backup interface with the highest IP address becomes the active router for the VRID.  Valid values: 3 – 254 Default: 100
snVrrpVirRtrTrackPriority fdry.1.2.12.3.1.1.5 Syntax: Integer	Read-write	Applies to interfaces that are configured with track ports.  It indicates the priority of the track ports. A higher the number indicates a higher priority. Track port priority is always lower than the “snVrrpVirRtrCfgPriority” priority.  This object is adjusted dynamically with the “snVrrpVirRtrCurrPriority” object when the Track Port state first changes from up to down.  Valid values: 1 – 254
snVrrpVirRtrCurrPriority fdry.1.2.12.3.1.1.6 Syntax: Integer	Read only	The current VRRP priority of this Layer 3 Switch for the VRID. The current priority can differ from the configured priority for the following reasons: <ul style="list-style-type: none"> <li>• The VRID is still in the initialization stage and has not yet become a Master or Backup. In this case, the current priority is 0.</li> <li>• The VRID is configured with track ports and the link on a tracked interface has gone down.</li> </ul> A higher the number indicates a higher priority.  This object is adjusted dynamically with the “snVrrpVirRtrTrackPriority” object.  Valid values: 1 – 254



Name, OID, and Syntax	Access	Description
snVrrpVirRtrHelloInt fdry.1.2.12.3.1.1.7 Syntax: Integer	Read-write	Shows the number of seconds between hello messages that are sent between the master and the backup.  Valid values: 1 – 84 seconds Default: 1 second
snVrrpVirRtrDeadInt fdry.1.2.12.3.1.1.8 Syntax: Integer	Read-write	Applies only to VRRP backups.  It shows the configured value for the dead interval. The dead interval is the number of seconds that a backup router waits for a Hello message from the VRID master before determining that the Master is no longer active.  If the Master does not send a Hello message before the dead interval expires, the backups negotiate (compare priorities) to select a new Master for the VRID.  Valid values: 0 – 84 seconds. A value of 0 means that this object has not been configured. Default: 0 seconds
snVrrpVirRtrPreemptMode fdry.1.2.12.3.1.1.9 Syntax: Integer	Read-write	Indicates if the backup preempt mode is enabled. The Backup preempt mode prevents a backup router with a higher VRRP priority from taking control of the VRID from another backup router that has a lower priority, but has already assumed control of the VRID:  <ul style="list-style-type: none"> <li>• disabled(0) – Prohibit preemption</li> <li>• enabled(1) – Allow preemption</li> </ul> Default: enabled(1)
snVrrpVirRtrState fdry.1.2.12.3.1.1.10 Syntax: Integer	Read only	Specifies the state of the VRRP Router's interface:  <ul style="list-style-type: none"> <li>• init(0) – Initialization state.</li> <li>• master(1) – Master state.</li> <li>• backup(2) – Backup state.</li> </ul>
snVrrpVirRtrActivate fdry.1.2.12.3.1.1.11 Syntax: Integer	Read-write	Indicates if the VRRP Router feature is enabled.  <ul style="list-style-type: none"> <li>• disabled(0) – The VRRP Router is deactivated</li> <li>• enabled(1) – The VRRP Router has been activated</li> </ul>
snVrrpVirRtrIpAddrMask fdry.1.2.12.3.1.1.12 Syntax: Octet string	Read-write	The number of IP addresses of this virtual router of this interface.

Name, OID, and Syntax	Access	Description
<p>snVrrpVirRtrTrackPortMask fdry.1.2.12.3.1.1.13 Syntax: Octet string</p>	<p>Read-write</p>	<p>This object was obsoleted after release 07.1.00 and replaced by “snVrrpVirRtrTrackPortList”.</p> <p>It specifies the identity of the physical port whose state is to be monitored. Each bit represents a port on a device.</p> <p>Valid values: There can be up to 64 octets in this object:</p> <ul style="list-style-type: none"> <li>• Chassis devices can have up to 32 octets.</li> <li>• Stackable devices can have up to 4 octets.</li> </ul> <p>Default: 0 octets</p> <p>If this object is configured on an interface, then the Preference Level for the interface will be adjusted dynamically, depending on the state of the Track Port:</p> <ul style="list-style-type: none"> <li>• When the Track Port states first changes from up to down, the interface’s Preference Level is reduced by the value of the Preference Level parameter.</li> <li>• The next time the Track Port state changes from down to up, the interface’s Preference Level is increased by the amount specified by the Preference Level.</li> </ul>
<p>snVrrpVirRtrTrackVifMask fdry.1.2.12.3.1.1.14 Syntax: Octet string</p>	<p>Read-write</p>	<p>This object was obsoleted after release 07.1.00 and replaced by “snVrrpVirRtrTrackVifPortList”.</p> <p>It specifies the identity of the virtual interface whose state is to be monitored. Each bit represents a port on a device.</p> <p>Valid values:</p> <ul style="list-style-type: none"> <li>• Chassis devices can have up to 32 octets.</li> <li>• Stackable devices can have up to 4 octets.</li> </ul> <p>Default: 0 octets</p> <p>If this object is configured on an interface, then the Preference Level for the interface will be adjusted dynamically, depending on the state of the Track Port:</p> <ul style="list-style-type: none"> <li>• When the Track Port states first changes from up to down, the interface’s Preference Level is reduced by the value of the Preference Level parameter.</li> <li>• The next time the Track Port state changes from down to up, the interface’s Preference Level is increased by the amount specified by the Preference Level.</li> </ul>

Name, OID, and Syntax	Access	Description
snVrrpVirRtrRowStatus fdry.1.2.12.3.1.1.15 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snVrrpVirRtrRxArpPktDropCnts fdry.1.2.12.3.1.1.16 Syntax: Counter	Read only	Shows the number of ARP packets addressed to the interface that were dropped.
snVrrpVirRtrRxIpPktDropCnts fdry.1.2.12.3.1.1.17 Syntax: Counter	Read only	Shows the number of IP packets addressed to the interface that were dropped.
snVrrpVirRtrRxPortMismatchCnts fdry.1.2.12.3.1.1.18 Syntax: Counter	Read only	Shows the number of packets received that did not match the configuration for the receiving interface.
snVrrpVirRtrRxNumOfIpMismatchCnts fdry.1.2.12.3.1.1.19 Syntax: Counter	Read only	Shows the number of packets received that did not match the configured IP addresses.
snVrrpVirRtrRxIpMismatchCnts fdry.1.2.12.3.1.1.20 Syntax: Counter	Read only	Shows the number of receive VRRP IP addresses that did not match the configured VRRP addresses.
snVrrpVirRtrRxHelloIntMismatchCnts fdry.1.2.12.3.1.1.21 Syntax: Counter	Read only	Shows the number of packets received that did not match the configured Hello interval.
snVrrpVirRtrRxPriorityZeroFromMasterCnts fdry.1.2.12.3.1.1.22 Syntax: Counter	Read only	Shows the counts of the virtual router interface with priority zero from the master.

Name, OID, and Syntax	Access	Description
snVrrpVirRtrRxHigherPriorityCnts fdry.1.2.12.3.1.1.23	Read only	Shows the number of VRRP packets received by the interface that had a higher backup priority for the VRID than what this interface's backup priority is.
snVrrpVirRtrTransToMasterStateC nts fdry.1.2.12.3.1.1.24 Syntax: Counter	Read only	Shows the number of times this interface has changed from the backup state to the master state for the VRID.
snVrrpVirRtrTransToBackupState Cnts fdry.1.2.12.3.1.1.25 Syntax: Counter	Read only	Shows the number of times this interface has changed from the master state to the backup state for the VRID.
snVrrpVirRtrCurrDeadInt fdry.1.2.12.3.1.1.26 Syntax: Integer	Read only	Shows the number of seconds a backup waits for a Hello message from the master before determining that the Master is no longer active. If the Master does not send a Hello message before the dead interval expires, the backups negotiate (compare priorities) to select a new master.
snVrrpVirRtrTrackPortList fdry.1.2.12.3.1.1.27 Syntax: Octet string	Read- write	<p>This object is available Foundry devices running IronWare release later than 07.1.00. It specifies the identity of the physical port whose state is to be monitored.</p> <p>Each port index is a 16-bit integer in big endian order. The first 8-bit is the slot number; the next 8-bit is the port number. Default value is 0 length octet string.</p> <p>If this object is configured on an interface, then the Preference Level for the interface will be adjusted dynamically, depending on the state of the Track Port:</p> <ul style="list-style-type: none"> <li>• When the Track Port state first changes from up to down, the interface's Preference Level is reduced by the value of the Preference Level parameter.</li> <li>• The next time the Track Port state changes from down to up, the interface's Preference Level is increased by the amount specified by the Preference Level.</li> </ul>

Name, OID, and Syntax	Access	Description
snVrrpVirRtrTrackVifPortList fdry.1.2.12.3.1.1.28 Syntax: Octet string	Read-write	<p>This object is available in Foundry devices running IronWare release later than 07.1.00. This object specifies the identity of the virtual interface whose state is to be monitored.</p> <p>Each port index is a 16-bit integer in big endian order. The first 8-bit is the slot number; the next 8-bit is the port number. Default value is 0 length octet string.</p> <p>If this object is configured on an interface, then the Preference Level for the interface will be adjusted dynamically, depending on the state of the Track Port:</p> <ul style="list-style-type: none"> <li>When the Track Port states first changes from up to down, the interface's Preference Level is reduced by the value of the Preference Level parameter.</li> <li>The next time the Track Port state changes from down to up, the interface's Preference Level is increased by the amount specified by the Preference Level.</li> </ul>

## VRRP and VRRPE Parameter Table 2

In IronWare Release 07.6.01, the following table replaces the "snVrrpVirRtrTable", which uses slot/port number to index entries. This new table uses the ifindex method to present the configuration and statistics for VRRP and VRRPE. Each entry in the table describes one VRRP or VRRPE router.

Name, OID, and Syntax	Access	Description
snVrrpVirRtr2Table fdry.1.2.12.5.1	None	The VRRP Virtual Router Table 2.
snVrrpVirRtr2Entry fdry.1.2.12.5.1.1	None	An entry in the VRRP Virtual Router Table 2.
snVrrpVirRtr2Id fdry.1.2.12.5.1.1.1 Syntax: Integer	Read only	Shows one of the VRID configured on this interface. If multiple VRIDs are configured on the interface, there is an entry for each VRID.
snVrrpVirRtr2Ownership fdry.1.2.12.5.1.1.2 Syntax: Integer	Read-write	<p>Indicates the owner of the VRRP router interface. The owner or master router owns the IP addresses associated with the VRID:</p> <ul style="list-style-type: none"> <li>incomplete(0) – No IP address has been assigned to this VRRP or VRRPE interface.</li> <li>owner(1) – The owner or the master router is the owner of the VRRP router interface. This applies only to VRRP.</li> <li>backup(2) – The backup router (VRRP or VRRPE) is the owner of the interface. This is the only value that can be assigned to a VRRPE router interface.</li> </ul>

Name, OID, and Syntax	Access	Description
<p>snVrrpVirRtr2CfgPriority fdry.1.2.12.5.1.1.3 Syntax: Integer</p>	Read-write	<p>Indicates the preferability of a router for becoming the active router for the interface. A higher number indicates a higher priority. If two or more devices are tied with the highest priority, the Backup interface with the highest IP address becomes the active router for the VRID.</p> <p>Valid values: 0 – 255, where:</p> <ul style="list-style-type: none"> <li>• 0 – The master no longer participates in the VRRP and a backup router should transition to be the new master</li> <li>• 255 – The router is the Owner</li> </ul> <p>Default: 100.</p>
<p>snVrrpVirRtr2TrackPriority fdry.1.2.12.5.1.1.4 Syntax: Integer</p>	Read-write	<p>Applies to interfaces that are configured with track ports. It indicates the priority of the track ports. The higher the number the higher the priority. Track port priority is always lower than the “snVrrpVirRtr2CfgPriority” priority.</p> <p>This object dynamically adjusts the value of the “snVrrpVirRtr2CfgPriority” object when the Track Port state first changes from Up to Down.</p> <p>Valid values: 1 – 254.</p>
<p>snVrrpVirRtr2CurrPriority fdry.1.2.12.5.1.1.5 Syntax: Integer</p>	Read only	<p>The current VRRP or VRRPE priority of this Layer 3 Switch for the VRID. The current priority can differ from the configured priority for the following reasons:</p> <ul style="list-style-type: none"> <li>• The VRID is still in the initialization stage and has not become a Master or Backup yet. In this case, the current priority is 0.</li> <li>• The VRID is configured with track ports and the link on a tracked interface has gone down.</li> </ul> <p>A higher number indicates a higher priority.</p> <p>This object is adjusted dynamically when the tracked port first changes from Up to Down.</p> <p>Valid values: 1 – 254.</p>
<p>snVrrpVirRtr2HelloInt fdry.1.2.12.5.1.1.6 Syntax: Integer</p>	Read-write	<p>Shows the number of seconds between hello advertisements from the master and the backup.</p> <p>Valid values: 1 – 84.</p> <p>Default: 1 second.</p>

Name, OID, and Syntax	Access	Description
snVrrpVirRtr2DeadInt fdry.1.2.12.5.1.1.7 Syntax: Integer	Read-write	<p>Applies only to VRRP or VRRPE backups.</p> <p>It shows the configured value for the dead interval. The dead interval is the number of seconds that a backup router waits for a Hello message from the VRID master before determining that the Master is no longer active.</p> <p>If the Master does not send a Hello message before the dead interval expires, the backups negotiate (compare priorities) to select a new Master for the VRID.</p> <p>Valid values: 1 – 84.</p> <p>Default: 0, which means that this object has not been configured.</p>
snVrrpVirRtr2PreemptMode fdry.1.2.12.5.1.1.8 Syntax: Integer	Read-write	<p>Indicates if the backup preempt mode is enabled:</p> <ul style="list-style-type: none"> <li>• disabled(0) – prohibit preemption</li> <li>• enabled(1) – allow preemption</li> </ul> <p>Default: enabled(1).</p> <p>The Backup preempt mode prevents a backup router with a higher VRRP priority from taking control of the VRID from another backup router that has a lower priority, but has already assumed control of the VRID.</p>
snVrrpVirRtr2State fdry.1.2.12.5.1.1.9 Syntax: Integer	Read only	<p>Specifies the VRRP or VRRPE router's interface state:</p> <ul style="list-style-type: none"> <li>• init(0) – Initialization state.</li> <li>• master(1) – Master state.</li> <li>• backup(2) – Backup state.</li> </ul>
snVrrpVirRtr2IpAddrMask fdry.1.2.12.5.1.1.10 Syntax: Octet string	Read-write	<p>The number of IP Addresses of this virtual router of this interface</p>
snVrrpVirRtr2Activate fdry.1.2.12.5.1.1.11 Syntax: Integer	Read-write	<p>Indicates if VRRP or VRRPE router is enabled.</p> <ul style="list-style-type: none"> <li>• disabled(0) – The router is deactivated</li> <li>• enabled(1) – The router has been activated</li> </ul>

Name, OID, and Syntax	Access	Description
snVrrpVirRtr2RowStatus fdry.1.2.12.5.1.1.12 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>• delete(3) – Delete the row</li> <li>• create(4) – Create a new row</li> <li>• modify(5) – Modify an existing row</li> <li>• If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</li> <li>• The following values can be returned on reads:                             <ul style="list-style-type: none"> <li>• noSuch(0) – No such row</li> <li>• invalid(1) – Row is inoperative</li> <li>• valid(2) – Row exists and is valid</li> </ul> </li> </ul>
snVrrpVirRtr2RxArpPktDropCnts fdry.1.2.12.5.1.1.13 Syntax: Counter	Read only	Shows the number of ARP packets addressed to the interface that were dropped.
snVrrpVirRtr2RxIpPktDropCnts fdry.1.2.12.5.1.1.14 Syntax: Counter	Read only	Shows the number of IP packets addressed to the interface that were dropped.
snVrrpVirRtr2RxPortMismatchCnts fdry.1.2.12.5.1.1.15 Syntax: Counter	Read only	Shows the number of packets received that did not match the configuration for the receiving interface.
snVrrpVirRtr2RxNumOfIpMismatchCnts fdry.1.2.12.5.1.1.16 Syntax: Counter	Read only	Shows the number of packets received that did not match the configured IP addresses.
snVrrpVirRtr2RxIpMismatchCnts fdry.1.2.12.5.1.1.17 Syntax: Counter	Read only	Shows the number of VRRP IP addresses received that did not match the VRRP or VRRPE addresses
snVrrpVirRtr2RxHelloIntMismatchCnts fdry.1.2.12.5.1.1.18 Syntax: Counter	Read only	Shows the number of packets received that did not match the configured Hello interval.
snVrrpVirRtr2RxPriorityZeroFromMasterCnts fdry.1.2.12.5.1.1.19 Syntax: Counter	Read only	Shows the count of the virtual router interface that received priority zero from the master.



Name, OID, and Syntax	Access	Description
snVrrpVirRtr2RxHigherPriorityCnts fdry.1.2.12.5.1.1.20 Syntax: Counter	Read only	Shows the number of packets received by the interface that had a higher backup priority for the VRID than this interface's backup priority for the VRID.
snVrrpVirRtr2TransToMasterStateCnts fdry.1.2.12.5.1.1.21 Syntax: Counter	Read only	Shows the number of times this interface has changed from the master state to the backup state for the VRID.
snVrrpVirRtr2TransToBackupStateCnts fdry.1.2.12.5.1.1.22 Syntax: Counter	Read only	Shows the number of times this interface has changed from the master state to the backup state.
snVrrpVirRtr2CurrDeadInt fdry.1.2.12.5.1.1.23 Syntax: Integer	Read only	Shows the current dead interval in 100 milliseconds for the virtual router. This is the time period that a backup waits for a Hello message from the master before determining that the Master is no longer active. If the Master does not send a Hello message before the dead interval expires, the backups negotiate (compare priorities) to select a new master for the VRID.
snVrrpVirRtr2TrackPortList fdry.1.2.12.5.1.1.24 Syntax: Octet string	Read-write	<p>Specifies the router's physical track port membership. The membership includes physical port and virtual ports whose state is to be monitored.</p> <p>Each port index is an ifIndex. If there are four or more consecutive ifIndexes, then encoding and decoding scheme is range based, as follows:</p> <ul style="list-style-type: none"> <li>Each range prefix with 0000 (2 octets) is not a valid ifIndex.</li> <li>The first two octets in a set of four octets indicate the beginning of the range. The next two octets show the end of the range.</li> <li>IfIndexes that are not in a range are displayed as it is.</li> </ul> <p>For example, you may see the following lists:</p> <ul style="list-style-type: none"> <li>Port list: 0001..0005 0015 0032..0047 0001..0005 and 0032..0047 show ranges of ifindexes; whereas, 0015 is one ifindex</li> <li>Port list in PDU: 0000 0001 0005 000f 0000 0020 002f The list contains ifindexes not in a range.</li> </ul> <p>If this object is configured, then the Preference Level of this interface will be adjusted dynamically depending on the state of the Track Port. The interface's Preference Level is reduced by the value of Preference Level parameter when the Track Port states first changes from Up to Down. When the Track Port returns to the Up state, the interface's Preference Level is increased by the amount specified by the Preference Level.</p>

Name, OID, and Syntax	Access	Description
snVrrpVirRtr2AdvertiseBackup fdry.1.2.12.5.1.1.25 Syntax: Integer	Read-write	Indicates if the ability for this Backup to advertise itself to the current Master is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0).
snVrrpVirRtr2MasterIpAddr fdry.1.2.12.5.1.1.26 Syntax: IpAddress	Read only	Shows the Master's real or virtual (primary) IP address. This IP address is listed as the source in VRRP and VRRPE advertisement that was last received by this virtual router.
snVrrpVirRtr2IpAddrCount fdry.1.2.12.5.1.1.27 Syntax: Integer	Read only	Shows the number of IP addresses that are associated with this virtual router. This number is equal to the number or rows in the vrrpAssolpAddrTable of the standard MIB that corresponds to a given ifindex and VRID pair.
snVrrpVirRtr2VirtualMacAddr fdry.1.2.12.5.1.1.28 Syntax: MAC address	Read only	Shows the virtual MAC address of the virtual router.

## VSRP

Virtual Switch Redundancy Protocol (VSRP) is a Foundry proprietary protocol that provides redundancy and sub-second failover in Layer 2 and Layer 3 mesh topologies. Based on the Foundry Virtual Router Redundancy Protocol Extended (VRRPE), VSRP provides one or more backups for a Layer 2 Switch or Layer 3 Switch. If the active Layer 2 Switch or Layer 3 Switch becomes unavailable, one of the backups takes over as the active device and continues forwarding traffic for the network.

Refer to the *Foundry Switch and Router Installation and Basic Configuration Guide* for detailed discussion on VSRP. The MIB objects in the sections following have been added to the Foundry MIB in IronWare release 07.6.01 to provide SNMP support for VSRP.

The following objects are available for VSRP:

- “Global VSRP Objects” on page 12-18
- “VSRP Interface Table” on page 12-19
- “VSRP Virtual Router Table” on page 12-20

### Global VSRP Objects

The following are the global objects for VSRP.

---

**NOTE:** Only one of the virtual router protocols can be enabled at any one time.

---

Name, OID, and Syntax	Access	Description
snVsrpGroupOperModeVsrp fdry.1.1.3.21.1.1 Syntax: Integer	Read-write	Indicates if VSRP is enabled or disable on this system: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>

Name, OID, and Syntax	Access	Description
snVsrplfMaxNumVridPerIntf fdry.1.1.3.21.1.3 Syntax: Integer	Read only	Indicates the maximum number of VRID that an interface can have.
snVsrplfMaxNumVridPerSystem fdry.1.1.3.21.1.4 Syntax: Integer	Read only	Indicates the maximum number of VRID that a system can have.
snVsrpClearVrrpStat fdry.1.1.3.21.1.5 Syntax: Integer	Read-write	Clears the VSRP statistics.

### VSRP Interface Table

The following table contains objects used to configure VSRP interfaces.

**NOTE:** Make sure that “snVsrpGroupOperModeVsrp” is set to enable(1).

Name, OID, and Syntax	Access	Description
snVsrplfTable fdry.1.1.3.21.2.1	None	The VSRP Interface Table
snVsrplfEntry fdry.1.1.3.21.2.1.1	None	An entry in the VSRP Interface Table.
snVsrplfVlanId fdry.1.1.3.21.2.1.1.1 Syntax: Integer	Read-write	VLAN ID used to index the entries in this table.
snVsrplfAuthType fdry.1.1.3.21.2.1.1.2 Syntax: Integer	Read-write	Indicates the authorization type used to verify access to the interface: <ul style="list-style-type: none"> <li>noAuth(0)</li> <li>simpleTextPasswd(1)</li> <li>ipAuthHeader(2)</li> </ul>
snVsrplfAuthPassword fdry.1.1.3.21.2.1.1.3 Syntax: Octet string	Read-write	Defines the password required if the “snVsrplfAuthType” object is set to simpleTextPasswd(1). This object can contain 1 – 7 octets.

## VSRP Virtual Router Table

The VSRP Virtual Router Table describes the configuration of the VSRP virtual router.

Name, OID, and Syntax	Access	Description
snVsrpVirRtrTable fdry.1.1.3.21.3.1	None	The VSRP Virtual Router Table
snVsrpVirRtrEntry fdry.1.1.3.21.3.1.1	None	An entry in the VSRP Virtual Router Table.
snVsrpVirRtrVlanId fdry.1.1.3.21.3.1.1.1 Syntax: Integer	Read only	VLAN index of the VSRP router.
snVsrpVirRtrId fdry.1.1.3.21.3.1.1.2 Syntax: Integer	Read only	Shows a virtual router ID for the interface.
snVsrpVirRtrOwnership fdry.1.1.3.21.3.1.1.3 Syntax: Integer	Read-write	Indicates the owner of the VSRP router interface. The owner or master router owns the IP addresses associated with the VRID: <ul style="list-style-type: none"> <li>incomplete(0) – No IP address has been assigned to this interface.</li> <li>owner(1) – This does not apply to VSRP.</li> <li>backup(2) – The backup router is the owner of the interface. This is the only value that can be assigned to a VSRP router interface.</li> </ul>
snVsrpVirRtrCfgPriority fdry.1.1.3.21.3.1.1.4 Syntax: Integer	Read-write	Indicates the preferability of a router for becoming the active router for the interface. A higher number indicates a higher priority. If two or more devices are tied with the highest priority, the Backup interface with the highest IP address becomes the active router for the VRID.  This object can be set only if “snVsrpVirRtrCfgPriority” is set to backup(2)  Valid values: 1 – 254  Default: 100.
snVsrpVirRtrTrackPriority fdry.1.1.3.21.3.1.1.5 Syntax: Integer	Read-write	Applies to interfaces that are configured with track ports.  It indicates the priority of the track ports. A higher number indicates a higher priority.  This object dynamically adjusts the value of the “snVrrpVirRtr2CfgPriority” object when the Track Port state first changes from Up to Down.  Valid values: 1 – 254.

Name, OID, and Syntax	Access	Description
snVsrpVirRtrCurrPriority fdry.1.1.3.21.3.1.1.6 Syntax: Integer	Read only	<p>The current VSRP priority of this Layer 3 Switch for the VRID. The current priority can differ from the configured priority for the following reasons:</p> <ul style="list-style-type: none"> <li>The VRID is still in the initialization stage and has not become a Master or Backup. In this case, the current priority is 0.</li> <li>The VRID is configured with track ports and the link on a tracked interface has gone down.</li> </ul> <p>A higher number indicates a higher priority.</p> <p>This object is adjusted dynamically when the tracked port first changes from Up to Down.</p> <p>Valid values: 1 – 254.</p>
snVsrpVirRtrHelloInt fdry.1.1.3.21.3.1.1.7 Syntax: Integer	Read-write	<p>Shows the number of seconds between hello advertisements sent from the master and the backup.</p> <p>Valid values: 1 – 84.</p> <p>Default: 1 second.</p>
snVsrpVirRtrDeadInt fdry.1.1.3.21.3.1.1.8 Syntax: Integer	Read-write	<p>Shows the number of seconds a Backup waits for a Hello message from the Master for the VRID before determining that the Master is no longer active. If the Master does not send a Hello messages before the dead interval expires and the backups negotiate (compare priorities) to select a new master for the</p> <p>Valid values: 1 – 84.</p> <p>Default: 1 second.</p>
snVsrpVirRtrPreemptMode fdry.1.1.3.21.3.1.1.9 Syntax: Integer	Read-write	<p>Indicates if the backup preempt mode is enabled:</p> <ul style="list-style-type: none"> <li>disabled(0) – prohibit preemption</li> <li>enabled(1) – allow preemption</li> </ul> <p>Default: enabled(1).</p> <p>The Backup preempt mode prevents a backup router with a higher priority from taking control of the VRID from another backup router that has a lower priority, but has already assumed control of the VRID.</p>
snVsrpVirRtrState fdry.1.1.3.21.3.1.1.10 Syntax: Integer	Read only	<p>Specifies the virtual router's interface state:</p> <ul style="list-style-type: none"> <li>init(0) – Initialization state</li> <li>master(1) – Master state</li> <li>backup(2) – Backup state</li> </ul>
snVsrpVirRtrIpAddrMask fdry.1.1.3.21.3.1.1.11 Syntax: Octet string	Read-write	<p>Specifies the number of IP addresses for this virtual router on the interface.</p>

Name, OID, and Syntax	Access	Description
snVsrpVirRtrActivate fdry.1.1.3.21.3.1.1.12 Syntax: Integer	Read-write	Indicates if VRRP or VRRPE router has been activated. <ul style="list-style-type: none"> <li>• disabled(0) – The router has not been activated</li> <li>• enabled(1) – The router has been activated</li> </ul>
snVsrpVirRtrTrackPortList fdry.1.1.3.21.3.1.1.13 Syntax: Octet string	Read-write	Specifies the router's physical track port membership. The membership includes physical port and virtual ports whose state is to be monitored. <p>Each port index is an ifIndex. If there are four or more consecutive ifIndexes, then encoding and decoding scheme is range based, as follows:</p> <ul style="list-style-type: none"> <li>• Each range prefix with 0000 (2 octets) is not a valid ifIndex.</li> <li>• The first two octets in a set of four octets indicate the beginning of the range. The next two octets show the end of the range.</li> <li>• Ifindexes that are not in a range are displayed as individual indexes.</li> </ul> For example, you may see the following lists: <ul style="list-style-type: none"> <li>• Port list: 0001..0005 0015 0032..0047 0001..0005 and 0032..0047 show ranges of ifindexes; whereas, 0015 is one ifindex</li> <li>• Port list in PDU: 0000 0001 0005 000f 0000 0020 002f The list contains ifindexes not in a range.</li> </ul> If this object is configured, then the Preference Level of this interface will be adjusted dynamically depending on the state of the Track Port. The interface's Preference Level is reduced by the value of Preference Level parameter when the Track Port states first changes from Up to Down. When the Track Port returns to the Up state, the interface's Preference Level is increased by the amount specified by the Preference Level.
snVsrpVirRtrAdvertiseBackup fdry.1.1.3.21.3.1.1.14 Syntax: Integer	Read-write	Indicates if the ability for this Backup to advertise itself to the current Master is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: disabled(0).
snVsrpVirRtrHoldDownInt fdry.1.1.3.21.3.1.1.15 Syntax: Integer	Read-write	The amount of time a Backup that has sent a Hello packet announcing its intent to become Master waits before beginning to forward traffic for the VRID. The hold-down interval prevents Layer 2 loops from occurring during VSRP's rapid failover. <p>The interval can from 1 – 84 seconds.</p> Default: 2 seconds.

Name, OID, and Syntax	Access	Description
snVsrpVirRtrInitTtl fdry.1.1.3.21.3.1.1.16 Syntax: Integer	Read-write	Indicates the time-to-live value (TTL) in the hello packets. TTL is the maximum number of hops a VSRP Hello packet can traverse before being dropped. TTL in a packet helps regulate the distance that a hello packet can travel. It prevents the flooding of VSRP hello packets in the network.  Valid values: 1 – 84 seconds.  Default: 1 second.
snVsrpVirRtrIncPortList fdry.1.1.3.21.3.1.1.17 Syntax: Octet string	Read-write	Groups all free ports of a VLAN into their control ports.
snVsrpVirRtrSave fdry.1.1.3.21.3.1.1.18 Syntax: Integer	Read-write	Indicates if the ability of VSRP to save its current parameter values has been enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0).
snVrrpVirRtrBackupInt fdry.1.1.3.21.3.1.1.19 Syntax: Integer	Read-write	Indicates the time interval when backup routers send hello message advertisements.  Valid values: 60 – 3600 seconds  Default: 60 seconds
snVsrpVirRtrRowStatus fdry.1.1.3.21.3.1.1.20 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. <ul style="list-style-type: none"> <li>The following values can be returned on reads:</li> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snVsrpVirRtrRxArpPktDropCnts fdry.1.1.3.21.3.1.1.21 Syntax: Counter	Read only	Shows the number of ARP packets addressed to the interface that were dropped.
snVsrpVirRtrRxIpPktDropCnts fdry.1.1.3.21.3.1.1.22 Syntax: Counter	Read only	Shows the number of IP packets addressed to the interface that were dropped.

Name, OID, and Syntax	Access	Description
snVsrpVirRtrRxPortMismatchCnts fdry.1.1.3.21.3.1.1.23 Syntax: Counter	Read only	Shows the number of packets received that did not match the configuration for the receiving interface.
snVsrpVirRtrRxNumOfIpMismatchCnts fdry.1.1.3.21.3.1.1.24 Syntax: Counter	Read only	Shows the number of packets received that did not match the configured IP addresses.
snVsrpVirRtrRxIpMismatchCnts fdry.1.1.3.21.3.1.1.25 Syntax: Counter	Read only	Shows the number of receive VSRP IP addresses that did not match the VSRP addresses
snVsrpVirRtrRxHelloIntMismatchCnts fdry.1.1.3.21.3.1.1.26 Syntax: Counter	Read only	Shows the number of packets received that did not match the configured Hello interval.
snVsrpVirRtrRxPriorityZeroFromMasterCnts fdry.1.1.3.21.3.1.1.27 Syntax: Counter	Read only	Shows the count of the virtual router interface with priority zero from the master.
snVsrpVirRtrRxHigherPriorityCnts fdry.1.1.3.21.3.1.1.28 Syntax: Counter	Read only	Shows the number of VSRP packets received by the interface that had a higher backup priority for the VRID than this interface's backup priority for the VRID.
snVsrpVirRtrTransToMasterStateCnts fdry.1.1.3.21.3.1.1.29 Syntax: Counter	Read only	Shows the number of times this interface has changed from the master state to the backup state for the VRID.
snVsrpVirRtrTransToBackupStateCnts fdry.1.1.3.21.3.1.1.30 Syntax: Counter	Read only	Shows the number of times this interface has changed from the master state to the backup state.
snVsrpVirRtrCurrDeadInt fdry.1.1.3.21.3.1.1.31 Syntax: Integer	Read only	Shows the current dead in 100-millisecond intervals for the virtual router. This is the time period that a backup waits for a Hello message from the master before determining that the Master is no longer active. If the Master does not send a Hello message before the dead interval expires and the backups negotiate (compare priorities) to select a new master for the
snVsrpVirRtrCurHelloInt fdry.1.1.3.21.3.1.1.32 Syntax: Integer	Read only	Shows the current backup router hello interval.



---

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snVsrpVirRtrCurHoldDownInt fdry.1.1.3.21.3.1.1.33 Syntax: Integer	Read only	Shows the current value of the hold-down interval.
snVsrpVirRtrCurlnitTtl fdry.1.1.3.21.3.1.1.34 Syntax: Integer	Read only	Shows the current time-to-live value.
snVsrpVirRtrHelloMacAddress fdry.1.1.3.21.3.1.1.35 Syntax: MAC address	Read only	Shows the MAC address of the hello packet.
snVsrpVirRtrMasterIpAddr fdry.1.1.3.21.3.1.1.36 Syntax: IpAddress	Read only	Shows the Master's real or virtual (primary) IP address. This is the IP address is listed as the source in VRRP and VRRPE advertisement that was last received by this virtual router.

---



---

# Chapter 13

## Global Router and IP

This chapter shows the router objects in the MIB. It contains the following sections:

- “Global Router Objects” on page 13-1
- “IP General Group” on page 13-2
- “IP Static Route Table” on page 13-4
- “IP Filter Table” on page 13-5
- “IP Interface Port Address Table” on page 13-8
- “IP Interface Port Access Table” on page 13-9
- “IP Interface Port Configuration Table” on page 13-10
- “Broadcast Forwarding Group” on page 13-12
- “Trace Route Group” on page 13-15
- “IP Forwarding Cache Table” on page 13-18
- “IP Prefix List Table” on page 13-19
- “IP AS-Path Access List String Table” on page 13-22

Refer to the *Foundry Enterprise Configuration and Management Guide* for details on the features discussed in this chapter.

### Global Router Objects

This section contains global MIB objects switching properties of the Layer 3 Switch, independent of any routing protocol.

---

Name, OID, and Syntax	Access	Description
snGblRtRouteOnly fdry.1.2.8.1.1 Syntax: Integer	Read- write	Determines if the Layer 3 Switch will route or switch packets: <ul style="list-style-type: none"><li>• disabled(0) – Router will first route the packets. If it cannot route them, it will switch packets.</li><li>• enabled(1) – Router will only route the packets; it will not switch them.</li></ul>

---

## IP General Group

The following are general objects for the IP group.

Name, OID, and Syntax	Access	Description
snRtClearArpCache fdry.1.2.2.1.1 Syntax: ClearStatus	Read-write	Clears learned ARP entries but does not remove any static ARP entries. The value for this object can be: <ul style="list-style-type: none"> <li>normal(0) – Do not clear learned entries</li> <li>clear(1) – Clear learned entries</li> </ul> This object is also available in the ServerIron.
snRtClearIpCache fdry.1.2.2.1.2 Syntax: ClearStatus	Read-write	Clears the entries in the IP Forwarding Cache Table. The value for this object can be: <ul style="list-style-type: none"> <li>normal(0) – Do not clear entries</li> <li>clear(1) – Clear entries</li> <li>This object is also available in the ServerIron.</li> </ul>
snRtClearIpRoute fdry.1.2.2.1.3 Syntax: ClearStatus	Read-write	Clears the IP route tables. The value for this object can be: <ul style="list-style-type: none"> <li>normal(0) – Do not clear entries</li> <li>clear(1) – Clear entries</li> <li>This object is also available in the ServerIron.</li> </ul>
snRtBootpServer fdry.1.2.2.1.4 Syntax: IpAddress	Read-write	Shows the IP address of the bootp server to which bootp packet need to be relayed.
snRtBootpRelayMax fdry.1.2.2.1.5 Syntax: Integer	Read-write	Specifies the maximum number of hops the bootp packet should travel. Valid values: Up to 15 hops
snRtArpAge fdry.1.2.2.1.6 Syntax: Integer	Read-write	Specifies the number of minutes that an ARP entry can be valid without having to be relearned. Valid values: Up to 240 minutes. A value of zero (0) means that the entry will not age out.
snRtIpIrdpEnable fdry.1.2.2.1.7 Syntax: Integer	Read-write	Indicates if router advertisement is enabled on this device: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snRtIpLoadShare fdry.1.2.2.1.8 Syntax: Integer	Read-write	Indicates if more than one route will be enabled to share the loads: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snRtIpProxyArp fdry.1.2.2.1.9 Syntax: Integer	Read-write	Indicates if the proxy ARP function is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>

Name, OID, and Syntax	Access	Description
snRtlpRarp fdry.1.2.2.1.10 Syntax: Integer	Read-write	Indicates if the RARP server is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snRtlpTtl fdry.1.2.2.1.11 Syntax: Integer	Read-write	Indicates the time-to-live (TTL) value that will be used in the IP header of an IP packet that was generated by this device.  Valid values: 1 – 255
snRtlpSetAllPortConfig fdry.1.2.2.1.12 Syntax: Integer	Read-write	Shows the index number of a row in the “snRtlpPortConfigTable” on page 13-10, such as “snRtlpPortConfigPortIndex” on page 13-11. All the writeable data from that row will be copied to all appropriate rows in all IP Interface Port Configuration Tables  <b>NOTE:</b> Prior to setting this object, make sure that the row identified in this object contains a value for all its objects; otherwise, the current data of the row will be used to set the entire IP interface configuration table.
snRtlpFwdCacheMaxEntries fdry.1.2.2.1.13 Syntax: Integer	Read only	Shows the maximum number of entries in the IP Forwarding Cache Table.
snRtlpFwdCacheCurEntries fdry.1.2.2.1.14 Syntax: Integer	Read only	Shows the current number of entries in the IP Forwarding Cache Table.
snRtlpMaxStaticRouteEntries fdry.1.2.2.1.14 Syntax: Integer	Read only	Shows the maximum number of entries in the IP Static Route table.
snRtlpDirBcastFwd fdry.1.2.2.1.16 Syntax: Integer	Read-write	Indicates if the directed broadcast forwarding feature is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snRtlpLoadShareNumOfPaths fdry.1.2.2.1.17 Syntax: Integer	Read-write	Specifies the number of routes to be used to share the load.
snRtlpLoadShareMaxPaths fdry.1.2.2.1.18 Syntax: Integer	Read only	Indicates the maximum number of routes that can be configured to share the loads.
snRtlpLoadShareMinPaths fdry.1.2.2.1.19 Syntax: Integer	Read only	Indicates the minimum number of routes that can be configured to share the loads.

Name, OID, and Syntax	Access	Description
snRtlpProtocolRouterId fdry.1.2.2.1.20 Syntax: IpAddress	Read-write	Shows the router ID for all IP Protocols.
snRtlpSourceRoute fdry.1.2.2.1.21 Syntax: Integer	Read-write	Indicates if strict source routing is enabled to drop source routed packets: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>

## IP Static Route Table

The IP Static Route Table contains a list of static routes. These routes can be one of the following types:

- Standard – the static route consists of the destination network address and network mask, plus the IP address of the next-hop gateway.
- Interface-based – the static route consists of the destination network address and network mask, plus the Layer 3 Switch interface through which you want the Layer 3 Switch to send traffic for the route. Typically, this type of static route is for directly attached to destination networks.
- Null – the static route consists of the destination network address and network mask, plus the “null0” parameter. Typically, the null route is configured as a backup route for discarding traffic if the primary route is unavailable.

IP Static Route Table also serves as the default route table.

Name, OID, and Syntax	Access	Description
snRtlpStaticRouteTable fdry.1.2.2.2	None	IP static route table
snRtlpStaticRouteEntry fdry.1.2.2.2.1	None	An entry in the IP static route table.
snRtlpStaticRouteIndex fdry.1.2.2.2.1.1 Syntax: Integer	Read only	The table index for a static route entry.
snRtlpStaticRouteDest fdry.1.2.2.2.1.2 Syntax: IpAddress	Read-write	Shows the destination IP address of the default route. The address 0.0.0.0 is the IP address of the default router.
snRtlpStaticRouteMask fdry.1.2.2.2.1.3 Syntax: IpAddress	Read-write	Shows the subnet mask of the default route’s destination IP address. The subnet mask 0.0.0.0 is the subnet mask of the default router.
snRtlpStaticRouteNextHop fdry.1.2.2.2.1.4 Syntax: IpAddress	Read-write	Shows the IP address of the next-hop router (gateway) for the route.

Name, OID, and Syntax	Access	Description
snRtIpStaticRouteMetric fdry.1.2.2.2.1.5 Syntax: Integer	Read-write	Shows the metrics to next hop router. Default: 1
snRtIpStaticRouteRowStatus fdry.1.2.2.2.1.6 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>other(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snRtIpStaticRouteDistance fdry.1.2.2.2.1.7 Syntax: Integer	Read-write	Specifies the administrative distance of the route. When comparing equal routes to a destination, the Layer 3 Switch prefers lower administrative distances over higher ones. Valid values: 1 – 255 Default: 1

## IP Filter Table

An IP filter is an access policy that determines whether the device forwards or drops IP packets. A filter consists of source and destination IP information and the action to take when a packet matches the values in the filter.

The following objects define IP Filters. They are available in all Foundry products.

Name, OID, and Syntax	Access	Description
snRtIpFilterTable fdry.1.2.2.3	None	IP Filter Table.
snRtIpFilterEntry fdry.1.2.2.3.1	None	An entry in the IP Filter Table
snRtIpFilterIndex fdry.1.2.2.3.1.1 Syntax: Integer	Read only	Shows the index for an entry in the IP Filter Table.

Name, OID, and Syntax	Access	Description
snRtIpFilterAction fdry.1.2.2.3.1.2 Syntax: Integer	Read-write	Determines what action to take if the IP packet matches this filter. <ul style="list-style-type: none"> <li>• deny(0)</li> <li>• permit(1)</li> <li>• qosEnabled(2)</li> </ul> Once you configure an IP access policy, the device denies all IP packets by default unless you explicitly permit them. Thus, if you want the device to permit all IP packets except the ones that you filter out, you must configure the last IP access policy to permit all IP packets.
snRtIpFilterProtocol fdry.1.2.2.3.1.3 Syntax: Integer	Read-write	Specifies the transport protocol that you can filter. Only the traffic for the transport protocol selected will be allowed: <ul style="list-style-type: none"> <li>• all(0) – All traffic of the transport protocols listed below will be permitted</li> <li>• ICMP(1)</li> <li>• IGMP(2)</li> <li>• IGRP(88)</li> <li>• OSPF(89)</li> <li>• TCP(6)</li> <li>• UDP(17)</li> </ul> In addition, if you filter TCP or UDP, you can also specify a particular application port (such as “HTTP” or “80”) or a logical expression consisting of an operator and port names or numbers.
snRtIpFilterSourceIp fdry.1.2.2.3.1.4 Syntax: IpAddress	Read-write	Shows the source IP address. The policy will be applied to packets that come from this IP address.
snRtIpFilterSourceMask fdry.1.2.2.3.1.5 Syntax: IpAddress	Read-write	Shows the source IP subnet mask. The policy will be applied to packets that come from this subnet mask.
snRtIpFilterDestIp fdry.1.2.2.3.1.6 Syntax: IpAddress	Read-write	Shows the destination IP address. The IP access policy will be applied to packets that are going to this IP address.
snRtIpFilterDestMask fdry.1.2.2.3.1.7 Syntax: IpAddress	Read-write	Shows the destination IP subnet mask. The IP access policy will be applied to packets that are going to this subnet mask.



Name, OID, and Syntax	Access	Description
snRtIpFilterOperator fdry.1.2.2.3.1.8 Syntax: Integer	Read-write	Applies only if the value of the object "snRtIpFilterProtocol" is TCP or UDP.  It specifies the type of comparison to be performed to TCP and UDP packets: <ul style="list-style-type: none"> <li>• greater(1) – The policy applies to TCP or UDP port numbers that are greater than the value of the "snRtIpFilterOperand" object.</li> <li>• equal(2) – The policy applies to TCP or UDP port numbers that are equal to the value of the "snRtIpFilterOperand" object.</li> <li>• less(3) – The policy applies to TCP or UDP port numbers that are less than the value of the "snRtIpFilterOperand" object.</li> <li>• notEqual(4) – The policy applies to all TCP or UDP port numbers except to those that are equal to the value of the "snRtIpFilterOperand" object.</li> </ul>
snRtIpFilterOperand fdry.1.2.2.3.1.9 Syntax: Integer	Read-write	Applies only if the value of the object "snRtIpFilterProtocol" is TCP or UDP.  Specifies the TCP or UDP port number that will be used in this filter.  Valid values: 0 – 65535. 0 means that this object is not applicable.
snRtIpFilterRowStatus fdry.1.2.2.3.1.10 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>• delete(3) – Delete the row</li> <li>• create(4) – Create a new row</li> <li>• modify(5) – Modify an existing row</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.  The following values can be returned on reads: <ul style="list-style-type: none"> <li>• noSuch(0) – No such row</li> <li>• invalid(1) – Row is inoperative</li> <li>• valid(2) – Row exists and is valid</li> </ul>
snRtIpFilterEstablished fdry.1.2.2.3.1.11 Syntax: Integer	Read-write	Applies only to TCP packets.  Indicates if the filtering of established TCP packets is enabled for packets that have the ACK or RESET flag on: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>

Name, OID, and Syntax	Access	Description
snRtlpFilterQoSPriority fdry.1.2.2.3.1.12 Syntax: Integer	Read-write	<p>The router Layer 4 QoS Priority values are:</p> <ul style="list-style-type: none"> <li>low(0) – lower priority</li> <li>high(1) – higher priority</li> </ul> <p>The Priority values are:</p> <ul style="list-style-type: none"> <li>level0(0) – lower priority</li> <li>level1(1)</li> <li>level2(2)</li> <li>level3(3),</li> <li>level4(4)</li> <li>level5(5)</li> <li>level6(6)</li> <li>level7(7) – higher priority</li> </ul>

## IP Interface Port Address Table

The IP Interface Port Address Table shows the port's IP address and its port type.

Name, OID, and Syntax	Access	Description
snRtlpPortAddrTable fdry.1.2.2.6	None	IP port address table.
snRtlpPortAddrEntry fdry.1.2.2.6.1	None	An entry in the IP Port Address table.
snRtlpPortAddrPortIndex fdry.1.2.2.6.1.1 Syntax: PortIndex	Read only	<p>The index of the port address entry.</p> <ul style="list-style-type: none"> <li>For FastIron or NetIron products, the value of this object is from 1 to 42</li> <li>For BigIron products, the value of this object is an encoded number: <ul style="list-style-type: none"> <li>Bit 0 to bit 7 – Port number.</li> <li>Bit 8 to bit 11 – Slot number.</li> </ul> </li> </ul>
snRtlpPortAddress fdry.1.2.2.6.1.2 Syntax: IpAddress	Read only	Specifies the port IP address.
snRtlpPortSubnetMask fdry.1.2.2.6.1.3 Syntax: IpAddress	Read-write	Specifies the port IP address subnet mask.

Name, OID, and Syntax	Access	Description
snRtIpPortAddrType fdry.1.2.2.6.1.4 Syntax: Integer	Read-write	Shows the port type of the entry: <ul style="list-style-type: none"> <li>primary(1)</li> <li>secondary(2)</li> </ul> Default: primary(1)
snRtIpPortRowStatus fdry.1.2.2.6.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> If the row exists, then a set with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## IP Interface Port Access Table

This table determines if the port is for incoming or outgoing traffic and the filter used on the interface.

Name, OID, and Syntax	Access	Description
snRtIpPortAccessTable fdry.1.2.2.7	None	IP Port Access Table.
snRtIpPortAccessEntry fdry.1.2.2.7.1	None	An entry in the IP Port Access Table.
snRtIpPortAccessPortIndex fdry.1.2.2.7.1.1 Syntax: PortIndex	Read only	The index for an entry in the IP Port Access Table. <ul style="list-style-type: none"> <li>For FastIron or NetIron products, the value of this object is from 1 to 42</li> <li>For BigIron products, the value of this object is an encoded number: <ul style="list-style-type: none"> <li>Bit 0 to bit 7 – Port number.</li> <li>Bit 8 to bit 11 – Slot number.</li> </ul> Beginning with software release 07.2.00, the following values have been added: <ul style="list-style-type: none"> <li>Bit 16, set to 1 – Virtual router interface</li> <li>Bit 17, set to 1 – Loopback interface.</li> </ul> </li> </ul>

Name, OID, and Syntax	Access	Description
snRtIpPortAccessDirection fdry.1.2.2.7.1.2 Syntax: Integer	Read only	Specifies if the port is for incoming or outgoing traffic. <ul style="list-style-type: none"> <li>in(1)</li> <li>out(2)</li> </ul>
snRtIpPortAccessFilters fdry.1.2.2.7.1.3 Syntax: Octet string	Read-write	Each octet represents a filter number.
snRtIpPortAccessRowStatus fdry.1.2.2.7.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## Port Configuration Tables

The following table defines the size, encapsulation format, and cost of the packet that will be transmitted through a port.

### IP Interface Port Configuration Table

The following table is used by all Foundry devices except BigIron MG8 and NetIron 40G (refer to "IP Interface Configuration Table" on page 13-12).

Name, OID, and Syntax	Access	Description
snRtIpPortConfigTable fdry.1.2.2.8	None	IP Port Configuration Table.
snRtIpPortConfigEntry fdry.1.2.2.8.1	None	An entry in the IP Port Configuration Table.

Name, OID, and Syntax	Access	Description
snRtlpPortConfigPortIndex fdry.1.2.2.8.1.1 Syntax: PortIndex	Read only	An index for an entry in the IP Port Configuration Table <ul style="list-style-type: none"> <li>For FastIron or NetIron products, the value of this object is from 1 to 42</li> <li>For BigIron products, the value of this object is an encoded number: <ul style="list-style-type: none"> <li>Bit 0 to bit 7 – Port number.</li> <li>Bit 8 to bit 11 – Slot number.</li> </ul> </li> </ul> <p>Beginning with software release 07.2.00, the following values have been added:</p> <ul style="list-style-type: none"> <li>Bit 16, set to 1 – Virtual router interface</li> <li>Bit 17, set to 1 – Loopback interface.</li> </ul>
snRtlpPortMtu fdry.1.2.2.8.1.2 Syntax: Integer	Read-write	Indicates the maximum size of IP packets that will be transmitted on the port.
snRtlpPortEncap fdry.1.2.2.8.1.3 Syntax: Integer	Read-write	Shows the encapsulation format that will be used on the IP frame transmitted on the port. <ul style="list-style-type: none"> <li>ethernet(1) – Ethernet</li> <li>snap(2) – ATM and Ethernet</li> <li>hdlc(3) – POS</li> <li>ppp(4) – POS</li> </ul>
snRtlpPortMetric fdry.1.2.2.8.1.4 Syntax: Integer	Read-write	Specifies the metric or cost to the router adds to the route. Valid values: 1 – 15 Default: 1
snRtlpPortDirBcastFwd fdry.1.2.2.8.1.5 Syntax: Integer	Read-write	Indicates if the directed broadcast forwarding feature is enabled. A directed broadcast is a packet containing all ones (or in some cases, all zeros) in the host portion of the destination IP address. When a router forwards such a broadcast, it sends a copy of the packet out each of its enabled IP interfaces: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> <p>Default: enabled(1)</p>

## IP Interface Configuration Table

The snRtIplfConfigTable defines the size, encapsulation format, and cost of the packet that will be transmitted through a port on BigIron MG8 and NetIron 40G devices. Other Foundry devices use the snRtIpPortConfigTable (refer to “IP Interface Port Configuration Table” on page 13-10).

Name, OID, and Syntax	Access	Description
snRtIplfConfigTable fdry.	None	IP Port IF Configuration Table.
snRtIplfConfigEntry fdry.	None	An entry in the IP Port IF Configuration Table.
snRtIplfConfigInterfaceIndex fdry. Syntax: PortIndex	Read only	An index for an entry in the IP Port Configuration Table.
snRtIplfMtu fdry. Syntax: Integer	Read-write	Indicates the maximum size of IP packets that will be transmitted on the port.
snRtIplfEncap fdry. Syntax: Integer	Read-write	Shows the encapsulation format that will be used on the IP frame transmitted on the port. <ul style="list-style-type: none"> <li>• ethernet(1) – Ethernet</li> <li>• snap(2) – ATM and Ethernet</li> <li>• hdlc(3) – POS</li> <li>• ppp(4) – POS</li> <li>• other(5)</li> </ul>
snRtIplfMetric fdry. Syntax: Integer	Read-write	Specifies the metric or cost to the router adds to the route. Valid values: 1 – 15 Default: 1
snRtIplfDirBcastFwd fdry. Syntax: Integer	Read-write	Indicates if the directed broadcast forwarding feature is enabled. A directed broadcast is a packet containing all ones (or in some cases, all zeros) in the host portion of the destination IP address. When a router forwards such a broadcast, it sends a copy of the packet out each of its enabled IP interfaces: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: enabled(1)

## Broadcast Forwarding Group

This section contains the following tables:

- “General UDP Broadcast Forwarding Group” on page 13-13

- “UDP Broadcast Forwarding Port Table” on page 13-13
- “UDP Helper Table” on page 13-14
- “General Trace Route Group” on page 13-16
- “Trace Route Result Table” on page 13-17

## General UDP Broadcast Forwarding Group

Name, OID, and Syntax	Access	Description
snRtUdpBcastFwdEnable fdry.1.2.2.9 Syntax: Integer	Read-write	Indicates if the UDP broadcast forwarding feature is enabled: <ul style="list-style-type: none"> <li>• disabled(0) – When this object is set to disabled, entries in the UDP Broadcast Forwarding Port Table are deleted.</li> <li>• enabled(1) – When UDP broadcast forwarding is enabled, default entries are added to the UDP broadcast forwarding port table.</li> </ul> Default: enabled(1)

## UDP Broadcast Forwarding Port Table

This table contains a list of UDP port numbers for which forwarding UDP broadcast is enabled.

Name, OID, and Syntax	Access	Description
snRtUdpBcastFwdPortTable fdry.1.2.2.9.2.1	None	The UDP Broadcast Forwarding Port Table
snRtUdpBcastFwdPortEntry fdry.1.2.2.9.2.1.1	None	An entry in the UDP Broadcast Forwarding Port Table.
snRtUdpBcastFwdPortIndex fdry.1.2.2.9.2.1.1.1 Syntax: Integer	Read only	The index of an entry in the UDP Broadcast Forwarding Port Tables. There can be up to 20 entries.

Name, OID, and Syntax	Access	Description
snRtUdpBcastFwdPortNumber fdry.1.2.2.9.2.1.1.2 Syntax: Integer	Read-write	Shows the port number for which the UDP broadcast forwarding feature has been enabled. Possible port numbers are: <ul style="list-style-type: none"> <li>• port(68) – bootpc</li> <li>• port(67) – bootps</li> <li>• port(9) – discard</li> <li>• port(53) – dns</li> <li>• port(90) – dnstcp</li> <li>• port(7) – echo</li> <li>• port(434) – mobile-ip</li> <li>• port(138) – netbios-dgm</li> <li>• port(137) – netbios-ns</li> <li>• port(123) – ntp</li> <li>• port(65) – tacacs</li> <li>• port(517) – talk</li> <li>• port(37) – time</li> <li>• port(69) – tftp</li> </ul> Other application port numbers can also be specified.
snRtUdpBcastFwdPortRowStatus fdry.1.2.2.9.2.1.1.3 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>• delete(3) – Delete the row</li> <li>• create(4) – Create a new row</li> <li>• modify(5) – Modify an existing row</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row</li> <li>• invalid(1) – Row is inoperative</li> <li>• valid(2) – Row exists and is valid</li> </ul>

### UDP Helper Table

A UDP Helper Table contains addresses that are used to forward a client's broadcast request for a UDP application when the client and server are on different networks. There can be up to four helper addresses on each interface. Helper addresses can be configured on an Ethernet port or a virtual interface.

Name, OID, and Syntax	Access	Description
snRtUdpHelperTable fdry.1.2.2.9.3.1	None	UDP Helper Table



Name, OID, and Syntax	Access	Description
snRtUdpHelperEntry fdry.1.2.2.9.3.1.1	None	An entry of the UDP Helper Table.
snRtUdpHelperPortIndex fdry.1.2.2.9.3.1.1.1 Syntax: PortIndex	Read only	Indicates the port index for a UDP Helper address. <ul style="list-style-type: none"> <li>For FastIron or NetIron products, the value of this object is from 1 to 42</li> <li>For BigIron products, the value of this object is an encoded number, where: <ul style="list-style-type: none"> <li>Bit 0 to bit 7 – Port number.</li> <li>Bit 8 to bit 11 – Slot number.</li> </ul> </li> </ul> Beginning with software release 07.2.00, the following values have been added: <ul style="list-style-type: none"> <li>Bit 16, set to 1 – Virtual router interface.</li> <li>Bit 17, set to 1 – Loopback interface.</li> </ul>
snRtUdpHelperIndex fdry.1.2.2.9.3.1.1.2 Syntax: Integer	Read only	An index in the UDP Helper Table for this entry. Valid values: 1– 4.
snRtUdpHelperAddrTypr fdry.1.2.2.9.3.1.1.3 Syntax: Integer	Read-write	Indicates if the address is unicast or subnet broadcast address. Valid values: <ul style="list-style-type: none"> <li>unicast(1)</li> <li>broadcast(2)</li> </ul>
snRtUdpHelperAddr fdry.1.2.2.9.3.1.1.4 Syntax: IpAddress	Read-write	Shows the IP address of the UDP helper. UDP packets will be forwarded to this address. It can be a helper address or a subnet broadcast address, but it cannot be 255.255.255.255 or 0.0.0.0.
snRtUdpHelperRowStatus fdry.1.2.2.9.3.1.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## Trace Route Group

This group uses the following method to detect routes used to reach a destination address:

1. The originating Layer 3 Switch sends a probe packet (a UDP packet) to the destination address with a time-to-Live (TTL) value of 1.
2. The first Layer 3 Switch that receives this packet decrements the TTL, then drops the packet and returns a ICMP packet to the originator.
3. The originating Layer 3 Switch records the route in the “snRtIpTraceRouteResultTable”.
4. The originating Layer 3 Switch sends a probe packet (a UDP packet) to the destination address with a TTL value of 2.
5. The second Layer 3 Switch that receives this packet decrements the TTL, then drops the packet and returns an ICMP packet to the originator.
6. The originating Layer 3 Switch records the route in “snRtIpTraceRouteResultTable”.

This procedure is repeated until the destination is reached or the maximum TTL is reached.

### General Trace Route Group

The following objects define the trace route probe packet.

Name, OID, and Syntax	Access	Description
snRtIpTraceRouteTargetAddr fdry.1.2.2.10.1.1 Syntax: IpAddress	Read-write	Shows the target IP address of the trace route.
snRtIpTraceRouteMinTtl fdry.1.2.2.10.1.2 Syntax: Integer	Read-write	Indicates the minimum TTL value carried in the first probe packet.  Valid values: 1 – 255 minutes Default: 1 minute
snRtIpTraceRouteMaxTtl fdry.1.2.2.10.1.3 Syntax: Integer	Read-write	Indicates the maximum TTL value carried in the last probe packet.  Valid values: 1 – 255 minutes. Default: 30 minutes
snRtIpTraceRouteTimeOut fdry.1.2.2.10.1.4 Syntax: Integer	Read-write	Indicates the number of seconds the Layer 3 Switch waits for a response from the probe packet (i.e. the ICMP packet) before timing out.  Valid values: 1 – 120 seconds. Default: 2 seconds

Name, OID, and Syntax	Access	Description
snRtIpTraceRouteControl fdry.1.2.2.10.1.5 Syntax: Integer	Read-write	<p>Indicates the progress of the trace route:</p> <ul style="list-style-type: none"> <li>start(1) – snRtIpTraceRouteDestAddr must have been initialized before start(1) can be written.</li> <li>abort(2) – Stops the current trace route operation.</li> <li>success(3) – The destination address is reached.</li> <li>failure(4) – Either the destination address is not reach, trace route times out, or the ending TTL is reached before the operation is completed.</li> <li>inProgress(5) – Trace route operation has started.</li> </ul> <p>Only "start" and "abort" are writable values; whereas, "success", "failure" and "inProgress" are read only (or returned) values.</p> <p>The "snRtIpTraceRouteResultTable" on page 13-17 contains the routes and target addresses.</p>

### Trace Route Result Table

This table contains the routes and the target addresses used in the trace route operation to reach the destination address.

Name, OID, and Syntax	Access	Description
snRtIpTraceRouteResultTable fdry.1.2.2.10.2.1	None	Trace Route Results Table.
snRtIpTraceRouteResultEntry fdry.1.2.2.10.2.1.1	None	An entry in the Trace Route Results Table.
snRtIpTraceRouteResultIndex fdry.1.2.2.10.2.1.1.1 Syntax: Integer	Read only	The index for an entry in the Trace Route Results Table.
snRtIpTraceRouteResultAddr fdry.1.2.2.10.2.1.1.2 Syntax: IpAddress	Read only	Indicates the IP address of the Layer 3 Switch or the target IP address of the Layer 3 Switch.
snRtIpTraceRouteResultRoundTri pTime1 fdry.1.2.2.10.2.1.1.3 Syntax: Time ticks	Read only	Shows the round trip time between the transmission of the first probe packet and the received response of the ICMP packet.
snRtIpTraceRouteResultRoundTri pTime2 fdry.1.2.2.10.2.1.1.4 Syntax: Time ticks	Read only	Shows the round trip time between the transmission of the second probe and the received response of the ICMP packet.

## IP Forwarding Cache Table

The IP forwarding cache provides a fast-path mechanism for forwarding IP packets. The cache contains entries for IP destinations.

Name, OID, and Syntax	Access	Description
snRtIpFwdCacheTable fdry.1.2.2.11	None	IP Forwarding Cache Table.
snRtIpFwdCacheEntry fdry.1.2.2.11.1	None	An entry in the IP Forwarding Cache Table.
snRtIpFwdCacheIndex fdry.1.2.2.11.1.1 Syntax: Integer	Read only	An index in the IP Forwarding Cache Table for this entry.
snRtIpFwdCacheIp fdry.1.2.2.11.1.2 Syntax: IpAddress	Read only	Shows the IP address of a forwarding cache station.
snRtIpFwdCacheMac fdry.1.2.2.11.1.3 Syntax: Octet string	Read only	Shows the MAC address of a forwarding cache station. This object has six octets.
snRtIpFwdCacheNextHopIp fdry.1.2.2.11.1.4 Syntax: IpAddress	Read only	Indicates the IP address of the Layer 3 Switch for the next hop.
snRtIpFwdCacheOutgoingPort fdry.1.2.2.11.1.5 Syntax: Integer	Read only	Specifies the outgoing port to which packets will be forwarded.  Valid values: 0 – 3900. A value of zero indicates that there is no outgoing port for this entry. Non-zero value has the following meaning: <ul style="list-style-type: none"> <li>• Bit 0 to bit 7 – Port number.</li> <li>• Bit 8 to bit 11 – Slot number.</li> </ul> For virtual Layer 3 Switch interface, slot number is 15. Port number is the virtual Layer 3 Switch port number, which is a value from 1 – 60.
snRtIpFwdCacheType fdry.1.2.2.11.1.6 Syntax: Integer	Read only	Indicates the type of entry this is: <ul style="list-style-type: none"> <li>• dynamic(1)</li> <li>• permanent(2)</li> </ul>

Name, OID, and Syntax	Access	Description
snRtIpFwdCacheAction fdry.1.2.2.11.1.7 Syntax: Integer	Read only	Indicates the action taken with this entry: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• forward(2)</li> <li>• forUs(3)</li> <li>• waitForArp(4)</li> <li>• complexFilter(5)</li> <li>• icmpDeny(6)</li> <li>• dropPacket(7)</li> </ul>
snRtIpFwdCacheFragCheck fdry.1.2.2.11.1.8 Syntax: Integer	Read only	Indicates if fragmentation-needed is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> <p><b>NOTE:</b> Foundry devices cannot forward the packet without fragmenting it.</p>
snRtIpFwdCacheSnapHdr fdry.1.2.2.11.1.9 Syntax: Integer	Read only	Indicates if Ethernet SNAP (also called IEEE 802.3) encapsulation is enabled: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>
snRtIpFwdCacheVlanId fdry.1.2.2.11.1.10 Syntax: Integer	Read only	Shows the VLAN ID of an IP Forwarding Cache Table entry. A value of zero indicates that no VLAN is associated with this entry.
snRtIpFwdCacheOutgoingIf fdry.1.2.2.11.1.11 Syntax: Integer	Read only	Shows the outgoing interface that will be used to forward packets. An value of zero indicates that no outgoing interface is associated with this entry.

## IP Prefix List Table

An IP prefix list specifies a list of networks. When you apply an IP prefix list to a neighbor, the Layer 3 Switch sends or receives only a route whose destination is in the IP prefix list. You can configure up to 100 prefix lists. The software interprets the prefix lists in sequential order, beginning with the lowest sequence number.

Name, OID, and Syntax	Access	Description
snIpPrefixListTable fdry.1.2.2.14	None	IP Prefix List Table.
snIpPrefixListEntry fdry.1.2.2.14.1	None	An entry in the IP Prefix List Table.

Name, OID, and Syntax	Access	Description
snIpPrefixListName fdry.1.2.2.14.1.1 Syntax: Octet string	Read only	Specifies the name of the prefix list. This name can be used when applying the prefix list to a neighbor. It appears in an octet string; each character of the name is represented by one octet. There can be up to 32 octets for this name.
snIpPrefixListSequence fdry.1.2.2.14.1.2 Syntax: Integer	Read only	Shows the sequence of an entry in the table. There can be up to 100 prefix list entries. If a sequence number is not specified, then entries are numbered in increments of 5, beginning with prefix list entry 5. Incoming or outgoing routes are matched against the entries in the IP Prefix List in numerical order, beginning with the lowest sequence number.
snIpPrefixListDesc fdry.1.2.2.14.1.3 Syntax: Octet string	Read-write	Specifies the description of the prefix. This description is in an octet string; each character in the description is represented by one octet. There can be up to 80 octets in the description.
snIpPrefixListAction fdry.1.2.2.14.1.4 Syntax: Integer	Read-write	Indicates what to do with the route if it matches this entry: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snIpPrefixListAddr fdry.1.2.2.14.1.5 Syntax: IpAddress	Read-write	Shows the IP address of the prefix.
snIpPrefixListMask fdry.1.2.2.14.1.6 Syntax: IpAddress	Read-write	Shows the number of bits in the prefix network mask.
snIpPrefixListGeValue fdry.1.2.2.14.1.7 Syntax: Integer	Read-write	Specifies that the prefix is greater than the value of the "snIpPrefixListMask" object. Valid values: 0 – 32
snIpPrefixListLeValue fdry.1.2.2.14.1.8 Syntax: Integer	Read-write	Specifies that the prefix is less than the value of the "snIpPrefixListMask" object. Valid values: 0 – 32

**NOTE:** You can specify a range of length for prefixes that are more specific than the values for the "snIpPrefixListAddr" and "snIpPrefixListMask" objects. The <ge-value> or <le-value> you specify must meet the following condition:

$$\text{length} < \text{ge-value} \leq \text{le-value} \leq 32$$

If a value for "snIpPrefixListGeValue" is specified, then the mask-length range is from the value of "snIpPrefixListGeValue" to 32.

If a value for "snIpPrefixListLeValue" is specified, then mask-length range is from length to the value of "snIpPrefixListLeValue".

If no value is specified for either the less than or greater than objects, then routes must exactly match the prefixes on the list.

---

Name, OID, and Syntax	Access	Description
snIpPrefixListRowStatus fdry.1.2.2.14.1.9 Syntax: Integer	Read- write	Controls the management of the table rows. The values that can be written are: <ul data-bbox="743 338 1154 457" style="list-style-type: none"><li>• delete(3) – Delete the row</li><li>• create(4) – Create a new row</li><li>• modify(5) – Modify an existing row</li></ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul data-bbox="743 625 1138 737" style="list-style-type: none"><li>• noSuch(0) – No such row</li><li>• invalid(1) – Row is inoperative</li><li>• valid(2) – Row exists and is valid</li></ul>
snIpPrefixListLength fdry.1.2.2.14.1.10 Syntax: Integer	Read- write	The length of the IP prefix's mask.

---

## IP AS-Path Access List Table

The IP AS-Path Access List Table (snIpAsPathAccessListTable) has been deprecated in IronWare software release 07.5.00 and is no longer supported in Foundry devices.

## IP AS-Path Access List String Table

AS-PATH is a list of the other ASs through which a route passes. BGP4 routers can use the AS-path to detect and eliminate routing loops. The IP AS-Path Access List Table contains filters that are used to deny or permit updates received from BGP4 neighbors.

Name, OID, and Syntax	Access	Description
snIpAsPathAccessListStringTable fdry.1.2.2.16	None	IP As-Path Access List Table.
snIpAsPathAccessListStringEntry fdry.1.2.2.16.1	None	An entry in the IP As-Path Access List Table.
snIpAsPathAccessListStringName fdry.1.2.2.16.1.1 Syntax: Display string	Read only	An index for the entry in the table.
snIpAsPathAccessListStringSequence fdry.1.2.2.16.1.2 Syntax: Integer	Read only	The sequence index for this entry in this table.
snIpAsPathAccessListStringAction fdry.1.2.2.16.1.3 Syntax: Integer	Read-write	Determines what to do with the packet if its address matches this entry: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snIpAsPathAccessListStringRegularExpression fdry.1.2.2.16.1.4 Syntax: Integer	Read-write	Specifies the AS path information that will be permitted or denied. This object contains a regular expression. Each character of the regular expression string is represented by one octet.



---

Name, OID, and Syntax	Access	Description
snIpAsPathAccessListStringRow Status fdry.1.2.2.16.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are <ul data-bbox="760 338 1166 457" style="list-style-type: none"><li>• delete(3) – Delete the row</li><li>• create(4) – Create a new row</li><li>• modify(5) – Modify an existing row</li></ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are deleted immediately. The following values can be returned on reads: <ul data-bbox="760 583 1149 699" style="list-style-type: none"><li>• noSuch(0) – No such row</li><li>• invalid(1) – Row is inoperative</li><li>• valid(2) – Row exists and is valid</li></ul>

---



---

# Chapter 14

## RIP

Routing Information Protocol (RIP) is an IP route exchange protocol that uses a distance vector (a number representing distance) to measure the cost of a given route. The cost is a distance vector because the cost often is equivalent to the number of hops between the Foundry Layer 3 Switch and the destination network.

A Foundry Layer 3 Switch can receive multiple paths to a destination. A RIP route can have a maximum cost of 15.

Refer to the *Foundry Enterprise Configuration and Management Guide* for details on the features discussed in this chapter.

### IP RIP General Group

The following objects are general objects for RIP.

Name, OID, and Syntax	Access	Description
snRtIpRipEnable fdry.1.2.3.1.1 Syntax: Integer	Read-write	Indicates if IP RIP routing is enabled: <ul style="list-style-type: none"><li>disabled(0)</li><li>enabled(1)</li></ul> Default: disabled
snRtIpRipUpdateTime fdry.1.2.3.1.2 Syntax: Integer	Read-write	Specifies the RIP update interval in seconds. Valid values: 1 – 1000 seconds
snRtIpRipRedisEnable fdry.1.2.3.1.3 Syntax: Integer	Read-write	Indicates if redistribution of static routes from the IP route table into RIP is enabled: <ul style="list-style-type: none"><li>disabled(0)</li><li>enabled(1)</li></ul> Default: disabled
snRtIpRipRedisDefMetric fdry.1.2.3.1.4 Syntax: Integer	Read-write	Shows the default metric to be used when static routes are redistributed to RIP. Valid values: 1 – 15

Name, OID, and Syntax	Access	Description
<p>snRtlpRipSetAllPortConfig fdry.1.2.3.1.5 Syntax: Integer</p>	<p>Read- write</p>	<p>The value of this object is a number corresponding to a row in the “snRtlpRipPortConfigPortIndex” object of the “snRtlpRipPortConfigTable”. The values of the “snRtlpRipPortVersion” and “snRtlpRipPortPoisonReverse” objects will be written to that row.</p> <p><b>NOTE:</b> Before setting this object, all the intended data of the given row of the table must be set. Otherwise, the current data of the row will be used to set the entire “IP RIP Port Configuration Table”. The previous setting will be overwritten by the new one.</p>
<p>snRtlpRipGblFiltList fdry.1.2.3.1.6 Syntax: Octet string</p>	<p>Read- write</p>	<p>An IP RIP global filter list. Each octet contains a filter ID number that forms a group of filters. A valid entry in the “snRtlpRipRouteFilterTable” with the corresponding filter ID number in the “snRtlpRipRouteFilterId” object must be created before a filter list is initialized.</p> <p>Valid values: 1 – 64 octets.</p>
<p>snRtlpRipFiltOnAllPort fdry.1.2.3.1.7 Syntax: Integer</p>	<p>Read- write</p>	<p>Applies the IP RIP global filter object “snRtlpRipGblFiltList” to all interfaces. This object is used to add and delete all RIP filter lists to and from all interfaces. Prior to sending this command, “snRtlpRipGblFiltList” must contain the correct filter list.</p> <p>The values that can be written are:</p> <ul style="list-style-type: none"> <li>• deleteAllInBound(2) – delete all in-bound filter lists from all ports.</li> <li>• deleteAllOutBound(3) – delete all out-bound filter lists from all ports.</li> <li>• addAllInBound(4) – add all in-bound filter lists to all ports.</li> <li>• addAllOutBound(5) – add all out-bound filter lists to all ports.</li> </ul> <p>If a set operation failed, then a SET with value of (2) or (3) returns the error code "GenError". If the operation succeeded, then entries in this filter list are deleted immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• valid(1) – set operation is done and is valid.</li> </ul>
<p>snRtlpRipDistance fdry.1.2.3.1.8 Syntax: Integer</p>	<p>Read- write</p>	<p>Shows the administrative distance of this filter.</p> <p>Valid values: 1 – 255.</p>

## IP RIP Port Configuration Table

The IP RIP Port Configuration Table contains the configuration of RIP on a particular interface. Before you can use this table, RIP must be enabled in the device and the “Redistribution Table” on page 14-3 must be configured with permit and deny commands.

Name, OID, and Syntax	Access	Description
snRtIpRipPortConfigTable fdry.1.2.3.2	None	The IP Rip Port Configuration Table.
snRtIpRipPortConfigEntry fdry.1.2.3.2.1	None	An entry in the IP Rip Port Configuration Table.
snRtIpRipPortConfigPortIndex fdry.1.2.3.2.1.1 Syntax: PortIndex	Read only	The port index for an entry in the IP Rip Port Configuration Table.
snRtIpRipPortVersion fdry.1.2.3.2.1.2 Syntax: Integer	Read-write	Specifies the IP RIP version on this port: <ul style="list-style-type: none"> <li>disabled(0) – RIP is disabled on this port</li> <li>v1Only(1) – RIP version 1 only</li> <li>v2Only(2) – RIP version 2 only</li> <li>v1CompatibleV2(3) – RIP version 2 is compatible with version 1</li> </ul>
snRtIpRipPortPoisonReverse fdry.1.2.3.2.1.3 Syntax: Integer	Read-write	Indicates if poison reverse is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Poison reverse prevents routing loops and slow convergence within the network.
snRtIpRipPortLearnDefault fdry.1.2.3.2.1.4 Syntax: Integer	Read-write	Indicates if the ability to learn advertised routes is enabled on the interface: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>

## Redistribution Table

The RIP Redistribution Table contains routes where RIP routes will be redistributed. RIP can redistribute routes from other routing protocols such as OSPF and BGP4 into RIP. A redistributed route is one that a Layer 3 Switch learns through another protocol, then distributes into RIP.

Name, OID, and Syntax	Access	Description
snRtIpRipRedisTable fdry.1.2.3.3	None	IP RIP Redistribution table.

Name, OID, and Syntax	Access	Description
snRtIpRipRedisEntry fdry.1.2.3.3.1	None	An entry in the IP RIP Redistribution table.
snRtIpRipRedisIndex fdry.1.2.3.3.1.1 Syntax: Integer	Read only	The table index for a IP RIP Redistribution entry. There can be up to 64 entries in this table.
snRtIpRipRedisAction fdry.1.2.3.3.1.2 Syntax: Integer	Read-write	Indicates what to do if routes match this IP RIP Redistribution entry. <ul style="list-style-type: none"> <li>• deny(0)</li> <li>• permit(1)</li> </ul>
snRtIpRipRedisProtocol fdry.1.2.3.3.1.3 Syntax: Integer	Read-write	Indicates which protocol will to be distributed: <ul style="list-style-type: none"> <li>• other(1) – Cannot be used for SNMP-SET:</li> <li>• all(2)</li> <li>• static(3)</li> <li>• ospf(4)</li> <li>• bgp(5)</li> <li>• isis(6)</li> </ul>
snRtIpRipRedisIp fdry.1.2.3.3.1.4 Syntax: IpAddress	Read-write	Shows the IP address of the IP route to be distributed. The address 0.0.0.0 means that all routes will be distributed.
snRtIpRipRedisMask fdry.1.2.3.3.1.5 Syntax: IpAddress	Read-write	Shows the IP subnet mask of the IP route to be distributed.
snRtIpRipRedisMatchMetric fdry.1.2.3.3.1.6 Syntax: Integer	Read-write	Specifies the metric of the route to be matched to determine the redistribution.  Valid values: 0 – 65535. A value of 0 means that any metric value will be matched.
snRtIpRipRedisSetMetric fdry.1.2.3.3.1.7 Syntax: Integer	Read-write	Specifies the new metric of the route to be advertised.  Valid values: 0 – 15. A value of 0 indicates that the default metric will be used.

Name, OID, and Syntax	Access	Description
snRtlpRipRedisRowStatus fdry.1.2.3.3.1.8 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snRtlpRipRedisRouteMapName fdry.1.2.3.3.1.9 Syntax: Display string	Read-write	Indicates the name of the route map used for this redistribution entry.

## IP RIP Route Filter Table

The IP RIP Route Filter Table defines the IP network numbers the router will learn from the RIP protocol. The numbers are stored in the router's IP routing table. Once RIP filters are defined, you can assign them to individual interfaces.

Name, OID, and Syntax	Access	Description
snRtlpRipRouteFilterTable fdry.1.2.3.4	None	IP RIP Route Filter Table.
snRtlpRipRouteFilterEntry fdry.1.2.3.4.1	None	An entry of the IP RIP route filter table.
snRtlpRipRouteFilterId fdry.1.2.3.4.1.1 Syntax: Integer	Read only	Shows the filter ID to identify a filter entry. There can be up to 64 entries in this table.
snRtlpRipRouteFilterAction fdry.1.2.3.4.1.2 Syntax: Integer	Read-write	<p>Indicates what action to take if the IP RIP packet matches this filter.</p> <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snRtlpRipRouteFilterIpAddr fdry.1.2.3.4.1.3 Syntax: IpAddress	Read-write	Indicates the route IP address that needs to be matched by any IP address in a RIP packet. A value of 0.0.0.0 means that any IP address in any RIP packets will be matched.

Name, OID, and Syntax	Access	Description
snRtlpRipRouteFilterSubnetMask fdry.1.2.3.4.1.4 Syntax: IpAddress	Read-write	If "snRtlpRipRouteFilterIpAddr" is 0, this value is ignored, and all IP RIP packets will be matched. Otherwise, this mask is applied to the IP RIP packet and then compared to "snRtlpRipRouteFilterIpAddr" to determine a match.
snRtlpRipRouteFilterRowStatus fdry.1.2.3.4.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## IP RIP Neighbor Filter Table

The IP RIP Neighbor Filter Table specifies the routers from which a router will receive RIP routes. By default, RIP routes will be learned from all neighbors.

Name, OID, and Syntax	Access	Description
snRtlpRipNbrFilterTable fdry.1.2.3.5	None	IP RIP Neighbor Filter Table
snRtlpRipNbrFilterEntry fdry.1.2.3.5.1	None	An entry of the IP RIP neighbor filter table.
snRtlpRipNbrFilterId fdry.1.2.3.5.1.1 Syntax: Integer	Read only	Indicates the ID of this entry in the table. There can be up to 64 entries in this table.
snRtlpRipNbrFilterAction fdry.1.2.3.5.1.2 Syntax: Integer	Read-write	Indicates what action to take if the source IP address in a packet matches the source IP address in this filter. The IP address to be matched is defined by the "snRtlpRipNbrFilterSourceIp" object. <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snRtlpRipNbrFilterSourceIp fdry.1.2.3.5.1.3 Syntax: IpAddress	Read-write	Shows the source IP address that needs to be matched by the RIP packet. An IP address of 0.0.0.0 always matches any source IP addresses in any IP RIP packets.



Name, OID, and Syntax	Access	Description
snRtlpRipNbrFilterRowStatus fdry.1.2.3.5.1.4 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## IP RIP Port Access Table

The IP RIP Port Access Table allows a group of RIP filters to be applied to an IP interface. The filters can be applied to either incoming or outgoing traffic.

Name, OID, and Syntax	Access	Description
snRtlpRipPortAccessTable fdry.1.2.3.6	None	IP interface RIP access table.
snRtlpRipPortAccessEntry fdry.1.2.3.6.1	None	An entry of the IP interface RIP access table.
snRtlpRipPortAccessPort fdry.1.2.3.6.1.1 Syntax: PortIndex	Read only	The port number to which the IP RIP filter applies.
snRtlpRipPortAccessDir fdry.1.2.3.6.1.2 Syntax: Integer	Read only	<p>Specifies if the filter is for incoming or outgoing packets:</p> <ul style="list-style-type: none"> <li>in(1) – Incoming packet</li> <li>out(2) – Outgoing packet</li> </ul>
snRtlpRipPortAccessFilterList fdry.1.2.3.6.1.3 Syntax: Octet string	Read-write	<p>Contains an IP RIP filter list.</p> <p>Valid values: Up to 64 octets. Each octet contains a filter ID number that consists of a group of filters. Before a filter list can be created, there must be valid entries in the IP RIP Route Filter Table ("snRtlpRipRouteFilterTable" object) with their corresponding filter ID number entered in the "snRtlpRipRouteFilterId" object.</p>

Name, OID, and Syntax	Access	Description
snRtIpRipPortAccessRowStatus fdry.1.2.3.6.1.4 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## Global RIP Statistics

These objects provide global RIP statistics. They were introduced in Service Provider Release 09.1.02 and Enterprise IronWare Release 07.8.00.

Name, Identifier, and Syntax	Access	Description
snRtIpRipStats fdry.1.2.3.9	NA	RIP Statistics group.
snRtIpRipStatsOutRequest fdry.1.2.3.9.1 Syntax: Integer	Read only	Number of outgoing RIP requests.
snRtIpRipStatsOutResponse fdry.1.2.3.9.2 Syntax: Integer	Read only	Number of outgoing RIP responses.
snRtIpRipStatsInRequest fdry.1.2.3.9.3 Syntax: Integer	Read only	Number of incoming RIP requests.
snRtIpRipStatsInResponse fdry.1.2.3.9.4 Syntax: Integer	Read only	Number of incoming RIP responses.
snRtIpRipStatsUnrecognized fdry.1.2.3.9.5 Syntax: Integer	Read only	Number of unrecognized RIP packets.

<b>Name, Identifier, and Syntax</b>	<b>Access</b>	<b>Description</b>
snRtIpRipStatsBadVersion fdry.1.2.3.9.6 Syntax: Integer	Read only	Number of RIP packets with bad version number.
snRtIpRipStatsBadAddrFamily fdry.1.2.3.9.7 Syntax: Integer	Read only	Number of RIP packets with bad address family value.
snRtIpRipStatsBadRequestFormat fdry.1.2.3.9.8 Syntax: Integer	Read only	Number of RIP packets with bad request format.
snRtIpRipStatsBadMetrics fdry.1.2.3.9.9 Syntax: Integer	Read only	Number of RIP packets with bad metric value.
snRtIpRipStatsBadRespFormat fdry.1.2.3.9.10 Syntax: Integer	Read only	Number of RIP packets with bad response format.
snRtIpRipStatsRespFromNonRipPort fdry.1.2.3.9.11 Syntax: Integer	Read only	Number of RIP packet responses coming from non-RIP configured ports.
snRtIpRipStatsResponseFromLoopback fdry.1.2.3.9.12 Syntax: Integer	Read only	Number of RIP packet responses coming from loopback ports.
snRtIpRipStatsPacketRejected fdry.1.2.3.9.13 Syntax: Integer	Read only	Number of RIP packets rejected.



---

# Chapter 15

## OSPF

This chapter presents the objects for the Open Shortest Path First (OSPF) protocol. OSPF objects are available in all Foundry devices, except ServerIron.

Objects presented in this chapter are:

- “OSPF General Objects” on page 15-2
- “OSPF Area Table” on page 15-4
- “Area Range Table” on page 15-5
- “OSPF Interface Configuration Tables” on page 15-6
- “OSPF Virtual Interface Table” on page 15-13
- “OSPF Redistribution of Routes Table” on page 15-16
- “OSPF Neighbor Table” on page 15-18
- “OSPF Virtual Neighbor Table” on page 15-21
- “OSPF Link-State Database” on page 15-23
- “OSPF Link State Database, External” on page 15-25
- “OSPF Area Status Table” on page 15-26
- “OSPF Interface Status Table” on page 15-27
- “OSPF Virtual Interface Status Table” on page 15-31
- “OSPF Routing Information Table” on page 15-34

For objects relating to OSPF traps, refer to the chapter “Traps and Objects to Enable Traps” on page 23-1.

Refer to the *Foundry Enterprise Configuration and Management Guide* for details on the features discussed in this chapter.

---

**NOTE:** Beginning with software release 07.6.03, Foundry devices support RFC 1850 instead of the objects in this chapter. Also, BigIron MG8, NetIron 40G, and FastIron Edge Switch support RFC 1850.

---

## OSPF General Objects

These objects provide information about the OSPF Process. They apply globally to the routers.

Name, OID, and Syntax	Access	Description
snOspfRouterId fdry.1.2.4.1.1 Syntax: RouterID	Read-write	Shows the IP address of the Autonomous System Boundary Router. Conventionally, this ID defaults to IP address of one of the routers to ensure uniqueness in the network. This object contains a 32-bit integer.  Reference: RFC 1583 "OSPF Version 2", section C.1 Global parameters
snOspfAdminStat fdry.1.2.4.1.2 Syntax: Integer	Read-write	Specifies the state of the OSPF in the router: <ul style="list-style-type: none"> <li>disabled(0) – OSPF is disabled on all interfaces</li> <li>enabled(1) – OSPF is active on at least one interface</li> </ul>
snOspfASBdrRtrStatus fdry.1.2.4.1.3 Syntax: TruthVal	Read-write	Indicates if this router is an Autonomous System Boundary Router: <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul> Reference: RFC 1583 "OSPF Version 2", Section 3.3 Classification of routers
snOspfRedisMode fdry.1.2.4.1.4 Syntax: Integer	Read-write	Specifies if OSPF redistribution has been enabled on this router: <ul style="list-style-type: none"> <li>disabled(0) – OSPF redistribution is disabled</li> <li>enabled(1) – OSPF redistribution is active</li> </ul>
snOspfDefaultOspfMetricValue fdry.1.2.4.1.5 Syntax: Integer	Read-write	Shows the cost of using a default OSPF Metric value on this route.  Valid values: 1 – 65535
snOspfExternLSACount fdry.1.2.4.1.6 Syntax: Counter	Read only	The number of external link-state advertisements in the link-state database.  Reference: RFC 1583 "OSPF Version 2", section A.4.5 AS external link advertisements (LS type 5)
snOspfExternLSACKsumSum fdry.1.2.4.1.7 Syntax: Integer	Read only	Indicates the 32-bit unsigned sum of the LS checksums of the external link-state advertisements contained in the link-state database. This sum can be used to determine if there has been a change in a router's link-state database and to compare the link-state database of two routers.
snOspfOriginateNewLSAs fdry.1.2.4.1.8 Syntax: Counter	Read only	Shows the number of new link-state advertisements that have been originated by the router. This number increments each time the router originates a new LSA.

Name, OID, and Syntax	Access	Description
snOspfRxNewLSAs fdry.1.2.4.1.9 Syntax: Counter	Read only	Shows the number of link-state advertisements received by the router. This number does not include newer instantiations of self-originated link-state advertisements.
snOspfOspfRedisMetricType fdry.1.2.4.1.10 Syntax: Integer	Read-write	Indicates the type of route: <ul style="list-style-type: none"> <li>type1(1) – External Type 1 (comparable value) the intra-area and inter-area routes. It is an OSPF metric plus the external Metric.</li> <li>type2(2) – External Type 2 (non-comparable value) routes, it is the external metric.</li> </ul>
snOspfExtLsdbLimit fdry.1.2.4.1.11 Syntax: Integer	Read-write	Provides compliance with RFC 1765 in the handling of OSPF external link-state database (LSDB) overflow  Specifies the maximum number of non-default AS-external-LSAs entries that can be stored in the link-state database. When the number of non-default AS-external-LSAs in a router's link-state database reaches ospfExtLsdbLimit, the router enters Overflow State. The router never holds more than ospfExtLsdbLimit non-default AS-external-LSAs in its database. OspfExtLsdbLimit MUST be set identically in all routers attached to the OSPF backbone and/or any regular OSPF area. (i.e., OSPF stub areas and NSSAs are excluded).  Valid values: 1 – 2000. If the value is -1, then there is no limit.
snOspfExitOverflowInterval fdry.1.2.4.1.12 Syntax: Integer	Read-write	Specifies the number of seconds that a router will attempt to leave the overflow state once it is in that state. This value allows the router to again originate non-default AS-external-LSAs. If this object is set to 0, the router will not leave the overflow state until it is restarted.  Valid values: 0 – 86400 seconds.
snOspfRfc1583Compatibility fdry.1.2.4.1.13 Syntax: Integer	Read-write	Specifies if the OSPF route is compatible with RFC1583 or RFC2178: <ul style="list-style-type: none"> <li>disabled(0) – Compatible with RFC 2178.</li> <li>enabled(1) – Compatible with RFC 1583.</li> </ul>
snOspfRouterIdFormat fdry.1.2.4.1.14 Syntax: Integer	Read-write	Specifies the format of how Router ID will be entered in the "snOspfRouterId" object: <ul style="list-style-type: none"> <li>integer(0) – Integer.</li> <li>ipAddress(1) – IP address.</li> </ul>
snOspfDistance fdry.1.2.4.1.15 Syntax: Integer	Read-write	Determines the OSPF administrative distance for intra-area routes.  Default: 110  Valid values: 1 – 255

Name, OID, and Syntax	Access	Description
snOspfDistanceIntra fdry.1.2.4.1.16	Read-write	Determines the OSPF administrative distance for intra-area routes.  Default: 110 Valid values: 1 – 255
snOspfDistanceInter fdry.1.2.4.1.17 Syntax: Integer	Read-write	Determines the OSPF administrative distance for inter-area routes.  Default: 110 Valid values: 1 – 255
snOspfDistanceExternal fdry.1.2.4.1.18 Syntax: Integer	Read-write	Determines the OSPF administrative distance for external routes.  Valid values: 1 – 255 Default: 110

## OSPF Area Table

The OSPF Area Data Structure contains information that describes the various OSPF areas. The interfaces and virtual links are configured as part of these areas. Area 0.0.0.0, by definition, is the Backbone Area.

Reference: RFC 1583 “OSPF Version 2”, section 6 The Area Data Structure

Name, OID, and Syntax	Access	Description
snOspfAreaTable fdry.1.2.4.2.1	None	The OSPF Area Table
snOspfAreaEntry fdry.1.2.4.2.1.1	None	An entry in the OSPF Area Table
snOspfAreald fdry.1.2.4.2.1.1.1 Syntax: AreaID	Read only	Specifies the address of the area. This address identifies the router, independent of its IP address. Area ID 0.0.0.0 is used for the OSPF backbone. The format used for this ID is specified by the “snOspfArealdFormat” object.  Reference: RFC 1583 “OSPF Version 2”, section C.2 Area parameters



Name, OID, and Syntax	Access	Description
snOspfImportASExtern fdry.1.2.4.2.1.1.2 Syntax: Integer	Read-write	<p>Indicates the type of OSPF area that this router supports:</p> <ul style="list-style-type: none"> <li>0 – Stub area. OSPF routers within a stub area cannot send or receive external LSAs. In addition, OSPF routers in a stub area must use a default route to the area's Area Border Router (ABR) or Autonomous System Boundary Router (ASBR) to send traffic out of the area.</li> <li>1 – Normal area. OSPF routers within a normal area can send and receive external link-state advertisements</li> <li>2 – NSSA area ASBR of an NSSA can import external route information into the area.</li> </ul> <p>Reference: RFC 1583 "OSPF Version 2", section C.2 Area parameters</p>
snOspfStubMetric fdry.1.2.4.2.1.1.3 Syntax: BigMetric	Read-write	<p>The metric value applied at the default type of service(ospfMetric). By default, this equals the least metric at the type of service among the interfaces to other areas. This object exist only if the value of snOspfAreaSummary is snOspfAreaSummary(2); Otherwise, an SNMP_GET/GET_NEXT attempt of this Object will return NO_SUCH_NAME.</p>
snOspfAreaRowStatus fdry.1.2.4.2.1.1.4 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snOspfArealdFormat fdry.1.2.4.2.1.1.5 Syntax: Integer	Read-write	<p>Specifies the format of Area ID entered in the "snOspfIfAreald" object:</p> <ul style="list-style-type: none"> <li>integer(0) – Integer</li> <li>ipAddress(1) – IP address</li> </ul>

## Area Range Table

The area range allows you to assign an aggregate value to a range of IP addresses. This aggregate value becomes the address that is advertised instead all of the individual addresses it represents being advertised. The Area Range table contains the aggregate value of the ranges of IP addresses that are configured to be propagated from an OSPF area.

Reference: RFC 1583 “OSPF Version 2”, section C.2 Area parameters.

Name, OID, and Syntax	Access	Description
snOspfAreaRangeTable fdry.1.2.4.3.1	None	The Area Range Table.
snOspfAreaRangeEntry fdry.1.2.4.3.1.1	None	An entry in the Area Range Table.
snOspfAreaRangeAreaID fdry.1.2.4.3.1.1.1 Syntax: AreaID	Read only	Specifies the ID of the area where the address range can be found. The object “snOspfAreaRangeAreaIDFormat” determines the format of this object.
snOspfAreaRangeNet fdry.1.2.4.3.1.1.2 Syntax: IpAddress	Read only	Specifies the IP Address of the net or subnet indicated by the range.
snOspfAreaRangeMask fdry.1.2.4.3.1.1.3 Syntax: IpAddress	Read-write	Specifies the subnet mask that pertains to the net or subnet.
snOspfAreaRangeRowStatus fdry.1.2.4.3.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snOspfAreaRangeAreaIDFormat fdry.1.2.4.3.1.1.5 Syntax: Integer	Read only	Specifies the format of how Area ID will be entered in the “snOspfAreaRangeAreaID” object: <ul style="list-style-type: none"> <li>integer(0) – Integer.</li> <li>ipAddress(1) – IP Address.</li> </ul>

## OSPF Interface Configuration Tables

The OSPF Interface Table augments the ifTable with OSPF specific information.

References:

- Reference: RFC 1583 “OSPF Version 2”, section C.3 Router interface parameters.
- Reference: RFC 1583 “OSPF Version 2”, section E Authentication.

## OSPF Interface Configuration Table

Name, OID, and Syntax	Access	Description
snOspfIfTable fdry.1.2.4.4.1	None	The OSPF Interface Configuration Table.
snOspfIfEntry fdry.1.2.4.4.1.1	None	An entry in the OSPF Interface Configuration Table.
snOspfIfPort fdry.1.2.4.4.1.1.1 Syntax: Integer	Read only	The physical router port of this OSPF interface.
snOspfIfAreaID fdry.1.2.4.4.1.1.2 Syntax: AreaID	Read-write	Specifies the address of the area in a 32-bit integer. This address uniquely identifies the area to which the interface connects. Area ID 0.0.0.0 is used for the OSPF backbone.  Default: '00000000'h, which equals to 0.0.0.0
snOspfIfAdminStat fdry.1.2.4.4.1.1.3 Syntax: Integer	Read-write	Indicates if neighbor relationships may be formed on this interface: <ul style="list-style-type: none"> <li>disabled(0) – The interface is external to OSPF</li> <li>enabled(1) – Neighbor relationships may be formed on the interface, which will be advertised as an internal route to an area.</li> </ul> Default: enabled(1)
snOspfIfRtrPriority fdry.1.2.4.4.1.1.4 Syntax: DesignatedRouterPriority	Read-write	Specifies the priority of this interface. This object is used in the designated router election algorithm for multi-access networks.  Valid values: 0 – 255. A value of 0 signifies that the router is not eligible to become the designated router on this particular network.  If two or more routers have the same priority value, then the router with the highest router ID becomes the designated router. The router with the next highest router ID becomes the backup designated router.
snOspfIfTransitDelay fdry.1.2.4.4.1.1.5 Syntax: UpToMaxAge	Read-write	Shows the time it takes to transmit link-state update packets on this interface.  Valid values: 0 – 3600 seconds  Default: 1 second
snOspfIfRetransInterval fdry.1.2.4.4.1.1.6 Syntax: UpToMaxAge	Read-write	Specifies the number of seconds between link-state advertisement retransmissions, for adjacencies belonging to this interface. This value is also used when retransmitting database description and link-state request packets. Values can be from 0 – 3600 seconds.  Default: 5 seconds

Name, OID, and Syntax	Access	Description
snOspfIfHelloInterval fdry.1.2.4.4.1.1.7 Syntax: HelloRange	Read- write	Specifies the number of seconds that router waits before it sends the next Hello packet on this interface. This value must be the same for all routers attached to a common network. Values can be from 1 – 65535 seconds (up to 'FFFF'h).  Valid values: 1 – 65535 seconds  Default: 10 seconds
snOspfIfRtrDeadInterval fdry.1.2.4.4.1.1.8 Syntax: PositiveInteger	Read- write	Specifies the number of seconds that neighbor routers wait for a router's Hello packets before they declare that the router is down. This should be a multiple of the Hello interval. This value must be the same for all routers attached to a common network.  Valid values: 1 – 2147483647 seconds  Default: 40 seconds
snOspfIfAuthType fdry.1.2.4.4.1.1.9 Syntax: Integer	Read- write	Specifies the authentication type for an interface.  Valid values: <ul style="list-style-type: none"> <li>• none(0)</li> <li>• simplePassword(1)</li> <li>• md5(2)</li> <li>• reserved for specification by IANA(&gt; 2)</li> </ul> Additional authentication types may be assigned locally on a per interface basis, up to 255.  Default: none(0)
snOspfIfAuthKey fdry.1.2.4.4.1.1.10 Syntax: Octet string	Read- write	Indicates the authentication key. <ul style="list-style-type: none"> <li>• If the authentication type selected is simple password, then this object requires an alphanumeric password. If the value is shorter than eight octets, the agent will left-adjust and zero-fill the key to equal eight octets.                               The simple password setting takes effect immediately. All OSPF packets transmitted on the interface contain this password. Any OSPF packet received on the interface is checked for this password. If the password is not present, then the packet is dropped. The password can be up to eight characters long.</li> <li>• If the authentication type is MD5, then a key ID and an MD5 key are required. The key ID is a number from 1 to 255 and identifies the MD5 key that is being used. The MD5 key can be up to sixteen alphanumeric characters long.</li> </ul> Default: '0000000000000000'h, which is equal to 0.0.0.0.0.0.0  When read, "snOspfIfAuthKey" always returns a blank.  Reference: RFC 1583 "OSPF Version 2", section 9, The Interface Data Structure

Name, OID, and Syntax	Access	Description
snOspfIfMetricValue fdry.1.2.4.4.1.1.11 Syntax: Integer	Read-write	Specifies the cost of using this type of service (TOS) on this interface. The default value of the TOS 0 Metric is equal to 10 <sup>8</sup> divided by the ifSpeed.
snOspfIfRowStatus fdry.1.2.4.4.1.1.12 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snOspfIfMd5AuthKeyId fdry.1.2.4.4.1.1.13 Syntax: Integer	Read-write	<p>Specifies the ID of the MD5 authentication key. If the object "snOspfVirtIfAuthType" is set to MD5, this object identifies the algorithm and secret key used to create the message digest appended to the OSPF packet. Key identifiers are unique per-interface (or equivalently, per-subnet).</p> <p>The value of this object must be a number from 1 – 255.</p>
snOspfIfMd5AuthKey fdry.1.2.4.4.1.1.14 Syntax: Octet string	Read-write	<p>Specifies the MD5 authentication key. If the object "snOspfVirtIfAuthType" is set to MD5, the value of this object is encrypted and included in each OSPF packet transmitted.</p> <p>The agent will left-adjust and zero-fill the key to equal 16 octets.</p> <p>When read, snOspfIfMd5AuthKey always returns a blank.</p>
snOspfIfMd5ActivationWaitTime fdry.1.2.4.4.1.1.15 Syntax: Integer	Read-write	<p>Determines when a newly configured MD5 authentication key is valid. This parameter provides a graceful transition from one MD5 key to another without disturbing the network. All new packets transmitted after the key activation wait time interval use the newly configured MD5 key. OSPF packets that contain the old MD5 key are accepted for up to five minutes after the new MD5 key is in operation. The range for the key activation wait time is from 0 – 14400 seconds.</p> <p>Default: 300 seconds</p>
snOspfIfAreaIdFormat fdry.1.2.4.4.1.1.16 Syntax: Integer	Read only	<p>Specifies the format of how Area ID will be entered in the "snOspfIfAreaId" object</p> <ul style="list-style-type: none"> <li>integer(0) – Integer</li> <li>ipAddress(1) – IP Address</li> </ul>

Name, OID, and Syntax	Access	Description
snOspfIfPassiveMode fdry.1.2.4.4.1.1.17 Syntax: Integer	Read-write	Indicates if passive mode is enabled on this interface: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snOspfIfDatabaseFilterAllOut fdry.1.2.4.4.1.1.18 Syntax: Integer	Read-write	Determines if the filtering of outgoing OSPF LSA on this interface is enabled: <ul style="list-style-type: none"> <li>disabled(0) – Filtering is disabled</li> <li>enabled(1) – Filtering is enabled</li> </ul>
snOspfIfMtuIgnore fdry.1.2.4.4.1.1.19 Syntax: Integer	Read-write	Determines if the MTU detection mode of this interface is enabled: <ul style="list-style-type: none"> <li>disabled(0) – MTU detection mode is disabled</li> <li>enabled(1) – MTU detection mode is enabled</li> </ul>
snOspfIfNetworkP2mp fdry.1.2.4.4.1.1.20 Syntax: Integer	Read-write	This object is not supported in Foundry devices. Determines if the P2MP mode of this interface is enabled: <ul style="list-style-type: none"> <li>disabled(0) – P2MP mode is disabled</li> <li>enabled(1) – P2MP mode is enabled</li> </ul>

## OSPF Interface 2 Configuration Table

Name, OID, and Syntax	Access	Description
snOspfIf2Table fdry.1.2.4.4.2 Syntax: Integer	None	Determines if the P2MP mode of this interface is enabled: <ul style="list-style-type: none"> <li>disabled(0) – P2MP mode is disabled</li> <li>enabled(1) – P2MP mode is enabled</li> </ul>
snOspfIf2Entry fdry.1.2.4.4.2.1	None	An entry in the OSPF Interface 2 Configuration Table.
snOspfIf2Port fdry.1.2.4.4.2.1.1 Syntax: Integer	Read only	The physical router port of this OSPF interface.
snOspfIf2ArealD fdry.1.2.4.4.2.1.2 Syntax: ArealD	Read-write	Specifies the address of the area in a 32-bit integer. This address uniquely identifies the area to which the interface connects. Area ID 0.0.0.0 is used for the OSPF backbone.  Default: '00000000'h, which equals to 0.0.0.0
snOspfIf2AdminStat fdry.1.2.4.4.2.1.3 Syntax: Integer	Read-write	Indicates if neighbor relationships may be formed on this interface: <ul style="list-style-type: none"> <li>disabled(0) – The interface is external to OSPF</li> <li>enabled(1) – Neighbor relationships may be formed on the interface, which will be advertised as an internal route to an area.</li> </ul> Default: enabled(1)

Name, OID, and Syntax	Access	Description
snOspfIf2RtrPriority fdry.1.2.4.4.2.1.4 Syntax: DesignatedRouterPriority	Read-write	<p>Specifies the priority of this interface. This object is used in the designated router election algorithm for multi-access networks.</p> <p>Valid values: 0 – 255. A value of 0 signifies that the router is not eligible to become the designated router on this particular network.</p> <p>If two or more routers have the same priority value, then the router with the highest router ID becomes the designated router. The router with the next highest router ID becomes the backup designated router.</p>
snOspfIf2TransitDelay fdry.1.2.4.4.2.1.5 Syntax: UpToMaxAge	Read-write	<p>Shows the time it takes to transmit link-state update packets on this interface.</p> <p>Valid values: 0 – 3600 seconds</p> <p>Default: 1 second</p>
snOspfIf2RetransInterval fdry.1.2.4.4.2.1.6 Syntax: UpToMaxAge	Read-write	<p>Specifies the number of seconds between link-state advertisement retransmissions, for adjacencies belonging to this interface. This value is also used when retransmitting database description and link-state request packets.</p> <p>Valid values: 0 – 3600 seconds</p> <p>Default: 5 seconds</p>
snOspfIf2HelloInterval fdry.1.2.4.4.2.1.7 Syntax: HelloRange	Read-write	<p>Specifies the number of seconds that router waits before it sends the next Hello packet on this interface. This value must be the same for all routers attached to a common network. Values can be from 1 – 65535 seconds (up to 'FFFF'h).</p> <p>Valid values: 1 – 65535 seconds</p> <p>Default: 10 seconds</p>
snOspfIf2RtrDeadInterval fdry.1.2.4.4.2.1.8 Syntax: PositiveInteger	Read-write	<p>Specifies the number of seconds that neighbor routers wait for a router's Hello packets before they declare that the router is down. This should be a multiple of the Hello interval. This value must be the same for all routers attached to a common network.</p> <p>Valid values: 1 – 2147483647 seconds</p> <p>Default: 40 seconds</p>
snOspfIf2AuthType fdry.1.2.4.4.2.1.9 Syntax: Integer	Read-write	<p>Specifies the authentication type for an interface.</p> <p>Valid values::</p> <ul style="list-style-type: none"> <li>• none(0)</li> <li>• simplePassword(1)</li> <li>• md5(2)</li> <li>• reserved for specification by IANA(&gt; 2)</li> </ul> <p>Additional authentication types may be assigned locally on a per interface basis. The value of this object can be up – 255.</p> <p>Default: none(0)</p>

Name, OID, and Syntax	Access	Description
<p>snOspfIf2AuthKey fdry.1.2.4.4.2.1.10 Syntax: Octet string</p>	Read-write	<p>Indicates the authentication key.</p> <ul style="list-style-type: none"> <li>If the authentication type selected is simple password, then this object requires an alphanumeric password. If the value is shorter than eight octets, the agent will left-adjust and zero-fill the key to equal eight octets.</li> </ul> <p>The simple password setting takes effect immediately. All OSPF packets transmitted on the interface contain this password. Any OSPF packet received on the interface is checked for this password. If the password is not present, then the packet is dropped. The password can be up to eight characters long.</p> <ul style="list-style-type: none"> <li>If the authentication type is MD5, then a key ID and an MD5 key are required. The key ID is a number from 1 to 255 and identifies the MD5 key that is being used. The MD5 key can be up to sixteen alphanumeric characters long.</li> </ul> <p>Valid values: Up to eight octets.</p> <p>Default: '0000000000000000'h which is equal to 0.0.0.0.0.0.0</p> <p>When read, "snOspfIf2AuthKey" always returns a blank.</p> <p>Reference: RFC 1583 "OSPF Version 2", section 9 The Interface Data Structure</p>
<p>snOspfIf2MetricValue fdry.1.2.4.4.2.1.11 Syntax: Integer</p>	Read-write	<p>Specifies the cost of using this type of service (TOS) on this interface. The default value of the TOS 0 Metric is equal to 10<sup>8</sup> divided by the ifSpeed.</p> <p>Valid values: 0 – 65535</p>
<p>snOspfIf2RowStatus fdry.1.2.4.4.2.1.12 Syntax: Integer</p>	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
<p>snOspfIf2Md5AuthKeyId fdry.1.2.4.4.2.1.13 Syntax: Integer</p>	Read-write	<p>Specifies the ID of the MD5 authentication key. If the object "snOspfVirtIfAuthType" is set to MD5, this object identifies the algorithm and secret key used to create the message digest appended to the OSPF packet. Key identifiers are unique per interface (or equivalently, per subnet).</p> <p>The value of this object must be a number from 1 – 255.</p>



Name, OID, and Syntax	Access	Description
snOspfIf2Md5AuthKey fdry.1.2.4.4.2.1.14 Syntax: Octet string	Read-write	Specifies the MD5 authentication key. If the object “snOspfVirtIfAuthType” is set to MD5, the value of this object is encrypted and included in each OSPF packet transmitted.  The agent will left-adjust and zero-fill the key to equal 16 octets.  When read, “snOspfIf2Md5AuthKey” always returns a blank.  Valid values: Up to 16 octets.
snOspfIf2Md5ActivationWaitTime fdry.1.2.4.4.2.1.15 Syntax: Integer	Read-write	Determines when a newly configured MD5 authentication key is valid. This parameter provides a graceful transition from one MD5 key to another without disturbing the network. All new packets transmitted after the key activation wait time interval use the newly configured MD5 key. OSPF packets that contain the old MD5 key are accepted for up to five minutes after the new MD5 key is in operation. The range for the key activation wait time is from 0 – 14400 seconds.  Default: 300 seconds
snOspfIf2AreaIdFormat fdry.1.2.4.4.2.1.16 Syntax: Integer	Read only	Specifies the format of how Area ID will be entered in the “snOspfIfAreaId” object <ul style="list-style-type: none"> <li>integer(0) – Integer</li> <li>ipAddress(1) – IP Address</li> </ul>
snOspfIf2PassiveMode fdry.1.2.4.4.2.1.17 Syntax: Integer	Read-write	Indicates if passive mode is enabled on this interface: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snOspfIf2DatabaseFilterAllOut fdry.1.2.4.4.2.1.18 Syntax: Integer	Read-write	Determines if the filtering of outgoing OSPF LSA on this interface is enabled: <ul style="list-style-type: none"> <li>disabled(0) – Filtering is disabled</li> <li>enabled(1) – Filtering is enabled</li> </ul>
snOspfIf2MtuIgnore fdry.1.2.4.4.2.1.19 Syntax: Integer	Read-write	Determines if the MTU detection mode of this interface is enabled: <ul style="list-style-type: none"> <li>disabled(0) – MTU detection mode is disabled</li> <li>enabled(1) – MTU detection mode is enabled</li> </ul>
snOspfIf2NetworkP2mp fdry.1.2.4.4.2.1.20 Syntax: Integer	Read-write	Determines if the P2MP mode of this interface is enabled: <ul style="list-style-type: none"> <li>disabled(0) – P2MP mode is disabled</li> <li>enabled(1) – P2MP mode is enabled</li> </ul>
snOspfIf2NetworkP2pt fdry.1.2.4.4.2.1.21 Syntax: Integer	Read-write	This object enables and disables OSPF point-to-point mode on an interface: <ul style="list-style-type: none"> <li>disabled(0) – Disables the feature</li> <li>enabled(1) – Enables the feature</li> </ul>

## OSPF Virtual Interface Table

The Virtual Interface Table describes the virtual links that the OSPF process is configured to carry.

References:

- RFC 1583 “OSPF Version 2”, section C.4 Virtual link parameters
- RFC 1583 “OSPF Version 2”, section 9 The Interface Data Structure

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snOspfVirtIfTable fdry.1.2.4.5.1	None	The OSPF Virtual Interface Table.
snOspfVirtIfEntry fdry.1.2.4.5.1.1	None	An entry in the OSPF Virtual Interface Table.
snOspfVirtIfArealD fdry.1.2.4.5.1.1.1 Syntax: ArealD	Read only	Specifies the ID of the transit Area that the Virtual link traverses. A value of 0.0.0.0 is not valid.
snOspfVirtIfNeighbor fdry.1.2.4.5.1.1.2 Syntax: RouterID	Read only	Shows the IP address of the ID of the router that is serving as the virtual neighbor.
snOspfVirtIfTransitDelay fdry.1.2.4.5.1.1.3 Syntax: UpToMaxAge	Read-write	Shows the time it takes to transmit link-state update packets on this interface.  Valid values: 0 – 3600 seconds  Default: 1 second
snOspfVirtIfRetransInterval fdry.1.2.4.5.1.1.4 Syntax: UpToMaxAge	Read-write	Specifies the interval between the retransmission of link-state advertisements to router adjacencies for this interface.  Valid values: 0 – 3600 seconds  Default: 5 seconds  This value is also used when retransmitting database description and link-state request packets. This value should be greater than the expected roundtrip time.
snOspfVirtIfHelloInterval fdry.1.2.4.5.1.1.5 Syntax: HelloRange	Read-write	Specifies the number of seconds that router waits before it sends the next Hello packet on this interface. This value must be the same for all routers attached to a common network.  Valid values: from 1 – 65535 seconds  Default: 10 seconds  This value must be the same for the virtual neighbor.
snOspfVirtIfRtrDeadInterval fdry.1.2.4.5.1.1.6 Syntax: PositiveInteger	Read-write	Specifies the number of seconds that neighbor routers wait for a router’s Hello packets before they declare that the router is down. This should be a multiple of the Hello interval. This value must be the same for the virtual neighbor.  Default: 60 seconds

Name, OID, and Syntax	Access	Description
snOspfVirtIfAuthType fdry.1.2.4.5.1.1.7 Syntax: Integer	Read- write	Specifies the authentication type for an interface. Valid values: <ul style="list-style-type: none"> <li>• none(0)</li> <li>• simplePassword(1)</li> <li>• md5(2)</li> <li>• reserved for specification by IANA(&gt; 2)</li> </ul> Additional authentication types may be assigned locally on a per interface basis. Default: none(0)
snOspfVirtIfAuthKey fdry.1.2.4.5.1.1.8 Syntax: Octet string	Read- write	Specifies the authentication key: <ul style="list-style-type: none"> <li>• If the authentication type selected is simple password, then this object requires an alphanumeric password. If the value is shorter than eight octets, the agent will left-adjust and zero-fill the key to equal eight octets.</li> </ul> The simple password setting takes effect immediately. All OSPF packets transmitted on the interface contain this password. Any OSPF packet received on the interface is checked for this password. If the password is not present, then the packet is dropped. The password can be up to eight characters long. <ul style="list-style-type: none"> <li>• If the authentication type is MD5, then a key ID and an MD5 key are required. The key ID is a number from 1 to 255 and identifies the MD5 key that is being used. The MD5 key can be up to sixteen alphanumeric characters long.</li> </ul> When read, "snOspfAuthKey" always returns a blank. Default: 0000000000000000'h, which is 0.0.0.0.0.0.0
snOspfVirtIfRowStatus fdry.1.2.4.5.1.1.9 Syntax: Integer	Read- write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>• delete(3) – Delete the row</li> <li>• create(4) – Create a new row</li> <li>• modify(5) – Modify an existing row</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>• noSuch(0) – No such row</li> <li>• invalid(1) – Row is inoperative</li> <li>• valid(2) – Row exists and is valid</li> </ul>

Name, OID, and Syntax	Access	Description
snOspfVirtIfMd5AuthKeyId fdry.1.2.4.5.1.1.10 Syntax: Integer	Read-write	Specifies the ID of the MD5 authentication key. This object identifies the algorithm and secret key used to create the message digest appended to the OSPF packet. Key identifiers are unique per interface.  If the object “snOspfVirtIfAuthType” is set to MD5, the value of this object must be a number from 1 to 255.
snOspfVirtIfMd5AuthKey fdry.1.2.4.5.1.1.11 Syntax: Octet string	Read-write	Specifies the MD5 authentication key. The value of this object is encrypted and included in each OSPF packet transmitted.  If the value of this object is shorter than 16 octets, the agent will left-adjust and zero-fill the key to equal 16 octets.  When read, snOspfIfMd5AuthKey always returns a blank.
snOspfVirtIfMd5ActivationWaitTime fdry.1.2.4.5.1.1.12 Syntax: Integer	Read-write	Determines when a newly configured MD5 authentication key is valid. This parameter provides a graceful transition from one MD5 key to another without disturbing the network. All new packets transmitted after the key activation wait time interval use the newly configured MD5 key. OSPF packets that contain the old MD5 key are accepted for up to five minutes after the new MD5 key is in operation.  Valid values: 0 – 14400 seconds Default: 300 seconds
snOspfVirtIfAreaIdFormat fdry.1.2.4.5.1.1.13 Syntax: Integer	Read only	Specifies the format of how Area ID will be entered in the “snOspfVirtIfAreaID” object: <ul style="list-style-type: none"> <li>integer(0) – Integer.</li> <li>ipAddress(1) – IP address.</li> </ul>

## OSPF Redistribution of Routes Table

The OSPF Redistribution of Routes Table contains a list of routes that will be used to decide whether a particular RIP or static route is to be imported into OSPF domain. Routes will be imported if the parameter “Import Route into OSPF” is enabled. They will be imported as external type 2 routes.

Name, OID, and Syntax	Access	Description
snOspfRedisTable fdry.1.2.4.6.1	None	The OSPF Redistribution Table contains a list of routes that could be imported into the OSPF domain.
snOspfRedisEntry fdry.1.2.4.6.1.1	None	An entry in the OSPF Redistribution Table
snOspfRedisIndex fdry.1.2.4.6.1.1.1 Syntax: Integer	Read only	An ID identifying this destination route.  There can be up to 64 entries for this object.

Name, OID, and Syntax	Access	Description
snOspfRedisIpAddress fdry.1.2.4.6.1.1.2 Syntax: IpAddress	Read-write	Shows the destination IP address that is associated with this particular route.
snOspfRedisMask fdry.1.2.4.6.1.1.3 Syntax: IpAddress	Read-write	Shows the subnet mask of this route.
snOspfRedisAction fdry.1.2.4.6.1.1.4 Syntax: Integer	Read-write	Specifies what action to be taken if the route matches this entry: <ul style="list-style-type: none"> <li>noImport(0) – Do not import route into the OSPF domain</li> <li>import(1) – Import the route is into OSPF domain as external type 2 route</li> </ul>
snOspfRedisProtocol fdry.1.2.4.6.1.1.5 Syntax: Integer	Read-write	Specifies how routes are imported into the OSPF domain: <ul style="list-style-type: none"> <li>rip(1) – the RIP route.</li> <li>all(2) – all protocol route.</li> <li>static(3) – the static route.</li> <li>bgp(4) – the BGP route.</li> <li>connected(5) – the connected route.</li> <li>isis(6) – the ISIS route.</li> </ul>
snOspfRedisSetOspfMetric fdry.1.2.4.6.1.1.6 Syntax: Integer	Read-write	The value indicates to which the route metric should match: <ul style="list-style-type: none"> <li>disabled(0) – the route metric does NOT match the OSPF metric field.</li> <li>enabled(1) – the route metric matches the OSPF metric field.</li> </ul>
snOspfRedisOspfMetricValue fdry.1.2.4.6.1.1.7 Syntax: Integer	Read-write	Specifies the cost of using this type of service (TOS) on this interface. Valid values: 0 – 65535.
snOspfRedisMatchRipMetric fdry.1.2.4.6.1.1.8 Syntax: Integer	Read-write	The value indicates to which the route metric should match: <ul style="list-style-type: none"> <li>disabled(0) – the route metric does NOT match the RIP metric field.</li> <li>enabled(1) – the route metric matches the RIP metric field.</li> </ul>
snOspfRedisRipMetricValue fdry.1.2.4.6.1.1.9 Syntax: Integer	Read-write	Specifies the cost of using RIP on this interface. Valid values: 1 – 15 hops.

Name, OID, and Syntax	Access	Description
snOspfRedisRowStatus fdry.1.2.4.6.1.1.10 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## OSPF Neighbor Table

The OSPF Neighbor Table describes non-virtual neighbors in the locality of the router.

Reference:

- RFC 1583 "OSPF Version 2", section 10 The Neighbor Data Structure
- RFC 1583 "OSPF Version 2", section 12.1.2 Options

Name, OID, and Syntax	Access	Description
snOspfNbrTable fdry.1.2.4.7.1	None	A table of non-virtual neighbor information.
snOspfNbrEntry fdry.1.2.4.7.1.1	None	An entry in the OSPF Neighbor Information Table. One entry represents one neighbor.
snOspfNbrEntryIndex fdry.1.2.4.7.1.1.1 Syntax: Integer	Read only	The table entry index of this neighbor.
snOspfNbrPort fdry.1.2.4.7.1.1.2 Syntax: Integer	Read only	Shows the physical port ID of this neighbor.
snOspfNbrIpAddr fdry.1.2.4.7.1.1.3 Syntax: IpAddress	Read only	Shows the IP address of this neighbor.
snOspfNbrIndex fdry.1.2.4.7.1.1.4 Syntax: Integer	Read only	Contains an index of each neighbor's port and IP address.

Name, OID, and Syntax	Access	Description
snOspfNbrRtrId fdry.1.2.4.7.1.1.5 Syntax: RouterID	Read only	Specifies the IP address of the neighboring router in the Autonomous System. The value of this object is a 32-bit integer.  Default: '00000000'h, which is equal to 0.0.0.0
snOspfNbrOptions fdry.1.2.4.7.1.1.6 Syntax: Integer	Read only	The bit mask that is set corresponding to the neighbor's options field: <ul style="list-style-type: none"> <li>• Bit 0 – The system will operate on type of service metrics other than TOS 0. The neighbor will ignore all metrics except for the TOS 0 metric.</li> <li>• Bit 1 – The associated area accepts and operates on external information; it is a stub area.</li> <li>• Bit 2 – The system is capable of routing IP Multicast datagrams. It implements the multicast extensions to OSPF.</li> <li>• Bit 3 – The associated area is an NSSA. These areas are capable of carrying type 7 external advertisements, which are translated into type 5 external advertisements at NSSA borders.</li> </ul> Default: 0
snOspfNbrPriority fdry.1.2.4.7.1.1.7 Syntax: DesignatedRouterPriority	Read only	Specifies the priority of this interface. This object is used in the designated router election algorithm for multi-access networks.  Valid values: 0 – 255  Default: 1. A value of 0 signifies that the router is not eligible to become the designated router on this particular network.  If two or more routers have the same priority value, then the router with the highest router ID becomes the designated router. The router with the next highest router ID becomes the backup designated router.

Name, OID, and Syntax	Access	Description
snOspfNbrState fdry.1.2.4.7.1.1.8 Syntax: Integer	Read only	<p>Shows the state of the communication between the Layer 3 Switch and the neighbor:</p> <ul style="list-style-type: none"> <li>• down(1) – There has been no recent information received from the neighbor.</li> <li>• attempt(2) – This state is only valid for neighbors attached to non-broadcast networks. It indicates that no recent information has been received from the neighbor.</li> <li>• init(3) – A Hello packet has recently been seen from the neighbor. However, bidirectional communication has not yet been established with the neighbor. (The router itself did not appear in the neighbor's Hello packet.) All neighbors in this state (or higher) are listed in the Hello packets sent from the associated interface.</li> <li>• twoWay(4) – Communication between the two routers is bidirectional. This is the most advanced state before beginning adjacency establishment. The Designated Router and Backup Designated Router are selected from the set of neighbors in the 2-Way state or greater.</li> <li>• exchangeStart(5) – The first step in creating an adjacency between the two neighboring routers. The goal of this step is to decide which router is the master, and to decide upon the initial Database Description (DD) sequence number. Neighbor communications in this state or greater are called adjacencies.</li> <li>• exchange(6) – The router is describing its entire link-state database by sending DD packets to the neighbor. Each DD packet has a DD sequence number, and is explicitly acknowledged. Only one DD packet can be outstanding at any time. In this state, link-state Request packets can also be sent asking for the neighbor's more recent advertisements. All adjacencies that are in the exchange state or greater are used by the flooding procedure. In fact, these adjacencies are fully capable of transmitting and receiving all types of OSPF routing protocol packets.</li> <li>• loading(7) – Link-state Request packets are sent to the neighbor asking for the more recent advertisements that have been discovered (but not yet received) in the exchange state.</li> <li>• full(8) – The neighboring routers are fully adjacent. These adjacencies will now appear in router links and network link advertisements.</li> </ul> <p>Default: down(1)</p>
snOspfNbrEvents fdry.1.2.4.7.1.1.9 Syntax: Counter	Read only	<p>Shows the number of times this neighbor's state has changed state, or the number of times an error occurred.</p>



Name, OID, and Syntax	Access	Description
snOspfNbrLsRetransQLen fdry.1.2.4.7.1.1.10 Syntax: Gauge	Read only	Specifies the interval between the retransmission of link-state advertisements to router adjacencies for this interface. The range is 0 – 3600 seconds.  Default: 5 seconds

## OSPF Virtual Neighbor Table

The OSPF Virtual Neighbor Table describes all virtual neighbors. Since Virtual links are configured in the virtual interface table, this table is read only.

Reference: RFC 1583 “OSPF Version 2”, section 15 Virtual Links

Name, OID, and Syntax	Access	Description
snOspfVirtNbrTable fdry.1.2.4.8.1	None	The OSPF Virtual Neighbor Table.
snOspfVirtNbrEntry fdry.1.2.4.8.1.1	None	An entry in the OSPF Virtual Neighbor Table.
snOspfVirtNbrEntryIndex fdry.1.2.4.8.1.1.1 Syntax: Integer	Read only	The ID of an entry in OSPF Virtual Neighbor Table.
snOspfVirtNbrArea fdry.1.2.4.8.1.1.2 Syntax: AreaID	Read only	Shows the ID of the transit area. The format is defined in the “snOspfVirtNbrAreaIDFormat” object.
snOspfVirtNbrRtrId fdry.1.2.4.8.1.1.3 Syntax: RouterID	Read only	Identifies the IP address of the neighboring router in the Autonomous System. This is a 32-bit integer.
snOspfVirtNbrIpAddr fdry.1.2.4.8.1.1.4 Syntax: IpAddress	Read only	Shows the IP address of this virtual neighbor.
snOspfVirtNbrOptions fdry.1.2.4.8.1.1.5 Syntax: Integer	Read only	Shows a bit map that corresponds to the neighbor’s options field. Thus, Bit 1, if set, indicates that the neighbor supports Type of Service Routing; if zero, no metrics other than TOS 0 are in use by the neighbor.

Name, OID, and Syntax	Access	Description
snOspfVirtNbrState fdry.1.2.4.8.1.1.6 Syntax: Integer	Read only	Shows the state of the communication between the Layer 3 Switch and the virtual neighbor: <ul style="list-style-type: none"> <li>• down(1) – There has been no recent information received from the neighbor.</li> <li>• attempt(2) – This state is only valid for neighbors attached to non-broadcast networks. It indicates that no recent information has been received from the neighbor.</li> <li>• init(3) – A Hello packet has recently been seen from the neighbor. However, bidirectional communication has not yet been established with the neighbor. (The router itself did not appear in the neighbor's Hello packet.) All neighbors in this state (or higher) are listed in the Hello packets sent from the associated interface.</li> <li>• twoWay(4) – Communication between the two routers is bidirectional. This is the most advanced state before beginning adjacency establishment. The Designated Router and Backup Designated Router are selected from the set of neighbors in the 2-Way state or greater.</li> <li>• exchangeStart(5) – The first step in creating an adjacency between the two neighboring routers. The goal of this step is to decide which router is the master, and to decide upon the initial DD sequence number. Neighbor communications in this state or greater are called adjacencies.</li> <li>• exchange(6) – The router is describing its entire link-state database by sending DD packets to the neighbor. Each DD packet has a DD sequence number, and is explicitly acknowledged. Only one DD packet can be outstanding at any time. In this state, link-state Request packets can also be sent asking for the neighbor's more recent advertisements. All adjacencies in exchange state or greater are used by the flooding procedure. In fact, these adjacencies are fully capable of transmitting and receiving all types of OSPF routing protocol packets.</li> <li>• loading(7) – Link-state Request packets are sent to the neighbor asking for the more recent advertisements that have been discovered (but not yet received) in the exchange state.</li> <li>• full(8) – The neighboring routers are fully adjacent. These adjacencies will now appear in router links and network link advertisements.</li> </ul>
snOspfVirtNbrEvents fdry.1.2.4.8.1.1.7 Syntax: Counter	Read only	Shows the number of times the state of this virtual link has changed or an error has occurred.
snOspfVirtNbrLSRetransQLen fdry.1.2.4.8.1.1.8 Syntax: Gauge	Read only	Shows the current length of the retransmission queue.

Name, OID, and Syntax	Access	Description
snOspfVirtNbrArealdFormat fdry.1.2.4.8.1.1.9 Syntax: Integer	Read only	Specifies the format of how Area ID will be entered in the “snOspfVirtNbrRtrld” object: <ul style="list-style-type: none"> <li>integer(0) – Integer</li> <li>ipAddress(1) – IP address</li> </ul>

## OSPF Link-State Database

The link-state database contains the link-state advertisement from all the areas to which the device is attached.

Reference: RFC 1583 “OSPF Version 2”, section 12 Link State Advertisements.

Name, OID, and Syntax	Access	Description
snOspfLsdbTable fdry.1.2.4.9.1	None	The OSPF Process’s link-state database.
snOspfLsdbEntry fdry.1.2.4.9.1.1	None	An entry in the OSPF Process’s link-state database. Each entry represents a single link-state advertisement.
snOspfLsdbEntryIndex fdry.1.2.4.9.1.1.1 Syntax: Integer	Read only	The ID of the entry in the link-state database.
snOspfLsdbAreald fdry.1.2.4.9.1.1.2 Syntax: Areald	Read only	Shows the Area from which the LSA was received. The value is in a 32-bit format.  Reference: RFC 1583 “OSPF Version 2”, section C.2 Area parameters
snOspfLsdbType fdry.1.2.4.9.1.1.3 Syntax: Integer	Read only	Specifies the type of the link-state advertisement. Each link-state type has a separate advertisement format. <ul style="list-style-type: none"> <li>routerLink(1)</li> <li>networkLink(2)</li> <li>summaryLink(3)</li> <li>asSummaryLink(4)</li> </ul> Reference: RFC 1583 “OSPF Version 2”, section A.4.1 The Link State Advertisement header
snOspfLsdbLsld fdry.1.2.4.9.1.1.4 Syntax: IpAddress	Read only	Specifies the link-state ID. This ID is an LS type-specific field containing either a Router ID or an IP Address. It identifies the piece of the routing domain that is being described by the advertisement.  Reference: RFC 1583 “OSPF Version 2”, section 12.1.4 Link State ID

Name, OID, and Syntax	Access	Description
snOspfLsdbRouterId fdry.1.2.4.9.1.1.5 Syntax: RouterID	Read only	Identifies the originating router in the Autonomous System. This information is in a 32-bit number. The format is determined by the “snOspfLsdbArealdFormat” object.  Reference: RFC 1583 “OSPF Version 2”, section C.1 Global parameters  <b>NOTE:</b> OSPF Sequence Number is a 32-bit signed integer. It starts with the value '80000001'h or '-7FFFFFFF'h, and increments until '7FFFFFFF'h Thus, a typical sequence number will be very negative.
snOspfLsdbSequence fdry.1.2.4.9.1.1.6 Syntax: Integer	Read only	Shows the sequence number of this entry. The OSPF neighbor that sent the LSA stamps the LSA with a sequence number to enable the Layer 3 Switch and other OSPF routers to determine which LSA for a given route is the most recent. This object can be used to detect old and duplicate link-state advertisements. The higher the sequence number, the more recent the advertisement.  Reference: RFC 1583 “OSPF Version 2”, section 12.1.6 LS sequence number
snOspfLsdbAge fdry.1.2.4.9.1.1.7 Syntax: Integer	Read only	Shows the age of the link-state advertisement in seconds.  Reference: RFC 1583 “OSPF Version 2”, section 12.1.1 LS age
snOspfLsdbChecksum fdry.1.2.4.9.1.1.8 Syntax: Integer	Read only	Indicates the checksum for the LSA packet. The checksum is based on all the fields in the packet except the age field. The Layer 3 Switch uses the checksum to verify that the packet is not corrupted.  Reference: RFC 1583 “OSPF Version 2”, section 2.1.7 LS checksum
snOspfLsdbAdvertisement fdry.1.2.4.9.1.1.9 Syntax: Octet string	Read only	Shows the data in the link-state advertisement, including its header in octets.  Reference: RFC 1583 “OSPF Version 2”, section Section 12 Link State Advertisements
snOspfLsdbArealdFormat fdry.1.2.4.9.1.1.10 Syntax: Integer	Read only	Specifies the format of how RouterId will be entered in the “snOspfLsdbRouterId” object: <ul style="list-style-type: none"> <li>• integer(0) – Integer</li> <li>• ipAddress(1) – IP address</li> </ul>

## OSPF Link State Database, External

The link-state database contains the link-state advertisement from throughout the areas that the device is attached to.

This table is identical to the OSPF LSDB Table in format, but contains only external link-state advertisement. The purpose is to allow external LSAs to be displayed once for the router rather than once in each non-stub area.

Name, OID, and Syntax	Access	Description
snOspfExtLsdbTable fdry.1.2.4.10.1	None	The Link-State External Database Table.  Reference: RFC 1583 "OSPF Version 2", section Section 12 Link State Advertisements
snOspfExtLsdbEntry fdry.1.2.4.10.1.1	None	An entry in the Link-State External Database Table. Each entry represents a single link-state advertisement.
snOspfExtLsdbEntryIndex fdry.1.2.4.10.1.1.1 Syntax: Integer	Read only	The table entry index of this link-state database.
snOspfExtLsdbType fdry.1.2.4.10.1.1.2 Syntax: Integer	Read only	Shows the type of the link-state advertisement. Each link-state type has a separate advertisement format.  Reference: RFC 1583 "OSPF Version 2", section Appendix A.4.1 The Link State Advertisement header
snOspfExtLsdbLsld fdry.1.2.4.10.1.1.3 Syntax: Integer	Read only	Specifies the external link-state ID. This ID is an LS type-specific field containing either a Router ID or an IP Address. It identifies the piece of the routing domain that is being described by the advertisement.  Reference: RFC 1583 "OSPF Version 2", section 12.1.4 Link-state ID
snOspfExtLsdbRouterId fdry.1.2.4.10.1.1.4 Syntax: Integer	Read only	Identifies the originating router in the Autonomous System. This information is in a 32-bit number.  Reference: RFC 1583 "OSPF Version 2", section C.1 Global parameters  <b>NOTE:</b> OSPF Sequence Number is a 32-bit signed integer. It starts with the value '80000001'h, or -'7FFFFFFF'h. It increments until '7FFFFFFF'h Thus, a typical sequence number will be very negative.
snOspfExtLsdbSequence fdry.1.2.4.10.1.1.5 Syntax: Integer	Read only	Shows the sequence number of this entry. The OSPF neighbor that sent the LSA stamps it with a sequence number to enable the Layer 3 Switch and other OSPF routers to determine which LSA for a given route is the most recent. This object can be used to detect old and duplicate link-state advertisements. The higher the sequence number, the more recent the advertisement.  Reference: RFC 1583 "OSPF Version 2", section 12.1.6 LS sequence number

Name, OID, and Syntax	Access	Description
snOspfExtLsdbAge fdry.1.2.4.10.1.1.6 Syntax: Integer	Read only	Shows the age of the link-state advertisement in seconds. Reference: RFC 1583 "OSPF Version 2", section 12.1.1 LS age
snOspfExtLsdbChecksum fdry.1.2.4.10.1.1.7 Syntax: Integer	Read only	Indicates the checksum for the LSA packet. The checksum is based on all the fields in the packet except the age field. The Layer 3 Switch uses the checksum to verify that the packet is not corrupted. Reference: RFC 1583 "OSPF Version 2", section 12.1.7 LS checksum
snOspfExtLsdbAdvertisement fdry.1.2.4.10.1.1.8 Syntax: Octet string	Read only	Shows the data in the link-state advertisement, including its header in octets. There can be up to 36 octets in this object. Reference: RFC 1583 "OSPF Version 2", section 12 Link State Advertisements

## OSPF Area Status Table

The OSPF Area Status Data Structure contains information regarding the configured parameters and cumulative statistics of the router's attached areas. The interfaces and virtual links are configured as part of these areas. Area 0.0.0.0 is the Backbone Area.

Reference: RFC 1583 "OSPF Version 2", section 6 The Area Data Structure

Name, OID, and Syntax	Access	Description
snOspfAreaStatusTable fdry.1.2.4.11.1	None	The OSPF Area Status Table.
snOspfAreaStatusEntry fdry.1.2.4.11.1.1	None	An entry in the OSPF Area Status Table.
snOspfAreaStatusEntryIndex fdry.1.2.4.11.1.1.1 Syntax: Integer	Read only	The ID of an entry in the OSPF Area Status Table.
snOspfAreaStatusAreald fdry.1.2.4.11.1.1.2 Syntax: Areald	Read only	Specifies the ID of an area. The format of this 32-bit integer is determined by the value of the "snOspfAreaStatusArealdFormat" object. Area ID 0.0.0.0 is used for the OSPF backbone. Reference: RFC 1583 "OSPF Version 2", section C.2 Area parameters
snOspfAreaStatusImportASExtern fdry.1.2.4.11.1.1.3 Syntax: Integer	Read only	The area's support for importing AS external link-state advertisements. Reference: RFC 1583 "OSPF Version 2", section C.2 Area parameters Default: 1

Name, OID, and Syntax	Access	Description
snOspfAreaStatusStubMetric fdry.1.2.4.11.1.1.4 Syntax: BigMetric	Read only	The metric value applied at the default type of service(ospfMetric). By default, this equals the least metric at the type of service among the interfaces to other areas. This object exist only if the value of snOspfAreaSummary is snOspfAreaSummary(2); Otherwise, an SNMP_GET/GET_NEXT attempt of this Object will return NO_SUCH_NAME.
snOspfAreaStatusSpfRuns fdry.1.2.4.11.1.1.5 Syntax: Counter	Read only	Shows the number of times that the intra-area route table has been recalculated using this area's link-state database.
snOspfAreaStatusAreaBdrRtrCount fdry.1.2.4.11.1.1.6 Syntax: Gauge	Read only	Show the number of area border routers that are reachable within this area. This is initially zero, the default, and is calculated in each shortest path first (SPF) pass.
snOspfAreaStatusASBdrRtrCount fdry.1.2.4.11.1.1.7 Syntax: Gauge	Read only	Shows the total number of Autonomous System border routers that are reachable within this area. This is initially zero, the default, and is calculated in each SPF pass.
snOspfAreaStatusLSACount fdry.1.2.4.11.1.1.8 Syntax: Gauge	Read only	Shows the total number of link-state advertisements in this area's link-state database, excluding AS external LSAs. Default: 0
snOspfAreaStatusLSACksumSum fdry.1.2.4.11.1.1.9 Syntax: Integer	Read only	Shows the total link-state advertisements of area's link-state database. This number is a 32-bit unsigned sum of the LS checksums, excluding external (LS type 5) link-state advertisements. The value can be used to determine if there has been a change in a router's link-state database, and to compare the link-state database of two routers. Default: 0
snOspfAreaStatusAreaIdFormat fdry.1.2.4.11.1.1.10 Syntax: Integer	Read only	Specifies the format of how Area ID will be entered in the "snOspfAreaStatusAreaId" object: <ul style="list-style-type: none"> <li>integer(0) – Integer.</li> <li>ipAddress(1) – IP address.</li> </ul>

## OSPF Interface Status Table

The OSPF Interface Status Table describes the interfaces from the viewpoint of OSPF. It augments the ifStatusTable with OSPF specific information.

Name, OID, and Syntax	Access	Description
snOspfIfStatusTable fdry.1.2.4.12.1	None	The OSPF Interface Status Table.

Name, OID, and Syntax	Access	Description
snOspfIfStatusEntry fdry.1.2.4.12.1.1	None	An entry in the OSPF Interface Status Table. Each entry represents one interface from the viewpoint of OSPF.
snOspfIfStatusEntryIndex fdry.1.2.4.12.1.1.1 Syntax: Integer	Read only	The ID of an entry in the OSPF Interface Status Table.
snOspfIfStatusPort fdry.1.2.4.12.1.1.2 Syntax: Integer	Read only	Shows the ID of the physical router port of this OSPF interface.
snOspfIfStatusIpAddress fdry.1.2.4.12.1.1.3 Syntax: IpAddress	Read only	Shows the IP address of this OSPF interface.
snOspfIfStatusAreaId fdry.1.2.4.12.1.1.4 Syntax: AreaId	Read only	Identifies the area to which the interface connects. This ID is a 32-bit integer. Area ID 0.0.0.0 (in the '00000000'h format) is used for the OSPF backbone.  The format of this ID is determined by the value of the "snOspfIfStatusAreaIdFormat" object.
snOspfIfStatusType fdry.1.2.4.12.1.1.5 Syntax: Integer	Read only	Identifies the OSPF interface type.  (By way of a default, this field may be derived from the corresponding value of ifType.) <ul style="list-style-type: none"> <li>• broadcast(1) – For broadcast LANs such as Ethernet and IEEE 802.5</li> <li>• nbma(2) – For X.25, Frame Relay, and similar technologies</li> <li>• pointToPoint(3) – For point-to-point interfaces</li> </ul>
snOspfIfStatusAdminStat fdry.1.2.4.12.1.1.6 Syntax: Integer	Read only	Shows if OSPF has been enabled to form neighbor relationships on the interface: <ul style="list-style-type: none"> <li>• disabled(0) – The interface is external to OSPF</li> <li>• enabled(1) – OSPF has been enabled to form neighbor relationships and the interface will be advertised as an internal route to some area</li> </ul>
snOspfIfStatusRtrPriority fdry.1.2.4.12.1.1.7 Syntax: DesignatedRouterPriority	Read only	Specifies the priority of this interface. This object is used in the designated router election algorithm for multi-access networks.  Valid values: 0 – 255  Default: 1. A value of 0 means that the router is not eligible to become the designated router on this particular network.  If two or more routers have the same priority value, then the router with the highest router ID becomes the designated router. The router with the next highest router ID becomes the backup designated router.



Name, OID, and Syntax	Access	Description
snOspfIfStatusTransitDelay fdry.1.2.4.12.1.1.8 Syntax: UpToMaxAge	Read only	Shows the time it takes to transmit link-state update packets on this interface.  Valid values: 0 – 3600 seconds Default: 1 second
snOspfIfStatusRetransInterval fdry.1.2.4.12.1.1.9 Syntax: UpToMaxAge	Read only	Shows the number of seconds between retransmissions of link-state advertisements, to adjacencies that belong to this interface. This value is also used when retransmitting database description and link-state request packets.  Valid values: 0 – 3600 seconds Default: 5 seconds
snOspfIfStatusHelloInterval fdry.1.2.4.12.1.1.10 Syntax: HelloRange	Read only	Specifies the number of seconds that router waits before it sends the next Hello packet on this interface. This value must be the same for all routers attached to a common network.  Valid values: 1 – 65535 seconds Default: 10 seconds
snOspfIfStatusRtrDeadInterval fdry.1.2.4.12.1.1.11 Syntax: PositiveInteger	Read only	Specifies the number of seconds that neighbor routers wait for a router's Hello packets before they declare that the router is down. This should be a multiple of the Hello interval and must be the same for all routers attached to a common network.  Default: 40 seconds
snOspfIfStatusState fdry.1.2.4.12.1.1.12 Syntax: Integer	Read only	Shows the OSPF Interface State. <ul style="list-style-type: none"> <li>• down(1)</li> <li>• loopback(2)</li> <li>• waiting(3)</li> <li>• pointToPoint(4)</li> <li>• designatedRouter(5)</li> <li>• backupDesignatedRouter(6)</li> <li>• otherDesignatedRouter(7)</li> </ul> Default: down(1)
snOspfIfStatusDesignatedRouter fdry.1.2.4.12.1.1.13 Syntax: IpAddress	Read only	Shows the IP Address of the designated router.  Default: '00000000'h, which equals to 0.0.0.0
snOspfIfStatusBackupDesignatedRouter fdry.1.2.4.12.1.1.14 Syntax: IpAddress	Read only	Shows the IP Address of the backup router.  Default: '00000000'h, which equals to 0.0.0.0

Name, OID, and Syntax	Access	Description
<p>snOspfIfStatusEvents fdry.1.2.4.12.1.1.15 Syntax: Counter</p>	Read only	<p>Shows the following:</p> <ul style="list-style-type: none"> <li>The number of times that the state of this OSPF interface has changed</li> <li>The number of times an error has occurred</li> </ul>
<p>snOspfIfStatusAuthType fdry.1.2.4.12.1.1.16 Syntax: Integer</p>	Read only	<p>Specifies the authentication type for an interface.</p> <p>Valid values::</p> <ul style="list-style-type: none"> <li>none(0)</li> <li>simplePassword(1)</li> <li>md5(2)</li> <li>reserved for specification by IANA(&gt; 2)</li> </ul> <p>Additional authentication types may be assigned locally on a per interface basis.</p> <p>Default: none(0)</p>
<p>snOspfIfStatusAuthKey fdry.1.2.4.12.1.1.17 Syntax: Octet string</p>	Read only	<p>Indicates the area's authentication key.</p> <ul style="list-style-type: none"> <li>If the authentication type selected is simple password, then this object requires an alphanumeric password. If the value is shorter than eight octets, the agent will left-adjust and zero-fill the key to equal eight octets.</li> </ul> <p>The simple password setting takes effect immediately. All OSPF packets transmitted on the interface contain this password. Any OSPF packet received on the interface is checked for this password. If the password is not present, then the packet is dropped. The password can be up to eight characters long.</p> <ul style="list-style-type: none"> <li>If the authentication type is MD5, then a key ID and an MD5 key are required. The key ID is a number from 1 to 255 and identifies the MD5 key that is being used. The MD5 key can be up to sixteen alphanumeric characters long.</li> </ul> <p>When read, "snOspfIfAuthKey" always returns a blank.</p> <p>Reference: RFC 1583 "OSPF Version 2", section 9 The Interface Data Structure</p> <p>Default: '0000000000000000'h – 0.0.0.0.0.0.0</p>
<p>snOspfIfStatusMetricValue fdry.1.2.4.12.1.1.18 Syntax: Integer</p>	Read only	<p>Specifies the cost of using this TOS on this interface. The default value of the TOS 0 Metric is 10<sup>8</sup> / ifSpeed.</p> <p>Valid values: 0 – 65535</p>
<p>snOspfIfStatusMd5AuthKeyId fdry.1.2.4.12.1.1.19 Syntax: Integer</p>	Read only	<p>Specifies the ID of the MD5 authentication key. This object identifies the algorithm and secret key used to create the message digest appended to the OSPF packet. Key identifiers are unique per interface.</p> <p>If the object "snOspfVirtIfAuthType" is set to MD5, the value of this object must be a number from 1 – 255.</p>

Name, OID, and Syntax	Access	Description
snOspfIfStatusMd5AuthKey fdry.1.2.4.12.1.1.20 Syntax: Octet string	Read only	Specifies the MD5 authentication key. The value of this object is encrypted and included in each OSPF packet transmitted.  If the value of this object is shorter than 16 octets, the agent will left-adjust and zero-fill the key to equal 16 octets.  When read, snOspfIfMd5AuthKey always returns a blank.
snOspfIfStatusMd5ActivationWait Time fdry.1.2.4.12.1.1.21 Syntax: Integer	Read only	Determines when a newly configured MD5 authentication key is valid. This parameter provides a graceful transition from one MD5 key to another without disturbing the network. All new packets transmitted after the key activation wait time interval use the newly configured MD5 key. OSPF packets that contain the old MD5 key are accepted for up to five minutes after the new MD5 key is in operation. The range for the key activation wait time is from 0 – 14400 seconds.
snOspfIfStatusAreaIdFormat fdry.1.2.4.12.1.1.22 Syntax: Integer	Read only	Specifies the format of how Area ID will be entered in the “snOspfIfStatusAreaId” object: <ul style="list-style-type: none"> <li>integer(0) – Integer.</li> <li>ipAddress(1) – IP address</li> </ul>

## OSPF Virtual Interface Status Table

The Virtual Interface Status Table contains information about this router’s virtual interfaces.

Reference: RFC 1583 “OSPF Version 2”, section C.4 Virtual link parameters.

Name, OID, and Syntax	Access	Description
snOspfVirtIfStatusTable fdry.1.2.4.13.1	None	The OSPF Virtual Interface Status Table.
snOspfVirtIfStatusEntry fdry.1.2.4.13.1.1	None	An entry in the The OSPF Virtual Interface Status Table. Each entry represents one interface.
snOspfVirtIfStatusEntryIndex fdry.1.2.4.13.1.1.1 Syntax: Integer	Read only	The ID of the entry in this table.
snOspfVirtIfStatusAreaID fdry.1.2.4.13.1.1.2 Syntax: AreaID	Read only	Shows the ID of the transit area that the virtual link traverses. The value of this object cannot be 0.0.0.0. The format of this object is determined by the value of the “snOspfVirtIfStatusAreaIdFormat” object.
snOspfVirtIfStatusNeighbor fdry.1.2.4.13.1.1.3 Syntax: RouterID	Read only	Shows the ID or IP address of the router that is serving as the virtual neighbor.

Name, OID, and Syntax	Access	Description
snOspfVirtIfStatusTransitDelay fdry.1.2.4.13.1.1.4 Syntax: UpToMaxAge	Read only	Shows the time it takes to transmit link-state update packets on this interface.  Valid values: 0 – 3600 seconds Default: 1 second
snOspfVirtIfStatusRetransInterval fdry.1.2.4.13.1.1.5 Syntax: UpToMaxAge	Read only	Specifies the interval between the retransmission of link-state advertisements to router adjacencies for this interface.  Valid values: 0 – 3600 seconds Default: 5 seconds
snOspfVirtIfStatusHelloInterval fdry.1.2.4.13.1.1.6 Syntax: HelloRange	Read only	Specifies the number of seconds that router waits before it sends the next Hello packet on this interface. This value must be the same for all routers attached to a common network.  Valid values: 1 – 65535 seconds Default: 10 seconds  This value must be the same for all routers attached to a common network.
snOspfVirtIfStatusRtrDeadInterval fdry.1.2.4.13.1.1.7 Syntax: PositiveInteger	Read only	Specifies the number of seconds that neighbor routers wait for a router's Hello packets before they declare that the router is down. This should be a multiple of the Hello interval. This value must be the same for all routers attached to a common network.  Default: 60 seconds
snOspfVirtIfStatusState fdry.1.2.4.13.1.1.8 Syntax: Integer	Read only	Shows the state of the OSPF virtual interface: <ul style="list-style-type: none"><li>• down(1)</li><li>• pointToPoint(4)</li></ul> Default: down(1)
snOspfVirtIfStatusEvents fdry.1.2.4.13.1.1.9 Syntax: Counter	Read only	Shows the following: <ul style="list-style-type: none"><li>• The number of times that the state of this OSPF interface has changed</li><li>• The number of times an error has occurred</li></ul>
snOspfVirtIfStatusAuthType fdry.1.2.4.13.1.1.10 Syntax: Integer	Read only	Specifies the authentication type for an interface.  Valid values:: <ul style="list-style-type: none"><li>• none(0)</li><li>• simplePassword(1)</li><li>• reserved for specification by IANA(&gt; 1)</li></ul> Additional authentication types may be assigned locally on a per interface basis. Default: none(0)

Name, OID, and Syntax	Access	Description
snOspfVirtIfStatusAuthKey fdry.1.2.4.13.1.1.11 Syntax: Octet string	Read only	<p>Specifies the authentication key.</p> <ul style="list-style-type: none"> <li>If the authentication type selected is simple password, then this object requires an alphanumeric password. If the value is shorter than eight octets, the agent will left-adjust and zero-fill the key to equal eight octets.</li> </ul> <p>The simple password setting takes effect immediately. All OSPF packets transmitted on the interface contain this password. Any OSPF packet received on the interface is checked for this password. If the password is not present, then the packet is dropped. The password can be up to eight characters long.</p> <ul style="list-style-type: none"> <li>If the authentication type is MD5, then a key ID and an MD5 key are required. The key ID is a number from 1 to 255 and identifies the MD5 key that is being used. The MD5 key can be up to sixteen alphanumeric characters long.</li> </ul> <p>When read, "snOspfIfAuthKey" always returns a blank.</p> <p>Reference: RFC 1583 "OSPF Version 2", section 9 The Interface Data Structure</p> <p>Default: '0000000000000000'h – 0.0.0.0.0.0.0</p>
snOspfVirtIfStatusMd5AuthKeyId fdry.1.2.4.13.1.1.12 Syntax: Integer	Read only	<p>Specifies the ID of the MD5 authentication key. This object identifies the algorithm and secret key used to create the message digest appended to the OSPF packet. Key identifiers are unique per interface.</p> <p>If the object "snOspfVirtIfAuthType" is set to MD5, the value of this object must be a number from 1 – 255.</p>
snOspfVirtIfStatusMd5AuthKey fdry.1.2.4.13.1.1.13 Syntax: Octet string	Read only	<p>Specifies the MD5 authentication key. The value of this object is encrypted and included in each OSPF packet transmitted.</p> <p>If the value of this object is shorter than 16 octets, the agent will left-adjust and zero-fill the key to equal 16 octets.</p> <p>When read, snOspfIfMd5AuthKey always returns a blank.</p>
snOspfVirtIfStatusMd5ActivationWaitTime fdry.1.2.4.13.1.1.14 Syntax: Integer	Read only	<p>Determines when a newly configured MD5 authentication key is valid. This parameter provides a graceful transition from one MD5 key to another without disturbing the network. All new packets transmitted after the key activation wait time interval use the newly configured MD5 key. OSPF packets that contain the old MD5 key are accepted for up to five minutes after the new MD5 key is in operation. The range for the key activation wait time is from 0 – 14400 seconds.</p>
snOspfVirtIfStatusAreaIdFormat fdry.1.2.4.13.1.1.15 Syntax: Integer	Read only	<p>Specifies the format of how Area ID will be entered in the "snOspfVirtIfStatusAreaID" object:</p> <ul style="list-style-type: none"> <li>integer(0) – Integer</li> <li>ipAddress(1) – IP address</li> </ul>

## OSPF Routing Information Table

The OSPF Routing Information Table contains information on the OSPF ABR/ASBR routing.

Name, OID, and Syntax	Access	Description
snOspfRoutingInfoTable fdry.1.2.4.14.1	None	The OSPF Routing Information Table.
snOspfRoutingInfoEntry fdry.1.2.4.14.1.1	None	An entry in the OSPF Routing Information Table.
snOspfRoutingInfoIndex fdry.1.2.4.14.1.1.1 Syntax: Integer	Read only	ID of an entry in this table.
snOspfRoutingInfoRouter fdry.1.2.4.14.1.1.2 Syntax: RouterID	Read only	Shows the ID or IP address of the destination router.
snOspfRoutingInfoRouterType fdry.1.2.4.14.1.1.3 Syntax: Integer	Read only	Shows what router type the destination router is: <ul style="list-style-type: none"> <li>abr(1) – Area Border Router.</li> <li>asbr(2) – Autonomous System Border Router.</li> <li>abrANDasbr(3) – Area Border and Autonomous System Border Router.</li> </ul>
snOspfRoutingInfoNextHopRouter ID fdry.1.2.4.14.1.1.4 Syntax: RouterID	Read only	Shows the ID or IP address of the next hop destination router.
snOspfRoutingInfoOutgoingInterfa ce fdry.1.2.4.14.1.1.5 Syntax: Integer	Read only	Shows the outgoing interface of the destination router.

---

# Chapter 16

## BGP4

**Border Gateway Protocol version 4 (BGP4)** on Foundry products using the CLI and the Web management interface. BGP4 is supported on the following Foundry products:

- NetIron Internet Backbone router
- BigIron Layer 3 Switch
- NetIron stackable Layer 3 Switch (must have 32MB RAM and 4MB flash module)
- TurboIron/8 Layer 3 Switch

---

**NOTE:** BGP4 is not supported on the FastIron II and FastIron Edge Switch devices. BGP4 is described in RFC 1771.

---

The Foundry implementation complies with RFC 1771. The Foundry BGP4 implementation also supports the following RFCs:

- RFC 1745 (OSPF Interactions)
- RFC 1965 (BGP4 Confederations)
- RFC 1997 (BGP Communities Attributes)
- RFC 2385 (TCP MD5 Signature Option)
- RFC 2439 (Route Flap Dampening)
- RFC 2796 (Route Reflection)
- RFC 2842 (Capability Advertisement)

Refer to the *Foundry Enterprise Configuration and Management Guide* for details on the features discussed in this chapter.

---

**NOTE:** Beginning with software release 07.6.03, Foundry devices support RFC 1657 instead of the objects in this chapter. Also, BigIron MG8, NetIron 40G, and FastIron Edge Switch support RFC 1657.

---

## BGP4 General Variables

These parameters apply globally to a device's BGP4 process.

Name, OID, and Syntax	Access	Description
snBgp4GenAlwaysCompareMed fdry.1.2.11.1.1 Syntax: Integer	Read-write	Indicates if the comparison of the Multi-Exit Discriminator for paths from neighbors in different AS is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snBgp4GenAutoSummary fdry.1.2.11.1.2 Syntax: Integer	Read-write	Indicates if subnet routes are automatically summarized: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snBgp4GenDefaultLocalPreference fdry.1.2.11.1.3 Syntax: Integer	Read-write	Sets the default local preference attribute.  When the router uses the BGP4 algorithm to select a route to send to the IP route table, one of the parameters the algorithm uses is the local preference. Local preference is an attribute that indicates a degree of preference for a route relative to other routes. BGP4 neighbors can send the local preference value as an attribute of a route in an UPDATE message.  Local preference applies only to routes within the local AS. BGP4 routers can exchange local preference information with neighbors who are also in the local AS; however, BGP4 routers do not exchange local preference information with neighbors in remote ASs.  Valid values: 0 – 4294967295 Default: 100
snBgp4GenDefaultInfoOriginate fdry.1.2.11.1.4 Syntax: Integer	Read-write	Indicates if the default Information Originate is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> <p>By default, the router does not originate and advertise a default route using BGP4. A BGP4 default route is the IP address 0.0.0.0 and the route prefix 0 or network mask 0.0.0.0. For example, 0.0.0.0/0 is a default route. You can enable the router to advertise a default BGP4 route using either of the following methods.</p> <p>Foundry Layer 3 Switches check for the existence of an IGP route with 0.0.0.0/0 in the IP route table before creating a local BGP route for 0.0.0.0/0.</p>
snBgp4GenFastExternalFallover fdry.1.2.11.1.5 Syntax: Integer	Read-write	Indicates if automatic resetting of BGP sessions of any directly adjacent sessions is enabled, if the links used to reach them go down. <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>



Name, OID, and Syntax	Access	Description
snBgp4GenNextBootNeighbors fdry.1.2.11.1.6 Syntax: Integer	Read-write	The next boot-configured number of neighbors in a BGP Peer Group. The minimum value of this object is the value of the "snBgp4GenMinNeighbors" object. Its maximum value is the value of the "snBgp4GenMaxNeighbors" object.
snBgp4GenNextBootRoutes fdry.1.2.11.1.7 Syntax: Integer	Read-write	The next boot-configured number of routes. The minimum value of this MIB is snBgp4GenMinRoutes. The maximum value of this MIB is "snBgp4GenMaxRoutes".
snBgp4GenSynchronization fdry.1.2.11.1.8 Syntax: Integer	Read-write	To enable or disable the synchronization between BGP and your IGP. <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snBgp4GenKeepAliveTime fdry.1.2.11.1.9 Syntax: Integer	Read-write	Indicates how often the device sends keep alive messages. Valid values: 1 – 65535 seconds Default: 60 seconds
snBgp4GenHoldTime fdry.1.2.11.1.10 Syntax: Integer	Read-write	Determines how many seconds the device will wait for a keep alive or update message from a BGP4 neighbor before deciding that the neighbor is dead. Valid values: 1 – 65535 seconds Default: 180 seconds
snBgp4GenRouterId fdry.1.2.11.1.11 Syntax: IpAddress	Read-write	Indicates the BGP Router IP address.
snBgp4GenTableMap fdry.1.2.11.1.12 Syntax: Octet string	Read-write	Defines the route map name. Each character of the name is represented by one octet. Valid values: Up to 32 octets.
snBgp4GenAdminStat fdry.1.2.11.1.13 Syntax: Integer	Read-write	Indicates if BGP4 routing is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snBgp4GenDefaultMetric fdry.1.2.11.1.14 Syntax: Integer	Read-write	Indicates the default metric values for the BGP4 protocol. The Foundry Layer 3 Switches can redistribute directly connected routes, static IP routes, RIP routes, and OSPF routes into BGP4. The MED (metric) is a global parameter that specifies the cost that will be applied to all routes by default when they are redistributed into BGP4. Valid values: 0 – 4294967295
snBgp4GenMaxNeighbors fdry.1.2.11.1.15 Syntax: Integer	Read only	Shows the maximum number of neighbors that can be configured in a BGP Peer Group.

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snBgp4GenMinNeighbors fdry.1.2.11.1.16 Syntax: Integer	Read only	Shows the minimum number of neighbors that can be configured in a BGP Peer Group.
snBgp4GenMaxRoutes fdry.1.2.11.1.17 Syntax: Integer	Read only	Shows the maximum number of configured routes.
snBgp4GenMinRoutes fdry.1.2.11.1.18 Syntax: Integer	Read only	Shows the minimum number of configured routes.
snBgp4GenMaxAddrFilters fdry.1.2.11.1.19 Syntax: Integer	Read only	Shows the maximum number of configured BGP4 address filters.
snBgp4GenMaxAggregateAddresses fdry.1.2.11.1.20 Syntax: Integer	Read only	Shows the maximum number of configured BGP4 aggregate addresses.
snBgp4GenMaxAsPathFilters fdry.1.2.11.1.21 Syntax: Integer	Read only	Shows the maximum number of configured BGP4 AS-PATH filters.
snBgp4GenMaxCommunityFilters fdry.1.2.11.1.22 Syntax: Integer	Read only	Shows the maximum number of configured BGP4 community filters.
snBgp4GenMaxNetworks fdry.1.2.11.1.23 Syntax: Integer	Read only	Shows the maximum number of configured BGP4 networks.
snBgp4GenMaxRouteMapFilters fdry.1.2.11.1.24 Syntax: Integer	Read only	Shows the maximum number of configured BGP4 route map filters.
snBgp4GenNeighPrefixMinValue fdry.1.2.11.1.25 Syntax: Integer	Read only	Shows the minimum configured value of BGP4 neighbor prefix.
snBgp4GenOperNeighbors fdry.1.2.11.1.26	Read only	Shows the current operational max number of neighbors configured for a BGP Group.

Name, OID, and Syntax	Access	Description
snBgp4GenOperRoutes fdry.1.2.11.1.27 Syntax: Integer	Read only	Shows the current operational number of routes.
snBgp4GenLocalAs fdry.1.2.11.1.28 Syntax: Integer	Read only	Shows the BGP4 local autonomous system number.
snBgp4GenRoutesInstalled fdry.1.2.11.1.29 Syntax: Integer	Read only	Shows the BGP4 installed routes.
snBgp4GenAsPathInstalled fdry.1.2.11.1.30 Syntax: Integer	Read only	Shows the BGP4 installed autonomous system path.
snBgp4ExternalDistance fdry.1.2.11.1.31 Syntax: Integer	Read-write	Determines the administrative distance for BGP external routes. Default: 200
snBgp4InternalDistance fdry.1.2.11.1.32 Syntax: Integer	Read-write	Determines the administrative distance for BGP internal routes. Default: 200
snBgp4LocalDistance fdry.1.2.11.1.33 Syntax: Integer	Read-write	Determines the administrative distance for BGP local routes. Default: 200
snBgp4OperNumOfAttributes fdry.1.2.11.1.34 Syntax: Integer	Read only	Shows the operational number of attribute entries.
snBgp4NextBootMaxAttributes fdry.1.2.11.1.35 Syntax: Integer	Read-write	Defines the next boot maximum attribute entries. Default: 10000, which means to reset to default
snBgp4ClusterId fdry.1.2.11.1.36 Syntax: Integer	Read-write	Defines a cluster ID which is represented by 4-unsigned-byte integers (0..0xFFFFFFFF). 0 means to reset to default.
snBgp4ClientToClientReflection fdry.1.2.11.1.37 Syntax: Integer	Read-write	Indicates if the client to client reflection in BGP4 is enabled. <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>

Name, OID, and Syntax	Access	Description
snBgp4GenTotalNeighbors fdry.1.2.11.1.38 Syntax: Integer	Read only	Shows the current total number of neighbors running in a BGP group.
snBgp4GenMaxPaths fdry.1.2.11.1.39 Syntax: Integer	Read-write	Indicates the maximum number of configured Paths.
snBgp4GenConfedId fdry.1.2.11.1.40 Syntax: Integer	Read-write	Determines the BGP4 Confederation ID. This ID identifies the confederation to BGP routers outside the confederation.  A confederation is a BGP4 AS that has been subdivided into multiple, smaller ASs. Subdividing an AS into smaller ASs simplifies administration and reduces BGP-related traffic, thus reducing the complexity of the Interior Border Gateway Protocol (IBGP) mesh among the BGP routers in the AS.  The confederation ID is the AS ID.
snBgp4GenConfedPeers fdry.1.2.11.1.41 Syntax: Octet string	Read-write	Specifies the sub-AS numbers that are members of the confederation. There is a maximum of 50 peers.  This is a number from 1 to 0xFFFF. It is represented by two octets.
snBgp4GenDampening fdry.1.2.11.1.42 Syntax: Integer	Read-write	Specifies the dampening of BGP4 in the device <ul style="list-style-type: none"> <li>• none(0) – BGP4 dampening is off</li> <li>• parameters(1) – Parameters are configurable</li> <li>• routemap(2) – Routemap is configurable</li> </ul>
snBgp4GenDampenHalfLife fdry.1.2.11.1.43 Syntax: Integer	Read-write	Specifies the number of minutes after which the route's penalty becomes half its value.
snBgp4GenDampenReuse fdry.1.2.11.1.44 Syntax: Integer	Read-write	Specifies how low a route's penalty must be before the route becomes eligible for use again after being suppressed.
snBgp4GenDampenSuppress fdry.1.2.11.1.45 Syntax: Integer	Read-write	Specifies how high a route's penalty can be before the Layer 3 Switch suppresses the route.
snBgp4GenDampenMaxSuppress fdry.1.2.11.1.46 Syntax: Integer	Read-write	Specifies the maximum number of minutes that a route can be suppressed regardless of how unstable it is.

Name, OID, and Syntax	Access	Description
snBgp4GenDampenMap fdry.1.2.11.1.47 Syntax: Octet string	Read-write	Specifies the name of the route map that will be used to redirect traffic.  The name is an octet string. Each character is represented by one octet.  Valid values: Up to 32 octets.

## BGP4 Network Table

The BGP4 Network Table shows the weight used for the network.

Name, OID, and Syntax	Access	Description
snBgp4NetworkTable fdry.1.2.11.10.1	None	The BGP4 Network Table.
snBgp4NetworkEntry fdry.1.2.11.10.1.1	None	An entry in the BGP4 Network Table.
snBgp4NetworkIp fdry.1.2.11.10.1.1.1 Syntax: IpAddress	Read only	Shows the IP Address for a network entry.
snBgp4NetworkSubnetMask fdry.1.2.11.10.1.1.2 Syntax: IpAddress	Read only	Shows the subnet mask for a network entry.
snBgp4NetworkWeight fdry.1.2.11.10.1.1.3 Syntax: Integer	Read-write	Shows the weight of the neighbor connection.  Valid values: 0 – 65535
snBgp4NetworkBackdoor fdry.1.2.11.10.1.1.4 Syntax: Integer	Read-write	Indicates if the backdoor option is enabled for this network: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> <p>The backdoor option changes the administrative distance of the route to this network from the EBGp administrative distance (20 by default) to the Local BGP weight (200 by default). The route is tagged as a backdoor route. Use this option when you want the router to prefer IGP routes such as RIP or OSPF routes over the EBGp route for the network</p>

Name, OID, and Syntax	Access	Description
snBgp4NetworkRowStatus fdry.1.2.11.10.1.1.5 Syntax: Integer		<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## BGP4 Address Filter Table

You can configure the router to explicitly permit or deny specific IP addresses received in updates from BGP4 neighbors by defining IP address filters. The router permits all IP addresses by default. You can define up to 100 IP address filters for BGP4.

- If you want “permit” to remain the default behavior, define individual filters to deny specific IP addresses.
- If you want to change the default behavior to “deny”, define individual filters to permit specific IP addresses.

**NOTE:** Once you define a filter, the default action for addresses that do not match a filter is “deny”. To change the default action to “permit”, configure the last filter as “permit any any”.

Address filters can be referred to by a BGP neighbor's distribute list number as well as by match statements in a route map.

Name, OID, and Syntax	Access	Description
snBgp4AddrFilterTable fdry.1.2.11.2.1	None	The BGP4 Address Filter Table
snBgp4AddrFilterEntry fdry.1.2.11.2.1.1	None	An entry in the BGP4 Address Filter Table
snBgp4AddrFilterIndex fdry.1.2.11.2.1.1.1 Syntax: Integer	Read only	The table index for a filter entry.
snBgp4AddrFilterAction fdry.1.2.11.2.1.1.2 Syntax: Integer	Read-write	<p>Indicates what the device will do if the BGP address matches this filter:</p> <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>

Name, OID, and Syntax	Access	Description
snBgp4AddrFilterSourceIp fdry.1.2.11.2.1.1.3 Syntax: IpAddress	Read-write	Specifies the source IP address.
snBgp4AddrFilterSourceMask fdry.1.2.11.2.1.1.4 Syntax: IpAddress	Read-write	Specifies the source IP subnet mask.
snBgp4AddrFilterDestIp fdry.1.2.11.2.1.1.5 Syntax: IpAddress	Read-write	Specifies the destination IP address.
snBgp4AddrFilterDestMask fdry.1.2.11.2.1.1.6 Syntax: IpAddress	Read-write	Specifies the destination IP subnet mask.
snBgp4AddrFilterRowStatus fdry.1.2.11.2.1.1.7 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## BGP4 Aggregate Address Table

By default, the Layer 3 Switch advertises individual routes for all the networks. The aggregation feature allows you to configure the Layer 3 Switch to aggregate routes in a range of networks into a single CIDR number.

Name, OID, and Syntax	Access	Description
snBgp4AggregateAddrTable fdry.1.2.11.3.1	None	The BGP4 Aggregate Address Table
snBgp4AggregateAddrEntry fdry.1.2.11.3.1.1	None	An entry in the BGP4 Aggregate Address Table

Name, OID, and Syntax	Access	Description
<p>snBgp4AggregateAddrIp fdry.1.2.11.3.1.1.1 Syntax: IpAddress</p>	Read only	<p>Shows the aggregate Address IP address.</p> <p>Specify 0 for the host portion and for the network portion that differs among the networks in the aggregate. For example, to aggregate 10.0.1.0, 10.0.2.0, and 10.0.3.0, enter the IP address 10.0.0.0 and the network mask 255.255.0.0 in the next object.</p>
<p>snBgp4AggregateAddrMask fdry.1.2.11.3.1.1.2 Syntax: IpAddress</p>	Read only	Shows the aggregate Address IP subnet mask.
<p>snBgp4AggregateAddrOption fdry.1.2.11.3.1.1.3 Syntax: Integer</p>	Read only	<p>Specifies the type of aggregate address option that is being used:</p> <ul style="list-style-type: none"> <li>• address(1) – Adds an address. This is the default option.</li> <li>• asSet(2) – Causes the router to aggregate AS-path information for all the routes in the aggregate address into a single AS-path.</li> <li>• summaryOnly(3) – Prevents the router from advertising more specific routes contained within the aggregate route.</li> <li>• suppressMap(4) – Prevents the more specific routes contained in the specified route map from being advertised.</li> <li>• advertiseMap(5) – Configures the router to advertise the more specific routes in the specified route map.</li> <li>• attributeMap(6) – Configures the router to set attributes for the aggregate routes based on the specified route map.</li> </ul>
<p>snBgp4AggregateAddrMap fdry.1.2.11.3.1.1.4 Syntax: Octet string</p>	Read-write	<p>Specifies the name of the route map to be used if the "snBgp4AggregateAddrOption" object is set to suppressMap(4), advertiseMap(5), or attributeMap(6).</p> <p>The value of this object is an octet string. Each character in the address map name is represented by one octet. There can be up to 32 octets in this object.</p>
<p>snBgp4AggregateAddrRowStatus fdry.1.2.11.3.1.1.5 Syntax: Integer</p>	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>• delete(3) – Delete the row</li> <li>• create(4) – Create a new row</li> <li>• modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row</li> <li>• invalid(1) – Row is inoperative</li> <li>• valid(2) – Row exists and is valid</li> </ul>



## BGP4 Attribute Entries Table

The BGP4 Attribute Entries Table contains the sets of BGP4 attributes stored in the router's memory. Each set of attributes is unique and can be associated with one or more routes.

Name, OID, and Syntax	Access	Description
snBgp4AttributeTable fdry.1.2.11.18.1	None	The BGP4 Attribute Entries Table.
snBgp4AttributeEntry fdry.1.2.11.18.1.1	None	An entry in the BGP4 Attribute Entries Table.
snBgp4AttributeIndex fdry.1.2.11.18.1.1.1 Syntax: Integer	Read only	Shows the index for a route entry.
snBgp4AttributeNextHop fdry.1.2.11.18.1.1.2 Syntax: Integer	Read only	Shows the IP address of the next hop router for routes that have this set of attributes.
snBgp4AttributeMetric fdry.1.2.11.18.1.1.3 Syntax: Integer	Read only	Shows the cost of the route entry.
snBgp4AttributeOrigin fdry.1.2.11.18.1.1.4 Syntax: Integer	Read only	Shows the origin of this route: <ul style="list-style-type: none"> <li>igp(0) – Routes with this set of attributes came to BGP through IGP.</li> <li>egp(1) – Routes with this set of attributes came to BGP through EGP.</li> <li>incomplete(2) – Routes came from an origin other than one of the above. For example, they may have been redistributed from OSPF or RIP.</li> </ul>
snBgp4AttributeAggregatorAs fdry.1.2.11.18.1.1.5 Syntax: Integer	Read only	Shows the aggregator AS number for an attribute entry. AS in which the network information in the attribute set was aggregated. This value applies only to aggregated routes and is otherwise 0.
snBgp4AttributeRouterId fdry.1.2.11.18.1.1.6 Syntax: Integer	Read only	Shows the ID of the device that originated this aggregator.
snBgp4AttributeAtomicAggregate Present fdry.1.2.11.18.1.1.7 Syntax: Integer	Read only	Shows if this aggregation has resulted in information loss. <ul style="list-style-type: none"> <li>false(0) – No information loss</li> <li>true(1) – Information has been lost</li> </ul>

Name, OID, and Syntax	Access	Description
snBgp4AttributeLocalPreference fdry.1.2.11.18.1.1.8 Syntax: Integer	Read only	Shows the degree of preference for routes that use this set of attributes, relative to other routes in the local AS.
snBgp4AttributeCommunityList fdry.1.2.11.18.1.1.9 Syntax: Octet string	Read only	Shows the communities that routes with this set of attributes are in.  A community is represented by four octets. The community list, could have some well known numbers such as: <ul style="list-style-type: none"> <li>BGP_COMMUNITY_ATTRIBUTE_NO_EXPORT0xFFFFFFFF01</li> <li>BGP_COMMUNITY_ATTRIBUTE_NO_ADVERTISE0xFFFFFFFFF02</li> </ul> If the community list is a NULL string (empty list) then the community is INTERNET, which is represented by a number from 1 to 0xFFFFFFFF.
snBgp4AttributeAsPathList fdry.1.2.11.18.1.1.10 Syntax: Octet string	Read only	Shows the ASs through which routes with this set of attributes have passed.  The local AS is shown in parentheses.  This is a number from 1 – 0xFFFF. This integer number is represented by two octets.
snBgp4AttributeOriginator fdry.1.2.11.18.1.1.11 Syntax: IpAddress	Read only	Shows the originator of the route in a route reflector environment.
snBgp4AttributeClusterList fdry.1.2.11.18.1.1.12 Syntax: Octet string	Read only	Shows the route reflector clusters through which this set of attributes has passed.  The list is a group of cluster IDs. Each ID is an IP address represented by four octets.

## BGP4 AS-Path Filter Table

A list of the other ASs through which a route passes. BGP4 routers can use the AS-path to detect and eliminate routing loops.

Name, OID, and Syntax	Access	Description
snBgp4AsPathFilterTable fdry.1.2.11.4.1	None	The BGP4 AS-Path Filter Table
snBgp4AsPathFilterEntry fdry.1.2.11.4.1.1	None	An entry in the BGP4 AS-Path Filter Table
snBgp4AsPathFilterIndex fdry.1.2.11.4.1.1.1 Syntax: Integer	Read only	The table index for a filter entry.

Name, OID, and Syntax	Access	Description
snBgp4AsPathFilterAction fdry.1.2.11.4.1.1.2 Syntax: Integer	Read-write	Specifies what the device will do if the BGP address matches this filter. <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snBgp4AsPathFilterRegularExpression fdry.1.2.11.4.1.1.3 Syntax: Octet string	Read-write	Shows the AS in the filter that is using a regular expression. Each character of the regular expression string is represented by one octet. Valid values: Up to 256
snBgp4AsPathFilterRowStatus fdry.1.2.11.4.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## BGP4 Community Filter Table

You can filter routes received from BGP4 neighbors based on community names.

Name, OID, and Syntax	Access	Description
snBgp4CommunityFilterTable fdry.1.2.11.5.1	None	The BGP4 Community Filter Table.
snBgp4CommunityFilterEntry fdry.1.2.11.5.1.1	None	An entry in the BGP4 Community Filter Table.
snBgp4CommunityFilterIndex fdry.1.2.11.5.1.1.1 Syntax: Integer	Read only	The table index for a filter entry.
snBgp4CommunityFilterAction fdry.1.2.11.5.1.1.2 Syntax: Integer	Read-write	Specifies what the device will do if the BGP address matches this filter. <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>

Name, OID, and Syntax	Access	Description
snBgp4CommunityFilterCommNum fdry.1.2.11.5.1.1.3 Syntax: Octet string	Read-write	Identifies the filter's number. This is a number from 1 – 0xFFFFFFFF. There can be up to 20 filters. Each integer is represented by four octets.
snBgp4CommunityFilterInternet fdry.1.2.11.5.1.1.4 Syntax: Integer	Read-write	Indicates if Internet Community is enabled <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snBgp4CommunityFilterNoAdvertise fdry.1.2.11.5.1.1.5 Syntax: Integer	Read-write	Checks the route to see if it has the keyword "NO_ADVERTISE". If the route has the keyword, it will not be advertised to EBGP peers: <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>
snBgp4CommunityFilterNoExport fdry.1.2.11.5.1.1.6 Syntax: Integer	Read-write	Checks the route to see if it has the keyword "NO_EXPORT". If the route has the keyword, it will not be advertised to EBGP peers outside the local AS: <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>
snBgp4CommunityFilterRowStatus fdry.1.2.11.5.1.1.7 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snBgp4CommunityFilterLocalAs fdry.1.2.11.5.1.1.8 Syntax: Integer	Read-write	Checks the route to see if it has the keyword "LOCAL_AS". If the route has the keyword the community applies only to confederations. The device will advertise the route only within the sub-AS. <ul style="list-style-type: none"> <li>false(0)</li> <li>true(1)</li> </ul>

## BGP4 Route Map Filter Table

A **route map** is a named set of match conditions and parameter settings that a Foundry Layer 3 Switch can use to modify route attributes and to control redistribution of routes.

BGP4 allows you to include the redistribution filters as part of a route map. A route map examines and modifies route information exchanged between BGP4 and RIP or OSPF.

Name, OID, and Syntax	Access	Description
snBgp4RouteMapFilterTable fdry.1.2.11.12.1	None	The BGP4 RouteMap Filter Table.
snBgp4RouteMapFilterEntry fdry.1.2.11.12.1.1	None	An entry in the BGP4 RouteMap Filter Table.
snBgp4RouteMapFilterMapName fdry.1.2.11.12.1.1.1 Syntax: Octet string	Read only	Shows the route map's name.  The value of this object contains an octet string. Each character is represented by one octet. There can be up to 32 octets in this object.
snBgp4RouteMapFilterSequenceNum fdry.1.2.11.12.1.1.2 Syntax: Integer	Read only	Shows the sequence number for this particular route map.
snBgp4RouteMapFilterAction fdry.1.2.11.12.1.1.3 Syntax: Integer	Read-write	Tells the device what to do if the BGP address matches this entry. <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snBgp4RouteMapFilterRowStatus fdry.1.2.11.12.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## BGP4 Route Map Match Configuration Table

A **route map** is a named set of match conditions and parameter settings that a Foundry Layer 3 Switch can use to modify route attributes and to control redistribution of routes.

BGP4 allows you to include the redistribution filters as part of a route map. A route map examines and modifies route information exchanged between BGP4 and RIP or OSPF.

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snBgp4RouteMapMatchTable fdry.1.2.11.13.1	None	The BGP4 Route Map Set Table
snBgp4RouteMapMatchEntry fdry.1.2.11.13.1.1	None	An entry in the BGP4 Route Map Set Table
snBgp4RouteMapMatchMapName fdry.1.2.11.13.1.1.1 Syntax: Octet string	Read only	Shows the name of the route map to be matched.  The value of this object is an octet string. Each character of the name is represented by one octet. There can be up to 32 octets in this object.
snBgp4RouteMapMatchSequenceNum fdry.1.2.11.13.1.1.2 Syntax: Integer	Read only	Shows the sequence number for this particular route map. Routes are matched to the route map in ascending numerical order. Matching stops once a match is found.
snBgp4RouteMapMatchAsPathFilter fdry.1.2.11.13.1.1.3 Syntax: Octet string	Read-write	Identifies the AS path list number that this route must match.  This is a number from 1 – 0xFFFF. There are 10. Each number consists of of two octets.
snBgp4RouteMapMatchCommunityFilter fdry.1.2.11.13.1.1.4 Syntax: Octet string	Read-write	Identifies the community filter number that this route must match.  This is a number from 1 – 0xFFFF. There are 10. Each number consists of of two octets.
snBgp4RouteMapMatchAddressFilter fdry.1.2.11.13.1.1.5 Syntax: Octet string	Read-write	Identifies the address filter number that this route must match.  This is a number from 1 – 0xFFFF. There are 10. Each number consists of two octets. There can be a total of 20 octets in this object.
snBgp4RouteMapMatchMetric fdry.1.2.11.13.1.1.6 Syntax: Integer	Read-write	Compares the route's MED (metric) to the this value. There can be up to 20 octets in this object.
snBgp4RouteMapMatchNextHopList fdry.1.2.11.13.1.1.7 Syntax: Octet string	Read-write	Compares the IP address of the route's next hop to the IP address filters in this route.  This is a number from 1 – 0xFFFF, represented by two octets. There are 16 of them. There can be a total of 32 octets in this object.

Name, OID, and Syntax	Access	Description
snBgp4RouteMapMatchRouteType fdry.1.2.11.13.1.1.8 Syntax: Integer	Read-write	Determines the OSPF route type to match: <ul style="list-style-type: none"> <li>• none(0)</li> <li>• external(1)</li> <li>• externalType1(2)</li> <li>• externalType2(3)</li> <li>• internal(4)</li> <li>• local(5)</li> </ul> <p>Currently only externalType1(2), externalType2(3), and internal(4) is supported for SNMP-SET.</p>
snBgp4RouteMapMatchTagList fdry.1.2.11.13.1.1.9 Syntax: Octet string	Read-write	Identifies the community tag access list that this route must match. <p>This is a number represented by an octet strings. There can be up to 32 octets in this object.</p>
snBgp4RouteMapMatchRowMask fdry.1.2.11.13.1.1.10 Syntax: Integer	Read-write	This object is used together with the MIB objects above in the same VARBIND to set and reset any MIBs in the table. The bit number is referred to the snBgp4RouteMapMatchEntry number of each row in the table: <p>The bit is ON - means set</p> <p>The bit is OFF - means reset</p>
snBgp4RouteMapMatchAsPathAccessList fdry.1.2.11.13.1.1.11 Syntax: Octet string	Read-write	Indicates which BGP AS path access list this route must match. <p>This is an integer from 1 – 0xFFFFFFFF, consisting of five sets of four octets.</p>
snBgp4RouteMapMatchCommunityList fdry.1.2.11.13.1.1.12 Syntax: Octet string	Read-write	Indicates which BGP community access list this route must match. <p>This is an integer from 1 – 0xFFFFFFFF, consisting of five sets of four octets.</p>
snBgp4RouteMapMatchAddressAccessList fdry.1.2.11.13.1.1.13 Syntax: Octet string	Read-write	Indicates which BGP address access list this route must match. <p>This is an integer from 1 – 0xFFFFFFFF, consisting of five sets of two octets.</p>
snBgp4RouteMapMatchAddressPrefixList fdry.1.2.11.13.1.1.14 Syntax: Octet string	Read-write	Indicates the prefix list that must match a BGP address access list. <p>Valid values: Up to 170 octets.</p>
snBgp4RouteMapMatchNextHopAccessList fdry.1.2.11.13.1.1.15 Syntax: Octet string	Read-write	Indicates the ID of the next hop router that this route must match. <p>This is an integer from 1 – 0xFFFFFFFF, consisting of five integers. Each integer has two octets.</p>

Name, OID, and Syntax	Access	Description
snBgp4RouteMapMatchNextHop PrefixList  fdry.1.2.11.13.1.1.16 Syntax: Octet string	Read- write	Indicates the prefix list of the next hop router that this route must.  Valid values: Up to 170 octets.

## BGP4 Route Map Set Configuration Table

A **route map** is a named set of match conditions and parameter settings that a Foundry Layer 3 Switch can use to modify route attributes and to control redistribution of routes.

BGP4 allows you to include the redistribution filters as part of a route map. A route map examines and modifies route information exchanged between BGP4 and RIP or OSPF.

Name, OID, and Syntax	Access	Description
snBgp4RouteMapSetTable fdry.1.2.11.14.1	None	The BGP4 Route Map Set Table.
snBgp4RouteMapSetEntry fdry.1.2.11.14.1.1	None	An entry in the BGP4 Route Map Set Table.
snBgp4RouteMapSetMapName fdry.1.2.11.14.1.1.1 Syntax: Octet string	Read only	Specifies the name of the route map you want to use to set or change BGP4 attributes for the network you are advertising  The value of this object is an octet string. Each character of the name is represented by one octet.
snBgp4RouteMapSetSequenceNumber fdry.1.2.11.14.1.1.2 Syntax: Integer	Read only	Shows the sequence of the route map.
snBgp4RouteMapSetAsPathType fdry.1.2.11.14.1.1.3 Syntax: Integer	Read- write	Specifies how an AS path for BGP routes will be modified: <ul style="list-style-type: none"> <li>tag(0) – Converts the tag of a route into an AS path.</li> <li>prepend(1) – Adds the specified AS numbers to the front of the value of the “snBgp4RouteMapSetAsPathString” object of the matching route.</li> </ul>
snBgp4RouteMapSetAsPathString fdry.1.2.11.14.1.1.4 Syntax: Octet string	Read- write	Specifies the AS-path string. This string is used only if the snBgp4RouteMapSetAsPathCmd was sent together with the value set to prepend(1).
snBgp4RouteMapSetAutoTag fdry.1.2.11.14.1.1.5 Syntax: Integer	Read- write	Indicates if the automatic tag option for BGP routes is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> <p>If enabled, the automatic tag calculates and sets an automatic tag value for the route</p>



Name, OID, and Syntax	Access	Description
snBgp4RouteMapSetCommunityType fdry.1.2.11.14.1.1.6 Syntax: Integer	Read-write	Indicates if BGP communities attributes are allowed: <ul style="list-style-type: none"> <li>nums(0) – Allow community attributes</li> <li>none(3) – No community attributes are allowed</li> </ul> The old values 1 and 2 are not valid starting with Release 05.03.00.
snBgp4RouteMapSetCommunityNum fdry.1.2.11.14.1.1.7 Syntax: Integer	Read-write	Shows the community number of this route. Applies only if the object "snBgp4RouteMapSetCommunityType" that was sent on this route is set to nums(0).
snBgp4RouteMapSetCommunityAdditive fdry.1.2.11.14.1.1.8 Syntax: Integer	Read-write	Indicates if the option to add the existing communities to the route is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snBgp4RouteMapSetLocalPreference fdry.1.2.11.14.1.1.9 Syntax: Integer	Read-write	Specifies the local preference for the route. You can set the preference to a value from 0 – 4294967295.
snBgp4RouteMapSetMetric fdry.1.2.11.14.1.1.10 Syntax: Integer	Read-write	Sets the MED (metric) value for the route.
snBgp4RouteMapSetNextHop fdry.1.2.11.14.1.1.11 Syntax: IpAddress	Read-write	Indicates the IP address of the next hop for the BGP routes.
snBgp4RouteMapSetOrigin fdry.1.2.11.14.1.1.12 Syntax: Integer	Read-write	Shows the BGP route origin: <ul style="list-style-type: none"> <li>igp(0) – Routes with this set of attributes came to BGP through IGP.</li> <li>egp(1) – Routes with this set of attributes came to BGP through EGP.</li> <li>incomplete(2) – routes came from an origin other than IGP or EGP. For example, they may have been redistributed from OSPF or RIP.</li> </ul>
snBgp4RouteMapSetTag fdry.1.2.11.14.1.1.13 Syntax: Integer	Read-write	Specifies the tag for BGP routes.
snBgp4RouteMapSetWeight fdry.1.2.11.14.1.1.14 Syntax: Integer	Read-write	Specifies the BGP weight for the routing table. Valid values: 0 – 65535

Name, OID, and Syntax	Access	Description
snBgp4RouteMapSetRowMask fdry.1.2.11.14.1.1.15 Syntax: Integer	Read-write	This object is used together with the MIB objects above in the same VARBIND to set and reset any MIBs in the table. The bit number is referred to the snBgp4RouteMapSetEntry number of each row in the table. <ul style="list-style-type: none"> <li>The bit is ON - means set</li> <li>The bit is OFF - means reset</li> </ul>
snBgp4RouteMapSetCommunityNums fdry.1.2.11.14.1.1.16 Syntax: Octet string	Read-write	Shows the community number for this route. Community number is a number from 1 – 0xFFFFFFFF. There are six community numbers. Each number is represented by four octets.
snBgp4RouteMapSetDampenHalfLife fdry.1.2.11.14.1.1.17 Syntax: Integer	Read-write	Specifies the number of minutes after which the route's penalty becomes half its value.
snBgp4RouteMapSetDampenReuse fdry.1.2.11.14.1.1.18 Syntax: Integer	Read-write	Specifies how low a route's penalty must be before the route becomes eligible for use again after being suppressed.
snBgp4RouteMapSetDampenSuppress fdry.1.2.11.14.1.1.19 Syntax: Integer	Read-write	Specifies how high a route's penalty can be before the Layer 3 Switch suppresses the route.
snBgp4RouteMapSetDampenMaxSuppress fdry.1.2.11.14.1.1.20 Syntax: Integer	Read-write	Specifies the maximum number of minutes that a route can be suppressed regardless of how unstable it is.

## BGP4 Redistribution of Routes Table

The BGP4 Redistribution of Routes Table contains configurations that could be imported into the BGP4 domain. Each entry specifies a particular RIP, OSPF, or static route that will be imported into the BGP4 domain.

Name, OID, and Syntax	Access	Description
snBgp4RedisTable fdry.1.2.11.11.1	None	The BGP4 Redistribution of Routes Table.
snBgp4RedisEntry fdry.1.2.11.11.1.1	None	An entry in the BGP4 Redistribution of Routes Table.

Name, OID, and Syntax	Access	Description
snBgp4RedisProtocol fdry.1.2.11.11.1.1.1 Syntax: Integer	Read only	Shows the type of route that was imported into the BGP4 domain: <ul style="list-style-type: none"> <li>rip(1) – RIP</li> <li>ospf(2) – OSPF</li> <li>static(3) – Static</li> <li>connected(4) – Connected</li> <li>isis(5) – ISIS</li> </ul>
snBgp4RedisMetric fdry.1.2.11.11.1.1.2 Syntax: Integer	Read-write	Indicates the metric used..
snBgp4RedisRouteMap fdry.1.2.11.11.1.1.3 Syntax: Octet string	Read-write	Indicates the name of the route map used. Each character is represented by one octet. Valid values: Up to 32 octets.
snBgp4RedisWeight fdry.1.2.11.11.1.1.4 Syntax: Integer	Read-write	Specifies the weight assigned to this entry.
snBgp4RedisMatchInternal fdry.1.2.11.11.1.1.5 Syntax: Integer	Read-write	Applies only to the OSPF protocol. <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snBgp4RedisMatchExternal1 fdry.1.2.11.11.1.1.6 Syntax: Integer	Read-write	Applies only to the OSPF protocol. <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snBgp4RedisMatchExternal2 fdry.1.2.11.11.1.1.7 Syntax: Integer	Read-write	Applies only to the OSPF protocol. <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snBgp4RedisRowStatus fdry.1.2.11.11.1.1.8 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## BGP4 Routes Operational Status Table

Name, OID, and Syntax	Access	Description
snBgp4RouteOperStatusTable fdry.1.2.11.16.1	None	The BGP4 Router Operational Status Table.
snBgp4RouteOperStatusEntry fdry.1.2.11.16.1.1	None	An entry in the BGP4 Router Operational Status Table.
snBgp4RouteOperStatusIndex fdry.1.2.11.16.1.1.1 Syntax: Integer	Read only	The index for a route entry.
snBgp4RouteOperStatusIp fdry.1.2.11.16.1.1.2 Syntax: IpAddress	Read only	Shows the IP address of the route.
snBgp4RouteOperStatusSubnetMask fdry.1.2.11.16.1.1.3 Syntax: IpAddress	Read only	Shows the IP Subnet Mask of the route.
snBgp4RouteOperStatusNextHop fdry.1.2.11.16.1.1.4 Syntax: IpAddress	Read only	Shows the IP address of the next hop in the route.
snBgp4RouteOperStatusMetric fdry.1.2.11.16.1.1.5 Syntax: Integer	Read only	Shows the value of the route's MED attribute.
snBgp4RouteOperStatusLocalPreference fdry.1.2.11.16.1.1.6 Syntax: Integer	Read only	Shows the degree of preference for this route relative to other routes in the local AS. When the BGP4 algorithm compares routes on the basis of local preferences, the route with the higher local preference is chosen. The preference can have a value from 0 – 4294967295.
snBgp4RouteOperStatusWeight fdry.1.2.11.16.1.1.7 Syntax: Integer	Read only	The value that this router associates with routes from a specific neighbor. For example, if the router receives routes to the same destination from two BGP4 neighbors, the router prefers the route from the neighbor with the larger weight.
snBgp4RouteOperStatusOrigin fdry.1.2.11.16.1.1.8 Syntax: Integer	Read only	Shows the route's origin: <ul style="list-style-type: none"> <li>igp(0) – Routes with this set of attributes came to BGP through IGP.</li> <li>egp(1) – Routes with this set of attributes came to BGP through EGP.</li> <li>incomplete(2) – routes came from an origin other than IGP or EGP. For example, they may have been redistributed from OSPF or RIP.</li> </ul>

Name, OID, and Syntax	Access	Description																
snBgp4RouteOperStatusStatus fdry.1.2.11.16.1.1.9 Syntax: Integer	Read only	Shows the route's status.  The value of this object is a bit array, a packed bit string. The following shows the meaning of each bit. A bit position may be set to 0 – FALSE or 1 – TRUE:  <table border="1"> <thead> <tr> <th>Bit position</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>6 – 31</td> <td>reserved</td> </tr> <tr> <td>5</td> <td>aggregate route for multiple networks</td> </tr> <tr> <td>4</td> <td>best route to destination</td> </tr> <tr> <td>3</td> <td>internal, learned through BGP4</td> </tr> <tr> <td>2</td> <td>local, originated on this device</td> </tr> <tr> <td>1</td> <td>suppressed, suppressed during aggregation and thus is not advertised to neighbors</td> </tr> <tr> <td>0</td> <td>valid</td> </tr> </tbody> </table>	Bit position	Meaning	6 – 31	reserved	5	aggregate route for multiple networks	4	best route to destination	3	internal, learned through BGP4	2	local, originated on this device	1	suppressed, suppressed during aggregation and thus is not advertised to neighbors	0	valid
Bit position	Meaning																	
6 – 31	reserved																	
5	aggregate route for multiple networks																	
4	best route to destination																	
3	internal, learned through BGP4																	
2	local, originated on this device																	
1	suppressed, suppressed during aggregation and thus is not advertised to neighbors																	
0	valid																	
snBgp4RouteOperStatusRouteTag fdry.1.2.11.16.1.1.10 Syntax: Integer	Read only	Sets the route's tag. This can be a value from 0 – 4294967295. This object applies only to routes redistributed into OSPF																
snBgp4RouteOperStatusCommunityList fdry.1.2.11.16.1.1.11 Syntax: Octet string	Read only	Shows the communities the route is in.  A community is represented by 4 octets. The community list, could have some well-known numbers such as: <ul style="list-style-type: none"> <li>BGP_COMMUNITY_ATTRIBUTE_NO_EXPORT0xFFFFFFFF01</li> <li>BGP_COMMUNITY_ATTRIBUTE_NO_ADVERTISE0xFFFFFFFFF02</li> </ul> If the community list is a NULL string (empty list) then the community is INTERNET, which is represented by a number from 1 – 0xFFFFFFFF.																
snBgp4RouteOperStatusAsPathList fdry.1.2.11.16.1.1.12 Syntax: Octet string	Read only	Shows the AS Path list of this route.  Valid values: 1 – 0xFFFF. This integer is represented by two octets.																

## BGP4 Neighbor General Configuration Table

The BGP4 protocol does not contain a peer discovery process. You must indicate the neighbor's IP address for each of the router's BGP4 neighbors (peers), as well as the AS each neighbor is in. Neighbors that are in different ASs communicate using EBGP. Neighbors within the same AS communicate use IBGP.

Name, OID, and Syntax	Access	Description
snBgp4NeighGenCfgTable fdry.1.2.11.6.1	None	The BGP4 Neighborhood General Configuration Table.
snBgp4NeighGenCfgEntry fdry.1.2.11.6.1.1	None	An entry in the BGP4 Neighborhood General Configuration Table.
snBgp4NeighGenCfgNeighIp fdry.1.2.11.6.1.1.1 Syntax: IpAddress	Read only	Shows the IP Address for a neighbor entry.
snBgp4NeighGenCfgAdvertlevel fdry.1.2.11.6.1.1.2 Syntax: Integer	Read-write	Specifies the minimum delay (in seconds) between messages to the specified neighbor.  Valid values: 0 – 600  Defaults: <ul style="list-style-type: none"> <li>30 for EBGP neighbors (neighbors in other ASs)</li> <li>5 for IBGP neighbors (neighbors in the same AS).</li> </ul>
snBgp4NeighGenCfgDefOriginate fdry.1.2.11.6.1.1.3 Syntax: Integer	Read-write	Indicates if the default originate for this neighbor is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> <p>If enabled, the device sends the default route 0.0.0.0 to the neighbor.</p>
snBgp4NeighGenCfgEbgpMultiho p fdry.1.2.11.6.1.1.4 Syntax: Integer	Read-write	Indicates if the EBGP Multihop for this neighbor is enabled. <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> <p>If enabled, the neighbor is more than one hop away and that the session type with the neighbor is thus EBGP multihop.  Default: disabled(0)</p>
snBgp4NeighGenCfgMaxPrefix fdry.1.2.11.6.1.1.5 Syntax: Integer	Read-write	Specifies the maximum number of IP network prefixes (routes) that can be learned from the specified neighbor or peer group. You can specify a value from 0 – 4294967295.  Default: 0 (unlimited)  The minimum value of the maximum prefix is defined by the “snBgp4GenNeighPrefixMinValue” object. The maximum value of the maximum prefix is defined by the “snBgp4GenOperRoutes” object.

Name, OID, and Syntax	Access	Description
snBgp4NeighGenCfgNextHopSelf fdry.1.2.11.6.1.1.6 Syntax: Integer	Read-write	Indicates if the option that allows the router to list itself as the next hop in the updates sent to the specified neighbor is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0)
snBgp4NeighGenCfgRemoteAs fdry.1.2.11.6.1.1.7 Syntax: Integer	Read-write	Specifies the AS that the remote neighbor is in. Valid values: 1 – 65535 Default: no default
snBgp4NeighGenCfgSendComm fdry.1.2.11.6.1.1.8 Syntax: Integer	Read-write	Indicates if the option to send community attributes in updates to specified neighbors is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0)
snBgp4NeighGenCfgWeight fdry.1.2.11.6.1.1.9 Syntax: Integer	Read-write	Assigns a weight to a neighbor connection. BGP4 prefers larger weights over smaller weights. Valid values: 0 – 65535 Default: 0
snBgp4NeighGenCfgWeightFilter List fdry.1.2.11.6.1.1.10 Syntax: Octet string	Read-write	Specifies a weight that the device applies to routes received from the neighbor that match the AS-path filter or ACL. Valid values: 1 – 0xFFFF. There are 16 of them. Each integer is represented by two octets.
snBgp4NeighGenCfgRowStatus fdry.1.2.11.6.1.1.11 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately. The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

Name, OID, and Syntax	Access	Description
snBgp4NeighGenCfgUpdateSrcLpIntf fdry.1.2.11.6.1.1.12 Syntax: Integer	Read-write	Specifies the loopback interface number for TCP connections. Valid values: 0 – 8  Generally, loopback interfaces are used for links to IBGP neighbors, which often are multiple hops away, rather than to EBGP neighbors. Zero interface means to restore the interface assignment to the closest interface, which is called the best local address.
snBgp4NeighGenCfgRouteRefClient fdry.1.2.11.6.1.1.13 Syntax: Integer	Read-write	Indicates if the option to allow this neighbor to be a router reflector client is enabled: <ul style="list-style-type: none"><li>• disabled(0)</li><li>• enabled(1)</li></ul>
snBgp4NeighGenCfgRemovePrivateAs fdry.1.2.11.6.1.1.14 Syntax: Integer	Read-write	Specifies if the option to remove private AS numbers from update messages that routers sent to this neighbor is enabled. <ul style="list-style-type: none"><li>• disabled(0)</li><li>• enabled(1)</li></ul> If enabled, the router will remove AS numbers 64512 – 65535 (the well known BGP4 private AS numbers) from the AS-path attribute in UPDATE messages the device sends to the neighbor. Default: disabled(0)
snBgp4NeighGenCfgEbgpMultiholdTtl fdry.1.2.11.6.1.1.15 Syntax: Integer	Read-write	Specifies the time-to-live (TTL) for the neighbor. Valid values: 0 – 255.  Default: 0. If you leave the EBGP TTL value set to 0, the software uses the IP TTL value.
snBgp4NeighGenCfgShutdown fdry.1.2.11.6.1.1.16 Syntax: Integer	Read-write	Indicates if BGP4 neighbor shutdown is enabled: <ul style="list-style-type: none"><li>• disabled(0)</li><li>• enabled(1)</li></ul> If enabled, the device shuts down the session with this neighbor. Shutting down the session allows you to completely configure the neighbor and save the configuration without actually establishing a session with the neighbor. Default: disabled(0)
snBgp4NeighGenCfgKeepAliveTime fdry.1.2.11.6.1.1.17 Syntax: Integer	Read-write	Indicates how often the device sends keep alive messages. This object overrides the global settings for the Keepalive Time  Valid values: 0 – 65535 seconds



Name, OID, and Syntax	Access	Description
snBgp4NeighGenCfgHoldTime fdry.1.2.11.6.1.1.18 Syntax: Integer	Read-write	Determines how many seconds the device will wait for a keep alive or update message from a BGP4 neighbor before deciding that the neighbor is dead.  This object overrides the global settings for Hold Time.  Valid values: 0 or 3 – 65535 seconds (1 and 2 seconds are not allowed)  If you set the Hold Time to 0, the router waits indefinitely for messages from a neighbor.
snBgp4NeighGenCfgDefOrigMap fdry.1.2.11.6.1.1.19 Syntax: Octet string	Read-write	Indicates if the name of the default route map. This is an octet string. Each character is represented by one octet.  Valid values: Up to 32 octets
snBgp4NeighGenCfgDesc fdry.1.2.11.6.1.1.20 Syntax: Octet string	Read-write	Specifies the name for the neighbor.  Valid values: Up to 80 octets
snBgp4NeighGenCfgPass fdry.1.2.11.6.1.1.21 Syntax: Octet string	Read-write	Specifies an MD5 password for securing sessions between the device and its neighbor.  Valid values: Up to 80 octets

## BGP4 Neighbor Distribute Group Table

Name, OID, and Syntax	Access	Description
snBgp4NeighDistGroupTable fdry.1.2.11.7.1	None	The BGP4 Neighbor Distribute Group Table
snBgp4NeighDistGroupEntry fdry.1.2.11.7.1.1	None	An entry in the BGP4 Neighbor Distribute Group Table
snBgp4NeighDistGroupNeighIp fdry.1.2.11.7.1.1.1 Syntax: IpAddress	Read only	Shows the IP Address for this entry.
snBgp4NeighDistGroupDir fdry.1.2.11.7.1.1.2 Syntax: Integer	Read only	Indicates if the access list is applied to incoming or outgoing advertisements: <ul style="list-style-type: none"> <li>out(0)</li> <li>in(1)</li> </ul>
snBgp4NeighDistGroupAccessList fdry.1.2.11.7.1.1.3 Syntax: Octet string	Read-write	Indicates the access list that will be applied to advertisements.  This is number from 1 – 0xFFFF. There are 16 of them. Each integer is represented by two octets.

Name, OID, and Syntax	Access	Description
<p>snBgp4NeighDistGroupRowStatus</p> <p>fdry.1.2.11.7.1.1.4</p> <p>Syntax: Integer</p>	<p>Read-write</p>	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>• delete(3) – Delete the row</li> <li>• create(4) – Create a new row</li> <li>• modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row</li> <li>• invalid(1) – Row is inoperative</li> <li>• valid(2) – Row exists and is valid</li> </ul>
<p>snBgp4NeighDistGroupInFilterList</p> <p>fdry.1.2.11.7.1.1.5</p> <p>Syntax: Octet string</p>	<p>Read-write</p>	<p>Indicates the group filter list that will be applied to incoming advertisements.</p> <p>This is number from 1 – 0xFFFF. There are 16 of them. Each integer is represented by two octets.</p>
<p>snBgp4NeighDistGroupOutFilterList</p> <p>fdry.1.2.11.7.1.1.6</p> <p>Syntax: Octet string</p>	<p>Read-write</p>	<p>Indicates the group filter list that will be applied to outgoing advertisements.</p> <p>This is number from 1 – 0xFFFF. There are 16 of them. Each integer is represented by two octets.</p>
<p>snBgp4NeighDistGroupInIpAccessList</p> <p>fdry.1.2.11.7.1.1.7</p> <p>Syntax: Octet string</p>	<p>Read-write</p>	<p>Indicates the access list that will be applied to incoming advertisements. This is number from 1 – 0xFFFF. There are 16 of them. Each integer is represented by two octets.</p>
<p>snBgp4NeighDistGroupOutIpAccessList</p> <p>fdry.1.2.11.7.1.1.8</p> <p>Syntax: Octet string</p>	<p>Read-write</p>	<p>Indicates the access list that will be applied to outgoing advertisements.</p> <p>This is number from 1 – 0xFFFF. There are 16 of them. Each integer is represented by two octets.</p>
<p>snBgp4NeighDistGroupInPrefixList</p> <p>fdry.1.2.11.7.1.1.9</p> <p>Syntax: Octet string</p>	<p>Read-write</p>	<p>Specifies the prefix name list of incoming advertisements.</p> <p>Valid values; Up to 32 octets</p>
<p>snBgp4NeighDistGroupOutPrefixList</p> <p>fdry.1.2.11.7.1.1.10</p> <p>Syntax: Octet string</p>	<p>Read-write</p>	<p>Specifies the prefix name list of outgoing advertisements.</p> <p>Valid values; Up to 32 octets</p>

## BGP4 Neighbor Filter Group Table

The BGP4 Neighbor Filter Group Table control the routes that the device learns or advertises.

Name, OID, and Syntax	Access	Description
snBgp4NeighFilterGroupTable fdry.1.2.11.8.1	None	The BGP4 Neighbor Filter Group Table.
snBgp4NeighFilterGroupEntry fdry.1.2.11.8.1.1	None	An entry in the BGP4 Neighbor Filter Group table.
snBgp4NeighFilterGroupNeighIp fdry.1.2.11.8.1.1.1 Syntax: IpAddress	Read only	Shows the IP Address for a neighbor entry.
snBgp4NeighFilterGroupDir fdry.1.2.11.8.1.1.2 Syntax: Integer	Read only	Shows the direction of advertisements to which the access list is applied. <ul style="list-style-type: none"> <li>out(0) – Outgoing</li> <li>in(1) – Incoming</li> </ul>
snBgp4NeighFilterGroupAccessList fdry.1.2.11.8.1.1.3 Syntax: Octet string	Read-write	Identifies the access list that is being used to filter a neighbor group.  This is a number from 1 – 0xFFFF. There are 16 of them. This integer is represented by two octets.
snBgp4NeighFilterGroupRowStatus fdry.1.2.11.8.1.1.4 Syntax: IpAddress	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.  The following values can be returned on reads: <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snBgp4NeighFilterGroupInFilterList fdry.1.2.11.8.1.1.5 Syntax: Octet string	Read-write	Identifies the filter list that is being used to filter incoming routes from a neighbor group.  This is a number from 1 – 0xFFFF. There are 16 of them. This integer is represented by two octets.

Name, OID, and Syntax	Access	Description
snBgp4NeighFilterGroupOutFilterList fdry.1.2.11.8.1.1.6 Syntax: Octet string	Read-write	Identifies the filter list that is being used to filter outgoing routes from a neighbor group.  This is a number from 1 – 0xFFFF. There are 16 of them. This integer is represented by two octets.
snBgp4NeighFilterGroupInAsPathAccessList fdry.1.2.11.8.1.1.7 Syntax: Octet string	Read-write	Identifies the AS path list that is being used to filter incoming routes from a neighbor group.  This is a number from 1 – 0xFFFF. There are 16 of them. This integer is represented by two octets.
snBgp4NeighFilterGroupOutAsPathAccessList fdry.1.2.11.8.1.1.8 Syntax: Octet string	Read-write	Identifies the AS path list that is being used to filter outgoing routes from a neighbor group.  This is a number from 1 – 0xFFFF. There are 16 of them. This integer is represented by two octets.
snBgp4NeighFilterGroupWeight fdry.1.2.11.8.1.1.9 Syntax: Integer	Read-write	Assign a weight to a neighbor filter.  Valid values: 0 – 65535
snBgp4NeighFilterGroupWeightAccessList fdry.1.2.11.8.1.1.10 Syntax: Octet string	Read-write	This is a number from 1 – 0xFFFF. There are 16 of them. This integer is represented by two octets.

## BGP4 Neighbor Route Map Table

A route map can be one of the parameters a BGP4 network can advertised. The Layer 3 Switch can use the route map to set or change BGP4 attributes when creating a local BGP4 route.

Name, OID, and Syntax	Access	Description
snBgp4NeighRouteMapTable fdry.1.2.11.9.1	None	The BGP4 Neighbor Route Map Table.
snBgp4NeighRouteMapEntry fdry.1.2.11.9.1.1	None	An entry in the BGP4 Route Map Table.
snBgp4NeighRouteMapNeighIp fdry.1.2.11.9.1.1.1 Syntax: IpAddress	Read only	Shows the IP Address for a neighbor entry.
snBgp4NeighRouteMapDir fdry.1.2.11.9.1.1.2 Syntax: Integer	Read only	Indicates the direction of the advertisement to which the access list is applied: <ul style="list-style-type: none"> <li>out(0)</li> <li>in(1)</li> </ul>

Name, OID, and Syntax	Access	Description
snBgp4NeighRouteMapMapName fdry.1.2.11.9.1.1.3 Syntax: Octet string	Read-write	Specifies the name of the route map you want to use. The value of this object is an octet string. Each character of the name is represented by one octet. There can be up to 32 octets in this object.
snBgp4NeighRouteMapRowStatus fdry.1.2.11.9.1.1.4 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## BGP4 Neighbor Operational Status Table

The BGP4 Neighbor Operational Status Table shows the state of a neighbor and statistics about the messages sent and received.

Name, OID, and Syntax	Access	Description
snBgp4NeighOperStatusTable fdry.1.2.11.15.1	None	The BGP4 Neighbor Operational Status Table.
snBgp4NeighOperStatusEntry fdry.1.2.11.15.1.1	None	An entry in the BGP4 Neighbor Operational Status Table.
snBgp4NeighOperStatusIndex fdry.1.2.11.15.1.1.1 Syntax: Integer	Read only	The index for the entry. Each entry represents a neighbor.
snBgp4NeighOperStatusIp fdry.1.2.11.15.1.1.2 Syntax: IpAddress	Read only	Shows the IP address of the neighbor.
snBgp4NeighOperStatusRemoteAs fdry.1.2.11.15.1.1.3 Syntax: Integer	Read only	Shows the AS that the neighbor is in.

Name, OID, and Syntax	Access	Description
snBgp4NeighOperStatusBgpType fdry.1.2.11.15.1.1.4 Syntax: Integer	Read only	Shows the type of BGP protocol used by this entry: <ul style="list-style-type: none"> <li>• ebgp(0) – The neighbor is in another AS</li> <li>• ibgp(1) – The neighbor is in the same AS</li> </ul>
snBgp4NeighOperStatusState fdry.1.2.11.15.1.1.5 Syntax: Integer	Read only	Shows the state of this neighbor: <ul style="list-style-type: none"> <li>• noState(0)</li> <li>• idle(1) – BGP4 process is waiting to be started. Usually, enabling BGP4 or establishing a neighbor session starts the BGP4 process. A minus sign (-) indicates that the session has gone down and the software is clearing or removing routes.</li> <li>• connect(2) – BGP4 is waiting for the connection process for the TCP neighbor session to be completed.</li> <li>• active(3) – BGP4 is waiting for a TCP connection from the neighbor.</li> <li>• openSent(4) – BGP4 is waiting for an Open message from the neighbor.</li> <li>• openConfirm(5) – BGP4 has received an OPEN message from the neighbor and is now waiting for either a KEEPALIVE or NOTIFICATION message. If the router receives a KEEPALIVE message from the neighbor, the state changes to established(6). If the message is a NOTIFICATION, the state changes to idle(1).</li> <li>• established(6) – BGP4 is ready to exchange UPDATE messages with the neighbor.</li> </ul> <p><b>NOTE:</b> If there is more BGP data in the TCP receiver queue, a plus sign (+) is also displayed.</p>
snBgp4NeighOperStatusKeepAliveTime fdry.1.2.11.15.1.1.6 Syntax: Integer	Read only	Specifies how often this router sends keep alive messages to the neighbor.
snBgp4NeighOperStatusHoldTime fdry.1.2.11.15.1.1.7 Syntax: Integer	Read only	Specifies how many seconds the router will wait for a keepalive or update message from a BGP4 neighbor before deciding that the neighbor is dead.
snBgp4NeighOperStatusAdvertiseInterval fdry.1.2.11.15.1.1.8 Syntax: Integer	Read only	Shows the minimum interval between the sending of BGP routing updates.
snBgp4NeighOperStatusKeepAliveTxCounts fdry.1.2.11.15.1.1.9	Read only	Shows the number of keep alive message sent.

Name, OID, and Syntax	Access	Description
snBgp4NeighOperStatusKeepAliveRxCounts fdry.1.2.11.15.1.1.10 Syntax: Counter	Read only	Shows the number of keep alive message received.
snBgp4NeighOperStatusUpdateTxCounts fdry.1.2.11.15.1.1.11 Syntax: Counter	Read only	Shows the number of updated message sent.
snBgp4NeighOperStatusUpdateRxCounts fdry.1.2.11.15.1.1.12 Syntax: Counter	Read only	Shows the number of updated message received.
snBgp4NeighOperStatusNotifTxCounts fdry.1.2.11.15.1.1.13 Syntax: Counter	Read only	Shows the number of Notification message sent.
snBgp4NeighOperStatusNotifRxCounts fdry.1.2.11.15.1.1.14 Syntax: Counter	Read only	Shows the number of Notification message received.
snBgp4NeighOperStatusOpenTxCounts fdry.1.2.11.15.1.1.15 Syntax: Counter	Read only	Shows the number of open message sent.
snBgp4NeighOperStatusOpenRxCounts fdry.1.2.11.15.1.1.16 Syntax: Counter	Read only	Shows the number of open message received.

## BGP4 Neighbor Summary Table

The BGP4 Neighbor Summary Table shows statistics for the router's BGP4 neighbors.

Name, OID, and Syntax	Access	Description
snBgp4NeighborSummaryTable fdry.1.2.11.17.1	None	The BGP4 Neighbor Summary Table.
snBgp4NeighborSummaryEntry fdry.1.2.11.17.1.1	None	An entry in the BGP4 Router Operational Status Table.

Name, OID, and Syntax	Access	Description
snBgp4NeighborSummaryIndex fdry.1.2.11.17.1.1.1 Syntax: Integer	Read only	The index for a route entry.
snBgp4NeighborSummaryIp fdry.1.2.11.17.1.1.2 Syntax: IpAddress	Read only	Shows the IP address of the neighbor.
snBgp4NeighborSummaryState fdry.1.2.11.17.1.1.3 Syntax: Integer	Read only	Shows the state of the BGP4 process during the current session with the neighbor. <ul style="list-style-type: none"> <li>• noState(0)</li> <li>• idle(1) – The BGP4 process is waiting to be started. Usually, enabling BGP4 or establishing a neighbor session starts the BGP4 process. A minus sign (-) indicates that the session has gone down and the software is clearing or removing routes.</li> <li>• connect(2) – Waiting for the connection process for the TCP neighbor session to be completed.</li> <li>• active(3) – BGP4 is waiting for a TCP connection from the neighbor.</li> <li>• openSent(4) – BGP4 is waiting for an Open message from the neighbor.</li> <li>• openConfirm(5) – BGP4 has received an OPEN message from the neighbor and is now waiting for either a KEEPALIVE or NOTIFICATION message. If the router receives a KEEPALIVE message from the neighbor, the state changes to established(6). If the message is a NOTIFICATION, the state changes to idle(1).</li> <li>• established(6) – BGP4 is ready to exchange UPDATE messages with the neighbor. If there is more BGP data in the TCP receiver queue, a plus sign (+) is also displayed.</li> </ul>
snBgp4NeighborSummaryStateChangeTime fdry.1.2.11.17.1.1.4 Syntax: Integer	Read only	Shows the number of times the state of this neighbor has changed. If the state frequently changes between CONNECT and ACTIVE, there may be a problem with the TCP connection.
snBgp4NeighborSummaryRoutesReceived fdry.1.2.11.17.1.1.5 Syntax: Integer	Read only	Shows the number of routes received from the neighbor during the current BGP4 session.
snBgp4NeighborSummaryRoutesInstalled fdry.1.2.11.17.1.1.6 Syntax: Integer	Read only	Indicates how many of the received routes was accepted and installed in the BGP4 route table.



## BGP4 Clear Neighbor Command Table

Name, OID, and Syntax	Access	Description
snBgp4ClearNeighborCmdTable fdry.1.2.11.19.1	None	The BGP4 Clear Neighbor Command Table.
snBgp4ClearNeighborCmdEntry fdry.1.2.11.19.1.1	None	An entry in the BGP4 Clear Neighbor Command Table.
snBgp4ClearNeighborCmdIp fdry.1.2.11.19.1.1.1 Syntax: IpAddress	Read only	Shows the IP Address of a neighbor entry. If the IP address is 255.255.255.255, then the entry applies to all neighbors.
snBgp4ClearNeighborCmdElement fdry.1.2.11.19.1.1.2 Syntax: Integer	Read-write	Indicates what will be cleared <ul style="list-style-type: none"> <li>valid(0) – Received in SNMP-GET.</li> <li>lastPacketWithError(1) – Clears the buffer containing the first 400 bytes of the last BGP4 packet that contained an error.</li> <li>notificationErrors(2) – Clears the buffer containing the last NOTIFICATION message sent or received.</li> <li>softOutbound(3) – Update all outbound routes by applying the new or changed filters, but sends only the existing routes affected by the new or changed filters to the neighbor.</li> <li>traffic(4) – Clears the BGP4 message counters for all neighbors (the default) or a neighbor.</li> <li>neighbor(5) – Clears the BGP4 message counter for all neighbors within a peer group.</li> </ul>

## BGP4 Neighbor Prefix Group Table

Name, OID, and Syntax	Access	Description
snBgp4NeighPrefixGroupTable fdry.1.2.11.20.1	None	The BGP4 Neighbor Prefix Group Table.
snBgp4NeighPrefixGroupEntry fdry.1.2.11.20.1.1	None	An entry in the BGP4 Neighbor Prefix Group Table. Each entry is a neighbor.
snBgp4NeighPrefixGroupNeighborIp fdry.1.2.11.20.1.1.1 Syntax: IpAddress	Read only	Shows the neighbor's IP Address.

Name, OID, and Syntax	Access	Description
<p>snBgp4NeighPrefixGroupDir fdry.1.2.11.20.1.1.2 Syntax: Integer</p>	Read only	<p>Shows the direction of the advertisement to which this filter will be applied:</p> <ul style="list-style-type: none"> <li>• outgoing(0) – Applied to routes that will be transmitted to the neighbor.</li> <li>• incoming(1) – Applied to routes received from the neighbor.</li> </ul>
<p>snBgp4NeighPrefixGroupInAccessList fdry.1.2.11.20.1.1.3 Syntax: Octet string</p>	Read-write	<p>If the “snBgp4NeighPrefixGroupDir” object is set to incoming(1), this object shows the name of the prefix list for incoming routes. There can be up to 32 octets in this object.</p>
<p>snBgp4NeighPrefixGroupOutAccessList fdry.1.2.11.20.1.1.4 Syntax: Octet string</p>	Read-write	<p>If the “snBgp4NeighPrefixGroupDir” object is set outgoing(0), this object shows the name of the prefix list for outgoing routes. There can be up to 32 octets in this object.</p>
<p>snBgp4NeighPrefixGroupRowStatus fdry.1.2.11.20.1.1.5 Syntax: Integer</p>	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>• delete(3) – Delete the row</li> <li>• create(4) – Create a new row</li> <li>• modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row</li> <li>• invalid(1) – Row is inoperative</li> <li>• valid(2) – Row exists and is valid</li> </ul>

---

# Chapter 17

## IPX

This chapter presents the objects in the Foundry MIBs for the Internet Packet Exchange (IPX) protocol. IPX is available in Foundry's Layer 3 Switches, such as the BigIron product.

Refer to the *Foundry Enterprise Configuration and Management Guide* for details on IPX support in Foundry devices.

---

**NOTE:** IPX is not supported on the BigIron MG8 and NetIron 40G.

---

### IPX General Objects

The following presents the general objects used to define IPX.

---

Name, OID, and Syntax	Access	Description
snIpxRoutingMode fdry.1.2.1.1.1 Syntax: Integer	Read-write	Shows the IPX Routing Mode status: <ul style="list-style-type: none"><li>disabled(0)</li><li>enabled(1)</li></ul>
snIpxNetBiosFilterMode fdry.1.2.1.1.2 Syntax: Integer	Read-write	Shows the NetBios Filter Mode status. <ul style="list-style-type: none"><li>disabled(0)</li><li>enabled(1)</li></ul>
snIpxClearCache fdry.1.2.1.1.3 Syntax: ClearStatus	Read-write	Indicates if the cache table will be cleared. <ul style="list-style-type: none"><li>normal(0)</li><li>clear(1)</li></ul>
snIpxClearRoute fdry.1.2.1.1.4 Syntax: ClearStatus	Read-write	Indicates if the IPX table will be cleared. <ul style="list-style-type: none"><li>normal(0)</li><li>clear(1)</li></ul>

---

Name, OID, and Syntax	Access	Description
snIpxClearTrafficCnts fdry.1.2.1.1.5 Syntax: ClearStatus	Read- write	Indicates if all IPX traffic counters are cleared: <ul style="list-style-type: none"> <li>• normal(0) – Do not clear counters</li> <li>• clear(1) – Clear counters</li> </ul> The IPX traffic counters affected by this object are: <ul style="list-style-type: none"> <li>• snIpxRcvPktsCnt</li> <li>• snIpxFwdPktsCnt</li> <li>• snIpxRcvDropPktsCnt</li> <li>• snIpxTxDropPktsCnt</li> <li>• snIpxRcvFiltPktsCnt</li> <li>• snIpxTxFiltPktsCnt</li> </ul>
snIpxRcvPktsCnt fdry.1.2.1.1.6 Syntax: Counter	Read only	The number of IPX packets received on the Layer 3 Switch.
snIpxTxPktsCnt fdry.1.2.1.1.7 Syntax: Counter	Read only	The number of IPX packets that originated on the Layer 3 Switch and sent on its port.
snIpxFwdPktsCnt fdry.1.2.1.1.8 Syntax: Counter	Read only	The number of IPX packets received by the Layer 3 Switch from another device and then sent out on its port.
snIpxRcvDropPktsCnt fdry.1.2.1.1.9 Syntax: Counter	Read only	The number of packets received by the Layer 3 Switch that the switch dropped.
snIpxRcvFiltPktsCnt fdry.1.2.1.1.10 Syntax: Counter	Read only	The number of packets received by a port that matched an inbound IPX filter configured on the port.
snIpxRipGblFiltList fdry.1.2.1.1.11 Syntax: Octet string	Read- write	An IPX RIP Global Filter List. There can be up to 32 octets in this object.

Name, OID, and Syntax	Access	Description
snlpxRipFiltOnAllPort fdry.1.2.1.1.12 Syntax: Integer	Read-write	Applies the IPX RIP Global filter list in the “snlpxRipGblFiltList” object to all interfaces. This object adds all RIP filter lists and deletes all RIP filter lists from all ports. Before sending this command, the “snlpxRipGblFiltList” object must be defined.  The values that can be written are: <ul style="list-style-type: none"> <li>• deleteAllInBound(2) – Deletes all in-bound filter lists from all ports.</li> <li>• deleteAllOutBound(3) – Deletes all out-bound filter lists from all ports.</li> <li>• addAllInBound(4) – Adds all in-bound filter lists to all ports.</li> <li>• addAllOutBound(5) – Adds all out-bound filter lists to all ports.</li> </ul> The following values can be returned on reads: <ul style="list-style-type: none"> <li>• noSuch(0) – Set operation has not be performed.</li> <li>• valid(1) – Set operation is done and is valid.</li> </ul>
snlpxSapGblFiltList fdry.1.2.1.1.13 Syntax: Octet string	Read-write	Contains an IPX SAP Global Filter List. There can be up to 32 octets in this object.
snlpxSapFiltOnAllPort fdry.1.2.1.1.14 Syntax: Integer	Read-write	Applies the IPX RIP Global filter list in the “snlpxSapGblFiltList” object to all interfaces. This object adds all filter lists and deletes all SAP filter lists from all ports. Before sending this command, the object “snlpxSapGblFiltList” must be defined.  The values that can be written are: <ul style="list-style-type: none"> <li>• deleteAllInBound(2) – Deletes all in-bound filter lists from all ports.</li> <li>• deleteAllOutBound(3) – Deletes all out-bound filter lists from all ports.</li> <li>• addAllInBound(4) – Adds all in-bound filter lists to all ports.</li> <li>• addAllOutBound(5) – Adds all out-bound filter lists to all ports.</li> </ul> The following values can be returned on reads: <ul style="list-style-type: none"> <li>• noSuch(0) – Set operation has not be performed.</li> <li>• valid(1) – Set operation is done and is valid.</li> </ul>
snlpxTxDropPktsCnt fdry.1.2.1.1.15 Syntax: Counter	Read only	Shows the number of packets that were queued to be sent on a port by the Layer 3 Switch, but then dropped.
snlpxTxFiltPktsCnt fdry.1.2.1.1.16 Syntax: Counter	Read only	The number of packets that were queued to be sent on a port that matched an outbound IPX filter that was configured on the port.

## IPX Cache Table

The IPX Cache Table contains information about the IPX forwarding cache for the router.

Name, OID, and Syntax	Access	Description
snIpxCacheTable fdry.1.2.1.2.1	None	The IPX Cache table
snIpxCacheEntry fdry.1.2.1.2.1.1	None	An entry in the IPX Cache table.
snIpxCacheIndex fdry.1.2.1.2.1.1.1 Syntax: Integer	Read only	The table index for a IPX Cache Table entry.
snIpxCacheNetNum fdry.1.2.1.2.1.1.2 Syntax: NetNumber	Read only	Shows the network number containing the destination node.
snIpxCacheNode fdry.1.2.1.2.1.1.3 Syntax: Physical address	Read only	Shows the number of the destination node.
snIpxCacheOutFilter fdry.1.2.1.2.1.1.4 Syntax: Integer	Read only	Shows if an outbound cache filter has been enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snIpxCacheEncap fdry.1.2.1.2.1.1.5 Syntax: Integer	Read only	Shows the IPX frame encapsulation type. <ul style="list-style-type: none"> <li>EthernetII(1)</li> <li>Ethernet8022(2)</li> <li>Ethernet8023(3)</li> <li>EthernetSnap(4)</li> </ul>
snIpxCachePort fdry.1.2.1.2.1.1.6 Syntax: PortIndex	Read only	Shows the number of the port through which the Layer 3 Switch sends IPX traffic to the destination network and node.
snIpxCachelf fdry.1.2.1.2.1.1.6 Syntax: InterfaceIndex	Read only	Shows the ID of the IPX router interface.

## IPX Route Table

The IPX Route Table contains objects for IPX routes.

Name, OID, and Syntax	Access	Description
snIpxRouteTable fdry.1.2.1.3.1	None	IPX route table.
snIpxRouteEntry fdry.1.2.1.3.1.1	None	An entry in the IPX route table
snIpxRouteIndex fdry.1.2.1.3.1.1.1 Syntax: Integer	Read only	The table index for a IPX route entry.
snIpxDestNetNum fdry.1.2.1.3.1.1.2 Syntax: Octet string	Read only	Shows the destination network number. A value of all zeros indicates that any destination network number is accepted.
snIpxFwdRouterNode fdry.1.2.1.3.1.1.3 Syntax: Physical address	Read only	Shows the MAC address of the next hop IPX router.
snIpxDestHopCnts fdry.1.2.1.3.1.1.4 Syntax: Integer	Read only	Shows the number of hops to reach the destination.
snIpxRouteMetric fdry.1.2.1.3.1.1.5 Syntax: Integer	Read only	Shows the metric for the next hop router.
snIpxDestPort fdry.1.2.1.3.1.1.6 Syntax: Integer	Read only	Shows the destination port.

## IPX Server Table

The IPX Server Table presents information about the IPX servers.

Name, OID, and Syntax	Access	Description
snIpxServerTable fdry.1.2.1.4.1	None	IPX Server table.
snIpxServerEntry fdry.1.2.1.4.1.1	None	An entry in the IPX Server table.

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snIpxServerIndex fdry.1.2.1.4.1.1.1 Syntax: Integer	Read only	The table index for a IPX Server entry.
snIpxServerType fdry.1.2.1.4.1.1.2 Syntax: Integer	Read only	Shows the IPX server type.
snIpxServerNetNum fdry.1.2.1.4.1.1.3 Syntax: NetNumber	Read only	Shows the IPX server network number.
snIpxServerNode fdry.1.2.1.4.1.1.4 Syntax: Physical address	Read only	Shows the IPX server node number.
snIpxServerSocket fdry.1.2.1.4.1.1.5 Syntax: Integer	Read only	Shows the IPX server socket number.
snIpxServerHopCnts fdry.1.2.1.4.1.1.6 Syntax: Integer	Read only	Shows the IPX number of intervening networks to reach the server.
snIpxServerName fdry.1.2.1.4.1.1.7 Syntax: Octet string	Read only	Shows the IPX server name. There can be up to 47 octets in this object.

### **IPX Forward Filter Table**

The following table defines forward filters, which controls the access of remote IPX clients to a a server with restricted access.

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snIpxFwdFilterTable fdry.1.2.1.5.1	None	IPX Forward Filter Table
snIpxFwdFilterEntry fdry.1.2.1.5.1.1	None	An entry in the IPX Forward Filter Table.
snIpxFwdFilterId fdry.1.2.1.5.1.1.1 Syntax: Integer	Read only	The filter ID for a filter entry.



Name, OID, and Syntax	Access	Description
snIpxFwdFilterAction fdry.1.2.1.5.1.1.2 Syntax: Integer	Read-write	Shows what action to take if the IPX packet matches this filter: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snIpxFwdFilterSocket fdry.1.2.1.5.1.1.3 Syntax: Integer	Read-write	Indicates the IPX Forward Filter Socket Number.
snIpxFwdFilterSrcNet fdry.1.2.1.5.1.1.4 Syntax: NetNumber	Read-write	Indicates the source network number.
snIpxFwdFilterSrcNode fdry.1.2.1.5.1.1.5 Syntax: Physical address	Read-write	Indicates the source node number.
snIpxFwdFilterDestNet fdry.1.2.1.5.1.1.6 Syntax: NetNumber	Read-write	Indicates the destination network number.
snIpxFwdFilterDestNode fdry.1.2.1.5.1.1.7 Syntax: Physical address	Read-write	Indicates the destination node number.
snIpxFwdFilterRowStatus fdry.1.2.1.5.1.1.8 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## IPX RIP Filter Table

The following table allows you to define filters that a router uses to block RIP routes being advertised to other parts of the network.

Name, OID, and Syntax	Access	Description
snIpxRipFilterTable fdry.1.2.1.6.1	None	IPX RIP Filter table.
snIpxRipFilterEntry fdry.1.2.1.6.1.1	None	An entry in the IPX RIP Filter table.
snIpxRipFilterId fdry.1.2.1.6.1.1.1 Syntax: Integer	Read only	The ID for an entry.
snIpxRipFilterAction fdry.1.2.1.6.1.1.2 Syntax: Integer	Read-write	Shows what action to take if the IPX packet matches this filter: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snIpxRipFilterNet fdry.1.2.1.6.1.1.3 Syntax: NetNumber	Read-write	Indicates the IPX RIP filter network number.
snIpxRipFilterMask fdry.1.2.1.6.1.1.4 Syntax: NetNumber	Read-write	Indicates the IPX RIP filter network/subnet mask.
snIpxRipFilterRowStatus fdry.1.2.1.6.1.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## IPX SAP Filter Table

The following table allows you to define filters that a router uses to block SAP routes being advertised to other parts of the network.

Name, OID, and Syntax	Access	Description
snIpxSapFilterTable fdry.1.2.1.7.1	None	IPX SAP Filter Table.
snIpxSapFilterEntry fdry.1.2.1.7.1.1	None	An entry in the IPX SAP Filter Table.
snIpxSapFilterId fdry.1.2.1.7.1.1.1 Syntax: Integer	Read only	The filter ID for a filter entry.
snIpxSapFilterAction fdry.1.2.1.7.1.1.2 Syntax: Integer	Read-write	Determines what action to take if the IPX packet matches this filter: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snIpxSapFilterType fdry.1.2.1.7.1.1.3 Syntax: Integer	Read-write	Identifies the IPX SAP filter type to be matched.
snIpxSapFilterName fdry.1.2.1.7.1.1.4 Syntax: Octet string	Read-write	Identifies the IPX SAP filter Name. Valid values: Up to 47 octets.
snIpxSapFilterRowStatus fdry.1.2.1.7.1.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## IPX IF Forward Access Table

Name, OID, and Syntax	Access	Description
snIpxIfFwdAccessTable fdry.1.2.1.8.1	None	IPX Interface (IF) Forward Access Table
snIpxIfFwdAccessEntry fdry.1.2.1.8.1.1	None	An entry in the IPX (IF) Forward Access Table
snIpxIfFwdAccessPort fdry.1.2.1.8.1.1.1 Syntax: Integer	Read only	The IPX interface to which the Forward Filter applies.
snIpxIfFwdAccessDir fdry.1.2.1.8.1.1.2 Syntax: Integer	Read only	Shows the direction of packets: <ul style="list-style-type: none"> <li>in(1)</li> <li>out(2)</li> </ul>
snIpxIfFwdAccessFilterList fdry.1.2.1.8.1.1.3 Syntax: Octet string	Read-write	An IPX IF Forward Filter List. There can be up to 32 octets in this object.
snIpxIfFwdAccessRowStatus fdry.1.2.1.8.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## IPX IF RIP Access Table

Name, OID, and Syntax	Access	Description
snIpxIfRipAccessTable fdry.1.2.1.9.1	None	IPX IF RIP Access Table
snIpxIfRipAccessEntry fdry.1.2.1.9.1.1	None	An entry in the IPX IF RIP Access Table

Name, OID, and Syntax	Access	Description
snIpxIfRipAccessPort fdry.1.2.1.9.1.1.1	Read only	The IPX interface to which the RIP Filter applies.
snIpxIfRipAccessDir fdry.1.2.1.9.1.1.2	Read only	Shows the direction of packets: <ul style="list-style-type: none"> <li>in(1)</li> <li>out(2)</li> </ul>
snIpxIfRipAccessFilterList fdry.1.2.1.9.1.1.3	Read-write	An IPX IF RIP Access Filter List.
snIpxIfRipAccessRowStatus fdry.1.2.1.9.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

### IPX IF SAP Access Table

Name, OID, and Syntax	Access	Description
snIpxIfSapAccessTable fdry.1.2.1.10.1	None	IPX IF SAP Access Table
snIpxIfSapAccessEntry fdry.1.2.1.10.1.1	None	An entry in the IPX IF SAP Access Table
snIpxIfSapAccessPort fdry.1.2.1.10.1.1.1 Syntax: Integer	Read only	The IPX interface to which the SAP Filter applies.
snIpxIfSapAccessDir fdry.1.2.1.10.1.1.2 Syntax: Integer	Read only	Shows the direction of packets: <ul style="list-style-type: none"> <li>in(1)</li> <li>out(2)</li> </ul>
snIpxIfSapAccessFilterList fdry.1.2.1.10.1.1.3 Syntax: Octet string	Read-write	An IPX IF SAP Access Filter List. There can be up to 32 octets in this object.

Name, OID, and Syntax	Access	Description
snIpxIfSapAccessRowStatus fdry.1.2.1.10.1.1.4 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

### IPX Port Address Table

Name, OID, and Syntax	Access	Description
snIpxPortAddrTable fdry.1.2.1.11.1	None	IPX Port Address Table
snIpxPortAddrEntry fdry.1.2.1.11.1.1	None	An entry in the IPX Port Address Table
snIpxPortAddrPort fdry.1.2.1.11.1.1.1 Syntax: PortIndex	Read only	The port index for port address entry.
snIpxPortAddrEncap fdry.1.2.1.11.1.1.2 Syntax: Integer	Read only	<p>Shows the IPX frame encapsulation type.</p> <ul style="list-style-type: none"> <li>Ethernet8022(1)</li> <li>Ethernet8023(2)</li> <li>EthernetII(3)</li> <li>EthernetSnap(4)</li> </ul> <p>Each network number must be assigned a unique frame type; otherwise, an SNMP-SET error will be returned.</p>
snIpxPortAddrNetNum fdry.1.2.1.11.1.1.3 Syntax: NetNumber	Read-write	An unique network number for the IPX interface port.

Name, OID, and Syntax	Access	Description
snIpxPortAddrRowStatus fdry.1.2.1.11.1.1.4 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snIpxPortAddrNetBiosFilterMode fdry.1.2.1.11.1.1.5 Syntax: Integer	Read-write	<p>Shows the status of the NetBios filter mode for each port address.</p> <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>

## IPX Port Counters Tables

Name, OID, and Syntax	Access	Description
snIpxPortCountersTable fdry.1.2.1.12.1	None	IPX Port Counters Table
snIpxPortCountersEntry fdry.1.2.1.12.1.1	None	An entry in the IPX Port Counters Table
snIpxPortCountersPort fdry.1.2.1.12.1.1.1 Syntax: PortIndex	Read only	The port index for an entry in the table.
snIpxPortCountersRcvPktsCnt fdry.1.2.1.12.1.1.2 Syntax: Counter	Read only	IPX incoming packets counter for the interface.
snIpxPortCountersTxPktsCnt fdry.1.2.1.12.1.1.3 Syntax: Counter	Read only	IPX Outgoing packets counter for the interface.
snIpxPortCountersFwdPktsCnt fdry.1.2.1.12.1.1.4 Syntax: Counter	Read only	IPX forwarding packets counter for the interface.

Name, OID, and Syntax	Access	Description
snlpxPortCountersRcvDropPktsCnt fdry.1.2.1.12.1.1.5 Syntax: Counter	Read only	IPX receiving drop packets counter for the interface.
snlpxPortCountersTxDropPktsCnt fdry.1.2.1.12.1.1.6 Syntax: Counter	Read only	IPX transmitting drop packets counter for the interface.
snlpxPortCountersRcvFiltPktsCnt fdry.1.2.1.12.1.1.7 Syntax: Counter	Read only	IPX receiving filter packets counter for the interface.
snlpxPortCountersTxFiltPktsCnt fdry.1.2.1.12.1.1.8 Syntax: Counter	Read only	IPX transmitting filter packets counter for the interface.



---

# Chapter 18

## AppleTalk

This section contains objects for AppleTalk. The AppleTalk feature is available in Layer 3 Switches. For details on AppleTalk support in Foundry devices, refer to the *Foundry Enterprise Configuration and Management Guide*.

This chapter contains the following sections:

- “AppleTalk General Group” on page 18-1
- “AppleTalk Socket Priority Table” on page 18-4
- “AppleTalk Port Zone Filter Table” on page 18-5
- “AppleTalk Port Table” on page 18-6
- “AppleTalk Forwarding Cache Table” on page 18-7
- “AppleTalk Zone Table” on page 18-8
- “AppleTalk Additional Zone Filter Table” on page 18-9

---

**NOTE:** AppleTalk is not supported on the BigIron MG8 and NetIron 40G.

---

### AppleTalk General Group

Name, OID, and Syntax	Access	Description
snRtATRoutingEnable fdry.1.2.10.1.1 Syntax: Integer	Read-write	Indicates if AppleTalk routing functions are enabled on this device: <ul style="list-style-type: none"><li>• disabled(0)</li><li>• enabled(1)</li></ul>
snRtATClearArpCache fdry.1.2.10.1.2 Syntax: ClearStatus	Read-write	Indicates if the cache will be cleared: <ul style="list-style-type: none"><li>• normal(0) – Data in AppleTalk ARP cache table will not be cleared.</li><li>• clear(1) – Data in AppleTalk ARP cache table will be cleared.</li></ul>

Name, OID, and Syntax	Access	Description
snRtATClearFwdCache fdry.1.2.10.1.3 Syntax: ClearStatus	Read-write	Indicates if all learned data from non-local networks that is currently in the AppleTalk forward cache table will be cleared: <ul style="list-style-type: none"> <li>• normal(0) – Data will not be cleared.</li> <li>• clear(1) – Data will be cleared.</li> </ul>
snRtATClearRoute fdry.1.2.10.1.4 Syntax: ClearStatus	Read-write	Indicates if all learned routes and zones (non-local routes and zones) that currently resident in the AppleTalk routing table and the AppleTalk route table will be cleared. <ul style="list-style-type: none"> <li>• normal(0) – Data will not be cleared.</li> <li>• clear(1) – Data will be cleared.</li> </ul>
snRtATClearTrafficCounters fdry.1.2.10.1.5 Syntax: ClearStatus	Read-write	Indicates if AppleTalk RTMP, ZIP, AEP, DDP, and AARP statistics counters will be cleared. <ul style="list-style-type: none"> <li>• normal(0) – Counters will not be cleared.</li> <li>• clear(1) – Counters will be cleared.</li> </ul>
snRtATArpRetransmitCount fdry.1.2.10.1.6 Syntax: Integer	Read-write	Indicates the maximum number of times that a packet will be sent out for ARP cache informational updates. The packet is sent out until the information is received or the maximum amount defined has been reached.  Valid values: 1 – 10  Default: 2
snRtATArpRetransmitInterval fdry.1.2.10.1.7 Syntax: Integer	Read-write	The number of seconds the device waits for an AppleTalk ARP response before sending out the next ARP packet.  Valid values: 1 – 120 seconds  Default: 1 second
snRtATGleanPacketsEnable fdry.1.2.10.1.8 Syntax: Integer	Read-write	Indicates if the AppleTalk glean packets function is enabled on this device: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> If enabled, the device tries to learn the MAC address from the packet instead of sending out an ARP request.  Default: disabled(0)
snRtATRtmpUpdateInterval fdry.1.2.10.1.9 Syntax: Integer	Read-write	Indicates how often the device sends RTMP updates on AppleTalk interfaces.  Valid values: 1 – 3600 seconds.  Default: 10 seconds.
snRtATZipQueryInterval fdry.1.2.10.1.10 Syntax: Integer	Read-write	Indicates how often the device transmits a ZIP query.  Valid values: 1 – 1000 seconds  Default: 10 seconds

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snRtATInRtmpPkts fdry.1.2.10.1.11 Syntax: Counter	Read only	Shows the total number of RTMP packets received by this device.
snRtATOutRtmpPkts fdry.1.2.10.1.12 Syntax: Counter	Read only	Shows the total number of RTMP packets that were transmitted by this device.
snRtATFilteredRtmpPkts fdry.1.2.10.1.13 Syntax: Counter	Read only	Shows the total number of RTMP packets that were filtered by this device.
snRtATInZipPkts fdry.1.2.10.1.14 Syntax: Counter	Read only	Shows the total number of ZIP packets that were received by this device.
snRtATOutZipPkts fdry.1.2.10.1.15 Syntax: Counter	Read only	Shows the total number of ZIP packets that were transmitted by this device.
snRtATInZipGZLPkts fdry.1.2.10.1.16 Syntax: Counter	Read only	Shows the total number of ZIP get zone list packets that were received by this device.
snRtATOutZipGZLPkts fdry.1.2.10.1.17 Syntax: Counter	Read only	Shows the total number of ZIP get zone list packets that were transmitted by this device.
snRtATInZipNetInfoPkts fdry.1.2.10.1.18 Syntax: Counter	Read only	Shows the total number of ZIP network information packets that were received by this device.
snRtATOutZipNetInfoPkts fdry.1.2.10.1.19 Syntax: Counter	Read only	Shows the total number of ZIP network information packets that were transmitted by this device.
snRtATInDdpPkts fdry.1.2.10.1.20 Syntax: Counter	Read only	Shows the total number of DDP datagrams that were received by this device.
snRtATOutDdpPkts fdry.1.2.10.1.21 Syntax: Counter	Read only	Shows the total number of DDP datagrams that were transmitted by this device.

Name, OID, and Syntax	Access	Description
snRtATForwardedDdpPkts fdry.1.2.10.1.22 Syntax: Counter	Read only	Shows the number of input DDP datagrams whose DDP final destination was not this device. The device attempted to forward the datagrams to that final destination.
snRtATInDeliveredDdpPkts fdry.1.2.10.1.23 Syntax: Counter	Read only	Shows the total number of input DDP datagrams whose final DDP destination is this device.
snRtATDroppedNoRouteDdpPkts fdry.1.2.10.1.24 Syntax: Counter	Read only	Shows the total number of DDP datagrams dropped because this device could not find a route to their final destination.
snRtATDroppedBadHopCountsDdpPkts fdry.1.2.10.1.25 Syntax: Counter	Read only	Shows the total number of input DDP datagrams that were dropped because this device was not their final destination and their hop count exceeded 15.
snRtATDroppedOtherReasonsDdpPkts fdry.1.2.10.1.26 Syntax: Counter	Read only	Shows the total number of DDP datagrams dropped for various reasons. For example, the device ran out of resources so the datagrams were dropped.
snRtATInAarpPkts fdry.1.2.10.1.27 Syntax: Counter	Read only	Shows the total number of AppleTalk ARP packets received by this device.
snRtATOutAarpPkts fdry.1.2.10.1.28 Syntax: Counter	Read only	Shows the total number of AppleTalk ARP packets that were transmitted by this device.

## AppleTalk Socket Priority Table

The AppleTalk Socket Priority Table shows the priority level assigned to each QoS socket. By default, all AppleTalk sockets are in the best effort queue (Chassis devices) or the normal queue (Stackable devices).

Name, OID, and Syntax	Access	Description
snRtATSocketPriorityTable fdry.1.2.10.2	None	AppleTalk Socket Priority Table.
snRtATSocketPriorityEntry fdry.1.2.10.2.1	None	An entry in the AppleTalk Socket Priority Table.
snRtATSocketPrioritySocket fdry.1.2.10.2.1.1 Syntax: Integer	Read only	The socket number for an entry. There can be up to 254 entries.

Name, OID, and Syntax	Access	Description
snRtATSocketPriorityPriority fdry.1.2.10.2.1.2 Syntax: Integer	Read-write	<p>Indicates the QoS priority for the socket.</p> <p>The priority level for a socket that applies to stackable devices are:</p> <ul style="list-style-type: none"> <li>low(0) – Low priority</li> <li>high(1) – High priority</li> </ul> <p>The priority level for a socket that applies to Chassis devices are:</p> <ul style="list-style-type: none"> <li>level0(0)</li> <li>level1(1)</li> <li>level2(2)</li> <li>level3(3),</li> <li>level4(4)</li> <li>level5(5)</li> <li>level6(6)</li> <li>level7(7)</li> </ul>

## AppleTalk Port Zone Filter Table

The AppleTalk Zone Filter Table shows if access to network zones is permitted or denied.

Name, OID, and Syntax	Access	Description
snRtATPortZoneFilterTable fdry.1.2.10.3	None	AppleTalk Port Zone Filter Table.
snRtATPortZoneFilterEntry fdry.1.2.10.3.1	None	An entry in the AppleTalk Port Zone Filter Table.
snRtATPortZoneFilterPortIndex fdry.1.2.10.3.1.1 Syntax: PortIndex	Read only	Shows the port index for a zone filter entry.
snRtATPortZoneFilterZone fdry.1.2.10.3.1.2 Syntax: Display string	Read only	<p>Shows the zone name granted for this filter:</p> <ul style="list-style-type: none"> <li>0 to 32 octets of AppleTalk</li> <li>ASCII if outside of AppleTalk</li> </ul>
snRtATPortZoneFilterAction fdry.1.2.10.3.1.3 Syntax: Integer	Read-write	<p>Indicates what the device will do with the AppleTalk packet to take if it matches this filter.</p> <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>

Name, OID, and Syntax	Access	Description
snRtATPortZoneFilterRtmpEnable fdry.1.2.10.3.1.4 Syntax: Integer	Read-write	Indicates if Routing Table Maintenance Protocol (RMTP) filtering is enabled on this device. RMTP filtering provides the zone filtering capability that allows devices to filter on a network. When this filter is enabled on an interface, the denied network numbers are removed from the RTMP packet before the packet is transmitted out of the interface. <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snRtATPortZoneFilterRowStatus fdry.1.2.10.3.1.5 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## AppleTalk Port Table

The AppleTalk Port Table defines how long a MAC address learned by a port through ARP remains valid.

The device resets the timer to zero each time the ARP entry is refreshed and removes the entry if the timer reaches the ARP age.

ARP age is managed on an individual port basis. However, when you enter an ARP age value for a port and apply the change to the running-config file or save the change to the startup-config file, the change is saved as the global setting. If you try to set different values for different ports, the interface does not display an error message. Instead, the most recent value you enter before saving the configuration change becomes the global setting.

Name, OID, and Syntax	Access	Description
snRtATPortTable fdry.1.2.10.4	None	The AppleTalk Port Table
snRtATPortEntry fdry.1.2.10.4.1	None	An entry in the AppleTalk Port Table
snRtATPortIndex fdry.1.2.10.4.1.1 Syntax: PortIndex	Read only	The port index for port table entry.

Name, OID, and Syntax	Access	Description
snRtATPortArpAge fdry.1.2.10.4.1.2 Syntax: Integer	Read-write	Shows the number of minutes an ARP entry can be valid without relearning. This can be from 0 – 240 minutes.  Default: 10 minutes. If this is set to 0, then the ARP entry will always relearn.
snRtATPortState fdry.1.2.10.4.1.3 Syntax: Integer	Read only	Shows the state of this port: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• down(2)</li> <li>• up(3)</li> </ul>
snRtATPortSeedRouter fdry.1.2.10.4.1.4 Syntax: Integer	Read only	Shows if this port is a seed or non-seed router: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• seedRouter(2)</li> <li>• nonSeedRouter(3)</li> </ul>
snRtATPortOperationMode fdry.1.2.10.4.1.5 Syntax: Integer	Read only	Shows the operational state of this port: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• seedRouter(2)</li> <li>• nonSeedRouter(3)</li> <li>• notOperational(4)</li> <li>• routingDisabled(5)</li> </ul>

## AppleTalk Forwarding Cache Table

The AppleTalk Forwarding Cache Table contains data learned from non-local networks that is currently resident in the AppleTalk cache.

Name, OID, and Syntax	Access	Description
snRtATFwdCacheTable fdry.1.2.10.5	None	AppleTalk Forwarding Cache Table.
snRtATFwdCacheEntry fdry.1.2.10.5.1	None	An entry in the AppleTalk Forwarding Cache Table.
snRtATFwdCacheIndex fdry.1.2.10.5.1.1 Syntax: Integer	Read only	Shows the table index for a table entry.
snRtATFwdCacheNetAddr fdry.1.2.10.5.1.2 Syntax: Octet string	Read only	Shows the AppleTalk network address of a station.

Name, OID, and Syntax	Access	Description
snRtATFwdCacheMacAddr fdry.1.2.10.5.1.3 Syntax: Octet string	Read only	Shows the MAC address of an AppleTalk station. This object has six octets.
snRtATFwdCacheNextHop fdry.1.2.10.5.1.4 Syntax: Integer	Read only	Shows the network address of the router in the next hop.
snRtATFwdCacheOutgoingPort fdry.1.2.10.5.1.5 Syntax: Integer	Read only	Shows the outgoing port through which the packets will be forwarded. If set to zero, then no outgoing port has been defined.
snRtATFwdCacheType fdry.1.2.10.5.1.6 Syntax: Integer	Read only	Shows the type of AppleTalk forwarding cache type: <ul style="list-style-type: none"> <li>dynamic(1)</li> <li>permanent(2)</li> </ul>
snRtATFwdCacheAction fdry.1.2.10.5.1.7 Syntax: Integer	Read only	Determines what the device will do if a match is found: <ul style="list-style-type: none"> <li>other(1)</li> <li>forward(2)</li> <li>forUs(3)</li> <li>waitForArp(4)</li> <li>dropPacket(5)</li> </ul>
snRtATFwdCacheVlanId fdry.1.2.10.5.1.8 Syntax: Integer	Read only	Shows the ID of the VLAN associated with this entry. If set to zero, then no VLAN is associated with this entry.

## AppleTalk Zone Table

The AppleTalk Zone Table shows the network numbers and zones learned on the network.

Name, OID, and Syntax	Access	Description
snRtATZoneTable fdry.1.2.10.6	None	AppleTalk Zone Table
snRtATZoneEntry fdry.1.2.10.6.1	None	An entry in the AppleTalk Zone Table
snRtATZoneIndex fdry.1.2.10.6.1.1 Syntax: Integer	Read only	Shows the table index for an AppleTalk zone table entry.



Name, OID, and Syntax	Access	Description
snRtATZoneNetStart fdry.1.2.10.6.1.2 Syntax: ATNetworkNumber	Read only	Shows the first AppleTalk network address in the range under this zone name. (Refer to the “snRtATZoneName” object.)
snRtATZoneNetEnd fdry.1.2.10.6.1.3 Syntax: ATNetworkNumber	Read only	Shows the last AppleTalk network addresses in the range under this zone name.
snRtATZoneName fdry.1.2.10.6.1.4 Syntax: Display string	Read only	Shows the zone’s name. There can be up – 32 characters in this object.

## AppleTalk Additional Zone Filter Table

The AppleTalk Additional Zone Filter Table contains information about zones that do not match any zones defined in the “AppleTalk Zone Table” on page 18-8.

Name, OID, and Syntax	Access	Description
snRtATAddZoneFilterTable fdry.1.2.10.7	None	The AppleTalk Additional Zone Filter Table.
snRtATAddZoneFilterEntry fdry.1.2.10.7.1	None	An entry in the AppleTalk Additional Zone Filter Table.
snRtATAddZoneFilterPortIndex fdry.1.2.10.7.1.1 Syntax: PortIndex	Read only	Shows the port index for additional zone filter table entry.
snRtATAddZoneFilterAction fdry.1.2.10.7.1.2 Syntax: Integer	Read-write	Indicates what the device will do when a match is found: <ul style="list-style-type: none"> <li>deny(0)</li> <li>permit(1)</li> </ul>
snRtATAddZoneFilterRtmpEnable fdry.1.2.10.7.1.3 Syntax: Integer	Read-write	Indicates if RTMP filtering on additional zone is enabled on this device: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>



---

# Chapter 19

## MPLS

This chapter presents SNMP MIB objects for the Multiprotocol Label Switching (MPLS) feature that is supported on the NetIron IMR 640 Router. These objects are available in the NetIron IMR 640 Router software release 02.1.00 and later. Refer to the *Foundry NetIron Service Provider Configuration and Management Guide for the NetIron IMR 640* for details about the MPLS feature.

### MPLS Objects

The following are the general

---

Name, OID, and Syntax	Access	Description
mplsVersion fdry.1.2.15.1.1.1 Syntax: Unsigned32	Read only	MPLS version number.
mplsConfiguredLsps fdry.1.2.15.1.2.1 Syntax: Unsigned32	Read Only	Number of configured LSPs. This is calculated by adding the number of RSVPs and statically configured Label-switched paths (LSPs).
mplsActiveLsps fdry.1.2.15.1.2.2 Syntax: Unsigned32	Read Only	Number of active LSPs. This is calculated by adding the number of RSVPs, LDPs, and statically configured LSPs.

---

### The MPLS LSP Table

The following table contains objects for the MPLS LSPs.

---

Name, OID, and Syntax	Access	Description
mplsLspTable fdry.1.2.15.1.2.3	N/A	The MPLS LSP Table

---

Name, OID, and Syntax	Access	Description
mplsLspEntry fdry.1.2.15.1.2.3.1	N/A	An entry in the MPLS LSP Tabel
mplsLspSignalingProto fdry.1.2.15.1.2.3.1.1 Syntax: Integer	N/A	MPLS signaling protocol used by this LSP: <ul style="list-style-type: none"> <li>• ldp(1)</li> <li>• rsvp(2)</li> </ul>
mplsLspIndex fdry.1.2.15.1.2.3.1.2 Syntax: Unsigned32	N/A	The unique index of the LSP in the system for a given signaling protocol.
mplsLspName fdry.1.2.15.1.2.3.1.3 Syntax: Displaystring	Read only	Name of the Label Switched Path.
mplsLspState fdry.1.2.15.1.2.3.1.4 Syntax: Integer	Read only	The operational state of the LSP: <ul style="list-style-type: none"> <li>• unknown(1)</li> <li>• up(2)</li> <li>• down(3)</li> </ul>
mplsLspPackets fdry.1.2.15.1.2.3.1.5 Syntax: Counter64	Read only	The number of packets that have been forwarded over the current LSP active path.
mplsLspAge fdry.1.2.15.1.2.3.1.6 Syntax: TimeStamp	Read only	The age, since creation of this LSP in 10-millisecond periods. Not supported in the BETA Release
mplsLspTimeUp fdry.1.2.15.1.2.3.1.7 Syntax: TimeStamp	Read only	The total time in 10-millisecond units when this LSP has been operational. Calculate the percentage up time as follows: $\text{mplsLspTimeUp} / \text{mplsLspAge} \times 100 \%$ Not supported in the BETA Release
mplsLspPrimaryTimeUp fdry.1.2.15.1.2.3.1.8 Syntax: TimeStamp	Read only	The total time in 10-millisecond units that this LSP's primary path has been operational. The percentage contribution of the primary path to the operational time is calculated using the following equation: $\text{mplsLspPrimaryTimeUp} / \text{mplsLspTimeUp} \times 100 \%$ Not supported in the BETA Release
mplsLspTransitions fdry.1.2.15.1.2.3.1.9 Syntax: TimeStamp	Read only	The number of times this LSP 's state transitioned from up to down and down to up.

---

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
mplsLspLastTransition fdry.1.2.15.1.2.3.1.10 Syntax: IpAddress	Read only	The time in 10-millisecond units since the last transition occurred on this LSP.  Not supported in the BETA Release
mplsLspFrom fdry.1.2.15.1.2.3.1.11 Syntax: IpAddress	Read only	Source IP address of this LSP.
mplsLspTo fdry.1.2.15.1.2.3.1.12	Read only	Destination IP address of this LSP.
mplsPathName fdry.1.2.15.1.2.3.1.13 Syntax: DisplayString	Read only	The name of the active path for this LSP. If there is no name, this field should be empty and all the fields in this table do not apply.
mplsPathType fdry.1.2.15.1.2.3.1.14 Syntax: Integer	Read only	The type of path that is active. This field is meaningless unless mplsPathName contains a value. Paths can be: <ul style="list-style-type: none"><li>• other(1)</li><li>• primary(2)</li><li>• standby(3)</li><li>• secondary(4)</li></ul>

---



---

# Chapter 20

## Monitoring and Logging

This chapter presents the MIB objects that can be used for monitoring and logging functions. It includes the following sections:

- “CPU Utilization” on page 20-1
- “Dynamic Memory Utilization” on page 20-3
- “System DRAM Information Group”
- “ARP Tables” on page 20-4
- “sFlow” on page 20-8
- “NetFlow Export” on page 20-9
- “System Logging” on page 20-13
- “CAM Statistics” on page 20-19
- “System Process Utilization Table” on page 20-23
- “Objects for Debugging” on page 20-24

### CPU Utilization

The following objects monitor CPU utilization in all Foundry devices. Refer to the *Foundry Switch and Router Installation and Basic Configuration Guide* for additional information on this feature.

---

Name, OID, and Syntax	Access	Description
snAgGblCpuUtilData fdry.1.1.2.1.35 Syntax: Gauge	Read only	Shows the CPU utilization since the last time the same command was given.
snAgGblCpuUtilCollect fdry.1.1.2.1.36 Syntax: Integer	Read-write	Enables or disables the collection of CPU utilization statistics in a device. This can be one of the following: <ul style="list-style-type: none"><li>• Enable(1)</li><li>• Disable(0)</li></ul>

---

Name, OID, and Syntax	Access	Description
snAgGblCpuUtil1SecAvg fdry.1.1.2.1.50 Syntax: Gauge	Read only	Shows CPU utilization every one second.
snAgGblCpuUtil5SecAvg fdry.1.1.2.1.51 Syntax: Gauge	Read only	Shows CPU utilization every 5 seconds.
snAgGblCpuUtil1MinAvg fdry.1.1.2.1.52 Syntax: Gauge	Read only	Shows CPU utilization every one minute.

## System CPU Utility Table

The following objects are available on all Foundry devices, except on ServerIron products.

Name, OID, and Syntax	Access	Description
snAgentCpuUtilTable fdry.1.1.2.11.1	None	A table listing the utilization of all CPUs in a device.
snAgentCpuUtilEntry fdry.1.1.2.11.1.1	None	A row in the CPU utilization table.
snAgentCpuUtilSlotNum fdry.1.1.2.11.1.1.1 Syntax: Integer	Read only	Shows the slot number of the module that contains the CPU.
snAgentCpuUtilCpuId fdry.1.1.2.11.1.1.2 Syntax: Integer	Read only	Available in all Foundry devices beginning with Release 07.2.x. Shows the ID of the CPU: <ul style="list-style-type: none"> <li>• 1 – Management CPU</li> <li>• 2 or greater – Slave CPU</li> </ul> A non-VM1/WSM management module has one CPU. A VM1/WSM module has one management CPU and 3 slave CPUs. The management CPU could be turned off. POS and ATM modules have no management CPU but have two slave CPUs.



Name, OID, and Syntax	Access	Description
snAgentCpuUtilInterval fdry.1.1.2.11.1.1.3 Syntax: Integer	Read only	Available in all Foundry devices beginning with Release 07.2.x.  Shows the CPU utilization in seconds.  CPU utilization of a primary module is displayed in 1, 5, 60, and 300 second intervals.  CPU utilization of a secondary module is displayed in 1, 5, 60, and 300 second intervals.
snAgentCpuUtilValue fdry.1.1.2.11.1.1.4 Syntax: Gauge	Read only	Available in all Foundry devices beginning with Release 07.2.x.  Shows the CPU utilization in one-hundredths of a percent.  This object is indexed by snAgentCpuUtilSlotNum, snAgentCpuUtilCpuld, and snAgentCpuUtilInterval.  For example, a BigIron 4000 has a management module in slot 1. The module is not a VM1 module and it has only one CPU. When an snmpget is issued to snAgentCpuUtilValue.1.1.300, which translates to slot 1, CPU 1, and 300 seconds, the result is 100. Each unit of the result equals to 0.01% CPU utilization and 100 equals to 1% CPU utilization.

## Dynamic Memory Utilization

The following objects manage dynamic memory utilization in all Foundry devices, except for stackable ServerIron and ServerIron XL. There are no objects for memory utilization in the stackable ServerIron. Refer to the *Foundry Switch and Router Installation and Basic Configuration Guide* for additional information on this feature.

Name, OID, and Syntax	Access	Description
snAgGblDynMemUtil fdry.1.1.2.1.53 Syntax: Gauge	Read only	Shows the dynamic memory utilization of the device in percentage units.  <b>NOTE:</b> In Service Provider Release 09.1.02 and Enterprise IronWare release 07.8.00, this object was replaced by "snAgSystemDRAMUtil".
snAgGblDynMemTotal fdry.1.1.2.1.54 Syntax: Integer	Read only	Shows the total amount of dynamic memory in a device in number of bytes.  <b>NOTE:</b> In Service Provider Release 09.1.02 and Enterprise IronWare release 07.8.00, this object was replaced by "snAgSystemDRAMTotal".
snAgGblDynMemFree fdry.1.1.2.1.55 Syntax: Integer	Read only	Shows the amount of system dynamic memory that is currently available in number of bytes.  <b>NOTE:</b> In Service Provider Release 09.1.02 and Enterprise IronWare release 07.8.00, this object was replaced by "snAgSystemDRAMFree".

## System DRAM Information Group

This group displays memory utilization statistics for protocols that use dynamic memory allocation. It shows the same information that a **show memory** command displays.

This group of objects was introduced in Service Provider Release 09.1.02 and Enterprise IronWare Release 07.8.00.

Name, Identifier, and Syntax	Access	Description
snAgSystemDRAM fdry.1.1.2.12.4	NA	The System DRAM Information Group
snAgSystemDRAMUtil fdry.1.1.2.12.4.1 Syntax: Integer	Read only	The amount of system dynamic memory that is currently utilized, in percent.  This object replaces “snAgGblDynMemUtil” in Service Provider Release 09.1.02 and Enterprise IronWare release 07.8.00.
snAgSystemDRAMTotal fdry.1.1.2.12.4.2 Syntax: Integer	Read only	The total amount of system dynamic memory, in bytes.  This object replaces “snAgGblDynMemTotal” in Service Provider Release 09.1.02 and Enterprise IronWare release 07.8.00.
snAgSystemDRAMFree fdry.1.1.2.12.4.3 Syntax: Integer	Read only	The amount of free system dynamic memory, in bytes.  This object replaces “snAgGblDynMemFree” in Service Provider Release 09.1.02 and Enterprise IronWare release 07.8.00.
snAgSystemDRAMForBGP fdry.1.1.2.12.4.4 Syntax: Integer	Read only	The amount of dynamic memory in bytes, used by BGP.
snAgSystemDRAMForOSPF fdry.1.1.2.12.4.5 Syntax: Integer	Read only	The amount of dynamic memory in bytes, used by OSPF.

## ARP Tables

The following tables are available to manage ARP using SNMP:

- “RARP Table” on page 20-5
- “Static ARP Table” on page 20-5
- “Global ARP Statistics” on page 20-7

Refer to the *Foundry Switch and Router Installation and Basic Configuration Guide* for additional information on this feature.

## RARP Table

The Reverse Address Resolution Protocol (RARP) provides a simple mechanism for directly-attached IP hosts to boot over the network. RARP allows an IP host that does not have a means of storing its IP address across power cycles or software reloads to query a directly-attached router for an IP address.

RARP is enabled by default. However, there must be a static RARP entry for each host that will use the Layer 3 Switch for booting. The following table contains the object that define each RARP entry. They are available in all Foundry devices, except ServerIron products.

Name, OID, and Syntax	Access	Description
snRtlpRarpTable fdry.1.2.2.4	None	IP RARP Table.
snRtlpRarpEntry fdry.1.2.2.4.1	None	An entry in the IP RARP Table.
snRtlpRarpIndex fdry.1.2.2.4.1.1 Syntax: Integer	Read only	An index for an entry in the RARP Table. There can be up to 16 entries.
snRtlpRarpMac fdry.1.2.2.4.1.2 Syntax: Octet string	Read-write	Shows the MAC address of the RARP client.
snRtlpRarpIp fdry.1.2.2.4.1.3 Syntax: IpAddress	Read-write	Shows the IP address for a RARP client.
snRtlpRarpRowStatus fdry.1.2.2.4.1.4 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## Static ARP Table

Address Resolution Protocol (ARP) is a standard IP protocol that enables an IP Layer 3 Switch to obtain the MAC address of another device's interface when the Layer 3 Switch knows the IP address of the interface. ARP is enabled by default and cannot be disabled.

The Static ARP Table in a Foundry Layer 3 Switch contains entries that are useful in cases where you want to pre-configure an entry for a device that is not connected to the Layer 3 Switch, or you want to prevent a particular entry from aging out. The software removes a dynamic entry from the ARP cache if the ARP aging interval expires before the entry is refreshed. Static entries do not age out, regardless of whether or not the Foundry device receives an ARP request from the device that has the entry's address.

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snRtStaticArpTable fdry.1.2.2.5	None	IP static ARP Table.
snRtStaticArpEntry fdry.1.2.2.5.1	None	An entry in the IP static ARP Table.
snRtStaticArpIndex fdry.1.2.2.5.1.1 Syntax: Integer	Read only	An index for a static ARP entry. There can be up to 16 entries.
snRtStaticArpIp fdry.1.2.2.5.1.2 Syntax: IpAddress	Read-write	Shows the IP address of a static ARP entry.
snRtStaticArpMac fdry.1.2.2.5.1.3 Syntax: Octet string	Read-write	Specifies the MAC address of a static ARP entry.
snRtStaticArpPort fdry.1.2.2.5.1.4 Syntax: PortIndex	Read-write	<p>Specifies the port number attached to the device that has the MAC address of the entry.</p> <ul style="list-style-type: none"> <li>For FastIron or NetIron products, the value of this object is from 1 – 42</li> <li>For BigIron products, the value of this object is an encoded number: <ul style="list-style-type: none"> <li>Bit 0 to bit 7 – Port number.</li> <li>Bit 8 to bit 11 – Slot number.</li> </ul> </li> </ul> <p>Beginning with software release 07.2.00, the following values have been added:</p> <ul style="list-style-type: none"> <li>Bit 16, set to 1 – Virtual router interface</li> <li>Bit 17, set to 1 – Loopback interface</li> </ul>

Name, OID, and Syntax	Access	Description
snRtStaticArpRowStatus fdry.1.2.2.5.1.5 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snRtStaticArpIfIndex fdry.1.2.2.5.1.6 Syntax: InterfaceIndex	Read-write	The interface index for this entry.

### Global ARP Statistics

The following are the MIB objects display statistics for ARP. These objects were introduced in Service Provider Release 09.1.02 and Enterprise IronWare Release 07.8.00.

Name, Identifier, and Syntax	Access	Description
snArpStatsTotalReceived fdry.1.1.3.22.1.1 Syntax: Counter32	Read only	The total number of ARP packets received from the interfaces, including those received in error.
snArpStatsRequestReceived fdry.1.1.3.22.1.2 Syntax: Counter32	Read only	The total number of input ARP request packets received from the interfaces.
snArpStatsRequestSent fdry.1.1.3.22.1.3 Syntax: Counter32	Read only	The total number of output ARP request packets sent from the interfaces.
snArpStatsRepliesSent fdry.1.1.3.22.1.4 Syntax: Counter32	Read only	The total number of output ARP reply packets sent from the interfaces.
snArpStatsPendingDrop fdry.1.1.3.22.1.5 Syntax: Counter32	Read only	The total number of ARP pending packets discarded.

Name, Identifier, and Syntax	Access	Description
snArpStatsInvalidSource fdry.1.1.3.22.1.6 Syntax: Counter32	Read only	The total number of ARP packets received with invalid sender protocol address.
snArpStatsInvalidDestination fdry.1.1.3.22.1.7 Syntax: Counter32	Read only	The total number of ARP packets received with invalid destination protocol address.

## sFlow

This section presents the sFlow objects that are proprietary to Foundry products. Refer to the section “RFC 3176: InMon Corporation’s sFlow: A Method for Monitoring Traffic in Switched And Routed Networks.” on page 2-14 to determine which standard objects can be used to manage sFlow in Foundry devices.

This section presents the following objects:

- “sFlow Source” on page 20-8
- “sFlow Collector” on page 20-8

Refer to the *Foundry Enterprise Configuration and Management Guide* for details on sFlow.

### sFlow Source

The following object supports the sFlow feature, which is available on certain modules.

Name, OID, and Syntax	Access	Description
snAgSFlowSourceInterface fdry.1.1.2.1.59 Syntax: InterfaceIndex	Read-write	Identifies the source interface for sFlow packets sent by the Foundry device that is running sFlow Export.  Use the ifIndex value for this object to specify the source interface to be used. The interface should have an IP address configured for sFlow. A value of 0 indicates that source interface has not been configured for sFlow. Port 65534 is used to specify a null port.

### sFlow Collector

Currently, RFC 3176 allows only one sFlow destination to be configured. To configure two or more destinations, use the following table.

Name, OID, and Syntax	Access	Description
snSflowCollectorTable fdry.1.1.3.19.2	None	Table of sFlow collectors, beginning with the second collector. Configure the first sFlow collector using the sFlowCollectorAddress and sFlowCollectorPort objects in the RFC 3176 sFlowTable.
snSflowCollectorEntry fdry.1.1.3.19.2.1	None	A row in the sflow collector table

---

snSflowCollectorIndex fdry.1.1.3.19.2.1.1 Syntax: Integer	Read only	The index to the sFlow collector table
snSflowCollectorIP fdry.1.1.3.19.2.1.2 Syntax: IpAddress	Read-write	The IP address of the sFlow collector
snSflowCollectorUDPPort fdry.1.1.3.19.2.1.3 Syntax: Integer	Read-write	The number of the UDP port used by the sFlow collector
snSflowCollectorRowStatus fdry.1.1.3.19.2.1.4 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>• delete(3) – Delete the row</li> <li>• create(4) – Create a new row</li> <li>• modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row</li> <li>• other(1) – Some other case</li> <li>• valid(2) – Row exists and is valid</li> </ul>

---

## NetFlow Export

The following objects provide configuration information on the NetFlow Export feature. They apply to all Foundry devices except the ServerIron products.

NetFlow Export collects information about the traffic that chassis devices receive, then forwards and exports that information to a third-party collector. Third-party applications can then use the information to create reports, bill customers for network usage and so on. For detailed information on the NetFlow Export feature, refer to the *Foundry Enterprise Configuration and Management Guide*.

The following sections present the objects available to manage NetFlow using SNMP:

- "Global NetFlow Objects" on page 20-10
- "NetFlow Export Collector Table" on page 20-10
- "NetFlow Export Aggregation Table" on page 20-11
- "NetFlow Export Interface Table" on page 20-13

## Global NetFlow Objects

Name, OID, and Syntax	Access	Description
snNetFlowGblEnable fdry.1.1.3.18.1.1 Syntax: Integer	Read-write	Determines if NetFlow Export is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0)
snNetFlowGblVersion fdry.1.1.3.18.1.2 Syntax: Integer	Read-write	Shows the NetFlow Export version. Default: Version 5
snNetFlowGblProtocolDisable fdry.1.1.3.18.1.3 Syntax: Integer	Read-write	Indicates if TCP or UDP protocols are disabled: <ul style="list-style-type: none"> <li>Bit 0 – Disables the export of all protocol except UDP and TCP</li> <li>Bit 1 – Disables the export of TCP protocol</li> <li>Bit 2 – Disables the export of UDP protocol</li> </ul> Default: 0
snNetFlowGblActiveTimeout fdry.1.1.3.18.1.4 Syntax: Integer	Read-write	Specifies the maximum number of minutes that an active flow can be in the NetFlow Export cache. Valid values: 1 – 60 minutes Default: 60 minutes
snNetFlowGblInactiveTimeout fdry.1.1.3.18.1.5 Syntax: Integer	Read-write	Specifies the maximum number of seconds that an inactive flow can be in the NetFlow Export cache. Valid values: 1 – 600 seconds Default: 60 seconds

## NetFlow Export Collector Table

The following table provides information about the NetFlow Export collector. They apply to all Foundry devices except the ServerIron products.

Collectors are where expired UPD packets from Foundry devices are sent. Refer to the *Foundry Enterprise Configuration and Management Guide* for details on this feature.

Name, OID, and Syntax	Access	Description
snNetFlowCollectorTable fdry.1.1.3.18.2	None	A table of each NetFlow Export collector information.
snNetFlowCollectorEntry fdry.1.1.3.18.2.1	None	A row in the NetFlow Export Collector Table.



Name, OID, and Syntax	Access	Description
snNetFlowCollectorIndex fdry.1.1.3.18.2.1.1 Syntax: Integer	Read only	The index to the NetFlow Export Collector Table. Valid values:1 – 10.
snNetFlowCollectorIp fdry.1.1.3.18.2.1.2 Syntax: IpAddress	Read-write	Shows the IP address of the collector.
snNetFlowCollectorUdpPort fdry.1.1.3.18.2.1.3 Syntax: Integer	Read-write	Shows the UDP port number of the collector.
snNetFlowCollectorSourceInterface fdry.1.1.3.18.2.1.4 Syntax: Integer	Read-write	Shows the source port for the NetFlow Export packets. Packets will be exported through this port: <ul style="list-style-type: none"> <li>A valid port number – The port configured to be the source port.</li> <li>0 – No source port specified. The port connected to the collector to the collector is the source port.</li> </ul>
snNetFlowCollectorRowStatus fdry.1.1.3.18.2.1.5 Syntax: Integer	Read-write	Creates or deletes a NetFlow Export Collector Table entry: <ul style="list-style-type: none"> <li>other(1)</li> <li>valid(2)</li> <li>delete(3)</li> <li>create(4)</li> </ul>

## NetFlow Export Aggregation Table

The following table provides information on the NetFlow Export aggregation schemes. They apply to all Foundry devices except the ServerIron products.

By default, NetFlow Export exports a separate flow for each unique set of flow information. To streamline data export, you can consolidate flows by creating aggregate caches that contain individual flows based on specific information in the flow. Refer to the *Foundry Enterprise Configuration and Management Guide* for details on the NetFlow Export aggregation.

Name, OID, and Syntax	Access	Description
snNetFlowAggregationTable fdry.1.1.3.18.3	None	The NetFlow Export Aggregation Table
snNetFlowAggregationEntry fdry.1.1.3.18.3.1	None	An entry in the NetFlow Export Aggregation Table.

Name, OID, and Syntax	Access	Description
<p>snNetFlowAggregationIndex fdry.1.1.3.18.3.1.1 Syntax: Integer</p>	Read only	<p>Specifies what information will be used to aggregate the flow:</p> <ul style="list-style-type: none"> <li>as(1) – Autonomous system scheme uses the input and output interfaces and the source and destination BGP4 AS.</li> <li>protocolPort(2) – IP protocol and application port source and destination IP protocol, and source and destination TCP or UDP port numbers.</li> <li>destPrefix(3) – Destination prefix scheme uses output interface, destination network mask and prefix, and destination BGP4 AS.</li> <li>sourcePrefix(4) – Source prefix scheme uses the input interface, source network mask and prefix, and source BGP4 AS.</li> <li>prefix(5) – Source and destination prefix scheme use the input and output interfaces, source and destination network masks and prefixes, and source and destination BGP4 AS.</li> </ul>
<p>snNetFlowAggregationIp fdry.1.1.3.18.3.1.2 Syntax: IpAddress</p>	Read-write	The IP address of the NetFlow Export aggregation collector.
<p>snNetFlowAggregationUdpPort fdry.1.1.3.18.3.1.3 Syntax: Integer</p>	Read-write	The UDP port of the NetFlow Export aggregation collector.
<p>snNetFlowAggregationSourceInterface fdry.1.1.3.18.3.1.4 Syntax: Integer</p>	Read-write	<p>Shows the source port to export the NetFlow Export aggregation packets:</p> <ul style="list-style-type: none"> <li>A valid port number – The port configured to be the source port.</li> <li>0 – No source port specified. The port connected to the collector to the collector is the source port.</li> </ul>
<p>snNetFlowAggregationNumberOfCacheEntries fdry.1.1.3.18.3.1.5 Syntax: Integer</p>	Read-write	Shows the maximum number of aggregated flows that the aggregation cache can contain.
<p>snNetFlowAggregationActiveTimeout fdry.1.1.3.18.3.1.6 Syntax: Integer</p>	Read-write	<p>Shows the maximum time in minutes that an active flow can remain in the NetFlow Export aggregation cache.</p> <p>Valid values: 1 – 60 minutes.</p> <p>Default: 30 minutes</p>
<p>snNetFlowAggregationInactiveTimeout fdry.1.1.3.18.3.1.7 Syntax: Integer</p>	Read-write	<p>Shows the maximum time in seconds that an inactive flow can remain in the NetFlow Export aggregation cache. The object can have a value from 10 – 600 seconds.</p> <p>Default: 15 seconds</p>

Name, OID, and Syntax	Access	Description
snNetFlowAggregationEnable fdry.1.1.3.18.3.1.8 Syntax: Integer	Read-write	Indicates if NetFlow Export aggregation for this aggregation scheme is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0)
snNetFlowAggregationRowStatus fdry.1.1.3.18.3.1.9 Syntax: Integer	Read-write	Creates or deletes a NetFlow Export Aggregation table entry: <ul style="list-style-type: none"> <li>other(1)</li> <li>valid(2)</li> <li>delete(3)</li> <li>create(4)</li> </ul>

## NetFlow Export Interface Table

The following table contains information about the switching type in every NetFlow Export interface. They apply to all Foundry devices except the ServerIron products.

Name, OID, and Syntax	Access	Description
snNetFlowIfTable fdry.1.1.3.18.4	None	Shows a list of interface entries. The number of entries is given by the value of ifNumber.
snNetFlowIfEntry fdry.1.1.3.18.4.1	None	Entry containing the type of switching performed on that interface.
snNetFlowIfIndex fdry.1.1.3.18.4.1.1 Syntax: Integer	Read only	Shows a unique value, greater than zero, for each interface. Valid values: 1 – 65536. It is recommended that values are assigned contiguously starting with 1. The value for each interface sub-layer must remain constant at least from one re-initialization of the entity's network management system to the next re-initialization.
snNetFlowIfFlowSwitching fdry.1.1.3.18.4.1.2 Syntax: Integer	Read-write	Indicates if flow switching in a particular interface is enabled: <ul style="list-style-type: none"> <li>disable(0)</li> <li>enable(1)</li> </ul>

## System Logging

The objects in this section manage system logging functions (Syslog) using SNMP. The objects are grouped in the following sections:

- “Global Objects” on page 20-14
- “Dynamic System Logging Buffer Table” on page 20-16
- “Static System Logging Buffer Table” on page 20-17

Refer to the *Foundry Switch and Router Installation and Basic Configuration Guide* and *Foundry ServerIron Installation and Configuration Guide* for additional information on Syslog.

## Global Objects

The objects below are for global system logging processes for all Foundry devices.

Name, OID, and Syntax	Access	Description																		
snAgSysLogGblEnable fdry.1.1.2.6.1.1 Syntax: Integer	Read-write	Enables or disables system logging. Set this object to one of the following values: <ul style="list-style-type: none"> <li>Disable(0)</li> <li>Enable(1)</li> </ul> Default: enable(1)																		
snAgSysLogGblBufferSize fdry.1.1.2.6.1.2 Syntax: Integer	Read-write	Sets the number of dynamic system logging entries. Valid values: Up to 100 entries. Default: 50 entries																		
snAgSysLogGblClear fdry.1.1.2.6.1.3 Syntax: Integer	Read-write	Clears the dynamic and static system log buffers. Set this object to one of the following values: <ul style="list-style-type: none"> <li>normal(0) – System logs will not be cleared</li> <li>clearAll(1) – Clears both dynamic and static system log buffers</li> <li>clearDynamic(2) – Clears only the dynamic system log</li> <li>clearStatic(3) – Clears only the static system log</li> </ul>																		
snAgSysLogGblCriticalLevel fdry.1.1.2.6.1.4 Syntax: Integer	Read-write	Filters and identifies the events that will be logged in the logging buffer. This object consists of 32 bits. The following shows the meaning of each bit: <table border="1" data-bbox="779 1134 1412 1680"> <thead> <tr> <th>Bit</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>8 to 31</td> <td>reserved</td> </tr> <tr> <td>7</td> <td>Warning (warning conditions)</td> </tr> <tr> <td>6</td> <td>Notification (normal but significant conditions)</td> </tr> <tr> <td>5</td> <td>Informational (informational messages)</td> </tr> <tr> <td>4</td> <td>Error (error conditions)</td> </tr> <tr> <td>2</td> <td>Debugging (debugging messages)</td> </tr> <tr> <td>1</td> <td>Critical (critical conditions). Setting this bit to 1 tells the logging buffer to accept the corresponding event.</td> </tr> <tr> <td>0</td> <td>Alert (immediate action needed). Setting this bit to 0 makes the logging buffer reject the corresponding event.</td> </tr> </tbody> </table> Default: 255	Bit	Meaning	8 to 31	reserved	7	Warning (warning conditions)	6	Notification (normal but significant conditions)	5	Informational (informational messages)	4	Error (error conditions)	2	Debugging (debugging messages)	1	Critical (critical conditions). Setting this bit to 1 tells the logging buffer to accept the corresponding event.	0	Alert (immediate action needed). Setting this bit to 0 makes the logging buffer reject the corresponding event.
Bit	Meaning																			
8 to 31	reserved																			
7	Warning (warning conditions)																			
6	Notification (normal but significant conditions)																			
5	Informational (informational messages)																			
4	Error (error conditions)																			
2	Debugging (debugging messages)																			
1	Critical (critical conditions). Setting this bit to 1 tells the logging buffer to accept the corresponding event.																			
0	Alert (immediate action needed). Setting this bit to 0 makes the logging buffer reject the corresponding event.																			
snAgSysLogGblLoggedCount fdry.1.1.2.6.1.5 Syntax: Counter	Read only	Shows the number events logged in the system logging buffer.																		

---

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snAgSysLogGblDroppedCount fdry.1.1.2.6.1.6 Syntax: Counter	Read only	Shows the number of events dropped from the system logging buffer.
snAgSysLogGblFlushedCount fdry.1.1.2.6.1.7 Syntax: Counter	Read only	Shows the number of times that the system logging buffer was cleared.
snAgSysLogGblOverrunCount fdry.1.1.2.6.1.8 Syntax: Counter	Read only	Shows the number of times that the system logging buffer has wrapped around.
snAgSysLogGblServer fdry.1.1.2.6.1.9 Syntax: IpAddress	Read-write	Shows the IP address of system log server.

---

Name, OID, and Syntax	Access	Description
snAgSysLogGblFacility fdry.1.1.2.6.1.10 Syntax: Integer	Read-write	Shows the facility code: <ul style="list-style-type: none"> <li>• kern(1)</li> <li>• user(2)</li> <li>• mail(3)</li> <li>• daemon(4)</li> <li>• auth(5)</li> <li>• syslog(6)</li> <li>• lpr(7)</li> <li>• news(8)</li> <li>• uucp(9)</li> <li>• sys9(10)</li> <li>• sys10(11)</li> <li>• sys11(12)</li> <li>• sys12(13)</li> <li>• sys13(14)</li> <li>• sys14(15)</li> <li>• cron(16)</li> <li>• local0(17)</li> <li>• local1(18)</li> <li>• local2(19)</li> <li>• local3(20)</li> <li>• local4(21)</li> <li>• local5(22)</li> <li>• local6(23)</li> <li>• local7(24)</li> </ul> Default: user(2)

### Dynamic System Logging Buffer Table

The following table applies to all Foundry devices. It contains the events logged in the Dynamic System Log. Events that are not logged in the Static System Log are logged in the Dynamic System Log.

Name, OID, and Syntax	Access	Description
snAgSysLogBufferTable fdry.1.1.2.6.2	None	Dynamic system logging buffer table.
snAgSysLogBufferEntry fdry.1.1.2.6.2.1	None	A row in the dynamic system logging buffer table.

Name, OID, and Syntax	Access	Description
snAgSysLogBufferIndex fdry.1.1.2.6.2.1.1 Syntax: Integer	Read only	Shows the index to the dynamic system logging buffer table.
snAgSysLogBufferTimeStamp fdry.1.1.2.6.2.1.2 Syntax: Time ticks	Read only	Shows the time stamp for when the event is logged.
snAgSysLogBufferCriticalLevel fdry.1.1.2.6.2.1.3 Syntax: Integer	Read only	Show how critical this event is: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• alert(2)</li> <li>• critical(3)</li> <li>• debugging(4)</li> <li>• emergency(5)</li> <li>• error(6)</li> <li>• informational(7)</li> <li>• notification(8)</li> <li>• warning(9)</li> </ul>
snAgSysLogBufferMessage fdry.1.1.2.6.2.1.4 Syntax: Display string	Read only	Displays the system logging message.
snAgSysLogBufferCalTimeStamp fdry.1.1.2.6.2.1.5 Syntax: Display string	Read only	Shows the time stamp when the event is logged. This object is used only if an external time source, such as an SNTP server, is configured. Otherwise, the value of this object is 0.  This object returns a NULL terminated time stamp string if the system calendar time was set. It returns a blank if the system calendar time was not set.

### Static System Logging Buffer Table

The following table applies to all Foundry devices. It contains the events logged in the Static System Log. The Static System Log receives power failures, fan failures, temperature warnings, or shutdown messages.

Name, OID, and Syntax	Access	Description
snAgStaticSysLogBufferTable fdry.1.1.2.6.3	None	Static system logging buffer table.
snAgStaticSysLogBufferEntry fdry.1.1.2.6.3.1	None	A row in the static system logging buffer table.

Name, OID, and Syntax	Access	Description
snAgStaticSysLogBufferIndex fdry.1.1.2.6.3.1.1 Syntax: Integer	Read only	The index to the static system logging buffer table.
snAgStaticSysLogBufferTimeSta mp fdry.1.1.2.6.3.1.2 Syntax: Time ticks	Read only	A time stamp, in number of time ticks, when the event is logged.
snAgStaticSysLogBufferCriticalLe vel fdry.1.1.2.6.3.1.3 Syntax: Integer	Read only	The critical level of this event: <ul style="list-style-type: none"> <li>• alert(2)</li> <li>• critical(3)</li> <li>• debugging(4)</li> <li>• emergency(5)</li> <li>• error(6)</li> <li>• informational(7)</li> <li>• notification(8)</li> <li>• warning(9)</li> </ul>
snAgStaticSysLogBufferMessage fdry.1.1.2.6.3.1.4 Syntax: Display string	Read only	The system logging message.
snAgStaticSysLogBufferCalTime Stamp fdry.1.1.2.6.3.1.5 Syntax: Display string	Read only	A time stamp when the event is logged. This object is used only if an external time source, such as an SNTP server, is configured. Otherwise, the value of this object is 0.  If an SNTP server is used to maintain time, then this object adds the value of the object "snAgStaticSysLogBufferTimeStamp" to the SNTP base to calculate the absolute time.  This object returns a NULL terminated time stamp string if the system calendar time was set. It returns a blank if the system calendar time was not set.

### System Log Server Table

The System Log (Syslog) Server Table shows which servers will receive Syslog messages. Every server in this table will receive all Syslog messages.

Name, OID, and Syntax	Access	Description
snAgSysLogServerTable fdry.1.1.2.6.4	None	System Log Server Table



Name, OID, and Syntax	Access	Description
snAgSysLogServerEntry fdry.1.1.2.6.4.1	None	A row in the System Log Server Table
snAgSysLogServerIP fdry.1.1.2.6.4.1.1 Syntax: IpAddress	Read-write	IP address of System Log server
snAgSysLogServerUDPPort fdry.1.1.2.6.4.1.2 Syntax: Integer	Read-write	UDP port number of the Syslog server. Valid values: 0 – 65535
snAgSysLogServerRowStatus fdry.1.1.2.6.4.1.3 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>other(1) – Other</li> <li>valid(2) – Row exists and is valid</li> </ul>

## CAM Statistics

The following tables present statistics for the CAM:

- “System Log Server Table”
- “IP CAM Statistics Table” on page 20-19

These tables were introduced in Service Provider Release 09.1.02 and Enterprise IronWare Release 07.8.00.

### IP CAM Statistics Table

This table lists the CAM statistics for Layer 3. It is equivalent to the **show cam ip <portnum> [<ip-addr> <ip-mask> | stat]** CLI command.

Name, Identifier, and Syntax	Access	Description
snCAMIpStatTable fdry.1.1.2.12.2	NA	IP CAM Statistics Table
snCAMIpStatEntry fdry.1.1.2.12.2.1	NA	An entry in the IP CAM Statistics Table. Each row shows statistics for one interface and level.
snCAMIpStatIfIndex fdry.1.1.2.12.2.1.1 Syntax: Unsigned32	Read only	The ifIndex value of the local interface.

Name, Identifier, and Syntax	Access	Description
snCAMIpStatLevel fdry.1.1.2.12.2.1.2 Syntax: Unsigned32	Read only	Level of CAM entry for that interface.
snCAMIpStatFreeEntries fdry.1.1.2.12.2.1.3 Syntax: Unsigned32	Read only	Free entries in the IP CAM for that interface and level.
snCAMIpStatTotalEntries fdry.1.1.2.12.2.1.4 Syntax: Unsigned32	Read only	Total entries in the IP CAM for that interface and level.

### CAM Statistics Table

This table shows CAM statistics for all master DMAs. It is equivalent to the **dm cam stat <dma master num>** CLI command.

Name, Identifier, and Syntax	Access	Description
snCAMStatTable fdry.1.1.2.12.3	NA	CAM Statistics Table
snCAMStatEntry fdry.1.1.2.12.3.1	NA	A row representing CAM statistics for a given DMA ID number.
snCamStatDMAIdNumber fdry.1.1.2.12.3.1.1 Syntax: Unsigned32	Read only	DMA ID number.
snCamStatDMAMasterNumber fdry.1.1.2.12.3.1.2 Syntax: Unsigned32	Read only	DMA master for the DMA ID number.
snCamStatFreePool0Entries fdry.1.1.2.12.3.1.3 Syntax: Unsigned32	Read only	CAM free pool0 entries.
snCamStatFreePool1Entries fdry.1.1.2.12.3.1.4 Syntax: Unsigned32	Read only	CAM free pool1 entries.
snCamStatFreePool2Entries fdry.1.1.2.12.3.1.5 Syntax: Unsigned32	Read only	CAM free pool2 entries.

<b>Name, Identifier, and Syntax</b>	<b>Access</b>	<b>Description</b>
snCamStatFreePool3Entries fdry.1.1.2.12.3.1.6 Syntax: Unsigned32	Read only	CAM free pool3 entries.
snCamStatFreeL2Entries fdry.1.1.2.12.3.1.7 Syntax: Unsigned32	Read only	CAM Free L2 entries
snCamStatFreeL2LowestSection fdry.1.1.2.12.3.1.8 Syntax: Unsigned32	Read only	CAM Free L2 lowest section entries.
snCamStatHostLookupCount fdry.1.1.2.12.3.1.9 Syntax: Unsigned32	Read only	CAM host lookup count for router.
snCamStatRouteLookupCount fdry.1.1.2.12.3.1.10 Syntax: Unsigned32	Read only	CAM route lookup count for router.
snCamStatLevel1 fdry.1.1.2.12.3.1.11 Syntax: Unsigned32	Read only	CAM stat level1 entries for router.
snCamStatLevel2 fdry.1.1.2.12.3.1.12 Syntax: Unsigned32	Read only	CAM stat level2 entries for router.
snCamStatLevel3 fdry.1.1.2.12.3.1.13 Syntax: Unsigned32	Read only	CAM stat level3 entries for router.
snCamStatMacFailCount fdry.1.1.2.12.3.1.14 Syntax: Unsigned32	Read only	CAM MAC fail count.
snCamStatIPRouteFailCount fdry.1.1.2.12.3.1.15 Syntax: Counter	Read only	CAM IP route fail count.
snCamStatIPSessionFailCount fdry.1.1.2.12.3.1.16 Syntax: Counter	Read only	CAM IP session fail count.

<b>Name, Identifier, and Syntax</b>	<b>Access</b>	<b>Description</b>
snCamStatIPMCastFailCount fdry.1.1.2.12.3.1.17 Syntax: Counter	Read only	CAM IP multicast fail count.
snCamStatL2SessionFailCount fdry.1.1.2.12.3.1.18 Syntax: Counter	Read only	CAM L2 session fail count.
snCamStatAddMACCount fdry.1.1.2.12.3.1.19 Syntax: Counter	Read only	CAM add MAC count.
snCamStatAddVLANCount fdry.1.1.2.12.3.1.20 Syntax: Counter	Read only	CAM add VLAN count.
snCamStatAddIPHostCount fdry.1.1.2.12.3.1.21 Syntax: Counter	Read only	CAM add IP host count.
snCamStatAddIPRouteCount fdry.1.1.2.12.3.1.22 Syntax: Counter	Read only	CAM add IP route count.
snCamStatAddIPSessionCount fdry.1.1.2.12.3.1.23 Syntax: Counter	Read only	CAM add IP session count.
snCamStatAddIPMCastCount fdry.1.1.2.12.3.1.24 Syntax: Counter	Read only	CAM add IP multicast count.
snCamStatAddL2SessionCount fdry.1.1.2.12.3.1.25 Syntax: Counter	Read only	CAM add L2 session count.
snCamStatAddIPXCount fdry.1.1.2.12.3.1.26 Syntax: Counter	Read only	CAM add IPX count.
snCamStatDeleteDMACamCount fdry.1.1.2.12.3.1.27 Syntax: Counter	Read only	CAM delete DMA CAM count.

## System Process Utilization Table

This table lists CPU utilization and statistics for all CPU processes on the device. It is equivalent to the **show process cpu** CLI command, which displays routing statistics for major protocols.

This table was introduced in Service Provider Release 09.1.02 and Enterprise IronWare Release 07.8.00.

Name, Identifier, and Syntax	Access	Description
snCpuProcessTable fdry.1.1.2.11.2	NA	System Process Utilization Table
snCpuProcessEntry fdry.1.1.2.11.2.1	NA	A row in the System Process Utilization Table.
snCpuProcessName fdry.1.1.2.11.2.1.1 Syntax: Display string	Read only	Name of the process.
snCpuProcess5SecUtil fdry.1.1.2.11.2.1.2 Syntax: Gauge	Read only	Statistics collected during the last 5 seconds of process utilization. Divide this number by 100 to get the percentage utilization.
snCpuProcess1MinUtil fdry.1.1.2.11.2.1.3 Syntax: Gauge	Read only	Statistics collected during the last 1 minute of process utilization. Divide this number by 100 to get the percentage utilization.
snCpuProcess5MinUtil fdry.1.1.2.11.2.1.4 Syntax: Gauge	Read only	Statistics collected during the last 5 minutes of process utilization. Divide this number by 100 to get the percentage utilization.
snCpuProcess15MinUtil fdry.1.1.2.11.2.1.5 Syntax: Gauge	Read only	Statistics collected during the last 15 minutes of process utilization. Divide this number by 100 to get the percentage utilization.
snCpuProcessRuntime fdry.1.1.2.11.2.1.6 Syntax: Counter	Read only	Process runtime in milliseconds.

## Objects for Debugging

The following objects are for debugging. They are equivalent to the **debug** CLI command.

These objects were introduced in Service Provider Release 09.1.02 and Enterprise IronWare Release 07.8.00.

Name, Identifier, and Syntax	Access	Description
snAgSystemDebug fdry.1.1.2.12.5	NA	The System Debug group
snAgSystemDebugTotalIn fdry.1.1.2.12.5.1 Syntax: Unsigned32	Read only	Total incoming packet count. Sum of Buffer Manager and CPU read count.
snAgSystemDebugTotalOut fdry.1.1.2.12.5.2 Syntax: Unsigned32	Read only	Total outgoing packet count.
snAgSystemDebugCpuQueueRead fdry.1.1.2.12.5.3 Syntax: Unsigned32	Read only	CPU Queue read count.
snAgSystemDebugDRAMBuffer fdry.1.1.2.12.5.4 Syntax: Unsigned32	Read only	DRAM buffer count.
snAgSystemDebugBMBuffer fdry.1.1.2.12.5.5 Syntax: Unsigned32	Read only	BM buffer count.
snAgSystemDebugBMFreeBuffer fdry.1.1.2.12.5.6 Syntax: Unsigned32	Read only	Free BM buffer count.
snAgSystemDebugBMFreeBufferMgmt fdry.1.1.2.12.5.7 Syntax: Unsigned32	Read only	Free BM buffer management count.
snAgSystemDebugIpcGigLock fdry.1.1.2.12.5.8 Syntax: Unsigned32	Read only	IPC GIG lock count.
snAgSystemDebugDRAMGetError fdry.1.1.2.12.5.9 Syntax: Unsigned32	Read only	DRAM get error count.

Name, Identifier, and Syntax	Access	Description
snAgSystemDebugDRAMToBMC opyFail  fdry.1.1.2.12.5.10  Syntax: Unsigned32	Read only	DRAM to Buffer Manager copy fail count.

---





---

# Chapter 21

## Layer 4 Switch Group

This chapter presents objects in the Foundry MIB and are specific to Layer 4 to 7 functionality. These objects are presented in the following sections:

- “Session” on page 21-2
- “Server Load Balancing Traffic Information” on page 21-3)
- “Hot Standby” on page 21-5
- “Layer 4 Policies” on page 21-6
- “Health Checks” on page 21-9
- “Web Cache Server Objects” on page 21-9
- “Real Server Objects” on page 21-18
- “Virtual Server Objects” on page 21-26
- “Bind Table” on page 21-34
- “GSLB Site Remote ServerIron Configuration Table” on page 21-36
- “Monitor Groups” on page 21-37

For trap objects and object to enable traps specific to ServerIron, refer to the following sections:

- “Objects to Enable Layer 4 Traps” on page 23-8
- “Layer 4 Traps” on page 23-26

Refer to the ServerIron manuals for details on the features discussed in this section. ServerIron manuals are listed in the section “Related Publications” on page 1-1.

## Session

The following objects define TCP and UDP sessions in a ServerIron.

Name, OID, and Syntax	Access	Description
snL4MaxSessionLimit fdry.1.1.4.1.1 Syntax: Integer	Read-write	Specifies the maximum number of active sessions the ServerIron allows. An active session is an entry in the ServerIron session table. A UDP or TCP session that has become idle but has not yet timed out (according to the UDP or TCP age timer) is an active session in the table.  Valid values: Depends on the target system configuration, but cannot exceed 2000000  Default: Depends on the target system configuration
snL4TcpSynLimit fdry.1.1.4.1.2 Syntax: Integer	Read-write	Shows the maximum number of TCP SYN requests per second per real server that the ServerIron is allowed to send. A TCP SYN request is a packet that a client sends to request a TCP connection to the server. Limiting the number of TCP SYN requests that can be sent to the server each second protects the ServerIron from TCP SYN attacks.  Valid values: 1 – 65535  Default: 65535
snL4slbGlobalSDAType fdry.1.1.4.1.3 Syntax: Integer	Read-write	Shows the method the ServerIron uses to select a real server for client request: <ul style="list-style-type: none"> <li>leastconnection(1) – The ServerIron sends the request to the real server that currently has the fewest number of active connections with clients.</li> <li>roundrobin(2) – The ServerIron sends the request to each server in rotation, regardless of how many connections each server has.</li> <li>weighted(3) – The ServerIron uses the weights you assign to the real servers to select a real server. The weights are based on the number of entries the ServerIron has for each server in the sessions table.</li> </ul> Default: leastconnection(1)
snL4slbTotalConnections fdry.1.1.4.1.4 Syntax: Counter	Read only	Shows the total number of client connections on the ServerIron since its last reboot. A connection consists of two sessions: client-to-server session and server-to-client session.
snL4slbLimitExceeds fdry.1.1.4.1.5 Syntax: Integer	Read only	Shows the number of times the TCP SYN requests from clients exceeded the configured “snL4TcpSynLimit” value.
snL4FreeSessionCount fdry.1.1.4.1.13 Syntax: Integer	Read only	Shows the number of sessions that are still available for use. This number is the maximum number of sessions configured, minus the number of active sessions.

Name, OID, and Syntax	Access	Description
snL4TcpAge fdry.1.1.4.1.28 Syntax: Integer	Read-write	<p>Specifies how many minutes a TCP server connection can remain inactive before the session times out and the ServerIron disconnects the session.</p> <p>Changing the value of this object affects only the new TCP sessions that are opened after the change is made. Current sessions will use the maximum age that was specified before the change occurred.</p> <p>This object globally sets the age for all TCP ports. To override this value for a port, specify the age locally on the individual port using the device's CLI.</p> <p>Valid values: 2 – 60 minutes</p> <p>Default value: 30 minutes</p>
snL4UdpAge fdry.1.1.4.1.29 Syntax: Integer	Read-write	<p>Specifies how many minutes a UDP server connection can remain inactive before the session times out and the ServerIron closes the session.</p> <p>Changing the value of this object affects only the new UDP sessions that are opened after the change is made. Current sessions will use the maximum age that was specified before the change occurred.</p> <p>This object globally sets the age for all TCP ports. To override this value for a port, specify the age locally on the individual port using the device's CLI.</p> <p>Valid values: 2 – 60 minutes</p> <p>Default: 5 minutes</p>

## Server Load Balancing Traffic Information

Server Load Balancing (SLB) is based on associations between real servers and virtual servers. The real servers are your application servers. The virtual servers have one or more virtual IP addresses (VIPs). You associate a real server with a virtual server by binding TCP/UDP ports on the real servers with TCP/UDP ports on the virtual server. When a client sends a TCP/UDP request for a port on the virtual server, the ServerIron sends the client's request to the real server.

The following objects provide information on the SLB traffic packets that were transmitted between the server and the clients.

Name, OID, and Syntax	Access	Description
snL4slbForwardTraffic fdry.1.1.4.1.6 Syntax: Counter	Read only	Shows the number of packets sent by clients to the server.
snL4slbReverseTraffic fdry.1.1.4.1.7 Syntax: Counter	Read only	Shows the number of packets sent by servers to clients. Generally, this value is 0 unless the client is using FTP or another application that causes the server to initiate connections.

Name, OID, and Syntax	Access	Description
snL4slbDrops fdry.1.1.4.1.8 Syntax: Integer	Read only	Shows the total number of packets dropped by the ServerIron. This statistic includes the following: <ul style="list-style-type: none"> <li>• TCP Resets – Resets sent by the ServerIron</li> <li>• Forward Resets – Resets from the client</li> <li>• Unsuccessful requests – Requests sent to a TCP or UDP port that is not bound to the request's destination VIP.</li> </ul>
snL4slbDangling fdry.1.1.4.1.9 Syntax: Integer	Read only	Shows the number of old types of connections. For use by Foundry technical support.
snL4slbDisableCount fdry.1.1.4.1.10 Syntax: Integer	Read only	Shows the number of packets the ServerIron dropped because they were sent by a client to a VIP port that is bound to a disabled real server port.
snL4slbAged fdry.1.1.4.1.11 Syntax: Integer	Read only	Shows the total number of TCP and UDP sessions that have been aged out and closed. A session ages out when the age timer configured on the ServerIron expires.
snL4slbFinished fdry.1.1.4.1.12 Syntax: Integer	Read only	The total number of TCP connections that are either in the FIN or RST state.
snL4unsuccessfulConn fdry.1.1.4.1.25 Syntax: Integer	Read only	Shows the number of packets that were dropped due to one of the following reasons: <ul style="list-style-type: none"> <li>• A deny filter configured on the switch matched the packet, causing the switch to drop the packet.</li> <li>• A client requested a TCP or UDP port that is not bound on the VI.</li> </ul>

## Hot Standby

Hot standby redundancy is a backup feature that allows a Foundry ServerIron to serve as an automatic backup for another ServerIron. Each hot-standby pair consists of two ServerIrons. One ServerIron serves as the primary or active ServerIron, and the other serves as the secondary or standby ServerIron. The standby ServerIron becomes active only if the primary ServerIron fails due to loss of power or loss of data path. The active and standby ServerIrons must have the same SLB or TCS configuration and share the same virtual MAC address. The shared MAC address can be selected from the available pool on either the active ServerIron or the standby ServerIron.

For more information on the Hot standby feature, refer to the *Foundry ServerIron Installation and Configuration Guide*.

The following objects apply to the Hot standby redundancy feature.

Name, OID, and Syntax	Access	Description
snL4BackupInterface fdry.1.1.4.1.14 Syntax: Integer	Read-write	Identifies which port is the hot standby port. This is the port that serves as a private link between the active and the redundant ServerIrons. The ServerIrons use this port to monitor any failover and to communicate those events to the standby.  Valid values: 0 – 26
snL4BackupMacAddr fdry.1.1.4.1.15 Syntax: Physical address	Read-write	Identifies the associated MAC address for the backup monitoring port. The active and backup ServerIron must have the same MAC address.
snL4Active fdry.1.1.4.1.16 Syntax: L4flag	Read only	The “snL4Redundancy” object and this object are the same.  Indicates if this ServerIron has been configured as redundant or hot standby: <ul style="list-style-type: none"> <li>false(0) – This ServerIron is the active one.</li> <li>true(1) – This ServerIron is the standby.</li> </ul>
snL4Redundancy fdry.1.1.4.1.17 Syntax: Integer	Read only	The “snL4Active” object and this object are the same.  Indicates if this ServerIron has been configured as redundant or hot standby: <ul style="list-style-type: none"> <li>false(0) – This ServerIron is the active one.</li> <li>true(1) – This ServerIron is the standby.</li> </ul>
snL4Backup fdry.1.1.4.1.18 Syntax: L4flag	Read only	Indicates if the ServerIron is the backup (standby) ServerIron: <ul style="list-style-type: none"> <li>false(0) – This ServerIron is the active one.</li> <li>true(1) – This ServerIron is the standby.</li> </ul>
snL4BecomeActive fdry.1.1.4.1.19 Syntax: Integer	Read only	Shows the number of times this ServerIron has changed from standby to active.
snL4BecomeStandBy fdry.1.1.4.1.20 Syntax: Integer	Read only	Shows the number of times this ServerIron has changed from active to standby.

Name, OID, and Syntax	Access	Description
snL4BackupState fdry.1.1.4.1.21 Syntax: Integer	Read only	Shows the state of the backup or redundancy link of the active or standby ServerIron: <ul style="list-style-type: none"> <li>slbSyncComplete(0) – Synchronization is complete.</li> <li>slbSyncReqMap(1) – Port map has been synchronized.</li> <li>slbSyncreqMac(2) – MAC addresses have been synchronized.</li> <li>slbSyncreqServers(3) – Server information has been synchronized.</li> <li>slbSyncReqL4(4) – L4 packets have been synchronized.</li> </ul>
snL4NoPDUSent fdry.1.1.4.1.22 Syntax: Integer	Read only	This object has been deprecated and is not supported.
snL4NoPDUCount fdry.1.1.4.1.23 Syntax: Integer	Read only	The number of missed Layer 4 or MAC-layer PDUs.
snL4NoPortMap fdry.1.1.4.1.24 Syntax: Integer	Read only	Shows the number of missed port map PDUs, which are PDUs used by ServerIron to discover information about the maps on the other ServerIron.

## Layer 4 Policies

This section presents the objects associated with Layer 4 policies. It contains the following tables:

- “Layer 4 Policy Table” on page 21-6
- “Layer 4 Policy Port Access Table” on page 21-8

### Layer 4 Policy Table

The Layer 4 Policy table allows you to configure Layer 4 policies and specify the ports to which they will be applied.

Name, OID, and Syntax	Access	Description
snL4PolicyTable fdry.1.1.4.11.1	None	The Layer 4 Policy Table.
snL4PolicyEntry fdry.1.1.4.11.1.1	None	An entry in the Layer 4 Policy Table.

Name, OID, and Syntax	Access	Description
snL4PolicyId fdry.1.1.4.11.1.1.1 Syntax: Integer	Read only	Specifies the ID of the policy. Valid values: 1 – 64
snL4PolicyPriority fdry.1.1.4.11.1.1.2 Syntax: Integer	Read-write	Shows the priority of the policy in the ServerIron: Standalone stackable ServerIrons have the following priorities: <ul style="list-style-type: none"> <li>normal(0) – normal priority</li> <li>high(1) – high priority</li> <li>cache(2) – priority for cache</li> <li>transparent(3) – priority for transparent</li> </ul> Non-stackable ServerIron Layer 4 priority values are: <ul style="list-style-type: none"> <li>level0(0)</li> <li>level1(1)</li> <li>level2(2)</li> <li>level3(3)</li> <li>level4(4)</li> <li>level5(5)</li> <li>level6(6)</li> <li>level7(7)</li> </ul>
snL4PolicyScope fdry.1.1.4.11.1.1.3 Syntax: Integer	Read-write	Indicates if the policy applies to one or all ports: <ul style="list-style-type: none"> <li>global(0) – Applies to all ports.</li> <li>local(1) – Applies to one port.</li> </ul>
snL4PolicyProtocol fdry.1.1.4.11.1.1.4 Syntax: Integer	Read-write	Indicates if the policy is for a UDP or TCP protocol: <ul style="list-style-type: none"> <li>udp(0)</li> <li>tcp(1)</li> </ul>
snL4PolicyPort fdry.1.1.4.11.1.1.5 Syntax: Integer	Read-write	Indicates the TCP or UDP port number to which this policy will be applied. Valid values: 1 – 65535

Name, OID, and Syntax	Access	Description
snL4PolicyRowStatus fdry.1.1.4.11.1.1.6 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

### Layer 4 Policy Port Access Table

The Layer 4 Policy Port Access table lists all access policy entries. These access policies are applied to IP interfaces (ports) that have Layer 4 IP policies configured on them. IP policies are described in the "snL4PolicyTable".

Name, OID, and Syntax	Access	Description
snL4PolicyPortAccessTable fdry.1.1.4.12.1	None	The IP Layer 4 Policy Interface (Port) Access Table.
snL4PolicyPortAccessEntry fdry.1.1.4.12.1.1	None	An entry in the table.
snL4PolicyPortAccessPort fdry.1.1.4.12.1.1.1 Syntax: Integer	Read only	The IP interface (port) to which the Layer 4 policy applies.
snL4PolicyPortAccessList fdry.1.1.4.12.1.1.2 Syntax: Octet string	Read-write	<p>This list consists of the policies configured in "snL4PolicyTable". Each octet in the list contains a valid ID number ("snL4PolicyId") that identifies a policy in the snL4PolicyTable. That policy must have been created prior to the using this object.</p> <p>Valid values: 1 – 64 octets</p>



Name, OID, and Syntax	Access	Description
snL4PolicyPortAccessRowStatus fdry.1.1.4.12.1.1.3 Syntax: Integer	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## Health Checks

The following are objects to check on the health of of a server. The ServerIron automatically uses a Layer 3 ping to check a server's health. Ping is enabled by default and cannot be disabled.

snL4PingInterval fdry.1.1.4.1.26 Syntax: Integer	Read-write	<p>Shows how often the ServerIron sends a Layer 3 IP ping to test the basic health and reachability of the real servers. This object allows you to change the interval between the ping packets.</p> <p>Valid values: 1 – 10 seconds</p> <p>Default: 2 seconds</p>
snL4PingRetry fdry.1.1.4.1.27 Syntax: Integer	Read-write	<p>Shows the number of times the ServerIron resends a ping to a real server that is not responding before the server fails the health check.</p> <p>Valid values: 2 – 10 tries</p> <p>Default: 4 tries</p>

## Web Cache Server Objects

Transparent Cache Switching (TCS) allows a ServerIron or Foundry backbone switch to detect and switch Web traffic to a local cache server within the network. Cache servers process Web queries faster and more efficiently by temporarily storing details about repetitive Web queries locally, reducing the number of external inquiries required to process a Web query. By limiting the number of queries sent to remote Web servers, the overall WAN access capacity required is lessened as is the overall operating cost for WAN access.

A single ServerIron (or hot standby pair) can provide transparent cache switching for up to 1024 Web cache servers. (A Web cache server must be a real server.) Foundry switches increase the reliability of transparent caching within a network by supporting redundant Web cache server configurations known as Web cache server groups, as well as supporting redundant paths to those server groups with the server backup option.

This section contains the following objects that are associated with Web cache servers:

- “Server Cache Groups” on page 21-10
- “Web Cache Group Table” on page 21-11

- “Web Cache Table” on page 21-12
- “Web Cache Real Server Port Table” on page 21-14
- “Web Cache Traffic Statistics Table” on page 21-15
- “Web Uncached Traffic Statistics Table” on page 21-17

## Server Cache Groups

All cache servers must belong to a cache group. The ServerIron uses a hashing algorithm to distribute HTTP requests among the servers in the cache group. In addition, cache groups provide automatic recovery from a failed or otherwise out-of-service Web cache server. If a Web cache server failure occurs, the ServerIron detects the failure and directs subsequent requests to the next available cache server or forwards the request directly to the WAN link. Up to four server cache groups can be assigned to a ServerIron.

Name, OID, and Syntax	Access	Description
snL4MaxNumWebCacheGroup fdry.1.1.4.1.40 Syntax: Integer	Read only	Shows the maximum number of Web cache groups that can be configured on this ServerIron.
snL4MaxNumWebCachePerGroup fdry.1.1.4.1.41 Syntax: Integer	Read only	Shows the maximum number of Web cache servers that a Web cache group can have.
snL4WebCacheStateful fdry.1.1.4.1.42 Syntax: Integer	Read-write	This object has been deprecated and is no longer supported.
snL4slbRouterInterfacePortMask fdry.1.1.4.1.39 Syntax: Integer	Read only	Shows the router interface port mask.  This object is not used or supported.
snL4slbRouterInterfacePortList fdry.1.1.4.1.51 Syntax: Octet string	Read-write	Shows Router interface port list. Each port index is a 16-bit integer in big endian order. The first 8-bit is the slot number, the other 8-bit is the port number.

## Web Cache Group Table

Web Cache Group table lists the configured group of Web cache servers on the ServerIron. The ServerIron uses a hashing algorithm to distribute the incoming HTTP requests among the servers in the cache group. In addition, cache groups provide automatic recovery from a failed or out-of-service Web cache server. If a Web cache server failure occurs, the ServerIron detects the failure and directs subsequent requests to the next available Web cache server or forwards the request directly to the WAN link. The “snL4MaxNumWebCachePerGroup” object defines the maximum number of Web cache servers that can be configured in a group. The “snL4MaxNumWebCacheGroup” defines the maximum number of cache groups that can be configured on a Web cache server.

Name, OID, and Syntax	Access	Description
snL4WebCacheGroupTable fdry.1.1.4.15.1	None	Web Cache Group table.
snL4WebCacheGroupEntry fdry.1.1.4.15.1.1	None	An entry in the Web Cache Group table.
snL4WebCacheGroupId fdry.1.1.4.15.1.1.1 Syntax: Integer	Read only	Shows the ID of an entry in the Web cache group entry.  Valid values: 1 – value of the “snL4MaxNumWebCacheGroup” object.
snL4WebCacheGroupName fdry.1.1.4.15.1.1.2 Syntax: L4ServerName	Read-write	Shows the name of the Web cache group. This name must be unique among the Web cache group names.  Valid values: 1 – 32 octets.
snL4WebCacheGroupWebCacheIpList fdry.1.1.4.15.1.1.3 Syntax: Octet string	Read-write	Contains a list of IP addresses of the Web cache servers in the group.  Valid values: The maximum of IP addresses that a group can contain is equal to the value of the “snL4MaxNumWebCachePerGroup” object. Each IP address contains up to four octets.
snL4WebCacheGroupDestMask fdry.1.1.4.15.1.1.4 Syntax: IpAddress	Read-write	Shows the destination hash-mask for the Web cache group. The ServerIron uses the destination hash-mask (this object) and the source hash-mask (“snL4WebCacheGroupSrcMask”) to forward the requests to the Web cache servers. This method ensures that a particular Web site is always cached on the same Web cache server to minimize duplication of content on the Web cache servers.  Default: 255.255.255.0
snL4WebCacheGroupSrcMask fdry.1.1.4.15.1.1.5 Syntax: IpAddress	Read-write	Specifies the source hash-mask for the Web cache group  The ServerIron uses the destination hash-mask (this object) and the source hash-mask (“snL4WebCacheGroupSrcMask”) to forward the requests to the Web cache servers. This method ensures that a particular Web site is always cached on the same Web cache server to minimize duplication of content on the Web cache servers.  Default: 0.0.0.0

Name, OID, and Syntax	Access	Description
snL4WebCacheGroupAdminStatus fdry.1.1.4.15.1.1.6 Syntax: Integer	Read-write	Indicates if the Web cache group feature is enabled. <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4WebCacheGroupRowStatus fdry.1.1.4.15.1.1.7 Syntax: L4RowStatus	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## Web Cache Table

A Web cache server is an application server which is load-balanced by the Server Load Balancing (SLB) switch. The following table contains the configuration of the Web cache servers in the network.

Name, OID, and Syntax	Access	Description
snL4WebCacheTable fdry.1.1.4.14.1	None	The Web Cache Table.
snL4WebCacheEntry fdry.1.1.4.14.1.1	None	An entry in the Web Cache Table.
snL4WebCacheIP fdry.1.1.4.14.1.1.1 Syntax: IpAddress	Read only	Indicates the IP address of the real server that is serving as the Web cache server.
snL4WebCacheName fdry.1.1.4.14.1.1.2 Syntax: L4ServerName	Read-write	Name of the real server that is serving as the Web cache server. This name must be unique among other Web cache server names.  Valid values: 1 – 32 octets

Name, OID, and Syntax	Access	Description
snL4WebCacheAdminStatus fdry.1.1.4.14.1.1.3 Syntax: L4Status	Read-write	<p>Indicates if the TCS feature is enabled in the real server that is serving as the Web cache server:</p> <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1) – When TCS is enabled, the feature detects HTTP traffic addressed for output to the Internet and redirects the traffic to the CPU. The CPU processes the traffic and forwards it to the cache servers instead.</li> </ul> <p><b>NOTE:</b> You cannot enable TCS on both a global (switch) and local (interface) basis.</p>
snL4WebCacheMaxConnections fdry.1.1.4.14.1.1.4 Syntax: Integer	Read-write	<p>The maximum number of connections the ServerIron can maintain in its session table for a Web cache server. When a Web cache server reaches this threshold, an SNMP trap is sent. When all the real servers in a server pool reach this threshold, additional TCP or UDP packets are dropped, and an ICMP destination unreachable message is sent.</p> <p>Valid values: 0 – 1000000 Default: 1000000</p>
snL4WebCacheWeight fdry.1.1.4.14.1.1.5 Syntax: Integer	Read-write	<p>Shows the Web cache server's least-connections weight. This parameter specifies the server's weight relative to other Web cache servers in terms of the number of connections on the server. This weight is based on the number of session table entries the ServerIron has for TCP or UDP sessions with the real server. However, if a weight based on the server response time is desired, this must be disabled (set to 0).</p> <p>Valid values: 0 – 65535 Default: 1</p>
snL4WebCacheRowStatus fdry.1.1.4.14.1.1.6 Syntax: L4Status	Read-write	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snL4WebCacheDeleteState fdry.1.1.4.14.1.1.7 Syntax: L4DeleteState	Read only	<p>Shows the state of the port being deleted:</p> <ul style="list-style-type: none"> <li>done(0) – The port is deleted</li> <li>waitunbind(1) – The port is in an unbind state</li> <li>waitdelete(2) – The port is in a delete state</li> </ul>

## Web Cache Real Server Port Table

The Web Cache Real Server Port Table consists of all the ports configured for the real server. Most attributes are configured globally for the port. Some additional and overriding local attributes can be configured in this table.

Name, OID, and Syntax	Access	Description
snL4WebCachePortTable fdry.1.1.4.18.1	None	Web Cache Server Port Table.
snL4WebCachePortEntry fdry.1.1.4.18.1.1	None	An entry in the Real Server Port table.
snL4WebCachePortServerIp fdry.1.1.4.18.1.1.1 Syntax: IpAddress	Read only	Shows the IP address of the Web cache server.
snL4WebCachePortPort fdry.1.1.4.18.1.1.2 Syntax: Integer	Read only	Shows the port that the Web cache server uses to listen for connections:  Valid values: 0 – 65535
snL4WebCachePortAdminStatus fdry.1.1.4.18.1.1.3 Syntax: L4Status	Read-write	Indicates if the Web cache server port is enabled: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4WebCachePortRowStatus fdry.1.1.4.18.1.1.4 Syntax: L4RowStatus	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snL4WebCachePortDeleteState fdry.1.1.4.18.1.1.5 Syntax: L4DeleteState	Read only	Shows the state of the port being deleted: <ul style="list-style-type: none"> <li>done(0) – The port is deleted.</li> <li>waitunbind(1) – The port is in an unbind state</li> <li>waitdelete(2) – The port is in a delete state</li> </ul>

## Web Cache Traffic Statistics Table

The Web Cache Traffic Statistics table contains traffic statistics for the client requests that go to the Web cache server.

Name, OID, and Syntax	Access	Description
snL4WebCacheTrafficStatsTable fdry.1.1.4.16.1	None	Web Cache Traffic Statistics Table.
snL4WebCacheTrafficStatsEntry fdry.1.1.4.16.1.1	None	An entry in the Web Cache Traffic Statistics Table.
snL4WebCacheTrafficIcp fdry.1.1.4.16.1.1.1 Syntax: IpAddress	Read only	Shows the IP address of the Web cache server.
snL4WebCacheTrafficPort fdry.1.1.4.16.1.1.2 Syntax: Integer	Read only	Shows the port that the Web cache server uses to listen for connections. Valid values: 0 – 65535
snL4WebCacheCurrConnections fdry.1.1.4.16.1.1.3 Syntax: Integer	Read only	Shows the number of the active connections between the clients and the Web cache server.
snL4WebCacheTotalConnections fdry.1.1.4.16.1.1.4 Syntax: Integer	Read only	Shows the total number of connections between clients and the Web cache server.
snL4WebCacheTxPkts fdry.1.1.4.16.1.1.5 Syntax: Counter	Read only	Shows the number of packets that was sent from the client or the Web server to the Web cache server.
snL4WebCacheRxPkts fdry.1.1.4.16.1.1.6 Syntax: Counter	Read only	Shows the number of packets that was sent from the Web cache server to the client or Web server.
snL4WebCacheTxOctets fdry.1.1.4.16.1.1.7 Syntax: Counter	Read only	Shows the number of octets that was sent from the client or Web server to the Web cache server.
snL4WebCacheRxOctets fdry.1.1.4.16.1.1.8 Syntax: Counter	Read only	Shows the number of octets that was sent from the Web cache server to the client or Web server.

Name, OID, and Syntax	Access	Description
snL4WebCachePortState fdry.1.1.4.16.1.1.9 Syntax: WebCacheState	Read only	<p>Shows the operational state of the server port:</p> <ul style="list-style-type: none"> <li>• disabled(0) – This state has been deprecated.</li> <li>• enabled(1) – The server is ready. There is no physical link to the Web cache server. The Web cache server is configured on the ServerIron but is not physically connected to the ServerIron.</li> <li>• failed(2) – The server failed. The Web cache server has failed to respond to repeated Layer 3 health checks (IP pings) Typically, a real server changes from the suspect(4) state to the failed(2) state.</li> <li>• testing(3) – The Web cache server is in testing mode. It is still reachable at Layer 3, but at least one of its application ports has failed to respond to its health checks. If the application port is not a TCP or UDP port known to the ServerIron, or if the Layer 7 health check for the port is disabled, only the Layer 4 health check is used. If the service is a TCP or UDP port known to the ServerIron and the Layer 7 health check is enabled, then the application must pass both health checks to avoid entering the testing(3) state.  The ServerIron continues to try to reach the application indefinitely. Thus, if the server continues to be reachable at Layer 3, the state will remain in the testing(3) state as long as the ServerIron cannot reach the application that is failing its health check.</li> <li>• suspect(4) – The Web cache server is responding slowly. The ServerIron associates a time stamp with each packet sent to and received from the Web cache servers. If the time gap between the last packet received from the server and the last packet sent to the server increases to three or four seconds, the ServerIron sends a ping (Layer 3 health check) to the server. If the server does not respond within the ping interval (configured in the “snL4PingInterval” object), the ServerIron changes the state to suspect(4) and resends the ping. The ping will be sent up to the number of retries specified by the ping retries parameter (configured in the “snL4PingRetry” object). If the server still does not respond after all the retries, the state changes to failed(2). If the server does respond, the state changes to active(6).</li> <li>• shutdown(5) – The Web cache server has been forced to shutdown. This option is used to gracefully shut down the Web cache server.</li> <li>• active(6) – The Web cache server responded to the Layer 3 health check (IP ping), and all the services on the real server have passed their Layer 4, and if applicable, Layer 7) health checks.</li> </ul>



## Web Uncached Traffic Statistics Table

The Web Uncached Traffic Statistics table contains traffic statistics for the client requests that go directly to the Web server. Client requests are directed to the Web server when the Web cache server is not available.

Name, OID, and Syntax	Access	Description
snL4WebUncachedTrafficStatsTable fdry.1.1.4.17.1	None	Web Uncached Traffic Statistics Table.
snL4WebUncachedTrafficStatsEntry fdry.1.1.4.17.1.1	None	An entry in the Web Uncached Traffic Statistics Table.
snL4WebServerPort fdry.1.1.4.17.1.1.1 Syntax: Integer	Read only	Identifies the ServerIron port that is attached to the Web servers. This port is typically the port attached to the Border Access Point (BAP) router that goes to the rest of the network or to the Internet.
snL4WebClientPort fdry.1.1.4.17.1.1.2 Syntax: Integer	Read only	Identifies the SLB switch port or Web client port, which connects the client to the ServerIron.
snL4WebUncachedTxPkts fdry.1.1.4.17.1.1.3 Syntax: Counter	Read only	Shows the number of uncached packets that was sent from the client port to the Web server.
snL4WebUncachedRxPkts fdry.1.1.4.17.1.1.4 Syntax: Counter	Read only	Shows the number of uncached packets that was sent from the Web server to the client port.
snL4WebUncachedTxOctets fdry.1.1.4.17.1.1.5 Syntax: Counter	Read only	Shows the number of uncached octets that was sent from the client port to the Web server.
snL4WebUncachedRxOctets fdry.1.1.4.17.1.1.6 Syntax: Counter	Read only	Shows the number of uncached octets that was sent from the Web server to the client port.
snL4WebServerPortName fdry.1.1.4.17.1.1.7 Syntax: Display string	Read only	Shows the name of the Web server port. Valid values: Up to 16 characters.
snL4WebClientPortName fdry.1.1.4.17.1.1.8 Syntax: Display string	Read only	Shows the name of the Web client port. Valid values: Up to 16 characters.

## Real Server Objects

A real server is an application server which is load-balanced by the Server Load Balancing (SLB) switch.

---

**NOTE:** The following tables have been replaced:

- The Real Server Table (snL4RealServerTable) has been deprecated and replaced by the Real Server Configuration Table (snL4RealServerCfg). Refer to page 21-18.
- Real Server Port Table (snL4RealServerPortTable) has been replaced by the Real Server Port Configuration Table (snL4RealServerPortCfg). Refer to page 21-19.
- Real Server Status Table (snL4RealServerStatusTable) has been replaced by the Real Server Statistics Table (snL4RealServerStatistic). Refer to page 21-21.
- The Real Server Port Status Table (snL4RealServerPortStatusTable) has been replaced by the Real Server Statistics Table (“snL4RealServerPortStatisticTable”). Refer to page 21-23.

---

This section presents the following tables:

- “Real Server Configuration Table” on page 21-18
- “Real Server Port Configuration Table” on page 21-19
- “Real Server Statistics Table” on page 21-21
- “Real Server Port Statistic Table” on page 21-23

Additional tables for real servers are included in the section “Monitor Groups” on page 21-37. Those tables provide historical information on data samples for real servers and real server ports.

### Real Server Configuration Table

The Real Server Configuration table shows the configuration of real servers. A real server is an application server which is load-balanced by the SLB switch.

Name, OID, and Syntax	Access	Description
snL4RealServerCfgTable fdry.1.1.4.19.1	None	Real Server Configuration Table.
snL4RealServerCfgEntry fdry.1.1.4.19.1.1	None	An entry in the Real Server Configuration Table.
snL4RealServerCfgIP fdry.1.1.4.19.1.1.1 Syntax: IpAddress	Read only	Shows the IP address of the real server.
snL4RealServerCfgName fdry.1.1.4.19.1.1.2 Syntax: L4ServerName	Read-write	Shows the name of the real server. This name must be unique among the real server names. Valid values: 1– 32 octets
snL4RealServerCfgAdminStatus fdry.1.1.4.19.1.1.3 Syntax: L4Status	Read-write	Enables or disables the real server: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul>

Name, OID, and Syntax	Access	Description
snL4RealServerCfgMaxConnections fdry.1.1.4.19.1.1.4 Syntax: Integer	Read-write	Specifies the maximum number of connections the ServerIron can maintain in its session table for a real server. When a real server reaches this threshold, an SNMP trap is sent. When all the real servers in a server pool reach this threshold, additional TCP or UDP packets are dropped, and an ICMP destination unreachable message is sent.  Valid values: 0 – 1000000  Default: 1000000
snL4RealServerCfgWeight fdry.1.1.4.19.1.1.5 Syntax: Integer	Read-write	Specifies the server's weight relative to other real servers. This weight is based on the number of session table entries the ServerIron has for TCP or UDP sessions with the real server. Set this object to 0 to disable it if a weight based on the server response time is desired.  Valid values: 0 – 65000. Setting this object to 0 disables it.  Default: 1
snL4RealServerCfgRowStatus fdry.1.1.4.19.1.1.6 Syntax: L4RowStatus	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snL4RealServerCfgDeleteState fdry.1.1.4.19.1.1.7 Syntax: L4DeleteState	Read only	Shows the state of the port being deleted: <ul style="list-style-type: none"> <li>done(0) – The port is deleted.</li> <li>waitunbind(1) – The port is in an unbind state</li> <li>waitdelete(2) – The port is in a delete state</li> </ul>

### Real Server Port Configuration Table

Real Server Port table contains all the ports that have been configured for the real server. Beginning with IronWare TrafficWorks Switch software release 09.0.00S and later, this table also shows information for remote servers.

Most attributes are configured globally for the server's port. This table allows you to change individual port attributes and override global settings.

Name, OID, and Syntax	Access	Description
snL4RealServerPortCfgTable fdry.1.1.4.20.1	None	Real Server Port table.
snL4RealServerPortCfgEntry fdry.1.1.4.20.1.1	None	An entry in the Real Server Port Configuration table.
snL4RealServerPortCfgIP fdry.1.1.4.20.1.1.1 Syntax: IpAddress	Read only	Specifies the IP address for the server.
snL4RealServerPortCfgServerName fdry.1.1.4.20.1.1.2 Syntax: L4ServerName	Read only	Specifies the name of the server. This name must be unique among the other servers.  Valid values: 1 – 32 octets
snL4RealServerPortCfgPort fdry.1.1.4.20.1.1.3 Syntax: Integer	Read only	Specifies the port that the server port uses to listen for connections  Valid values: 0 – 65535
snL4RealServerPortCfgAdminStatus fdry.1.1.4.20.1.1.4 Syntax: L4Status	Read-write	Enables or disable the application port on the server: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4RealServerPortCfgRowStatus fdry.1.1.4.20.1.1.5 Syntax: L4RowStatus	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snL4RealServerPortCfgDeleteState fdry.1.1.4.20.1.1.6 Syntax: L4DeleteState	Read only	Shows the state of the port being deleted: <ul style="list-style-type: none"> <li>done(0) – The port is deleted.</li> <li>waitunbind(1) – The port is in an unbind state</li> <li>waitdelete(2) – The port is in a delete state</li> </ul>

Name, OID, and Syntax	Access	Description
snL4RealServerPortCfgMaxConnections fdry.1.1.4.20.1.1.7 Syntax: Integer	Read-write	Defines the maximum number of connections allowed per port. Enter a value up to 1000000.

## Real Server Statistics Table

Real Server Statistics table contains statistics for all real servers configured as SLB switches on the ServerIron

Name, OID, and Syntax	Access	Description
snL4RealServerStatisticTable fdry.1.1.4.23.1	None	The Real Server Statistic Table.
snL4RealServerStatisticEntry fdry.1.1.4.23.1.1	None	An entry in the Real Server Statistic Table.
snL4RealServerStatisticRealIP fdry.1.1.4.23.1.1.1 Syntax: IpAddress	Read only	Shows the IP address of the real server.
snL4RealServerStatisticName fdry.1.1.4.23.1.1.2 Syntax: L4ServerName	Read only	Shows the name of the real server.
snL4RealServerStatisticReceivePackets fdry.1.1.4.23.1.1.3 Syntax: Counter	Read only	Shows the number of packets the ServerIron has received from the real server.
snL4RealServerStatisticTransmitPackets fdry.1.1.4.23.1.1.4 Syntax: Counter	Read only	Shows the number of packets the ServerIron has sent to the real server.
snL4RealServerStatisticCurConnections fdry.1.1.4.23.1.1.5 Syntax: Integer	Read only	Shows the number of client connections currently on the real server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4RealServerStatisticTotalConnections fdry.1.1.4.23.1.1.6 Syntax: Counter	Read only	Shows the number of client connections on the real server since the last time the ServerIron was rebooted. A connection consists of two sessions: the client-to-server session and the server-to-client session.

Name, OID, and Syntax	Access	Description
snL4RealServerStatisticAge fdry.1.1.4.23.1.1.7 Syntax: Integer	Read only	Shows the total number of TCP and UDP sessions that the ServerIron closed because the connection aged out. A session ages out when the age timer configured on the ServerIron expires.
snL4RealServerStatisticState fdry.1.1.4.23.1.1.8 Syntax: Integer	Read only	<p>Shows the operational state of the real server when the statistics were obtained:</p> <ul style="list-style-type: none"> <li>• disabled(0) – This value has been deprecated and is not used.</li> <li>• enabled(1) – There is no link to the real server. The real server is configured on the ServerIron but is not physically connected to the ServerIron.</li> <li>• failed(2) – The server has failed to respond to repeated Layer 3 health checks (IP pings). Typically, a real server changes to the failed(2) state from the suspect(4) state.</li> <li>• testing(3) – The real server is still reachable at Layer 3, but at least one of the application ports on the real server has failed to respond to its health checks. If the application port is not a TCP or UDP port known to the ServerIron, or if the Layer 7 health check for the port is disabled, only the Layer 4 health check is used. If the service is a TCP or UDP port known to the ServerIron and the Layer 7 health check is enabled, then the application must pass both health checks to avoid entering the testing(3) state. The ServerIron continues to try to reach the application indefinitely. If the server continues to be reachable at Layer 3, the state will remain testing(3) as long as the ServerIron cannot reach the application that is failing its health check.</li> <li>• suspect(4) – The ServerIron associates a time stamp with each packet sent to and received from the real servers. If the time gap between the last packet received from the real server and the last packet sent to the real server increases to three or four seconds, the ServerIron sends a Layer 3 health check (ping) to the real server. If the real server does not respond within the ping interval (configured in the “snL4PingInterval” object), the ServerIron changes the state to suspect(4) and resends the ping, up to the number of retries specified by the “snL4PingRetry” object. If the server still doesn’t respond after all the retries, the state changes to failed(2). If the server does respond, the state changes to active(6).</li> <li>• shutdown(5) – The forced-shutdown option has been used to gracefully shut down the real server.</li> <li>• active(6) – The real server has responded to the Layer 3 health check (IP ping) and all the services on the real server have passed their Layer 4, and if applicable, Layer 7) health checks.</li> </ul>

Name, OID, and Syntax	Access	Description
snL4RealServerStatisticReassignments fdry.1.1.4.23.1.1.9 Syntax: Integer	Read only	Shows the number of times the ServerIron has reassigned the connection to another real server in the rotation because the real server that is in use has not responded to two TCP SYNs from the client.
snL4RealServerStatisticReassignmentLimit fdry.1.1.4.23.1.1.10 Syntax: Integer	Read only	Shows the number of missed connection requests (TCP SYN) the ServerIron accepts before moving the connection to another ServerIron.
snL4RealServerStatisticFailedPortExists fdry.1.1.4.23.1.1.11 Syntax: Integer	Read only	Shows the number of times a client request could not be fulfilled because the client requested a port that is not configured on the real server.
snL4RealServerStatisticFailTime fdry.1.1.4.23.1.1.12 Syntax: Integer	Read only	Show the number of seconds from the last retry attempt to connect to the real server. The object value is valid only if the real server's state is failed(2).
snL4RealServerStatisticPeakConnections fdry.1.1.4.23.1.1.13 Syntax: Integer	Read only	Shows the highest number of simultaneous client connections on the real server since the last time the ServerIron was rebooted. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4RealServerStatisticTotalReverseConnections fdry.1.1.4.23.1.1.14 Syntax: Integer	Read only	Shows the total number of connections to the client that was initiated by the real server.
snL4RealServerStatisticCurrentSessions fdry.1.1.4.23.1.1.15 Syntax: Integer	Read only	Shows the total number of open sessions on the ServerIron. A connection consists of two sessions: the client-to-server session and the server-to-client session.

### Real Server Port Statistic Table

Real Server Port Statistics contains statistics for all the ports configured for all the real servers. Beginning with IronWare TrafficWorks Switch software release 09.0.00S and later and 09.1.01R and later, this table also shows information for remote servers.

Name, OID, and Syntax	Access	Description
snL4RealServerPortStatisticTable fdry.1.1.4.24.1	None	Real Server Port Statistic table.
snL4RealServerPortStatisticEntry fdry.1.1.4.24.1.1	None	An entry in the Real Server Port Statistic table.

Name, OID, and Syntax	Access	Description
snL4RealServerPortStatisticIP fdry.1.1.4.24.1.1.1 Syntax: IpAddress	Read only	Shows the IP address of the server where the port is located.
snL4RealServerPortStatisticPort fdry.1.1.4.24.1.1.2 Syntax: Integer	Read only	The port number that the server uses to listen for connections.
snL4RealServerPortStatisticServerName fdry.1.1.4.24.1.1.3 Syntax: L4ServerName	Read only	Shows the name of the server.
snL4RealServerPortStatisticReassignCount fdry.1.1.4.24.1.1.4 Syntax: Integer	Read only	Shows the number of times the ServerIron has reassigned the connection to another server in the rotation because the server that is in use has not responded to two TCP SYNs from the client.



Name, OID, and Syntax	Access	Description
snL4RealServerPortStatisticState fdry.1.1.4.24.1.1.5 Syntax: Integer	Read only	<p>Shows the operational state of the server when the statistics were obtained:</p> <ul style="list-style-type: none"> <li>• disabled(0) – This value has been deprecated and is not used.</li> <li>• enabled(1) – There is no link to the server. The server is configured on the ServerIron but is not physically connected to the ServerIron.</li> <li>• failed(2) – The server has failed to respond to repeated Layer 3 health checks (IP pings). Typically, a server changes to the failed(2) state from the suspect(4) state.</li> <li>• testing(3) – The server is still reachable at Layer 3, but at least one of the application ports on the server has failed to respond to its health checks. If the application port is not a TCP or UDP port known to the ServerIron or if the Layer 7 health check for the port is disabled, only the Layer 4 health check is used. If the service is a TCP or UDP port known to the ServerIron and the Layer 7 health check is enabled, then the application must pass both health checks to avoid entering the testing(3) state. The ServerIron continues to try to reach the application indefinitely. If the server continues to be reachable at Layer 3, the state will remain testing(3) as long as the ServerIron cannot reach the application that is failing its health check.</li> <li>• suspect(4) – The ServerIron associates a time stamp with each packet sent to and received from the servers. If the time gap between the last packet received from the server and the last packet sent to the server increases to three or four seconds, the ServerIron sends a Layer 3 health check (ping) to the server. If the server does not respond within the ping interval (configured in the “snL4PingInterval” object) the ServerIron changes the state to suspect(4) and resends the ping, up to the number of retries specified by the “snL4PingRetry” object. If the server still doesn't respond after all the retries, the state changes to failed(2). If the server does respond, the state changes to active(6).</li> <li>• shutdown(5) – The forced-shutdown option has been used to gracefully shut down the server.</li> <li>• active(6) – The server has responded to the Layer 3 health check (IP ping), and all the services on the server have passed their Layer 4, and if applicable, Layer 7) health checks.</li> </ul>
snL4RealServerPortStatisticFailTime fdry.1.1.4.24.1.1.6 Syntax: Integer	Read only	<p>This object applies only ports whose operational state is failed(2).</p> <p>Shows the number of seconds that has elapsed since the last time the port tried to re-establish connection with the server.</p>

Name, OID, and Syntax	Access	Description
snL4RealServerPortStatisticCurrentConnection fdry.1.1.4.24.1.1.7 Syntax: Integer	Read only	Shows the number of client connections currently on the this port of the server. A connection consists of two sessions, the client-to-server session and the server-to-client session.
snL4RealServerPortStatisticTotalConnection fdry.1.1.4.24.1.1.8 Syntax: Counter	Read only	Shows the number of client connections on the server since the last time the ServerIron rebooted. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4RealServerPortStatisticRxPackets fdry.1.1.4.24.1.1.9 Syntax: Counter	Read only	Shows the number of packets that the ServerIron has received from the server.
snL4RealServerPortStatisticTxPackets fdry.1.1.4.24.1.1.10 Syntax: Counter	Read only	Shows the number of packets the ServerIron has sent to the server.
snL4RealServerPortStatisticRxBytes fdry.1.1.4.24.1.1.11 Syntax: Counter	Read only	Shows the number of bytes the ServerIron has received from the server.
snL4RealServerPortStatisticTxBytes fdry.1.1.4.24.1.1.12 Syntax: Counter	Read only	Shows the number of bytes the ServerIron has sent to the server.
snL4RealServerPortStatisticPeakConnection fdry.1.1.4.24.1.1.13 Syntax: Integer	Read only	Shows the highest number of simultaneous client connections on the server since the last time the ServerIron was rebooted. A connection consists of two sessions: the client-to-server session and the server-to-client session.

## Virtual Server Objects

The SLB switch serves as the front-end for real servers and load balances the real servers. To allow the SLB switches to perform this function, virtual servers should be configured on the ServerIron and must be bound to their related real servers. The virtual servers are visible to the clients while real servers are hidden by the virtual servers

This section presents the following tables for virtual servers:

- “Virtual Server Configuration Table” on page 21-27
- “Virtual Server Port Configuration Table” on page 21-29
- “Virtual Server Statistic Table” on page 21-31

**NOTE:** The following tables have been replaced:

- The Virtual Server Table (snL4VirtualServerTable) has been replaced by the Virtual Server Configuration Table (snL4VirtualServerCfg). Refer to page 21-27.
- The Virtual Server Port Table (snL4VirtualServerPortTable) has been replaced by the Virtual Server Port Configuration Table (snL4VirtualServerPortCfg). Refer to page 21-29.
- The Virtual Server Status Table (snL4VirtualServerStatusTable) has been replaced by the Virtual Server Statistics Table (snL4VirtualServerStatistic). Refer to page 21-31.
- The Virtual Server Port Status Table (snL4VirtualServerPortStatusTable) has been replaced by the Virtual Server Port Statistics Table (snL4VirtualServerPortStatisticTable). Refer to page 21-33.

Additional tables for virtual servers are included in the section “Monitor Groups” on page 21-37. Those tables provide historical information on data samples for virtual servers and virtual server ports.

## Virtual Server Configuration Table

The Virtual Server Configuration table allows you to configure virtual servers on the ServerIron.

Name, OID, and Syntax	Access	Description
snL4VirtualServerCfgTable fdry.1.1.4.21.1	None	The Virtual Server Configuration table.
snL4VirtualServerCfgEntry fdry.1.1.4.21.1.1	None	An entry in the Virtual Server Configuration table.
snL4VirtualServerCfgVirtualIP fdry.1.1.4.21.1.1.1 Syntax: IpAddress	Read only	Specifies the virtual server IP Address.
snL4VirtualServerCfgName fdry.1.1.4.21.1.1.2 Syntax: L4ServerName	Read-write	Specifies the name of the virtual server. This name must be unique among the other virtual servers.  Valid values: 1 – 32 octets
snL4VirtualServerCfgAdminStatus fdry.1.1.4.21.1.1.3 Syntax: L4Status	Read-write	Indicates if the virtual server feature is enabled on the ServerIron: <ul style="list-style-type: none"> <li>• disabled(0)</li> <li>• enabled(1)</li> </ul> Default: enabled(1)

Name, OID, and Syntax	Access	Description
<p>snL4VirtualServerCfgSDAType fdry.1.1.4.21.1.1.4 Syntax: Integer</p>	<p>Read-write</p>	<p>Specifies the load-balancing or Session Distribution Algorithm method that the ServerIron uses to select a real server for a client request. The following methods are supported:</p> <ul style="list-style-type: none"> <li>• default(0) – The ServerIron uses the global SDAType configured (snL4SibGlobalSDAType)</li> <li>• leastconnection(1) – The ServerIron sends the request to the real server that currently has the fewest active connections with clients.</li> <li>• roundrobin(2) – The ServerIron sends the request to each real server in rotation, regardless of how many connections or sessions each real server has.</li> <li>• weighted(3) – The ServerIron uses the weights you assign to the real servers to select a real servers. The weights are based on the number of session table entries the switch has for each server.</li> </ul> <p>Default: default(0)</p>
<p>snL4VirtualServerCfgRowStatus fdry.1.1.4.21.1.1.5 Syntax: L4RowStatus</p>	<p>Read-write</p>	<p>Controls the management of the table rows. The values that can be written are:</p> <ul style="list-style-type: none"> <li>• delete(3) – Delete the row</li> <li>• create(4) – Create a new row</li> <li>• modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>• noSuch(0) – No such row</li> <li>• invalid(1) – Row is inoperative</li> <li>• valid(2) – Row exists and is valid</li> </ul>
<p>snL4VirtualServerCfgDeleteState fdry.1.1.4.21.1.1.6 Syntax: L4DeleteState</p>	<p>Read only</p>	<p>Shows the state of the port being deleted:</p> <ul style="list-style-type: none"> <li>• done(0) – The port is deleted.</li> <li>• waitunbind(1) – The port is in an unbind state.</li> <li>• waitdelete(2) – The port is in a delete state.</li> </ul>

Name, OID, and Syntax	Access	Description
snL4VirtualServerCfgSymPriority fdry.1.1.4.21.1.1.7 Syntax: Integer	Read-write	<p>When a pair of SLB switches are configured to provide redundancy for individual virtual IP addresses (VIPs), an symmetric SLB priority must be specified on each switch for each of the VIPs. The switch with the higher priority for a given VIP is the default active switch for that VIP. The other switch is the default standby for the VIP.</p> <p>It is recommended that you use a priority of 2 (instead of 1) as a low priority or 254 (instead of 255) as a high priority. This method would make it easy to force a failover of the high priority switch to a low priority switch by simply changing the priority on one of the switches.</p> <p>For example, we can force a failover by changing the priority on the high priority switch from 254 to 1. Since the priority on the low priority switch is 2, the low priority switch takes over for the VIP. Likewise, we can force the low priority switch to take over by changing its priority to 255, since the priority on the high priority switch is only 254.</p> <p>Valid values: 0 – 255 Default: 0</p>

### Virtual Server Port Configuration Table

The Virtual Server Port Configuration Table contains all the ports configured for the virtual server. This table allows you to configure attributes for individual ports and override global attributes for those ports.

Name, OID, and Syntax	Access	Description
snL4VirtualServerPortCfgTable fdry.1.1.4.22.1	None	Virtual Server Port Configuration table.
snL4VirtualServerPortCfgEntry fdry.1.1.4.22.1.1	None	An entry in the Virtual Server Port Configuration table.
snL4VirtualServerPortCfgIP fdry.1.1.4.22.1.1.1 Syntax: IpAddress	Read only	Indicates the IP address of the virtual server where the port is located.
snL4VirtualServerPortCfgPort fdry.1.1.4.22.1.1.2 Syntax: Integer	Read only	<p>Specifies the port that the virtual server (SLB switch) uses to listen for connections from clients.</p> <p>Valid values: 0 – 65535</p>
snL4VirtualServerPortCfgServerName fdry.1.1.4.22.1.1.3 Syntax: L4ServerName	Read only	<p>Specifies the name of the virtual server. This name must be different from the names of other virtual servers.</p> <p>Valid values: 1 – 32 octets</p>

Name, OID, and Syntax	Access	Description
snL4VirtualServerPortCfgAdminS tatus fdry.1.1.4.22.1.1.4 Syntax: L4Status	Read- write	Enables or disables the port on the virtual server for accepting client requests and load balancing those request among the real servers. <ul style="list-style-type: none"> <li>• disable(0)</li> <li>• enable(1)</li> </ul> Default: enable(1)
snL4VirtualServerPortCfgSticky fdry.1.1.4.22.1.1.5 Syntax: L4Status	Read- write	Enables or disables the “sticky” feature. If enabled, the ServerIron sends all requests from the same client to this application and to the same real server during the current session. By default, the ServerIron sends a client request to the next available real server, based on the load balancing method. This is true regardless of whether the client has already sent a request for the same application. If the switch has to send all of a client requests for a given application to the same real server during a client session with the server, set this object to enable(1) for the application port. Set this object and the “snL4VirtualServerPortCfgConcurrent” object to enable(1), on ServerIron FTP ports that use passive FTP: <ul style="list-style-type: none"> <li>• disable(0)</li> <li>• enable(1)</li> </ul> Default: disable(0)
snL4VirtualServerPortCfgConcurr ent fdry.1.1.4.22.1.1.6 Syntax: L4Status	Read- write	Enables or disables the port for concurrent connections. A port that allows concurrent connections can have more than one connection open to the same client at the same time. The concurrent feature allows a client to have sessions on different application ports on the same real server at the same time. When an application port is enabled to be concurrent, the real server can open additional concurrent TCP or UDP sessions with the client using arbitrary TCP or UDP port numbers. Set this object and the “snL4VirtualServerPortCfgSticky” object to enable(1) on ServerIron FTP ports that use passive FTP: <ul style="list-style-type: none"> <li>• disable(0)</li> <li>• enable(1)</li> </ul> Default: disable(0)

Name, OID, and Syntax	Access	Description
snL4VirtualServerPortCfgRowStatus fdry.1.1.4.22.1.1.7 Syntax: L4RowStatus	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>
snL4VirtualServerPortCfgDeleteState fdry.1.1.4.22.1.1.8 Syntax: L4DeleteState	Read only	Shows the state of the port being deleted: <ul style="list-style-type: none"> <li>done(0) – The port is deleted.</li> <li>waitunbind(1) – The port is in an unbind state.</li> <li>waitdelete(2) – The port is in a delete state.</li> </ul>

### Virtual Server Statistic Table

Virtual Server Statistics table contains statistics for all the virtual servers configured in the ServerIron.

Name, OID, and Syntax	Access	Description
snL4VirtualServerStatisticTable fdry.1.1.4.25.1	None	The Virtual Server Statistic Table.
snL4VirtualServerStatisticEntry fdry.1.1.4.25.1.1	None	An entry in the Virtual Server Statistic Table.
snL4VirtualServerStatisticIP fdry.1.1.4.25.1.1.1 Syntax: IpAddress	Read only	Shows the IP address of the virtual server.
snL4VirtualServerStatisticName fdry.1.1.4.25.1.1.2 Syntax: L4ServerName	Read only	Shows the name of the virtual server.
snL4VirtualServerStatisticReceivePkts fdry.1.1.4.25.1.1.3 Syntax: Counter	Read only	Shows the number of packets the ServerIron has received from the real server.

Name, OID, and Syntax	Access	Description
snL4VirtualServerStatisticTransmitPkts fdry.1.1.4.25.1.1.4 Syntax: Counter	Read only	Shows the number of packets the ServerIron has sent to the real server.
snL4VirtualServerStatisticTotalConnections fdry.1.1.4.25.1.1.5 Syntax: Counter	Read only	Shows the number of client connections on the virtual server since the last time the ServerIron was booted. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4VirtualServerStatisticReceiveBytes fdry.1.1.4.25.1.1.6 Syntax: Counter64	Read only	The number of bytes the switch has received from the real server.
snL4VirtualServerStatisticTransmitBytes fdry.1.1.4.25.1.1.7 Syntax: Counter64	Read only	The number of bytes the switch has sent to the real server
snL4VirtualServerStatisticSymmetricState fdry.1.1.4.25.1.1.8 Syntax: Integer	Read only	Shows which ServerIron is the active one: <ul style="list-style-type: none"> <li>• other(3) – Not the active ServerIron</li> <li>• active(5) – Active ServerIron</li> </ul>
snL4VirtualServerStatisticSymmetricPriority fdry.1.1.4.25.1.1.9 Syntax: Integer	Read only	Shows the Symmetric SLB priority configured on the ServerIron.
snL4VirtualServerStatisticSymmetricKeep fdry.1.1.4.25.1.1.10 Syntax: Integer	Read only	This object is applicable only to the active ServerIrons.  Shows the number of times an SSLB backup has failed to communicate with the active ServerIron. By default, the counter is incremented by 1 every 400 milliseconds, if the backup switch is responding slowly to the active switch's keepalive message. The counter is reset to 0 each time the backup switch replies to a keepalive message. If the counter exceeds the maximum number allowed (20 by default, thus 8 seconds), the standby switch takes over as the new active switch. Normally, this field almost always contains 0.
snL4VirtualServerStatisticSymmetricActivates fdry.1.1.4.25.1.1.11 Syntax: Counter	Read only	The number of times this ServerIron has become the active switch.



Name, OID, and Syntax	Access	Description
snL4VirtualServerStatisticSymmetricInactives fdry.1.1.4.25.1.1.12 Syntax: Counter	Read only	Shows the number of times this ServerIron has changed from being the active switch to the backup switch.
snL4VirtualServerStatisticSymmetricBestStandbyMacAddr fdry.1.1.4.25.1.1.13 Syntax: Physical address	Read only	Shows the MAC address of the backup ServerIron with the second-highest priority. This ServerIron will become the active switch if a failover occurs.
snL4VirtualServerStatisticSymmetricActiveMacAddr fdry.1.1.4.25.1.1.14 Syntax: Physical address	Read only	Shows the MAC address of the active ServerIron with the highest priority. This ServerIron will become the backup switch if a failover occurs.

### Virtual Server Port Statistics Table

Virtual Server Port Statistics table contains statistics for all the ports configured for all the virtual servers.

Name, OID, and Syntax	Access	Description
snL4VirtualServerPortStatisticTable fdry.1.1.4.26.1	None	The Virtual Server Port Statistic table.
snL4VirtualServerPortStatisticEntry fdry.1.1.4.26.1.1	None	An entry in the Virtual Server Port Statistic table.
snL4VirtualServerPortStatisticIP fdry.1.1.4.26.1.1.1 Syntax: IpAddress	Read only	The IP address of the virtual server that the port is located.
snL4VirtualServerPortStatisticPort fdry.1.1.4.26.1.1.2 Syntax: Integer	Read only	Shows the ID of the port that the virtual server (SLB switch) uses to listen for connections.
snL4VirtualServerPortStatisticServerName fdry.1.1.4.26.1.1.3 Syntax: L4ServerName	Read only	Shows the name of the virtual server.
snL4VirtualServerPortStatisticCurrentConnection fdry.1.1.4.26.1.1.4 Syntax: Integer	Read only	Shows the number of client connections currently on the virtual server. A connection consists of two sessions: the client-to-server session and the server-to-client session.

Name, OID, and Syntax	Access	Description
snL4VirtualServerPortStatisticTotalConnection fdry.1.1.4.26.1.1.5 Syntax: Counter	Read only	The number of client connections on the virtual server since the last time the ServerIron was rebooted. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4VirtualServerPortStatisticPeakConnection fdry.1.1.4.26.1.1.6 Syntax: Integer	Read only	The highest number of connections the VIP has had at any time.

## Bind Table

Virtual servers must be bound to real servers. The Bind table contains information about the bindings between the virtual servers (external or front-end servers visible to clients) and real or application servers (servers that serve the client requests).

### L4 Bind Table

**NOTE:** This table has been deprecated. Use the snL4VirtualServerBindTable instead.

Name, OID, and Syntax	Access	Description
snL4BindTable fdry.1.1.4.6.1	None	The Bind table.
snL4BindEntry fdry.1.1.4.6.1.1	None	An entry in the Bind table.
snL4BindIndex fdry.1.1.4.6.1.1.1 Syntax: Integer	Read only	The index for this entry. This must be unique and care must be taken to assign an unused index when creating an entry.
snL4BindVirtualServerName fdry.1.1.4.6.1.1.2 Syntax: L4ServerName	Read-write	Indicates the name of the virtual server. Valid values: 1 – 32 octets
snL4BindVirtualPortNumber fdry.1.1.4.6.1.1.3 Syntax: Integer	Read-write	Specifies the TCP or UDP port number on the virtual server that will be bound to the real server. Valid values: 0 – 65535
snL4BindRealServerName fdry.1.1.4.6.1.1.4 Syntax: L4ServerName	Read-write	Indicates the name of the real server that has been configured on the ServerIron. Valid values: 1 – 32 octets

Name, OID, and Syntax	Access	Description
snL4BindRealPortNumber fdry.1.1.4.6.1.1.5 Syntax: Integer	Read-write	Specifies the TCP or UDP port number of the real server to which the virtual port is bound.  Valid values: 0 – 65535
snL4BindRowStatus fdry.1.1.4.6.1.1.6 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>delete(3) – Delete the row</li> <li>create(4) – Create a new row</li> <li>modify(5) – Modify an existing row</li> </ul> <p>If the row exists, then a SET with a value of create(4) returns a "bad value" error. Deleted rows are removed from the table immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>noSuch(0) – No such row</li> <li>invalid(1) – Row is inoperative</li> <li>valid(2) – Row exists and is valid</li> </ul>

## L4 Virtual Server Bind Table

This table replaces the snL4BindTable.

Name, OID, and Syntax	Access	Description
snL4VirtualServerBindTable fdry.1.1.4.6.2	N/A	The Virtual Server Bind Table.
snL4VirtualServerBindEntry fdry.1.1.4.6.2.1	N/A	An entry in the snL4VirtualServerBindTable.
snL4BindingRealServerIP fdry.1.1.4.6.2.1.1 Syntax: IpAddress	Read only	The IP address of the real server that will be bound to the virtual server.
snL4BindingRealServerPort fdry.1.1.4.6.2.1.2 Syntax: Integer	Read only	The port on the real server that will be bound to the virtual server.
snL4BindingRealServerName fdry.1.1.4.6.2.1.3 Syntax: L4ServerName	Read-write	The name of the real server.
snL4BindingVirtualServerIP fdry.1.1.4.6.2.1.4 Syntax: IpAddress	Read-write	The IP address of the virtual server to which the real server will be bound.

Name, OID, and Syntax	Access	Description
snL4BindingVirtualServerPort fdry.1.1.4.6.2.1.5 Syntax: Integer	Read-write	The port on the virtual server to which the real server will be bound.
snL4BindingVirtualServerName fdry.1.1.4.6.2.1.6 Syntax: L4ServerName	Read only	The name of the virtual server.
snL4BindingRowStatus fdry.1.1.4.6.2.1.7 Syntax: Integer	Read-write	Creates or delete a bind entry: <ul style="list-style-type: none"> <li>• valid(1)</li> <li>• waiting-for-delete(2)</li> <li>• delete(3)</li> <li>• create(4)</li> </ul>

## GSLB Site Remote ServerIron Configuration Table

Global Server Load Balancing (GSLB) enables a ServerIron to add intelligence to authoritative Domain Name Servers (DNSs) by serving as a proxy to the servers. As a DNS proxy, the GSLB ServerIron evaluates the server IP addresses in the replies from the DNS for which the ServerIron is a proxy. Based on the results of the evaluation, the GSLB ServerIron can change the order of the addresses in the reply so that the “best” host address for the client is first on the list.

The GSLB Site Remote ServerIron Configuration table contains the configuration of ServerIrons that act as DNS proxies to the clients. They also intercept the IP addresses replied by the DNS authoritative servers to select the best address for the requesting client.

Name, OID, and Syntax	Access	Description
snL4GslbSiteRemoteServerIronTable fdry.1.1.4.27.1	None	The GSLB Remote ServerIron Configuration Table.
snL4GslbSiteRemoteServerIronEntry fdry.1.1.4.27.1.1	None	An entry in the GSLB Remote ServerIron Configuration table.
snL4GslbSiteRemoteServerIronIP fdry.1.1.4.27.1.1.1 Syntax: IpAddress	Read only	Specifies the management IP address of the remote ServerIron in a site. This address must not be any of the configured VIPs.

Name, OID, and Syntax	Access	Description
snL4GslbSiteRemoteServerIronPreference fdry.1.1.4.27.1.1.2 Syntax: Integer	Read-write	<p>Specifies the preference of a remote ServerIron. This metric is a numeric preference value, that is assigned to each site ServerIron. It is used to select that ServerIron if the previous metrics do not select a best site. The GSLB policy prefers the site ServerIron with the highest administrative preference. The preference allows to do the following.</p> <ul style="list-style-type: none"> <li>Temporarily change the preference of a ServerIron site to accommodate changing network conditions. For example, if sites are offering proxy content service, the link between a site proxy server farm and the content origin may be highly congested, making that site less desirable. This factor is not visible to the ServerIrons and thus cannot be reflected in the other GSLB metrics.</li> <li>Temporarily disqualify a site ServerIron from being selected, without otherwise changing the site configuration or the GSLB ServerIron configuration. For example, maintenance can be performed on the site ServerIron without making network changes. In this case, set the preference to 0.</li> <li>A GSLB ServerIron can be biased, that is, it can be configured as a site ServerIron (for locally configured VIPs) to always favor itself as the best site. In this case, assign a preference of 255 to the site for the GSLB ServerIron itself, and assign a lower preference to the other site ServerIrons, or use the default (128) for those sites.</li> </ul> <p>The administrative preference is disabled by default, which means it is not included as one of the GSLB metrics. When this metric is enabled, the default administrative preference for sites is applied. It can be changed on an individual site basis."</p> <p>Valid values: 0 – 255</p> <p>Default: 128</p>

## Monitor Groups

The monitor groups includes tables that control the periodic statistical sampling of data. Data is collected for real servers, virtual servers, real server ports, and virtual server ports. The data is then placed in the appropriate tables. Each entry in any of the tables is equal to one data sample. An entry identifies the sample's data source, polling period, and other information.

If the probe keeps track of the time of day when collecting data samples, it should take the first sample when the next hour begins.

The probe is encouraged to add two entries per monitored interface upon initialization. One entry should describe a short term polling period, the other, a long term polling period. Suggested intervals for the entries are 30 seconds for the short term polling period and 30 minutes for the long term period.

The monitor groups are presented in the following sections:

- “Real Server History Control Table” on page 21-38
- “Real Server History Group” on page 21-40
- “Real Server Port History Control Group” on page 21-42
- “Real Server Port History Group” on page 21-44

- “Virtual Server History Control Group” on page 21-45
- “Virtual Server History Table” on page 21-47
- “Virtual Server Port History Control Table” on page 21-48
- “Virtual Server Port History Table” on page 21-50

## Real Server History Control Table

Real Server History Control Table contains objects that control the collection of data samples for real servers.

Name, OID, and Syntax	Access	Description
snL4RealServerHistoryControlTable fdry.1.1.4.28.1	None	The Real Server History Control Table
snL4RealServerHistoryControlEntry fdry.1.1.4.28.1.1	None	An entry in the Real Server History Control Table.
snL4RealServerHistoryControlIndex fdry.1.1.4.28.1.1.1 Syntax: Integer	Read only	An index that uniquely identifies an entry in this table. Each entry defines a set of samples at a particular interval for a real server on the ServerIron.  Valid values: Up to 65535 entries.
snL4RealServerHistoryControlDataSource fdry.1.1.4.28.1.1.2 Syntax: Object Identifier	Read-write	This object identifies the source of the historical data that was collected for this entry. The source can be any real server on this ServerIron.  It identifies a particular instance defined in the “snL4RealServerStatisticTable”.  It may not be modified if the value of the “snL4RealServerHistoryControlStatus” object for this entry source is equal to valid(1).
snL4RealServerHistoryControlBucketsRequested fdry.1.1.4.28.1.1.3 Syntax: Integer	Read-write	The requested number of data samples that will be saved for this entry. The number of samples saved in the object “snL4RealServerHistoryControlBucketsGranted” should be close to the value of this object. If the value of this object is modified, then the value of the “snL4RealServerHistoryControlBucketsGranted” object will be adjusted according to the new value of this object.  Valid values: 1 – 65535  Default: 50

Name, OID, and Syntax	Access	Description
snL4RealServerHistoryControlBucketsGranted fdry.1.1.4.28.1.1.4 Syntax: Integer	Read only	<p>The number of data samples that was actually saved for this entry.</p> <p>If the value of the “snL4RealServerHistoryControlBucketsRequested” object is modified, then the actual number of samples saved by this object will be adjusted accordingly.</p> <p>If all the requested buckets are filled, a new bucket will be added to the table, and the oldest bucket for the entry will be deleted.</p> <p>If the value of this object changes to a value less than the current value, enough of the oldest entries will be deleted so that the number of buckets does not exceed the new value of this object.</p> <p>If the value of this object changes to a value greater than the current value, the number of buckets will increase but not exceed the new value of this object.</p>
snL4RealServerHistoryControlInterval fdry.1.1.4.28.1.1.5 Syntax: Integer	Read-write	<p>Shows the interval, in seconds, over which the data is sampled for each bucket.</p> <p><b>NOTE:</b> A counter for a bucket may overflow without any indication; therefore, be sure to account for the overflow in all the counters you configure. Consider the minimum time it takes for a counter to overflow and set this object (snL4RealServerHistoryControlInterval) to a value less than the overflow interval. This is especially important for the “octets” counter in any data-source table.</p> <p>You cannot modify the value of this object if the value of this entry’s “snL4RealServerHistoryControlStatus” object is equal to valid(1).</p> <p>Valid values: 1 – 3600 seconds</p> <p>Default: 1800 seconds</p>
snL4RealServerHistoryControlOwner fdry.1.1.4.28.1.1.6 Syntax: Display string	Read-write	<p>The administrator who owns or configured this entry.</p>
snL4RealServerHistoryControlStatus fdry.1.1.4.28.1.1.7 Syntax: Integer	Read-write	<p>The state of this entry:</p> <ul style="list-style-type: none"> <li>• valid(1)</li> <li>• createRequest(2)</li> <li>• underCreation(3)</li> <li>• invalid(4) – When the entry is set to this state, it will be deleted from the table.</li> </ul>

## Real Server History Group

The Real Server History Group table contains historical data samples that were collected for real servers.

Each counter in this table counts the same event as the counters used by the “snL4RealServerStatisticEntry”; however, the value of the counters in this table represents a cumulative sum of a sampling period.

Name, OID, and Syntax	Access	Description
snL4RealServerHistoryTable fdry.1.1.4.28.2	None	The Real Server History Group table.
snL4RealServerHistoryEntry fdry.1.1.4.28.2.1	None	An entry in the Real Server History Group table. An entry is a historical sample of statistics on a particular real server. This sample is associated with the “snL4RealServerHistoryControlEntry” object, which sets up the parameters for a regular collection of these samples.
snL4RealServerHistoryIndex fdry.1.1.4.28.2.1.1 Syntax: Integer	Read only	Shows the index entry as identified by the “snL4RealServerHistoryControllIndex”.
snL4RealServerHistorySampleIndex fdry.1.1.4.28.2.1.2 Syntax: Integer	Read only	An index that uniquely identifies this particular sample among all samples associated with the same entry. This index starts at 1 and increases by one as each new sample is taken. There can be up to 214,748,3647 samples.
snL4RealServerHistoryIntervalStart fdry.1.1.4.28.2.1.3 Syntax: Time ticks	Read only	The value of sysUpTime at the start of the interval used to measure data samples.  If the probe keeps track of the time of day, set the data sampling to start at the beginning of the next hour.  <b>NOTE:</b> Following this rule may require the probe to delay the collection of the first sample for an entry, since each sample must be of the same interval. Also, data for the sample that is currently being collected is not accessible in this table until the end of its interval.
snL4RealServerHistoryReceivePackets fdry.1.1.4.28.2.1.4 Syntax: Counter	Read only	Shows the number of packets the ServerIron has received from the real server.
snL4RealServerHistoryTransmitPackets fdry.1.1.4.28.2.1.5 Syntax: Counter	Read only	Shows the number of packets the ServerIron has sent to the real server.
snL4RealServerHistoryTotalConnections fdry.1.1.4.28.2.1.6 Syntax: Counter	Read only	Shows the total number of client connections on the real server. A connection consists of two sessions: the client-to-server session and the server-to-client session.



---

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snL4RealServerHistoryCurConnections fdry.1.1.4.28.2.1.7 Syntax: Integer	Read only	Shows the number of client connections currently on the real server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4RealServerHistoryPeakConnections fdry.1.1.4.28.2.1.8 Syntax: Integer	Read only	Shows the highest number of client connections on the real server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4RealServerHistoryReassignments fdry.1.1.4.28.2.1.9 Syntax: Integer	Read only	Shows the number of times the ServerIron has reassigned the connection to another real server in the rotation because the real server that is in use has not responded to two TCP SYNs from the client.

---

## Real Server Port History Control Group

Real Server Port History Control Table lists all the controls for collecting data samples for a real server port.

Name, OID, and Syntax	Access	Description
snL4RealServerPortHistoryControlTable fdry.1.1.4.28.3	None	Real Server Port History Control Table
snL4RealServerPortHistoryControlEntry fdry.1.1.4.28.3.1	None	An entry in the Real Server Port History Control Table.
snL4RealServerPortHistoryControlIndex fdry.1.1.4.28.3.1.1 Syntax: Integer	Read only	An index that uniquely identifies an entry in this table. Each entry defines a set of samples at a particular interval for a real server port on the ServerIron.  Valid values: Up to 65535 entries.
snL4RealServerPortHistoryControlDataSource fdry.1.1.4.28.3.1.2 Syntax: Object Identifier	Read-write	This object identifies the source of the historical data that was collected for this entry. The source can be any real server port on this ServerIron.  It identifies a particular instance defined in the "snL4RealServerStatisticTable".  It may not be modified if the value of the "snL4VirtualServerPortHistoryControlStatus" object for this entry source is equal to valid(1).
snL4RealServerPortHistoryControlBucketsRequested fdry.1.1.4.28.3.1.3 Syntax: Integer	Read-write	The requested number of data samples that will be saved for this entry. The number of actual samples saved in the "snL4RealServerPortHistoryControlBucketsGranted" object should be close to the value of this object. If the value of this object is modified, then the value of the "snL4RealServerPortHistoryControlBucketsGranted" object will be adjusted according to the new value of this object.  Valid values: 1 – 65535  Default: 50

Name, OID, and Syntax	Access	Description
snL4RealServerPortHistoryControlBucketsGranted fdry.1.1.4.28.3.1.4 Syntax: Integer	Read only	<p>The number of data samples that was actually saved for this entry.</p> <p>If the value of the “snL4RealServerPortHistoryControlBucketsRequested” object is modified, then the actual number of samples saved by this object will be adjusted accordingly.</p> <p>If all the requested buckets are filled, a new bucket will be added to the table, and the oldest bucket for the entry will be deleted.</p> <p>If the value of this object changes to a value less than the current value, enough of the oldest entries will be deleted so that the number of buckets does not exceed the new value of this object.</p> <p>If the value of this object changes to a value greater than the current value, the number of buckets will increase but will not exceed the new value of this object.</p>
snL4RealServerPortHistoryControlInterval fdry.1.1.4.28.3.1.5 Syntax: Integer	Read-write	<p>Shows the interval, in seconds, over which the data is sampled for each bucket.</p> <p><b>NOTE:</b> A counter for a bucket may overflow without any indication; therefore, be sure to account for the overflow in all the counters you configure. Consider the minimum time it takes for a counter to overflow and set this object (snL4RealServerPortHistoryControlInterval) to a value less than the overflow interval. This is especially important for the “octets” counter in any data-source table.</p> <p>You cannot modify the value of this object if the value of this entry’s “snL4RealServerPortHistoryControlStatus” object is equal to valid(1).</p> <p>Valid values: 1 – 3600 seconds</p> <p>Default: 1800 seconds</p>
snL4RealServerPortHistoryControlOwner fdry.1.1.4.28.3.1.6 Syntax: Display string	Read-write	The administrator who owns or configured this entry.
snL4RealServerPortHistoryControlStatus fdry.1.1.4.28.3.1.7 Syntax: Integer	Read-write	<p>The state of this entry:</p> <ul style="list-style-type: none"> <li>• valid(1)</li> <li>• createRequest(2)</li> <li>• underCreation(3)</li> <li>• invalid(4) – This entry will be deleted from the table if it is set to this state.</li> </ul>

## Real Server Port History Group

The Real Server Port History Group contains history data samples for each port on the real server.

Name, OID, and Syntax	Access	Description
snL4RealServerPortHistoryTable fdry.1.1.4.28.4	None	The Real Server Port History Group table.
snL4RealServerPortHistoryEntry fdry.1.1.4.28.4.1	None	An entry in the Real Server Port History Group table. An entry is a historical sample of statistics on a particular real server port. This sample is associated with the "snL4RealServerPortHistoryControlEntry" object, which sets up the parameters for the regular collection of these samples.
snL4RealServerPortHistoryIndex fdry.1.1.4.28.4.1.1 Syntax: Integer	Read only	Shows the index entry as identified by the "snL4RealServerPortHistoryControlIndex".
snL4RealServerPortHistorySampleIndex fdry.1.1.4.28.4.1.2 Syntax: Integer	Read only	An index that uniquely identifies this particular sample among all samples associated with the same entry. This index starts at 1 and increases by one as each new sample is taken. There can be up to 214,748,3647 samples.
snL4RealServerPortHistoryIntervalStart fdry.1.1.4.28.4.1.3 Syntax: Time ticks	Read only	The value of sysUpTime at the start of the interval used to measure data samples.  If the probe keeps track of the time of day, set the data sampling to start at the beginning of the next hour.  <b>NOTE:</b> Following this rule may require the probe to delay the collection of the first sample for an entry, since each sample must be of the same interval. Also, data for the sample that is currently being collected is not accessible in this table until the end of its interval.
snL4RealServerPortHistoryReceivePkts fdry.1.1.4.28.4.1.4 Syntax: Counter	Read only	Shows the number of packets the ServerIron has received from the real server.
snL4RealServerPortHistoryTransmitPkts fdry.1.1.4.28.4.1.5 Syntax: Counter	Read only	Shows the number of packets the ServerIron sent to the real server.
snL4RealServerPortHistoryTotalConnections fdry.1.1.4.28.4.1.6 Syntax: Counter	Read only	Shows the total number of client connections on the real server. A connection consists of two sessions: the client-to-server session and the server-to-client session.

Name, OID, and Syntax	Access	Description
snL4RealServerPortHistoryCurConnections fdry.1.1.4.28.4.1.7 Syntax: Integer	Read only	Shows the number of client connections currently on the real server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4RealServerPortHistoryPeakConnections fdry.1.1.4.28.4.1.8 Syntax: Integer	Read only	Shows the highest number of client connections on the real server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4RealServerPortHistoryResponseTime fdry.1.1.4.28.4.1.9 Syntax: Integer	Read only	Shows the round trip time for a response from a real server on this port.

### Virtual Server History Control Group

The Real Server History Control Table contains objects that control the collection of data samples for virtual servers.

Name, OID, and Syntax	Access	Description
snL4VirtualServerHistoryControlTable fdry.1.1.4.28.5	None	The Virtual Server History Control Group Table.
snL4VirtualServerHistoryControlEntry fdry.1.1.4.28.5.1	None	An entry in the Virtual Server History Control Table.
snL4VirtualServerHistoryControlIndex fdry.1.1.4.28.5.1.1 Syntax: Integer	Read only	An index that uniquely identifies an entry in this table. Each entry defines a set of samples at a particular interval for a virtual server on the ServerIron. This object can have up to 65535 entries.
snL4VirtualServerHistoryControlDataSource fdry.1.1.4.28.5.1.2	Read-write	This object identifies the source of the historical data that was collected for this entry. The source can be any virtual server on this ServerIron.  It identifies a particular instance defined in the "snL4VirtualServerStatisticTable".  It may not be modified if the value of the "snL4VirtualServerHistoryControlStatus" object for this entry source is equal to valid(1).

Name, OID, and Syntax	Access	Description
snL4VirtualServerHistoryControlBucketsRequested fdry.1.1.4.28.5.1.3 Syntax: Integer	Read-write	Indicates the requested number of data samples that will be saved for this entry. The number of samples saved in the object "snL4VirtualServerHistoryControlBucketsGranted" should be close to the value of this object. If the value of this object is modified, then the value of the "snL4VirtualServerHistoryControlBucketsGranted" object will be adjusted according to the new value of this object.  Valid values: 1 – 65535  Default: 50
snL4VirtualServerHistoryControlBucketsGranted fdry.1.1.4.28.5.1.4 Syntax: Integer	Read only	The number of data samples that was actually saved for this entry.  If the value of the "snL4VirtualServerHistoryControlBucketsRequested" object is modified, then the actual number of samples saved by this object will be adjusted accordingly.  If all the requested buckets are filled, a new bucket will be added to the table, and the oldest bucket for the entry will be deleted.  If the value of this object changes to a value less than the current value, enough of the oldest entries will be deleted so that the number of buckets does not exceed the new value of this object.  If the value of this object changes to a value greater than the current value, the number of buckets will increase but not exceed the new value of this object.
snL4VirtualServerHistoryControlInterval fdry.1.1.4.28.5.1.5 Syntax: Integer	Read-write	Shows the interval, in seconds, over which the data is sampled for each bucket.  <b>NOTE:</b> A counter for a bucket may overflow without any indication; therefore, be sure to account for the overflow in all the counters you configure. Consider the minimum time it takes for a counter to overflow and set this object (snL4VirtualServerHistoryControlInterval) to a value less than the overflow interval. This is especially important for the "octets" counter in any data-source table.  You cannot modify the value of this object if the value of this entry's "snL4VirtualServerHistoryControlStatus" object is equal to valid(1).  Valid values: 1 – 3600 seconds  Default: 1800 seconds
snL4VirtualServerHistoryControlOwner fdry.1.1.4.28.5.1.6 Syntax: Display string	Read-write	The administrator who owns or configured this entry.

Name, OID, and Syntax	Access	Description
snL4VirtualServerHistoryControlStatus fdry.1.1.4.28.5.1.7 Syntax: Integer	Read-write	The state of this entry: <ul style="list-style-type: none"> <li>valid(1)</li> <li>createRequest(2)</li> <li>underCreation(3)</li> <li>invalid(4) – This entry will be deleted from the table if it is changed to this state.</li> </ul>

## Virtual Server History Table

The Virtual Server History Group table contains historical data samples that were collected for virtual servers.

Each counter in this table identifies the same event as the counters used by the “snL4VirtualServerStatisticEntry”; however, the value of the counters in this table represents a cumulative sum of a sampling period.

Name, OID, and Syntax	Access	Description
snL4VirtualServerHistoryTable fdry.1.1.4.28.6	None	The Virtual Server History Table.
snL4VirtualServerHistoryEntry fdry.1.1.4.28.6.1	None	An entry in the Virtual Server History Group table. An entry is a historical sample of statistics on a particular virtual server. This sample is associated with the “snL4VirtualServerHistoryControlEntry” object, which sets up the parameters for a regular collection of these samples.
snL4VirtualServerHistoryIndex fdry.1.1.4.28.6.1.1 Syntax: Integer	Read only	Shows the index entry as identified by the “snL4VirtualServerHistoryControlIndex”.
snL4VirtualServerHistorySampleIndex fdry.1.1.4.28.6.1.2 Syntax: Integer	Read only	An index that uniquely identifies this particular sample among all samples associated with the same entry. This index starts at 1 and increases by one as each new sample is taken. There can be up to 214,748,3647 samples.
snL4VirtualServerHistoryIntervalStart fdry.1.1.4.28.6.1.3 Syntax: Time ticks	Read only	The value of sysUpTime at the start of the interval used to measure data samples.  If the probe keeps track of the time of day, set the data sampling to start at the beginning of the next hour.  <b>NOTE:</b> Following this rule may require the probe to delay the collection of the first sample for an entry, since each sample must be of the same interval. Also, data for the sample that is currently being collected is not accessible in this table until the end of its interval.
snL4VirtualServerHistoryReceivePkts fdry.1.1.4.28.6.1.4 Syntax: Counter	Read only	Shows the number of packets the ServerIron has received from the virtual server.

Name, OID, and Syntax	Access	Description
snL4VirtualServerHistoryTransmitPkts fdry.1.1.4.28.6.1.5 Syntax: Counter	Read only	Shows the number of packets the ServerIron sent to the virtual server.
snL4VirtualServerHistoryTotalConnections fdry.1.1.4.28.6.1.6 Syntax: Counter	Read only	Shows the total number of client connections on the virtual server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4VirtualServerHistoryCurrentConnections fdry.1.1.4.28.6.1.7 Syntax: Integer	Read only	Shows the number of client connections currently on the virtual server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4VirtualServerHistoryPeakConnections fdry.1.1.4.28.6.1.8 Syntax: Integer	Read only	Shows the highest number of client connections on the virtual server. A connection consists of two sessions: the client-to-server session and the server-to-client session.

### Virtual Server Port History Control Table

The Virtual Server Port History Control Table lists all the controls for collecting data samples for a virtual server port.

Name, OID, and Syntax	Access	Description
snL4VirtualServerPortHistoryControlTable fdry.1.1.4.28.7	None	The Virtual Server Port History Control Table
snL4VirtualServerPortHistoryControlEntry fdry.1.1.4.28.7.1	None	An entry in the Virtual Server Port History Control Table.
snL4VirtualServerPortHistoryControlIndex fdry.1.1.4.28.7.1.1 Syntax: Integer	Read only	An index that uniquely identifies an entry in this table. Each entry defines a set of samples at a particular interval for a virtual server port on the ServerIron. This object can have up to 65535 entries.
snL4VirtualServerPortHistoryControlDataSource fdry.1.1.4.28.7.1.2 Syntax: Object Identifier	Read-write	This object identifies the source of the historical data that was collected for this entry. The source can be any virtual server port on this ServerIron.  It identifies a particular instance defined in the "snL4VirtualServerStatisticTable".  It may not be modified if the value of the "snL4VirtualServerPortHistoryControlStatus" object for this entry source is equal to valid(1).



Name, OID, and Syntax	Access	Description
snL4VirtualServerPortHistoryControlBucketsRequested fdry.1.1.4.28.7.1.3 Syntax: Integer	Read-write	The requested number of data samples that will be saved for this entry. The number of actual samples saved in the "snL4VirtualServerPortHistoryControlBucketsGranted" object should be close to the value of this object. If the value of this object is modified, then the value of the "snL4VirtualServerPortHistoryControlBucketsGranted" object will be adjusted according to the new value of this object.  Valid values: 1 – 65535  Default: 50
snL4VirtualServerPortHistoryControlBucketsGranted fdry.1.1.4.28.7.1.4 Syntax: Integer	Read only	The number of data samples that was actually saved for this entry.  If the value of the "snL4VirtualServerPortHistoryControlBucketsRequested" object is modified, then the actual number of samples saved by this object will be adjusted accordingly.  If all the requested buckets are filled, a new bucket will be added to the table, and the oldest bucket for the entry will be deleted.  If the value of this object changes to a value less than the current value, enough of the oldest entries will be deleted so that the number of buckets does not exceed the new value of this object.  If the value of this object changes to a value greater than the current value, the number of buckets will increase but will not exceed the new value of this object.
snL4VirtualServerPortHistoryControlInterval fdry.1.1.4.28.7.1.5 Syntax: Integer	Read-write	Shows the interval, in seconds, over which the data is sampled for each bucket.  <b>NOTE:</b> A counter for a bucket may overflow without any indication; therefore, be sure to account for the overflow in all the counters you configure. Consider the minimum time it takes for a counter to overflow and set this object (snL4VirtualServerPortHistoryControlInterval) to a value less than the overflow interval. This is especially important for the "octets" counter in any data-source table.  You cannot modify the value of this object if the value of this entry's "snL4VirtualServerPortHistoryControlStatus" object is equal to valid(1).  Valid values: 1 – 3600 seconds  Default: 1800 seconds
snL4VirtualServerPortHistoryControlOwner fdry.1.1.4.28.7.1.6 Syntax: Display string	Read-write	The administrator who owns or configured this entry.

Name, OID, and Syntax	Access	Description
snL4VirtualServerPortHistoryControlStatus fdry.1.1.4.28.7.1.7 Syntax: Integer	Read-write	The state of this entry: <ul style="list-style-type: none"> <li>valid(1)</li> <li>createRequest(2)</li> <li>underCreation(3)</li> <li>invalid(4) – This entry will be deleted from the table if its state changes to this state.</li> </ul>

## Virtual Server Port History Table

The Virtual Server Port History Group contains history data samples for each port on the virtual server.

Name, OID, and Syntax	Access	Description
snL4VirtualServerPortHistoryTable fdry.1.1.4.28.8	None	The Virtual Server Port History Table.
snL4VirtualServerPortHistoryEntry fdry.1.1.4.28.8.1	None	An entry in the Virtual Server Port History Group table. An entry is a historical sample of statistics on a particular virtual server port. This sample is associated with the “snL4VirtualServerPortHistoryControlEntry” object, which sets up the parameters for a regular collection of these samples.
snL4VirtualServerPortHistoryIndex fdry.1.1.4.28.8.1.1 Syntax: Integer	Read only	Shows the index entry as identified by the “snL4VirtualServerPortHistoryControlIndex”.
snL4VirtualServerPortHistorySampleIndex fdry.1.1.4.28.8.1.2 Syntax: Integer	Read only	An index that uniquely identifies this particular sample among all samples associated with the same entry. This index starts at 1 and increases by one as each new sample is taken. There can be up to 214,748,3647 samples.
snL4VirtualServerPortHistoryIntervalStart fdry.1.1.4.28.8.1.3 Syntax: Time ticks	Read only	The value of sysUpTime at the start of the interval used to measure data samples.  If the probe keeps track of the time of day, set the data sampling to start at the beginning of the next hour.  <b>NOTE:</b> Following this rule may require the probe to delay the collection of the first sample for an entry, since each sample must be of the same interval. Also, data for the sample that is currently being collected is not accessible in this table until the end of its interval.
snL4VirtualServerPortHistoryReceivePkts fdry.1.1.4.28.8.1.4 Syntax: Counter	Read only	Shows the number of packets the ServerIron has received from the virtual server port.

---

<b>Name, OID, and Syntax</b>	<b>Access</b>	<b>Description</b>
snL4VirtualServerPortHistoryTransmitPkts fdry.1.1.4.28.8.1.5 Syntax: Counter	Read only	Shows the number of packets the ServerIron sent to the virtual server.
snL4VirtualServerPortHistoryTotalConnections fdry.1.1.4.28.8.1.6 Syntax: Counter	Read only	Shows the total number of client connections on the virtual server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4VirtualServerPortHistoryCurrentConnections fdry.1.1.4.28.8.1.7 Syntax: Integer	Read only	Shows the number of client connections currently on the virtual server. A connection consists of two sessions: the client-to-server session and the server-to-client session.
snL4VirtualServerPortHistoryPeakConnections fdry.1.1.4.28.8.1.8 Syntax: Integer	Read only	Shows the highest number of client connections on the virtual server. A connection consists of two sessions: the client-to-server session and the server-to-client session.

---



---

# Chapter 22

## Wireless Features

The wgGroup (OID: fdry.1.1.3.23.1) contains MIB objects for wireless LAN features. The group is available on WLAN switches. The following sections present the objects in the MIB group.

### General MIB Objects

The following table list the general MIB objects for the wireless feature support.

---

Name, Identifier, and Syntax	Access	Description
wgMobilityId fdry.1.1.3.23.1.1 Syntax: Integer	Read-write	Specifies the wireless mobility domain to which this WLAN switch belongs.  Valid value: 1 - 65535. Enter 0 to remove the WLAN switch from a wireless mobility domain.
wgVpnPTDeletePolicy fdry.1.1.3.23.1.2 Syntax: Integer	Read-write	Deletes a VPN passthrough policy from the WLAN switch. enter a valid VPN passthrough policy ID to remove the policy.

---

### WiFi Interface Table

The WiFi Interface Table controls the wireless feature support on an WLAN switch.

---

Name, Identifier, and Syntax	Access	Description
wglfTable fdry.1.1.3.23.2	N/A	WiFi Interface Table
wglfEntry fdry.1.1.3.23.2.1	N/A	An entry of the WiFi Interface Table.

---

Name, Identifier, and Syntax	Access	Description
wglfIndex fdry.1.1.3.23.2.1.1 Syntax: Integer	Read-only	The ifIndex value of the switch interface.
wglfWirelessEnable fdry.1.1.3.23.2.1.2 Syntax: Integer	Read-write	Enables or disables the wireless feature support on an interface: <ul style="list-style-type: none"> <li>other(1)</li> <li>enable(2)</li> <li>disable(3)</li> </ul> The default is disable(3).
wglfPnPLearnNewAP fdry.1.1.3.23.2.1.3 Syntax: Integer	Read-write	Enables or disables the ability of an interface to learn new access points. This object is used by the ADC feature: <ul style="list-style-type: none"> <li>other(1)</li> <li>enable(2)</li> <li>disable(3)</li> </ul>
wglfAutoPortDisable fdry.1.1.3.23.2.1.4 Syntax: Integer	Read-write	This object is for the Automatic Port Deactivation feature. If set to enable, the interface is automatically disabled if the link status of the interface changes: <ul style="list-style-type: none"> <li>other(1)</li> <li>enable(2)</li> <li>disable(3)</li> </ul>
wglfVpnPTPolicyId fdry.1.1.3.23.2.1.5 Syntax: Integer	Read-write	This object binds a VPN Passthrough policy to the interface. To bind an interface to a VPN passthrough policy, enter it's policy ID. It must be a valid policy number that is larger than zero. To unbind an interface to a VPN passthrough policy enter zero for the policy ID.
wglfFullCompRoamingEnable fdry.1.1.3.23.2.1.5 Syntax: Integer	Read-write	Indicates if full compatibility tunneling mode is enabled on the interface: <ul style="list-style-type: none"> <li>other(1) – Other</li> <li>enable(2) – Full compatibility tunneling is enabled.</li> <li>disable(3) – Full compatibility tunneling is disabled. High performance tunneling is used.</li> </ul>

## Roaming Peer Table

The Roaming Peer Table shows information about the WLAN switch peers in a Wireless Mobility configuration.

Name, Identifier, and Syntax	Access	Description
wgRoamingPeerTable fdry.1.1.3.23.3	N/A	The Roaming Peer Table.

Name, Identifier, and Syntax	Access	Description
wgRoamingPeerEntry fdry.1.1.3.23.3.1	N/a	An entry of the Roaming Peer Table.
wgRoamingPeerIpAddress fdry.1.1.3.23.3.1.1 Syntax: IpAddress	Read-only	The IP Address of a peer.
wgRoamingPeerConnectionStatus fdry.1.1.3.23.3.1.2 Syntax: Integer	Read-only	Shows the state of the connection; <ul style="list-style-type: none"> <li>other(1)</li> <li>configured(2)</li> <li>established(3)</li> </ul>
wgRoamingPeerRowStatus fdry.1.1.3.23.3.1.3 Syntax: Integer	Read-write	Shows the state of the row in the PeerRow Table: <ul style="list-style-type: none"> <li>other(1)</li> <li>valid(2)</li> <li>delete(3)</li> <li>create(4)</li> </ul>

## Access Point Automatic Discovery and Configuration Table

The Access Point (AP) Automatic Discovery and Configuration (ADC) Table defines the IP address, subnet mask, and default gateway of the access point that will be assigned to an access point with the specified MAC address. This information can be pre-configured on a WLAN switch interface. When the access point that has the matching MAC address is attached to the interface, the pre-configured IP address, subnet mask, and default gateway are assigned to that access point.

Name, Identifier, and Syntax	Access	Description
wgPnPTable fdry.1.1.3.23.4	N/A	AP ADC Table.
wgPnPEntry fdry.1.1.3.23.4.1 Syntax: WgPnPEntry	N/A	An entry in the AP ADC Table.
wgPnPIfIndex fdry.1.1.3.23.4.1.1 Syntax: Integer	Read-only	The ifIndex value of the switch interface.
wgPnPMacAddress fdry.1.1.3.23.4.1.2 Syntax: MacAddress	Read-only	MAC address of the attached AP.

Name, Identifier, and Syntax	Access	Description
wgPnPIpAddress fdry.1.1.3.23.4.1.3 Syntax: IpAddress	Read-write	IP address of the attached AP.
wgPnPIpAddressMask fdry.1.1.3.23.4.1.4 Syntax: IpAddress	Read-write	Subnet mask of the attached AP.
wgPnPDefaultGateway fdry.1.1.3.23.4.1.5 Syntax: IpAddress	Read-write	Default gateway of the attached AP.
wgPnPStatus fdry.1.1.3.23.4.1.6 Syntax: Integer	Read-only	The state of the access point that is defined for the interface: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• discovered(2) – WLAN switch discovered a new access point that has not been configured.</li> <li>• configured(3) – The access point's IP address, subnet mask, and default gateway have been defined on the interface, but the access point with the matching MAC address is not attached to the interface.</li> <li>• operational(4) – The access point's IP address, subnet mask, and default gateway have been defined on the interface and the access point with the matching MAC address is attached to the interface and is operational.</li> </ul>
wgPnPRowStatus fdry.1.1.3.23.4.1.7 Syntax: Integer	Read-write	Creates, deletes or modifies a row in the AP ADC Table: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> <li>• modify(5)</li> </ul>

## VPN Passthrough Server Table

The VPN Passthrough Server Table contains the VPN policies that have been configured on the WLAN switch.

Name, Identifier, and Syntax	Access	Description
wgVpnPTServerTable fdry.1.1.3.23.5	N/A	The VPN Passthrough Server Table.
wgVpnPTServerEntry fdry.1.1.3.23.5.1	N/A	An entry in the VPN Passthrough Server Table.



Name, Identifier, and Syntax	Access	Description
wgVpnPTServerPolicyId fdry.1.1.3.23.5.1.1 Syntax: Integer	Read-only	The ID of a VPN passthrough policy. The value of this object must be greater than zero.
wgVpnPTServerIpAddress fdry.1.1.3.23.5.1.2 Syntax: IpAddress	Read-only	The IP address of the VPN server that will be used to terminate VPN traffic that goes through this switch.
wgVpnPTServerRowStatus fdry.1.1.3.23.5.1.3 Syntax: Integer	Read-write	Creates or deletes a row in the VPN Passthrough Server Table: <ul style="list-style-type: none"> <li>other(1)</li> <li>valid(2)</li> <li>delete(3)</li> <li>create(4)</li> </ul>

## VPN Passthrough Filter Table

The VPN Passthrough Filter Table shows the VPN passthrough policies and the action the policy takes when it encounters VPN traffic that matches the policy.

Name, Identifier, and Syntax	Access	Description
wgVpnPTFilterTable fdry.1.1.3.23.6	N/A	The VPN Passthrough Filter Table
wgVpnPTFilterEntry fdry.1.1.3.23.6.1	N/A	An entry in the VPN Passthrough Filter Table.
wgVpnPTFilterPolicyId fdry.1.1.3.23.6.1.1 Syntax: Integer	Read-only	The ID of the VPN passthrough policy. This is a number greater than zero.
wgVpnPTFilterProtocol fdry.1.1.3.23.6.1.2 Syntax: Integer	Read-only	Specifies which protocol will be allowed to passthrough: <ul style="list-style-type: none"> <li>other(1)</li> <li>udp(2)</li> <li>tcp(3)</li> </ul>
wgVpnPTFilterPort fdry.1.1.3.23.6.1.4 Syntax: Integer	Read-only	Specifies which protocol interface (number) will be allowed to passthrough.

Name, Identifier, and Syntax	Access	Description
wgVpnPTFilterRowStatus fdry.1.1.3.23.6.1.4 Syntax: Integer	Read-write	Creates or deletes a row of VPN Passthrough Filter Table: <ul style="list-style-type: none"> <li>• other(1)</li> <li>• valid(2)</li> <li>• delete(3)</li> <li>• create(4)</li> </ul>

## VPN Passthrough Policy Table

The VPN Passthrough Policy Table shows to which interfaces a VPN policy is bound.

Name, Identifier, and Syntax	Access	Description
wgVpnPTPolicyTable fdry.1.1.3.23.7	N/A	VPN Passthrough Policy Table
wgVpnPTPolicyEntry fdry.1.1.3.23.7.1	N/A	An entry in the VPN Passthrough Policy Table.
wgVpnPTPolicyId fdry.1.1.3.23.7.1.1 Syntax: Integer	Read-only	The ID of the VPN policy. The value of this object must be greater than zero.
wgVpnPTPolicyPortList fdry.1.1.3.23.7.1.2 Syntax: IfIndexList	Read-only	Shows a list of ports to which this VPN policy is bound.

---

# Chapter 23

## Traps and Objects to Enable Traps

The following sections comprise this chapter:

- “Objects to Enable or Disable Standard Traps” on page 23-1 presents the objects from the standard MIBs that enable SNMP traps.
- “Objects for Foundry Traps” on page 23-2 contains object to enable the SNMP traps that are proprietary to Foundry devices.
- “Standard Traps” on page 23-10 lists the standard SNMP traps that are supported in the MIB.
- “Foundry Traps” on page 23-12 details the SNMP traps in the Foundry MIB that are proprietary to Foundry devices.
- “Examples” on page 23-35 presents examples of how to configure SNMP traps for a Foundry device.

---

**NOTE:** By default, all traps are enabled.

---

### Objects to Enable or Disable Standard Traps

The following objects from RFC 1213 are the standard objects supported in the Foundry MIB. They are used to set SNMP traps.

Name, OID, and Syntax	Access	Description
snmpInTraps 1.3.6.1.2.1.11.19	Read only	Shows the total number of SNMP trap PDUs that have been accepted and processed by the SNMP protocol.
snmpOutTraps 1.3.6.1.2.1.11.29	Read only	Shows the total number of SNMP trap PDUs that have been generated by the SNMP protocol.

Name, OID, and Syntax	Access	Description
snmpEnableAuthenTraps 1.3.6.1.2.1.11.30	Read-write	Indicates if the SNMP agent process is permitted to generate authentication failure traps. The value of this object overrides any configuration information. This objects provides a way to disable all authentication failure traps.  <b>NOTE:</b> It is strongly recommended that this object be stored in the non-volatile memory so that it remains constant between re-initializations of the network management system.

## Objects for Foundry Traps

The following sections present the objects used to enable the traps that are proprietary to Foundry devices:

- “Trap Information” on page 23-2
- “Trap Receiver Table” on page 23-2
- “General Chassis and Agent Traps” on page 23-4
- “Enable VRRP Traps” on page 23-5
- “Enable FSRP Traps” on page 23-5
- “Enable OSPF Trap Objects” on page 23-6
- “Objects to Enable Layer 4 Traps” on page 23-8

### Trap Information

The following objects provide general information on traps.

Name, OID, and Syntax	Access	Description
snAgTrpRcvrCurEntry fdry.1.1.2.1.16 Syntax: Integer	Read only	Shows the total number of entries that are currently in the Trap Receiver Table. There can be up to 255 entries.
snAgGblTrapMessage fdry.1.1.2.1.44 Syntax: Display string	Read only	Shows a generic trap message.

### Trap Receiver Table

This table allows you to configure trap receivers.

Name, OID, and Syntax	Access	Description
snAgTrpRcvrTable fdry.1.1.2.3.1	None	The Trap Receiver Table

Name, OID, and Syntax	Access	Description
snAgTrpRcvrEntry fdry.1.1.2.3.1.1	None	A row in the Trap Receiver Table. The column "snAgTrpRcvrStatus" is used to create and delete rows in the table. Creation requires a SET PDU with objects snAgTrpRcvrIndex, snAgTrpRcvrIpAddr, snAgTrpRcvrComm and snAgTrpRcvrStatus.
snAgTrpRcvrIndex fdry.1.1.2.3.1.1.1 Syntax: Integer	Read only	Shows the index in the Trap Receiver Table. Valid values: 1 – 10
snAgTrpRcvrIpAddr fdry.1.1.2.3.1.1.2 Syntax: IpAddress	Read-write	Indicates the IP address of the SNMP manager that will receive the trap.
snAgTrpRcvrComm fdry.1.1.2.3.1.1.3 Syntax: Octet string	Read-write	Indicates the community string to use to access the trap receiver. This object can have up to 32 octets.
snAgTrpRcvrStatus fdry.1.1.2.3.1.1.4 Syntax: Integer	Read-write	Controls the management of the table rows. The values that can be written are: <ul style="list-style-type: none"> <li>ignore(5) – Do not send traps to this entry at this time</li> <li>delete(3) – Delete the row. (See note below regarding deleting a trap receiver.)</li> <li>create(4) – Create a new row</li> </ul> <p>If the row exists, then a SET with a value of create(5) returns error "badValue". Deleted rows are deleted immediately.</p> <p>The following values can be returned on reads:</p> <ul style="list-style-type: none"> <li>other(1) – Some other case</li> <li>valid(2) – Row exists and is valid</li> <li>ignore(5) – Do not send traps to this entry at this time</li> </ul>
snAgTrpRcvrUDPPort fdry1.1.2.3.1.1.5 Syntax: Integer	Read-write	Indicates the UDP port number of the trap receiver. Valid values: 0 – 65535 Default: 162

**NOTE:** To delete a trap receiver, the agent needs the following varbinds in the setRequest PDU: snAgTrpRcvrIpAddr, snAgTrpRcvrComm, and snAgTrpRcvrStatus. The snAgTrpRcvrStatus object must be set to delete(3).

## General Chassis and Agent Traps

The following objects enable or disable traps related to the device's power supply, fan, and interface links.

Name, OID, and Syntax	Access	Description
snChasEnablePwrSupplyTrap fdry.1.1.1.1.12 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate power supply failure traps: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snChasEnableFanTrap fdry.1.1.1.1.16 Syntax: Integer	Read-write	For chassis devices only. Indicates if the SNMP agent process has been enabled to generate fan failure traps: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0)
snAgGblEnableColdStartTrap fdry.1.1.2.1.21 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate cold start traps: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: enabled(1)
snAgGblEnableLinkUpTrap fdry.1.1.2.1.22 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate link up traps: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: enabled(1)
snAgGblEnableLinkDownTrap fdry.1.1.2.1.23 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate link down traps: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: enabled(1)
snAgGblEnableModuleInsertedTrap fdry.1.1.2.1.42 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate traps for hardware modules that have been inserted in the chassis: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: enabled(1)

Name, OID, and Syntax	Access	Description
snAgGblEnableModuleRemovedTrap fdry.1.1.2.1.43 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate traps for hardware modules that have been removed from the chassis: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: enabled(1)
snChasEnableTempWarnTrap fdry.1.1.1.1.21 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate temperature warning traps: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: disabled(0)
snAgentEnableMgmtModRedunStateChangeTrap fdry.1.1.2.10.1.4 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate management module redundancy state change traps: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: enabled(1)
snAgTrapHoldTime fdry.1.1.2.1.58 Syntax: Integer	Read-write	The number of seconds that traps will be held during device initialization. Traps are buffered while the device initialized; they are sent once the device is back online.

### Enable VRRP Traps

Name, OID, and Syntax	Access	Description
snVrrpIfStateChangeTrap fdry.1.2.12.1.2 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate VRRP interface state change traps: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: enabled(0)

### Enable FSRP Traps

Name, OID, and Syntax	Access	Description
snFsrpIfStateChangeTrap fdry.1.2.7.1.2 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate FSRP interface state change traps: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> Default: enabled(1)

## Enable VSRP Traps

Name, OID, and Syntax	Access	Description
snVsrplfStateChangeTrap fdry.1.1.3.21.1.2 Syntax: Integer	Read-write	<p>Indicates if the SNMP agent will generate a trap when an interface state change occur:</p> <ul style="list-style-type: none"> <li>disabled(0) – No trap will be generated.</li> <li>enabled(1) – The TRAP_VRRP_IF_STATE_CHANGE will be generated. Since only one of the virtual router protocols (VRRP, VRRPE, or VSRP) can be enabled at any one time, they all generate the same trap.</li> </ul> <p>Default is enabled(1).</p>

## Enable OSPF Trap Objects

The following are support objects for the OSPF traps.

Name, OID, and Syntax	Access	Description
snOspfSetTrap fdry.1.2.4.15.1 Syntax: Octet string	Read-write	<p>Indicates if specific OSPF traps are enabled.</p> <p>This object contains four octets, serving as a bit map for the trap events defined by the OSPF traps. A value of 1 in the bit field indicates that the trap is enabled. The right-most bit (least significant) represents Trap 0.</p>
snOspfConfigErrorType fdry.1.2.4.15.2 Syntax: Integer	Read only	<p>Indicates the potential types of configuration conflicts used by the ospfConfigError and ospfConfigVirtError traps.</p> <ul style="list-style-type: none"> <li>badVersion(1)</li> <li>areaMismatch(2)</li> <li>unknownNbmaNbr(3) – Router is eligible</li> <li>unknownVirtualNbr(4)</li> <li>authTypeMismatch(5)</li> <li>authFailure(6)</li> <li>netMaskMismatch(7)</li> <li>helloIntervalMismatch(8)</li> <li>deadIntervalMismatch(9)</li> <li>optionMismatch(10)}</li> </ul>



Name, OID, and Syntax	Access	Description
snOspfPacketType fdry.1.2.4.15.3 Syntax: Integer	Read only	Indicates the OSPF packet type in the trap. <ul style="list-style-type: none"> <li>hello(1)</li> <li>dbDescript(2)</li> <li>lsReq(3)</li> <li>lsUpdate(4)</li> <li>lsAck(5)}</li> </ul>
snOspfPacketSrc fdry.1.2.4.15.4 Syntax: IpAddress	Read only	Show the IP address of an inbound packet that cannot be identified by a neighbor instance.
snOspfTrapsGenerationMode fdry.1.2.4.15.5 Syntax: Integer	Read-write	Indicates if this router has been enabled to generate OSPF traps. <ul style="list-style-type: none"> <li>disabled(0) – OSPF traps cannot be generated by this router, even if the object “snOspfSetTrap” is set to generate traps.</li> <li>enabled(1) – OSPF traps can be generated by the router.</li> </ul> <p>This object provides global control on the generation of traps.</p>

## Enable Switch Group Traps

Name, OID, and Syntax	Access	Description
snSwEnableBridgeNewRootTrap fdry.1.1.3.1.25 Syntax: Integer	Read-write	Indicates If the SNMP agent process is enabled to generate bridge new root traps. <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> <p>Default: enabled(1)</p>
snSwEnableBridgeTopoChangeTrap fdry.1.1.3.1.26 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate bridge topology change traps: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> <p>Default: enabled(1)</p>
snSwEnableLockedAddrViolationTrap fdry.1.1.3.1.27 Syntax: Integer	Read-write	Indicates if the SNMP agent process has been enabled to generate locked address violation traps: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul> <p>Default: enabled(1)</p>

## Objects to Enable Layer 4 Traps

The following objects enable or disable traps for Layer 4 functionalities.

Name, OID, and Syntax	Access	Description
snL4EnableMaxSessionLimitReachedTrap fdry.1.1.4.1.30 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps if the maximum number of connections has been reached: <ul style="list-style-type: none"><li>disabled(0)</li><li>enabled(1)</li></ul>
snL4EnableTcpSynLimitReachedTrap fdry.1.1.4.1.31 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps if the maximum number of TCP SYN has been reached: <ul style="list-style-type: none"><li>disabled(0)</li><li>enabled(1)</li></ul>
snL4EnableRealServerUpTrap fdry.1.1.4.1.32 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the real server is up: <ul style="list-style-type: none"><li>disabled(0)</li><li>enabled(1)</li></ul>
snL4EnableRealServerDownTrap fdry.1.1.4.1.33 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the real server is down: <ul style="list-style-type: none"><li>disabled(0)</li><li>enabled(1)</li></ul>
snL4EnableRealServerPortUpTrap fdry.1.1.4.1.34 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the real server TCP port is up: <ul style="list-style-type: none"><li>disabled(0)</li><li>enabled(1)</li></ul>
snL4EnableRealServerPortDownTrap fdry.1.1.4.1.35 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the real server TCP port is down: <ul style="list-style-type: none"><li>disabled(0)</li><li>enabled(1)</li></ul>
snL4EnableRealServerMaxConnLimitReachedTrap fdry.1.1.4.1.36 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the real server reaches its maximum number of connections: <ul style="list-style-type: none"><li>disabled(0)</li><li>enabled(1)</li></ul>
snL4EnableBecomeStandbyTrap fdry.1.1.4.1.37 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the Server Load Balancing switch changes its state from active to standby: <ul style="list-style-type: none"><li>disabled(0)</li><li>enabled(1)</li></ul>

Name, OID, and Syntax	Access	Description
snL4EnableBecomeActiveTrap fdry.1.1.4.1.38 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the Server Load Balancing switch changes its state from standby to active: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableGslbHealthCheckIpUpTrap fdry.1.1.4.1.43 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when an application port in a domain on the site IP address passes its Layer 4 TCP or UDP health check, resulting in a status change to UP: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableGslbHealthCheckIpDownTrap fdry.1.1.4.1.44 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps whenever the GSLB determines that the IP address belonging to a domain name for which the ServerIron is providing GSLB is DOWN: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableGslbHealthCheckIpPortUpTrap fdry.1.1.4.1.45 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when an application port in a domain on the site IP address passes its Layer 4 TCP or UDP health check, resulting in a status change to UP: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableGslbHealthCheckIpPortDownTrap fdry.1.1.4.1.46 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when an application port in a domain on the site IP address fails its Layer 4 TCP or UDP health check, resulting in a status change to DOWN: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableGslbRemoteGslbSiDownTrap fdry.1.1.4.1.47 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the connection from this site to the remote GSLB ServerIron is DOWN: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableGslbRemoteGslbSiUpTrap fdry.1.1.4.1.48 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the connection from this site to the remote GSLB ServerIron is UP: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>

Name, OID, and Syntax	Access	Description
snL4EnableGslbRemoteSiDownTrap fdry.1.1.4.1.49 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the GSLB connection from this GSLB to the remote ServerIron is DOWN: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>
snL4EnableGslbRemoteSiUpTrap fdry.1.1.4.1.50 Syntax: Integer	Read-write	Indicates if this device has been enabled to generate traps when the GSLB connection from this GSLB to remote the ServerIron is UP: <ul style="list-style-type: none"> <li>disabled(0)</li> <li>enabled(1)</li> </ul>

## Standard Traps

Standard traps that are supported in the Foundry devices are presented in the following sections:

- “System Status Traps” on page 23-10
- “Traps for Spanning Tree Protocol” on page 23-11
- “Traps for Alarms” on page 23-12

## System Status Traps

Foundry supports the following traps from RFC 1215:

Trap Name and Number	Varbind	Description
coldStart(0)	(None)	Indicates that the sending protocol entity is reinitializing itself; the agent's configuration or the protocol entity implementation may be altered.
warmStart(1)	(None)	Indicates that the sending protocol entity is reinitializing itself; however, the agent configuration nor the protocol entity implementation is not altered.
linkDown(2)	ifIndex(1) ifDescr(2)	A failure in one of the communication links.  Beginning with IronWare TrafficWorks Switch software release 09.0.00S, this trap is generated when a port's state changes to DOWN. The message generated by this trap shows the port name and number. For example,  Interface <port-name> <port-num>, state down
linkUp(3)	ifIndex(1) ifDescr(2)	The communication link is up.  Beginning with IronWare TrafficWorks Switch software release 09.0.00S, this trap is generated when a port's state changes to UP. The message generated by this trap shows the port name and number. For example,  Interface <port-name> <port-num>, state up

Trap Name and Number	Varbind	Description
<p><b>NOTE:</b> Regarding linkUp and linkDown traps:</p> <ul style="list-style-type: none"> <li>Release 07.1.x. supports a maximum of 32 ports per module; therefore the ifIndex for this release ranges from 1 – 32 for Slot 1, 33 – 64 for Slot 2 and so on.</li> <li>Release 07.2.x supports a maximum of 64 ports per module; therefore, the ifIndex for the release ranges from 1 – 64 for Slot 1, 65 – 128 for Slot2 and so on.</li> </ul> <p>Thus for Slot 2/Port 1, the value of the ifIndex of the port in Release 07.1.x is 33; whereas, in Release 07.2.x, it is 65.</p>		
authenticationFailure(40)	(none)	<p>Indicates that the sending protocol entity is the addressee of a protocol message that is not properly authenticated. While implementations of the SNMP must be capable of generating this trap, they must also be capable of suppressing the emission of such traps via an implementation-specific mechanism.</p> <p><b>NOTE:</b> On Terathon devices, this trap is supported in software release 01.1.01.</p>

## Traps for Spanning Tree Protocol

Foundry supports the following traps for Spanning Tree Protocol from RFC 1493.

:

Trap Name and Number	Description
newRoot(1) <b>NOTE:</b> On Terathon devices, this trap is supported in software release 01.1.01.	Indicates that the sending agent has become the new root of the Spanning Tree. The trap is sent by a bridge soon after its election as the new root, for example, upon expiration of the Topology Change Timer immediately subsequent to its election.
topologyChange(2) <b>NOTE:</b> On Terathon devices, this trap is supported in software release 01.1.01.	Is sent by a bridge when any of its configured ports transitions from the Learning state to the Forwarding state, or from the Forwarding state to the Blocking state. The trap is not sent if a newRoot trap is sent for the same transition.

## Traps for Alarms

Foundry supports the following traps for alarms from RFC 1757:

Name, OID, and Syntax	Description
alarmRisingThreshold	<p>A threshold for the sampled statistic. This object generates an event when the current sampled value is greater than or equal to this threshold, and the value at the last sampling interval was less than this threshold. This object also generates an event if the first sample after this entry becomes valid is greater than or equal to this threshold and the associated alarmStartupAlarm is equal to risingAlarm(1) or risingOrFallingAlarm(3).</p> <p>After a rising event is generated, another such event will not be generated until the sampled value falls below this threshold and reaches the alarmFallingThreshold.</p>
alarmFallingThreshold	<p>A threshold for the sampled statistic. This object generates an event when the current sampled value is less than or equal to this threshold, and the value at the last sampling interval was greater than this threshold. This object also generates an event if the first sample after this entry becomes valid is less than or equal to this threshold and the associated alarmStartupAlarm is equal to fallingAlarm(2) or risingOrFallingAlarm(3).</p> <p>After a falling event is generated, another such event will not be generated until the sampled value rises above this threshold and reaches the alarmRisingThreshold.</p>

## Foundry Traps

This section presents the objects to enable traps in Foundry devices and the traps generated for the feature. The information can be found in the following sections:

- “General Traps” on page 23-13
- “FSRP Trap” on page 23-20
- “VRRP Trap” on page 23-19
- “VSRP Traps” on page 23-20
- “OSPF Traps” on page 23-20
- “Layer 4 Traps” on page 23-26
- “ICMP Traps” on page 23-30
- “TCP Trap” on page 23-30
- “MPLS Traps” on page 23-31
- “BGP Traps” on page 23-32
- “Port Security Traps” on page 23-32
- “MRP Traps” on page 23-33
- “Traps for Wireless Features.” on page 23-33

**NOTE:** The Traps in the Foundry MIBs include the following lines in their description:

```
--#TYPE "Foundry Trap: Power Supply Failure"
--#SUMMARY "Power supply fails, error status %d."
--#ARGUMENTS { 0 }
--#SEVERITY MINOR
--#STATE OPERATIONAL
```

These lines are used by the HP OpenView network management system.

## General Traps

The table below lists the general traps generated by Foundry devices. Refer to the previous sections in this chapter to determine if traps for a feature need to be enabled (for example, OSPF traps need to be enabled.)

Trap Name and Number	Varbinds	Severity	Description and Trap Message												
snTrapChasPwrSupply (1)	snChasPwrSupplyStatus	Minor	<p>The power supply failed or is not operating normally.</p> <p>The value is a packed bit string; the power supply statuses are encoded into four bits (a nibble). The following shows the meaning of each bit:</p> <p>(bit 0 is the least significant bit).</p> <table border="1"> <thead> <tr> <th>Bit position</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>4 to 31</td> <td>Reserved</td> </tr> <tr> <td>3</td> <td>Power Supply 2 DC (0=bad, 1=good).</td> </tr> <tr> <td>2</td> <td>Power Supply 1 DC (0=bad, 1=good).</td> </tr> <tr> <td>1</td> <td>Power Supply 2 present status (0=present, 1=not-present).</td> </tr> <tr> <td>0</td> <td>Power Supply 1 present status (0=present, 1=not-present).</td> </tr> </tbody> </table> <p><b>Sample Trap Message:</b></p> <p>Power supply fails, error status &lt;snChasPwrSupplyStatus&gt;</p>	Bit position	Meaning	4 to 31	Reserved	3	Power Supply 2 DC (0=bad, 1=good).	2	Power Supply 1 DC (0=bad, 1=good).	1	Power Supply 2 present status (0=present, 1=not-present).	0	Power Supply 1 present status (0=present, 1=not-present).
Bit position	Meaning														
4 to 31	Reserved														
3	Power Supply 2 DC (0=bad, 1=good).														
2	Power Supply 1 DC (0=bad, 1=good).														
1	Power Supply 2 present status (0=present, 1=not-present).														
0	Power Supply 1 present status (0=present, 1=not-present).														
snTrapLockedAddressViolation(2)	snSwViolatorPortNumber snSwViolatorMacAddress	Minor	<p>The number of source MAC addresses received from a port is greater than the maximum number of addresses configured for that port.</p> <p><b>Sample Trap Message:</b></p> <p>Lock address violation on Port &lt;snSwViolatorPortNumber&gt; with MAC Address &lt;snSwViolatorMacAddress&gt;</p>												

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapLockedAddressViolation2(32)	snAgGblTrapMessage	Minor	<p>The number of source MAC addresses received from a port is greater than the maximum number of addresses configured for that port.</p> <p><b>Sample Trap Message:</b></p> <p>Locked address violation at interface Ethernet &lt;port&gt;, address &lt;mac&gt;</p>
snTrapModuleInserted(28)  <b>NOTE:</b> On Terathon devices, this trap is supported is software release 01.1.01.	snAgentBrdIndex	Informational	<p>A module was inserted into the chassis while the system is running.</p> <p>This trap is supported on the</p> <p><b>Sample Trap Message:</b></p> <p>Module &lt;snAgentBrdIndex&gt; was inserted to the chassis during system running</p>
snTrapModuleRemoved(29)  <b>NOTE:</b> On Terathon devices, this trap is supported is software release 01.1.01.	snAgentBrdIndex	Informational	<p>A module was removed from the chassis while the system is running.</p> <p><b>Sample Trap Message:</b></p> <p>Module &lt;snAgentBrdIndex&gt; was removed from the chassis during system running</p>
snTrapChasPwrSupplyFailed(30)	snChasPwrSupplyIndex  snChasPwrSupplyDescription	Minor	<p>A power supply in the device failed.</p> <p><b>Sample Trap Message:</b></p> <p>Power supply &lt;snChasPwrSupplyIndex&gt; (&lt;snChasPwrSupplyDescription&gt;) failed</p>
snTrapChasFanFailed(31)	snChasFanIndex  snChasFanDescription	Minor	<p>A fan in the device failed.</p> <p><b>Sample Trap Message:</b></p> <p>Fan &lt;snChasFanIndex&gt; (&lt;snChasFanDescription&gt;) failed</p>
snTrapMgmtModuleRedunStateChange(35)	snAgGblTrapMessage	Warning	<p>The management module changed its redundancy state.</p> <p><b>Sample Trap Message:</b></p> <p>Management module at slot &lt;slot-num&gt; state changed from &lt;old-state&gt; to &lt;new-state&gt;</p>



Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapTemperatureWarning(36) <b>NOTE:</b> On Terathon devices, this trap is supported is software release 01.1.01.	snAgGblTrapMessage	Critical	The actual temperature reading is above the warning temperature threshold.  <b>Sample Trap Message:</b>  Temperature <actual-temp> C degrees, warning level <warning-temp> C degrees, shutdown level <shutdown-temp> C degrees
snTrapAccessListDeny(37)	snAgGblTrapMessage	Warning	A packet was denied by an access list.  <b>Sample Trap Message (for RIP):</b>  rip filter list <id> in rip denied <IP>, <n> event(s)
snTrapMacFilterDeny(38)	snAgGblTrapMessage	Warning	A packet was denied by a MAC address filter.  <b>Sample Trap Message</b>  mac filter group denied packets on port <n> src macaddr <mac>, <n> packets
snTrapDuplicateIp(56)		Major	A duplicate IP address was detected.  <b>Sample Trap Message:</b>  Duplicate IP address detect.
snTrapRunningConfigChanged(73)	snAgGblTrapMessage	Informational	The running configuration has been changed.  <b>NOTE:</b> For Terathon devices, this trap is generated if the running configuration was changed through TFTP or Secure Copy.  <b>Sample Trap Message:</b>  Running-config was changed by user1 from telnet client 192.168.2.129.
snTrapStartupConfigChanged(74)	snAgGblTrapMessage	Informational	The start-up configuration has been changed.  <b>Sample Trap Message:</b>  Startup-config was changed from console.

Trap Name and Number	Varbinds	Severity	Description and Trap Message
<p>snTrapUserLogin(75)</p> <p><b>NOTE:</b> Available in the following releases:</p> <ul style="list-style-type: none"> <li>Enterprise Software Release 07.8.00 and later</li> <li>FastIron SuperX Release 02.0.01 and later.</li> </ul>	snAgGblTrapMessage	Informational	<p>A user logged in to a device.</p> <p><b>Sample Trap Message:</b></p> <pre>user1 login to USER EXEC mode.</pre>
<p>snTrapUserLogout(76)</p> <p><b>NOTE:</b> Available in the following releases:</p> <ul style="list-style-type: none"> <li>Enterprise Software Release 07.8.00 and later</li> <li>FastIron SuperX Release 02.0.01 and later.</li> </ul>	snAgGblTrapMessage	Informational	<p>A user logged out of a device.</p> <p><b>Sample Trap Message:</b></p> <pre>user1 logout from USER EXEC mode.</pre>
<p>snTrapClientLoginReject (110)</p> <p><b>NOTE:</b> Available in the following releases:</p> <ul style="list-style-type: none"> <li>Enterprise Software Release 07.8.00 and later</li> <li>FastIron SuperX Release 02.0.01 and later.</li> <li>FastIron Edge Switch Release 03.3.01a and later</li> </ul>	snAgGblTrapMessage	Informational	<p>A login by a Telnet or SSH client failed.</p> <p><b>Format:</b></p> <pre>telnet SSH access [by &lt;username&gt;] from src IP &lt;ip&gt;, src MAC &lt;mac&gt; rejected, &lt;n&gt; attempt(s)</pre>
<p>snTrapLocalUserConfig Change(111)</p> <p><b>NOTE:</b> Available in the following releases:</p> <ul style="list-style-type: none"> <li>Enterprise Software Release 07.8.00 and later</li> <li>FastIron SuperX Release 02.0.01 and later.</li> <li>FastIron Edge Switch Release 03.3.01a and later</li> </ul>	snAgGblTrapMessage	Informational	<p>The configuration of a local user account has been changed.</p> <p><b>Format:</b></p> <pre>user &lt;name&gt; added deleted modified from console telnet ssh web snmp</pre>

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapVlanConfigChange(112)	snAgGblTrapMessage	Informational	A VLAN configuration has been changed. <b>Format:</b> vlan <vlan-id> added deleted modified from console telnet ssh web snmp session
<p><b>NOTE:</b> Available in the following releases:</p> <ul style="list-style-type: none"> <li>Enterprise Software Release 07.8.00 and later</li> <li>FastIron SuperX Release 02.0.01 and later.</li> <li>FastIron Edge Switch Release 03.3.01a and later</li> </ul>			
snTrapAclConfigChange(113)	snAgGblTrapMessage	Informational	An ACL configuration has been changed. <b>Format:</b> ACL <acl-id> added deleted modified from console telnet ssh web snmp session
<p><b>NOTE:</b> Available in the following releases:</p> <ul style="list-style-type: none"> <li>Enterprise Software Release 07.8.00 and later</li> <li>FastIron SuperX Release 02.0.01 and later.</li> <li>FastIron Edge Switch Release 03.3.01a and later</li> </ul>			
snTrapMacFilterConfigChange(114)	snAgGblTrapMessage	Informational	A MAC filter configuration has been changed. <b>Format:</b> MAC Filter <added deleted> from console telnet ssh web snmp session (filter id=<id>, src mac=<mac> any, dst mac=<mac> any)
<p><b>NOTE:</b> Available in the following releases:</p> <ul style="list-style-type: none"> <li>Enterprise Software Release 07.8.00 and later</li> <li>FastIron SuperX Release 02.0.01 and later.</li> <li>FastIron Edge Switch Release 03.3.01a and later</li> </ul>			

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapSNMPConfigChange(115)	snAgGblTrapMessage	Informational	SNMP configuration has been changed.  <b>Format:</b>  [read-only community read-write community contact location user group view engineId trap host] "<value>" deleted added modified from console telnet ssh web snmp session  <b>NOTE:</b> A contact, location, user, group, view, trap host name may be displayed for <value>.
snTrapSyslogConfigChange(116)	snAgGblTrapMessage	Informational	Syslog configuration has been changed.  <b>Format:</b>  Syslog server <ip-address> deleted added modified from console telnet ssh web snmp  or  Syslog operation enabled disabled from console telnet ssh web snmp
snTrapPasswordConfigChange(117)	snAgGblTrapMessage	Informational	The enable or line password has been changed  <b>Format:</b>  Enable <super port-config read-only> password deleted added modified from console telnet ssh web snmp  or  Line password deleted added modified from console telnet ssh web snmp

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapServerStatusChange(118)	snAgGblTrapMessage	Informational	SNMP trap server has been enabled or disabled.  <b>Format:</b>  SSH Telnet server enabled disabled from console telnet ssh web snmp session [by <user> <username>]
<p><b>NOTE:</b> Available in the following releases:</p> <ul style="list-style-type: none"> <li>Enterprise Software Release 07.8.00 and later</li> <li>FastIron SuperX Release 02.0.01 and later.</li> <li>FastIron Edge Switch Release 03.3.01a and later</li> </ul>			
snTrapPortPriorityChange(122)	snAgGblTrapMessage	Informational	This trap is generated when a port's priority is changed.  <b>Format:</b>  Port <port-number> priority changed to <new-priority>
<p><b>NOTE:</b> Available in the following releases:</p> <ul style="list-style-type: none"> <li>FastIron SuperX Release 02.0.01 and later.</li> <li>FastIron Edge Switch Release 03.3.01a and later</li> <li>Service Provider Release 09.2.00</li> </ul>			

## VRRP Trap

Only devices that support VRRP can use the following trap:

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapVrrpIfStateChange(34)	snAgGblTrapMessage	Warning	A VRRP routing device changed state from master to backup or vice-versa.  <b>Sample Trap Message:</b>  VRRP intf state changed, intf <port>, vrid <id>, state <new-state>.

## FSRP Trap

Only devices that support FSRP can use the FSRP trap object.

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapFsrpIfStateChange(33)	snAgGblTrapMessage	Informational	An FSRP routing device changed state from active to standby or vice-versa.  <b>Sample Trap Message:</b>  SRP_FSRP intf state changed, intf <port>, addr <ip>, state <new-state>.

## VSRP Traps

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapVsrpStateChange(81)	snAgGblTrapMessage	Informational	An VSRP routing device changed its state
snTrapVsrpCamError(82)	snAgGblTrapMessage	Informational	A VSRP CAM error has occurred.

## OSPF Traps

**NOTE:** Beginning with software release 07.6.03, Foundry devices support RFC 1850 instead of the objects in this section. Also, BigIron MG8 and NetIron 40G support RFC 1850.

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapOspfIfStateChange(3)	snOspfRouterId (The originator of the trap)  snOspfIfStatusIpAddress  snOspfIfStatusState (The new state)	Informational	There has been a change in the state of a non-virtual OSPF interface. This trap should be generated when the interface state regresses (e.g., goes from Dr to Down) or progresses to a terminal state (i.e., Point-to-Point, DR Other, Dr, or Backup).  <b>Sample Trap Message:</b>  OSPF router id <snOspfRouterId>, interface <snOspfIfStatusIpAddress> state changed to <snOspfIfStatusState>.

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapOspfVirtIfStateChange(4)	snOspfRouterId (The originator of the trap)  snOspfVirtIfStatusAreaID  snOspfVirtIfStatusNeighbor  snOspfVirtIfStatusState (The new state)	Informational	<p>There has been a change in the state of an OSPF virtual interface. This trap should be generated when the interface state regresses (e.g., goes from Point-to-Point to Down) or progresses to a terminal state (i.e., Point-to-Point).</p> <p><b>Sample Trap Message:</b></p> <pre>OSPF router id &lt;snOspfRouterId&gt;, virtual interface area id &lt;snOspfVirtIfStatusAreaID&gt; neighbor &lt;snOspfVirtIfStatusNeighbor&gt; state changed to &lt;snOspfVirtIfStatusState&gt;.</pre>
snOspfNbrStateChange(5)	snOspfRouterId (The originator of the trap)  snOspfNbrIpAddr  snOspfNbrRtrId  snOspfNbrState (The new state)	Informational	<p>There has been a change in the state of a non-virtual OSPF neighbor. This trap should be generated when the neighbor state regresses (e.g., goes from Attempt or Full to 1-Way or Down) or progresses to a terminal state (e.g., 2-Way or Full). When an neighbor transitions from or to Full on non-broadcast multi-access and broadcast networks, the trap should be generated by the designated router. A designated router transitioning to Down will be noted by ospfNbrStateChange.</p> <p><b>Sample Trap Message:</b></p> <pre>OSPF router id &lt;snOspfRouterId&gt; neighbor area &lt;snOspfNbrIpAddr&gt;, neighbor router id &lt;snOspfNbrRtrId&gt; state changed to &lt;snOspfNbrState&gt;.</pre>
snOspfVirtNbrStateChange(6)	snOspfRouterId (The originator of the trap)  snOspfVirtNbrArea  snOspfVirtNbrRtrId  snOspfVirtNbrState (The new state)	Informational	<p>There has been a change in the state of an OSPF virtual neighbor. This trap should be generated when the neighbor state regresses (e.g., goes from Attempt or Full to 1-Way or Down) or progresses to a terminal state (e.g., Full).</p> <p><b>Sample Trap Message:</b></p> <pre>OSPF router id &lt;snOspfRouterId&gt; virtual neighbor area &lt;snOspfVirtNbrArea&gt;, virtual neighbor router id &lt;snOspfVirtNbrRtrId&gt; state changed to &lt;snOspfVirtNbrState&gt;.</pre>

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snOspfIfConfigError(7)	<p>snOspfRouterId (The originator of the trap)</p> <p>snOspfIfStatusIpAddress</p> <p>snOspfPacketSrc (The source IP address)</p> <p>snOspfConfigErrorType (Type of error)</p> <p>snOspfPacketType</p>	Major	<p>A packet has been received on a non-virtual interface from a router whose configuration parameters conflict with this router's configuration parameters.</p> <p><b>NOTE:</b> The event optionMismatch should cause a trap only if it prevents an adjacency from forming.</p> <p><b>Trap Message:</b></p> <p>Configuration error type &lt;snOspfConfigErrorType&gt; with packet type &lt;snOspfPacketType&gt; has been received on interface &lt;snOspfIfStatusIpAddress&gt;, router id &lt;snOspfRouterId&gt; from &lt;snOspfPacketSrc&gt;.</p>
snOspfVirtIfConfigError(8)	<p>snOspfRouterId (The originator of the trap)</p> <p>snOspfVirtIfStatusAreaID</p> <p>snOspfVirtIfStatusNeighbor</p> <p>snOspfConfigErrorType (Type of error)</p> <p>snOspfPacketType</p>	Major	<p>A packet has been received on a virtual interface from a router whose configuration parameters conflict with this router's configuration parameters.</p> <p><b>NOTE:</b> The event optionMismatch should cause a trap only if it prevents an adjacency from forming.</p> <p><b>Trap Message:</b></p> <p>Configuration error type &lt;snOspfConfigErrorType&gt; with packet type &lt;snOspfPacketType&gt; has been received on virtual interface area id &lt;snOspfVirtIfStatusAreaID&gt;, router id &lt;snOspfRouterId&gt; from neighbor &lt;snOspfVirtIfStatusNeighbor&gt;.</p>
snOspfIfAuthFailure(9)	<p>snOspfRouterId (The originator of the trap)</p> <p>snOspfIfStatusIpAddress</p> <p>snOspfPacketSrc (The source IP address)</p> <p>snOspfConfigErrorType (authTypeMismatch or authFailure)</p> <p>snOspfPacketType</p>	Minor	<p>A packet has been received on a non-virtual interface from a router whose authentication key or authentication type conflicts with this router's authentication key or authentication type.</p> <p><b>Trap Message:</b></p> <p>OSPF authentication failed. Router ID &lt;snOspfRouterId&gt;, Interface &lt;snOspfIfStatusIpAddress&gt;, packet src &lt;snOspfPacketSrc&gt;, error type &lt;snOspfConfigErrorType&gt; and packet type &lt;snOspfPacketType&gt;.</p>



Trap Name and Number	Varbinds	Severity	Description and Trap Message
snOspfVirtIfAuthFailure (10)	snOspfRouterId (The originator of the trap)  snOspfVirtIfStatusAreaID  snOspfVirtIfStatusNeighbor  snOspfConfigErrorType (authTypeMismatch or authFailure)  snOspfPacketType	Minor	A packet has been received on a virtual interface from a router whose authentication key or authentication type conflicts with this router's authentication key or authentication type.  <b>Trap Message:</b>  OSPF authentication failed. Router ID <snOspfRouterId>, virtual interface <snOspfVirtIfStatusAreaID>, Neighbor <snOspfVirtIfStatusNeighbor>, Error type <snOspfConfigErrorType> and packet type <snOspfPacketType>.
snOspfIfRxBadPacket (11)	snOspfRouterId (The originator of the trap)  snOspfIfStatusIpAddress  snOspfPacketSrc (The source IP address)  snOspfPacketType	Warning	An OSPF packet has been received on a non-virtual interface that cannot be parsed.  <b>Trap Message:</b>  OSPF Router Id <snOspfRouterId>, interface <snOspfIfStatusIpAddress> receive bad packet (type <snOspfPacketType>) from <snOspfPacketSrc>.
snOspfVirtIfRxBadPacket(12)	snOspfRouterId (The originator of the trap)  snOspfVirtIfStatusAreaID  snOspfVirtIfStatusNeighbor  snOspfPacketType	Warning	An OSPF packet has been received on a virtual interface that cannot be parsed.  <b>Trap Message:</b>  OSPF router id <snOspfRouterId>, virtual interface <snOspfVirtIfStatusAreaID> received bad packet (type <snOspfPacketType>) from neighbor <snOspfVirtIfStatusNeighbor>.

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snOspfTxRetransmit(13)	snOspfRouterId (The originator of the trap)  snOspfIfStatusIpAddress  snOspfNbrRtrId (Destination)  snOspfPacketType  snOspfLsdbType  snOspfLsdbLsId  snOspfLsdbRouterId	Warning	An OSPF packet has been retransmitted on a non- virtual interface. All packets that may be re- transmitted are associated with an LSDB entry. The LS type, LS ID, and Router ID are used to identify the LSDB entry.  <b>Trap Message:</b>  OSPF router id <snOspfRouterId> interface <snOspfIfStatusIpAddress> retransmitted packet type <snOspfPacketType>, LSDB type <snOspfLsdbType>, LSDB LS ID <snOspfLsdbLsId> and LSDB router id <snOspfLsdbRouterId> to Neighbor router id <snOspfNbrRtrId>.
ospfVirtIfTxRetransmit(14)	snOspfRouterId (The originator of the trap)  snOspfVirtIfStatusAreaID  snOspfVirtIfStatusNeighbor  snOspfPacketType  snOspfLsdbType  snOspfLsdbLsId  snOspfLsdbRouterId	Warning	An OSPF packet has been retransmitted on a virtual interface. All packets that may be retransmitted are associated with an LSDB entry. The LS type, LS ID, and Router ID are used to identify the LSDB entry.  <b>Trap Message:</b>  OSPF router id <snOspfRouterId>, virtual interface area id <snOspfVirtIfStatusAreaID> retransmitted packet type <snOspfPacketType>, LSDB type <snOspfLsdbType>, LSDB LS ID <snOspfLsdbLsId> and LSDB router id <snOspfLsdbRouterId> to Neighbor <snOspfVirtIfStatusNeighbor>.

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snOspfOriginateLsa(15)	snOspfRouterId (The originator of the trap)  snOspfLsdbAreaId (0.0.0.0 for AS Externals)  snOspfLsdbType  snOspfLsdbLsId  snOspfLsdbRouterId	Informational	This router originated a new LSA. This trap should not be invoked for simple refreshes of LSAs (which happens every 30 minutes), but instead will only be invoked when an LSA is (re-originated due to a topology change. Additionally, this trap does not include LSAs that are being flushed because they have reached MaxAge  <b>Trap Message:</b>  New LSA (area id <snOspfLsdbAreaId>, type <snOspfLsdbType>, LS Id <snOspfLsdbLsId> and router id <snOspfLsdbRouterId>) has been originated by router id <snOspfRouterId>.
snOspfMaxAgeLsa(16)	snOspfRouterId (The originator of the trap)  snOspfLsdbAreaId (0.0.0.0 for AS Externals)  snOspfLsdbType  snOspfLsdbLsId  snOspfLsdbRouterId	Warning	One of the LSA in the router's link-state database has aged to MaxAge.  <b>Trap Message:</b>  The LSA (area id <snOspfLsdbAreaId>, type <snOspfLsdbType>, LS Id <snOspfLsdbLsId> and router id <snOspfLsdbRouterId>) in router id <snOspfRouterId> link-state database has aged to maximum age.
snOspfLsdbOverflow (17)	snOspfRouterId (The originator of the trap)  snOspfExtLsdbLimit	Warning	The number of LSAs in the router's link-state database has exceeded the ospfExtLsdbLimit.  <b>Trap Message:</b>  The number of LSAs in the OSPF router id <snOspfRouterId> link-state database has exceeded <snOspfExtLsdbLimit>.
snOspfLsdbApproaching Overflow(18)	snOspfRouterId (The originator of the trap)  snOspfExtLsdbLimit	Informational	The number of LSAs in the router's link-state database has exceeded ninety percent of the ospfExtLsdbLimit.  <b>Trap Message:</b>  The number of LSAs in the OSPF router id <snOspfRouterId> link-state database has exceeded ninety percent of <snOspfExtLsdbLimit>.

## Layer 4 Traps

The following table presents the traps that can be generated for Layer 4 functionalities.

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapL4MaxSessionLimitReached(19)	snL4MaxSessionLimit	Warning	<p>The maximum number of connections has been reached.</p> <p><b>Trap Message:</b></p> <p>SLB maximum number of connections &lt;snL4MaxSessionLimit&gt; has been reached.</p>
snTrapL4TcpSynLimitReached(20)	snL4TcpSynLimit	Warning	<p>The TCP SYN limits have been reached.</p> <p><b>Trap Message:</b></p> <p>SLB TCP Syn limits &lt;snL4TcpSynLimit&gt; have been reached.</p>
snTrapL4RealServerUp(21)	snL4TrapRealServerIP snL4TrapRealServerName	Informational	<p>The load balancing real server is up.</p> <p><b>Trap Message:</b></p> <p>SLB real server &lt;snL4TrapRealServerIP&gt; &lt;snL4TrapRealServerName&gt; is up.</p>
snTrapL4RealServerDown(22)	snL4TrapRealServerIP snL4TrapRealServerName	Informational	<p>The load balancing real server is down.</p> <p><b>Trap Message:</b></p> <p>SLB real server &lt;snL4TrapRealServerIP&gt; &lt;snL4TrapRealServerName&gt; is down.</p>
snTrapL4RealServerPortUp(23)	snL4TrapRealServerIP snL4TrapRealServerName snL4TrapRealServerPort	Informational	<p>The load balancing real server TCP port is up.</p> <p><b>Trap Message:</b></p> <p>SLB real server port &lt;snL4TrapRealServerIP&gt; &lt;snL4TrapRealServerName&gt; &lt;snL4TrapRealServerPort&gt; is up</p>
snTrapL4RealServerPortDown(24)	snL4TrapRealServerIP snL4TrapRealServerName snL4TrapRealServerPort	Informational	<p>The load balancing real server TCP port is down.</p> <p><b>Trap Message:</b></p> <p>SLB real server port &lt;snL4TrapRealServerIP&gt; &lt;snL4TrapRealServerName&gt; &lt;snL4TrapRealServerPort&gt; is.</p>

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapL4RealServerMaxConnectionLimitReached(25)	snL4TrapRealServerIP snL4TrapRealServerName snL4TrapRealServerCurConnections	Warning	The real server reached its maximum number of connections.  <b>Trap Message:</b>  SLB real server <snL4TrapRealServerIP> <snL4TrapRealServerName> maximum connection <snL4TrapRealServerCurConnections> has been reached.
snTrapL4RealServerResponseTimeLowerLimit(67)	snAgGblTrapMessage	Warning	The real server average response time exceeded the lower threshold.  <b>Trap Message:</b>  Port <port-num> on server <server-name>: <IP>: Avg response time <num> has exceeded lower threshold
snTrapL4RealServerResponseTimeUpperLimit(68)	snAgGblTrapMessage	Warning	The real server average response time exceeded the upper threshold.  <b>Trap Message:</b>  Port <port-num> on server <server-name>: <IP>: Avg response time <num> has exceeded upper threshold; Bringing down the port...
snTrapL4BecomeStandby(26)		Warning	The Server Load Balancing switch changed its state from active to standby.  <b>Trap Message:</b>  SLB changes state from active to standby.
snTrapL4BecomeActive(27)		Warning	The Server Load Balancing switch changed its state from standby to active.  <b>Trap Message:</b>  SLB changes state from standby to active.
snTrapL4GslbRemoteUp(39)	snAgGblTrapMessage	Warning	The connection to the remote ServerIron is up.  <b>Trap Message:</b>  L4 gslb connection to site <name> SI <agent IP> <SI name> is up

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapL4GslbRemoteDown(40)	snAgGblTrapMessage	Warning	<p>The connection to the remote ServerIron is down.</p> <p><b>Trap Message:</b></p> <p>L4 gslb connection to site &lt;name&gt; SI &lt;agent IP&gt; &lt;SI name&gt; is down</p>
snTrapL4GslbRemoteControllerUp(41)	snAgGblTrapMessage	Warning	<p>The connection to the GSLB ServerIron is up.</p> <p><b>Trap Message:</b></p> <p>L4 gslb connection to gslb SI &lt;IP&gt; is up</p>
snTrapL4GslbRemoteControllerDown(42)	snAgGblTrapMessage	Warning	<p>The connection to the GSLB ServerIron is down.</p> <p><b>Trap Message:</b></p> <p>L4 gslb connection to gslb SI &lt;IP&gt; is down</p>
snTrapL4GslbHealthCheckIpUp(43)	snAgGblTrapMessage	Warning	<p>The GSLB health check for an address changed from the down to the active state.</p> <p><b>Trap Message:</b></p> <p>L4 gslb health-check &lt;IP&gt; of &lt;subname&gt;.&lt;zonenumber&gt; status changed to up</p>
snTrapL4GslbHealthCheckIpDown(44)	snAgGblTrapMessage	Warning	<p>The GSLB health check for an address changed from the active to the down state.</p> <p><b>Trap Message:</b></p> <p>L4 gslb health-check &lt;IP&gt; of &lt;subname&gt;.&lt;zonenumber&gt; status changed to down</p>
snTrapL4GslbHealthCheckIpPortUp(45)	snAgGblTrapMessage	Warning	<p>A port for a health check address is up.</p> <p><b>Trap Message:</b></p> <p>L4 gslb health-check &lt;IP&gt; of &lt;subname&gt;.&lt;zonenumber&gt; port &lt;server-port&gt; is up</p>
snTrapL4GslbHealthCheckIpPortDown(46)	snAgGblTrapMessage	Warning	<p>A port for a health check address is down.</p> <p><b>Trap Message:</b></p> <p>L4 gslb health-check &lt;IP&gt; of &lt;subname&gt;.&lt;zonenumber&gt; port &lt;server-port&gt; is down</p>

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapL4FirewallBecomeStandby(47)		Major	The Server Load Balancing switch firewall changed its state from active to standby.  <b>Trap Message:</b>  firewall group #<group> become standby
snTrapL4FirewallBecomeActive(48)		Major	The Server Load Balancing switch firewall changed its state from standby to active.  <b>Trap Message:</b>  firewall group #<group> become active
snTrapL4FirewallPathUp(49)		Minor	The Server Load Balancing switch firewall path is up.  <b>Trap Message:</b>  firewall path up target <IP> nexthop <IP> path <num> port <num>
snTrapL4FirewallPathDown(50)		Minor	The Server Load Balancing switch firewall path is down.  <b>Trap Message:</b>  Firewall path down target <IP> nexthop <IP> path <num> port <num>
snTrapL4ContentVerification(55)		Informational	The HTTP match list pattern has been found.  <b>Trap Message:</b>  HTTP match-list pattern is found.
snTrapL4TcpAttackRateExceedMax(69)	snAgGblTrapMessage	Warning	The TCP attack rate exceeds the configured maximum TCP attack rate.  <b>Trap Message:</b>  L4 TCP Attack Rate Exceed Max
snTrapL4TcpAttackRateExceedThreshold(70)	snAgGblTrapMessage	Warning	The TCP attack rate exceeds 80% of the configured maximum.  <b>Trap Message:</b>  L4 TCP Attack Rate Exceed Threshold
snTrapL4ConnectionRateExceedMax(71)	snAgGblTrapMessage	Critical	Layer 4 connection rate exceeds the configured maximum.  <b>Trap Message:</b>  L4 Connection Rate Exceed Max

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapL4ConnectionRateExceedThreshold	snAgGblTrapMessage	Warning	<p>The Layer 4 connection rate exceeds 80% of the configured maximum.</p> <p><b>Trap Message:</b></p> <p>L4 Connection Rate Exceed Threshold</p>

## ICMP Traps

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapIcmpLocalExceedBurst(51)	snAgGblTrapMessage	Warning	<p>Incoming ICMP exceeded the maximum local burst packets.</p> <p><b>Trap Message:</b></p> <p>Local ICMP exceeds &lt;num&gt; burst packets, stopping for &lt;num&gt; seconds!!</p>
snTrapIcmpTransitExceedBurst(52)	snAgGblTrapMessage	Warning	<p>Transit ICMP exceeded the maximum transit burst.</p> <p><b>Trap Message:</b></p> <p>Transit ICMP in interface &lt;port-num&gt; exceeds &lt;num&gt; burst packets, stopping for &lt;num&gt; seconds!!</p>

## TCP Trap

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapTcpLocalExceedBurst(53)	snAgGblTrapMessage	Warning	<p>Incoming TCP SYN exceeded the maximum local burst packets.</p> <p><b>Trap Message:</b></p> <p>Local TCP exceeds &lt;num&gt; burst packets, stopping for &lt;num&gt; seconds!!</p>



Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapTcpTransitExceedBurst(54)	snAgGblTrapMessage	Warning	<p>Transit TCP exceeded the maximum transit burst packets.</p> <p><b>Trap Message:</b></p> <p>Transit TCP in interface &lt;port-num&gt; exceeds &lt;num&gt; burst packets, stopping for &lt;num&gt; seconds!!</p> <p>On ServerIron software release 09.0.00S, this trap is generated when the number of source MAC addresses received from a port is greater than the maximum number of MAC addresses configured for that port. The trap message displays the port name and port number.</p> <p><b>Trap Message:</b></p> <p>Locked address violation at &lt;port-name&gt; &lt;port-num&gt;, address &lt;mac&gt;</p>

## MPLS Traps

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapMplsProblem(57)		Major	<p>MPLS problem detected.</p> <p><b>Trap Message:</b></p> <p>MPLS Problem detect.</p>
snTrapMplsException(58)		Major	<p>MPLS exception detected.</p> <p><b>Trap Message:</b></p> <p>MPLS Exception detect.</p>
snTrapMplsAudit(59)		Informational	<p>MPLS audit trap.</p> <p><b>Trap Message:</b></p> <p>MPLS Audit Trap.</p>
snTrapMplsDeveloper(60)		Informational	<p>MPLS developer trap.</p> <p><b>Trap Message:</b></p> <p>MPLS Developer Trap.</p>

## BGP Traps

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapBgpPeerUp(65)	snAgGblTrapMessage	Informational	The BGP peer is up. <b>Trap Message:</b> BGP Peer <IP> UP(ESTABLISHED)
snTrapBgpPeerDown(66)	snAgGblTrapMessage	Informational	The BGP peer is down. <b>Trap Message:</b> BGP Peer <IP> DOWN (<reason-string>)\n

## Port Security Traps

The Port Security feature enables Foundry device to learn a limited number of “secure” MAC addresses on an interface. The interface will forward only those packets with source MAC addresses that match these secure addresses. If the interface receives MAC addresses that are included in its secure MAC list, the Foundry device generates the following traps:

**NOTE:** This trap applies to ports that have the Port Security feature enabled. Port security is available beginning with IronWare software release 07.5.04A.

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapPortSecurityViolation(77)	snAgGblTrapMessage	Minor	Packets from unknown MAC address are dropped. <b>Sample Trap Message:</b> Foundry Trap: Port Security Violation
snTrapPortSecurityShutdown(78)	snAgGblTrapMessage	Minor	The port is disabled for the amount of time configured using the <b>violation shutdown &lt;minutes&gt;</b> port security CLI command. <b>Sample Trap Message:</b> Foundry Trap: Port Security Violation Cause Shutdown
snTrapPortPriorityChange(122)	snAgGblTrapMessage	Informational	This trap is generated when a port's priority is changed. <b>Format:</b> Port <port-number> priority changed to <new-priority>

## MRP Traps

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapMrpStateChange TRAP(79)	snAgGblTrapMessage	Informational	An MRP state occurred.
snTrapMrpCamError(80)	snAgGblTrapMessage	Informational	An MRP CAM error occurred.

## Traps for Wireless Features.

**NOTE:** The traps in the sections below are available on devices that support the wireless features, such as automatic discovery and configuration (ADC), wireless mobility, and others.

### Wireless Feature Traps

The IronPoint–FES generates the following general traps for wireless feature support. See the sections below on specific wireless features to determine what traps are generated for that feature.

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapWirelessStationStateChange(127)	snAgGblTrapMessage	Alert	<p>The state of the wireless station (client) that is associated with this IronPoint–FES through the access point has changed.</p> <p><b>Message Format</b></p> <p>&lt;date-time&gt;:N: New Station &lt;mac-address&gt; discovered   removed</p>
snTrapWirelessSappStateChange(129)	snAgGblTrapMessage	Alert	<p>The state of the communication between an access point and this IronPoint–FES has changed.</p> <p><b>Message Format</b></p> <p>&lt;date-time&gt;:N:AP &lt;AP-IP-address&gt; has changed state from &lt;old-state&gt; to&lt;new-state&gt;</p>

## Wireless Mobility Traps

The following traps are generated by the IronPoint–FES for Wireless Mobility.

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapWirelessIrpPeerStateChange(126)	snAgGblTrapMessage	Alert	<p>The state of an IronPoint–FES peer has changed.</p> <p><b>Message Format</b></p> <p>&lt;date-time&gt;:N:Mobility Peer &lt;IronPoint–FES-IP-address&gt; has changed state from &lt;old-state&gt; to &lt;new-state&gt;</p>
snTrapWirelessStationRoamingEventTriggered(128)	snAgGblTrapMessage	Alert	<p>A wireless station (client) roamed from or to the access point that is attached to this IronPoint–FES.</p> <p><b>Message Format</b></p> <p>&lt;date-time&gt; : N:Station 0009.5b66.eac6 has roamed to switch &lt;IronPoint–FES-IP-address&gt;</p>

## ADC Trap

The following SNMP trap is generated for the ADC feature.

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapPnPStatusChange(125)	snAgGblTrapMessage	Informational	<p>The access point's ADC status changed.</p> <p><b>Message Format</b></p> <p>&lt;date-time&gt;:N:PnP status of AP MAC address &lt;mac-address&gt; at port &lt;port-number&gt; has changed from &lt;old state&gt; to &lt;new-state&gt;</p>

## Automatic Port Disablement Traps

The following traps are generated for the Automatic Port Deactivation feature.

Trap Name and Number	Varbinds	Severity	Description and Trap Message
snTrapAutoPortDisableTrigger(123)	snAgGblTrapMessage	Alerts	<p>The specified interface has been deactivated and disabled.</p> <p><b>Message Format</b></p> <p>Automatic port disable was triggered at port &lt;port-number&gt;</p>
snTrapAutoPortDisableRelease(124)	snAgGblTrapMessage	Alerts	<p>The disabled interface has been released and re-enabled.</p> <p><b>Message Format</b></p> <p>Automatic port disable was released at port &lt;port-number&gt;</p>

## Examples

The following is an example of how to generate an SNMP trap for an RMON event.

If you want to configure a Foundry device to send an SNMP trap when CPU utilization exceeds 50 percent, do the following:

1. Configure an RMON alarm with an ID of 1 that checks for snAgGblCpuUtil1MinAvg every 300 sec. In every sample, check if the CPU utilization falls exceeds 50 percent. If it does, send an event(id 1) with owner name as "Tom". The event trigger is re-armed, when the falling-threshold value falls below 45%

```
BigIron(config)# rmon alarm 1 snAgGblCpuUtil1MinAvg.0 300 absolute rising-
threshold 50 1 falling-threshold 45 65535 owner Tom
```

2. Configure an RMON event with an ID of 1, which sends an send a SNMP trap that contains the community string "public", some description, and owner Tom whenever CPU utilization exceeds 50 percent.

```
BigIron(config)# rmon event 1 description "CPU Utilization exceeds 50%" trap
public owner Tom
```



---

# Appendix A

## Using SNMP to Upgrade Software

This chapter presents some of the common procedures for using SNMP MIB objects to manage Foundry devices. You can use a third-party SNMP management application such as HP OpenView to upgrade software on a Foundry device.

---

**NOTE:** In software releases earlier than 07.5.00, the SNMP agent does not check for type validity with the SNMP version. In software release 07.5.00 and above, the SNMP agent does not send a reply for a varbind, if the type of the varbind is not a known type for that version of SNMP. For example, MIB objects of type Counter64 cannot be retrieved using a v1 packet, as Counter64 is a v2c and v3 type.

---

**NOTE:** Make sure you use the correct procedure for your device and processor type. For example, do not use the Management Processor procedure to upgrade the Switching Processors on a module.

---

**NOTE:** The syntax shown in this section assumes that you have installed HP OpenView in the "/usr" directory.

---

**NOTE:** Foundry recommends that you make a backup copy of the startup-config file before you upgrade the software. If you need to run an older release, you will need to use the backup copy of the startup-config file.

---

This appendix presents the following procedures:

- "Upgrading a Stackable Device or a Chassis Module's Management Processor" on page A-1
- "Upgrading Switching Processors on a Chassis Device" on page A-2

### Upgrading a Stackable Device or a Chassis Module's Management Processor

Use this procedure to upgrade the following:

- A Stackable device
- A management II, III, or IV module
- The management processor on the Velocity Management Module (VM1)

To upgrade flash code on the Management Processor:

1. Configure a read-write community string on the Foundry device, if one is not already configured. To configure a read-write community string, enter the following command from the global CONFIG level of the CLI:

**snmp-server community** <string> **ro** | **rw**

where <string> is the community string and can be up to 32 characters long.

2. On the Foundry device, enter the following command from the global CONFIG level of the CLI:

**no snmp-server pw-check**

This command disables password checking for SNMP set requests. If password checking is enabled (the default) and a third-party SNMP management application does not add a password to the password field when it sends SNMP set requests to a Foundry device, the Foundry device rejects the request.

3. From the command prompt in the UNIX shell, enter the following command:

```
/usr/OV/bin/snmpset -c <rw-community-string> <fdry-ip-addr> 1.3.6.1.4.1.1991.1.1.2.1.5.0  
ipaddress <tftp-ip-addr> 1.3.6.1.4.1.1991.1.1.2.1.6.0 octetstringascii <file-name>  
1.3.6.1.4.1.1991.1.1.2.1.7.0 integer <command-integer>
```

where:

<rw-community-string> is a read-write community string configured on the Foundry device.

<fdry-ip-addr> is the Foundry device's IP address.

<tftp-ip-addr> is the TFTP server's IP address.

<file-name> is the image file name.

<command-integer> is one of the following:

- **20** – Download the flash code into the device's primary flash area.
- **22** – Download the flash code into the device's secondary flash area.

## Upgrading Switching Processors on a Chassis Device

Use this procedure to upgrade the Switching Processors on the following types of modules:

- Velocity Management Module (VM1)
- OC-3, OC-12, and OC-48 non-Network Processor Architecture (NPA) POS modules
- OC-48 NPA POS modules
- ATM modules

To upgrade flash code on the Switching Processors:

1. Configure a read-write community string on the Foundry device, if one is not already configured. To configure a read-write community string, enter the following command from the global CONFIG level of the CLI:

**snmp-server community** <string> **ro** | **rw**

where <string> is the community string and can be up to 32 characters long.

2. On the Foundry device, enter the following command from the global CONFIG level of the CLI:

**no snmp-server pw-check**

This command disables password checking for SNMP set requests. This command disables password checking for SNMP set requests. If password checking is enabled (the default) and a third-party SNMP management application does not add a password to the password field when it sends SNMP set requests to a Foundry device, the Foundry device rejects the request.

3. From the command prompt in the UNIX shell, enter the following command:

```
/usr/OV/bin/snmpset -c <rw-community-string> <fdry-ip-addr> 1.3.6.1.4.1.1991.1.1.2.1.5.0  
ipaddress <tftp-ip-addr> 1.3.6.1.4.1.1991.1.1.2.1.6.0 octetstringascii <file-name>  
1.3.6.1.4.1.1991.1.1.2.1.56.0 integer <module-type>
```



**1.3.6.1.4.1.1991.1.1.2.1.57.0 integer <slotnum>**  
**1.3.6.1.4.1.1991.1.1.2.1.7.0 integer <command-integer>**

where:

<rw-community-string> is a read-write community string configured on the Foundry device.

<fdry-ip-addr> is the Foundry device's IP address.

<tftp-ip-addr> is the TFTP server's IP address.

<file-name> is the image file name.

<module-type> is one of the following:

- **2** – VM1 module.
- **3** – OC-3, OC-12, and OC-48 non-Network Processor Architecture (NPA) POS modules.
- **4** – OC-48 NPA POS modules.
- **5** – ATM module.

<slotnum> is the slot that contains the module you are upgrading. To upgrade all modules of the type you specified, enter 0 (zero):

<command-integer> is one of the following:

- **24** – Download the flash code into the device's primary flash area.
- **25** – Download the flash code into the device's secondary flash area.



# Index by Object Name

Use this index to search for a MIB object by name.

accessIron 3-9  
dcrs7504Router 3-9  
dcrs7504Switch 3-9  
dcrs7508Router 3-9  
dcrs7508Switch 3-9  
dcrs7515Router 3-9  
dcrs7515Switch 3-9  
digitalChina 3-9  
edgelron 3-8  
edgelronMib 3-8  
edgelronType2 3-8  
edgelronType2Mib 3-8  
mplsActiveLsps 19-1  
mplsConfiguredLsps 19-1  
mplsLspAge 19-2  
mplsLspEntry 19-2  
mplsLspFrom 19-3  
mplsLspIndex 19-2  
mplsLspLastTransition 19-3  
mplsLspName 19-2  
mplsLspPackets 19-2  
mplsLspPrimaryTimeUp 19-2  
mplsLspSignalingProto 19-2  
mplsLspState 19-2  
mplsLspTable 19-1  
mplsLspTimeUp 19-2  
mplsLspTo 19-3  
mplsLspTransitions 19-2  
mplsPathName 19-3  
mplsPathType 19-3  
mplsVersion 19-1  
ospfVirtIfTxRetransmit (14) 23-24  
sn4802Router 3-3  
sn4802SI 3-4  
sn4802Switch 3-3  
snAccountingCommandLevel 6-10  
snAccountingCommandMethods 6-10  
snAccountingExec 6-10  
snAccountingSystem 6-10  
snAgAclAction 8-8  
snAgAclBindToPortEntry 8-15  
snAgAclBindToPortTable 8-15  
snAgAclComments 8-13  
snAgAclDestinationIp 8-10  
snAgAclDestinationMask 8-10  
snAgAclDestinationOperand1 8-11  
snAgAclDestinationOperand2 8-11  
snAgAclDestinationOperator 8-11  
snAgAclDscpMapping 8-14  
snAgAclDscpMarking 8-13  
snAgAclEntry 8-8  
snAgAclEstablished 8-12  
snAgAclFlowCounter 8-12  
snAgAclGblCurRowIndex 8-7  
snAgAclIcmpCode 8-14  
snAgAclIfBindDirection 8-17  
snAgAclIfBindEntry 8-17  
snAgAclIfBindIndex 8-17

snAgAcIfBindNameString 8-17  
 snAgAcIfBindNum 8-17  
 snAgAcIfBindTable 8-17  
 snAgAcIfBindVifPortList 8-17  
 snAgAcIfRowStatus 8-18  
 snAgAcIfIndex 8-8  
 snAgAcIfPriority 8-13  
 snAgAcIfLogOption 8-12  
 snAgAcIfName 8-8  
 snAgAcIfNameString 8-16  
 snAgAcIfNum 8-16  
 snAgAcIfNumber 8-8  
 snAgAcIfPacketCounter 8-12  
 snAgAcIfPortBindDirection 8-16  
 snAgAcIfPortNum 8-16  
 snAgAcIfPortRowStatus 8-16  
 snAgAcIfPrecedence 8-11  
 snAgAcIfPriorityForce 8-13  
 snAgAcIfPriorityMapping 8-13  
 snAgAcIfProtocol 8-9  
 snAgAcIfRowStatus 8-12  
 snAgAcIfSourceIp 8-9  
 snAgAcIfSourceMask 8-9  
 snAgAcIfSourceOperand1 8-9  
 snAgAcIfSourceOperand2 8-10  
 snAgAcIfSourceOperator 8-9  
 snAgAcIfStandardFlag 8-12  
 snAgAcIfTable 8-8  
 snAgAcIfTos 8-12  
 snAgBindPortListInVirtualInterface 8-16  
 snAgBootSeqEntry 5-11  
 snAgBootSeqFilename 5-11  
 snAgBootSeqIndex 5-11  
 snAgBootSeqInstruction 5-11  
 snAgBootSeqIpAddr 5-11  
 snAgBootSeqRowStatus 5-12  
 snAgBootSeqTable 5-11  
 snAgBuildDate 5-10  
 snAgBuildtime 5-10  
 snAgBuildVer 5-11  
 snAgCfgEosChkSum 5-25  
 snAgCfgEosEntry 5-25  
 snAgCfgEosIndex 5-25  
 snAgCfgEosPacket 5-25  
 snAgCfgEosTable 5-25  
 snAgCfgFname 5-6  
 snAgCfgLoad 5-7  
 snAgConfigFromNVRAM 5-3  
 snAgDefGwayIp 5-12  
 snAgentBrdAlarmLeds 4-13  
 snAgentBrdAlarmLedString 4-14  
 snAgentBrdEntry 4-7  
 snAgentBrdExpBrdDescription 4-11  
 snAgentBrdExpBrdId 4-11  
 snAgentBrdExpPortTotal 4-11  
 snAgentBrdIndex 4-7  
 snAgentBrdMainBrdDescription 4-7  
 snAgentBrdMainBrdId 4-7  
 snAgentBrdMainPortTotal 4-11  
 snAgentBrdMediaLeds 4-12  
 snAgentBrdMediaLedString 4-14  
 snAgentBrdModuleStatus 4-12  
 snAgentBrdRedundantStatus 4-13  
 snAgentBrdRxTrafficLeds 4-13  
 snAgentBrdRxTrafficLedString 4-14  
 snAgentBrdSpeedLeds 4-12  
 snAgentBrdSpeedLedString 4-14  
 snAgentBrdStatusLeds 4-12  
 snAgentBrdStatusLedString 4-13  
 snAgentBrdTable 4-7  
 snAgentBrdTrafficLeds 4-12  
 snAgentBrdTrafficLedString 4-14  
 snAgentBrdTxTrafficLeds 4-13  
 snAgentBrdTxTrafficLedString 4-14  
 snAgentConfigModuleDescription 4-18  
 snAgentConfigModuleEntry 4-16  
 snAgentConfigModuleIndex 4-16  
 snAgentConfigModuleMgmtModuleType 4-19  
 snAgentConfigModuleNumberOfCpus 4-19  
 snAgentConfigModuleNumberOfPorts 4-19  
 snAgentConfigModuleOperStatus 4-18  
 snAgentConfigModuleRowStatus 4-18  
 snAgentConfigModuleSerialNumber 4-19  
 snAgentConfigModuleTable 4-15  
 snAgentConfigModuleType 4-17  
 snAgentCpuUtilCpuId 20-2

---

snAgentCpuUtilEntry 20-2  
snAgentCpuUtilInterval 20-3  
snAgentCpuUtilSlotNum 20-2  
snAgentCpuUtilTable 20-2  
snAgentCpuUtilValue 20-3  
snAgentEnableMgmtModRedunStateChange-Trap 23-5  
snAgentRedunActiveMgmtMod 4-19  
snAgentRedunBkupBootLoad 4-20  
snAgentRedunBkupCopyBootCode 4-20  
snAgentRedunSwitchOver 4-20  
snAgentRedunSyncConfig 4-20  
snAgentSysParaConfigCurrent 5-13  
snAgentSysParaConfigDefault 5-13  
snAgentSysParaConfigDescription 5-13  
snAgentSysParaConfigEntry 5-13  
snAgentSysParaConfigIndex 5-13  
snAgentSysParaConfigMax 5-13  
snAgentSysParaConfigMin 5-13  
snAgentSysParaConfigTable 5-13  
snAgentUserAcctEncryptCode 6-2  
snAgentUserAcctEntry 6-2  
snAgentUserAcctName 6-2  
snAgentUserAcctPassword 6-2  
snAgentUserAcctPrivilege 6-2  
snAgentUserAcctRowStatus 6-2  
snAgentUserAcctTable 6-2  
snAgentUserMaxAcct 6-1  
snAgEraseNVRAM 5-2  
snAgFlashImgVer 5-9  
snAgGblBannerExec 5-24  
snAgGblBannerIncoming 5-24  
snAgGblBannerMotd 5-24  
snAgGblBufferShortage 5-26  
snAgGblCpuUtil1MinAvg 20-2  
snAgGblCpuUtil1SecAvg 20-2  
snAgGblCpuUtil5SecAvg 20-2  
snAgGblCpuUtilCollect 20-1  
snAgGblCpuUtilData 20-1  
snAgGblCurrentSecurityLevel 6-4  
snAgGblDataRetrieveMode 5-25  
snAgGblDmaFailure 5-26  
snAgGblDynMemFree 20-3  
snAgGblDynMemTotal 20-3  
snAgGblDynMemUtil 20-3  
snAgGblEnableColdStartTrap 23-4  
snAgGblEnableLinkDownTrap 23-4  
snAgGblEnableLinkUpTrap 23-4  
snAgGblEnableModuleInsertedTrap 23-4  
snAgGblEnableModuleRemovedTrap 23-5  
snAgGblEnableSLB 6-5  
snAgGblEnableTelnetServer 6-5  
snAgGblEnableWebMgmt 6-5  
snAgGblExcessiveErrorWarning 5-26  
snAgGblIfIpAddr 5-12  
snAgGblIfIpMask 5-12  
snAgGblLevelPasswordsMask 6-3  
snAgGblPassword 6-3  
snAgGblPasswordChangeMode 6-3  
snAgGblQueueOverflow 5-26  
snAgGblReadOnlyCommunity 6-4  
snAgGblReadWriteCommunity 6-4  
snAgGblResourceLowWarning 5-26  
snAgGblSecurityLevelBinding 6-5  
snAgGblSecurityLevelSet 6-3  
snAgGblTelnetLoginTimeout 6-5  
snAgGblTelnetPassword 6-5  
snAgGblTelnetTimeout 6-4  
snAgGblTrapMessage 23-2  
snAgImgFname 5-4  
snAgImgLoad 5-5  
snAgImgLoadSPModuleNumber 5-8  
snAgImgLoadSPModuleType 5-8  
snAgImgVer 5-8  
snAgReload 5-2  
snAgSFlowSourceInterface 20-8  
snAgSoftwareFeature 5-9  
snAgStaticSysLogBufferCalTimeStamp 20-18  
snAgStaticSysLogBufferCriticalLevel 20-18  
snAgStaticSysLogBufferEntry 20-17  
snAgStaticSysLogBufferIndex 20-18  
snAgStaticSysLogBufferMessage 20-18  
snAgStaticSysLogBufferTable 20-17  
snAgStaticSysLogBufferTimeStamp 20-18  
snAgSysLogBufferCalTimeStamp 20-17  
snAgSysLogBufferCriticalLevel 20-17

snAgSysLogBufferEntry 20-16  
snAgSysLogBufferIndex 20-17  
snAgSysLogBufferMessage 20-17  
snAgSysLogBufferTable 20-16  
snAgSysLogBufferTimeStamp 20-17  
snAgSysLogGblBufferSize 20-14  
snAgSysLogGblClear 20-14  
snAgSysLogGblCriticalLevel 20-14  
snAgSysLogGblDroppedCount 20-15  
snAgSysLogGblEnable 20-14  
snAgSysLogGblFacility 20-16  
snAgSysLogGblFlushedCount 20-15  
snAgSysLogGblLoggedCount 20-14  
snAgSysLogGblOverrunCount 20-15  
snAgSysLogGblServer 20-15  
snAgSysLogServerEntry 20-19  
snAgSysLogServerIP 20-19  
snAgSysLogServerRowStatus 20-19  
snAgSysLogServerTable 20-18  
snAgSysLogServerUDPPort 20-19  
snAgSystemDebug 20-24  
snAgSystemDebugBMBuffer 20-24  
snAgSystemDebugBMFreeBuffer 20-24  
snAgSystemDebugBMFreeBufferMgmt 20-24  
snAgSystemDebugCpuQueueRead 20-24  
snAgSystemDebugDRAMBuffer 20-24  
snAgSystemDebugDRAMGetError 20-24  
snAgSystemDebugDRAMToBMCopyFail 20-25  
snAgSystemDebugLpcGigLock 20-24  
snAgSystemDebugTotalIn 20-24  
snAgSystemDebugTotalOut 20-24  
snAgSystemDRAM 20-4  
snAgSystemDRAMForBGP 20-4  
snAgSystemDRAMForOSPF 20-4  
snAgSystemDRAMFree 20-4  
snAgSystemDRAMTotal 20-4  
snAgSystemDRAMUtil 20-4  
snAgSystemLog 6-4  
snAgTftpServerIp 5-4  
snAgTrapHoldTime 23-5  
snAgTrpRcvrComm 23-3  
snAgTrpRcvrCurEntry 23-2  
snAgTrpRcvrEntry 23-3  
snAgTrpRcvrIndex 23-3  
snAgTrpRcvrIpAddr 23-3  
snAgTrpRcvrStatus 23-3  
snAgTrpRcvrTable 23-2  
snAgTrpRcvrUDPPort 23-3  
snAgWebMgmtServerTcpPort 6-1  
snAgWriteNVRAM 5-3  
snArpStatsInvalidDestination 20-8  
snArpStatsInvalidSource 20-8  
snArpStatsPendingDrop 20-7  
snArpStatsRepliesSent 20-7  
snArpStatsRequestReceived 20-7  
snArpStatsRequestSent 20-7  
snArpStatsTotalReceived 20-7  
snAuthorizationCommand Methods 6-9  
snAuthorizationCommandLevel 6-9  
snAuthorizationExec 6-9  
snBgp4AddrFilterAction 16-8  
snBgp4AddrFilterDestIp 16-9  
snBgp4AddrFilterDestMask 16-9  
snBgp4AddrFilterEntry 16-8  
snBgp4AddrFilterIndex 16-8  
snBgp4AddrFilterRowStatus 16-9  
snBgp4AddrFilterSourceIp 16-9  
snBgp4AddrFilterSourceMask 16-9  
snBgp4AddrFilterTable 16-8  
snBgp4AggregateAddrEntry 16-9  
snBgp4AggregateAddrIp 16-10  
snBgp4AggregateAddrMap 16-10  
snBgp4AggregateAddrMask 16-10  
snBgp4AggregateAddrOption 16-10  
snBgp4AggregateAddrRowStatus 16-10  
snBgp4AggregateAddrTable 16-9  
snBgp4AsPathFilterAction 16-13  
snBgp4AsPathFilterEntry 16-12  
snBgp4AsPathFilterIndex 16-12  
snBgp4AsPathFilterRegularExpression 16-13  
snBgp4AsPathFilterRowStatus 16-13  
snBgp4AsPathFilterTable 16-12  
snBgp4AttributeAggregatorAs 16-11  
snBgp4AttributeAsPathList 16-12  
snBgp4AttributeAtomicAggregatePresent 16-11  
snBgp4AttributeClusterList 16-12

---

snBgp4AttributeCommunityList 16-12  
snBgp4AttributeEntry 16-11  
snBgp4AttributeIndex 16-11  
snBgp4AttributeLocalPreference 16-12  
snBgp4AttributeMetric 16-11  
snBgp4AttributeNextHop 16-11  
snBgp4AttributeOrigin 16-11  
snBgp4AttributeOriginator 16-12  
snBgp4AttributeRouterId 16-11  
snBgp4AttributeTable 16-11  
snBgp4ClearNeighborCmdElement 16-35  
snBgp4ClearNeighborCmdEntry 16-35  
snBgp4ClearNeighborCmdIp 16-35  
snBgp4ClearNeighborCmdTable 16-35  
snBgp4ClientToClientReflection 16-5  
snBgp4ClusterId 16-5  
snBgp4CommunityFilterAction 16-13  
snBgp4CommunityFilterCommNum 16-14  
snBgp4CommunityFilterEntry 16-13  
snBgp4CommunityFilterIndex 16-13  
snBgp4CommunityFilterInternet 16-14  
snBgp4CommunityFilterLocalAs 16-14  
snBgp4CommunityFilterNoAdvertise 16-14  
snBgp4CommunityFilterNoExport 16-14  
snBgp4CommunityFilterRowStatus 16-14  
snBgp4CommunityFilterTable 16-13  
snBgp4ExternalDistance 16-5  
snBgp4GenAdminStat 16-3  
snBgp4GenAlwaysCompareMed 16-2  
snBgp4GenAsPathInstalled 16-5  
snBgp4GenAutoSummary 16-2  
snBgp4GenConfedId 16-6  
snBgp4GenConfedPeers 16-6  
snBgp4GenDampenHalfLife 16-6  
snBgp4GenDampening 16-6  
snBgp4GenDampenMap 16-7  
snBgp4GenDampenMaxSuppress 16-6  
snBgp4GenDampenReuse 16-6  
snBgp4GenDampenSuppress 16-6  
snBgp4GenDefaultInfoOriginate 16-2  
snBgp4GenDefaultLocalPreference 16-2  
snBgp4GenDefaultMetric 16-3  
snBgp4GenFastExternalFallover 16-2  
snBgp4GenHoldTime 16-3  
snBgp4GenKeepAliveTime 16-3  
snBgp4GenLocalAs 16-5  
snBgp4GenMaxAddrFilters 16-4  
snBgp4GenMaxAggregateAddresses 16-4  
snBgp4GenMaxAsPathFilters 16-4  
snBgp4GenMaxCommunityFilters 16-4  
snBgp4GenMaxNeighbors 16-3  
snBgp4GenMaxNetworks 16-4  
snBgp4GenMaxPaths 16-6  
snBgp4GenMaxRouteMapFilters 16-4  
snBgp4GenMaxRoutes 16-4  
snBgp4GenMinNeighbors 16-4  
snBgp4GenMinRoutes 16-4  
snBgp4GenNeighPrefixMinValue 16-4  
snBgp4GenNextBootNeighbors 16-3  
snBgp4GenNextBootRoutes 16-3  
snBgp4GenOperNeighbors 16-4  
snBgp4GenOperRoutes 16-5  
snBgp4GenRouterId 16-3  
snBgp4GenRoutesInstalled 16-5  
snBgp4GenSynchronization 16-3  
snBgp4GenTableMap 16-3  
snBgp4GenTotalNeighbors 16-6  
snBgp4InternalDistance 16-5  
snBgp4LocalDistance 16-5  
snBgp4NeighborSummaryEntry 16-33  
snBgp4NeighborSummaryIndex 16-34  
snBgp4NeighborSummaryIp 16-34  
snBgp4NeighborSummaryRouteInstalled 16-34  
snBgp4NeighborSummaryRouteReceived 16-34  
snBgp4NeighborSummaryState 16-34  
snBgp4NeighborSummaryStateChgTime 16-34  
snBgp4NeighborSummaryTable 16-33  
snBgp4NeighDistGroupAccessList 16-27  
snBgp4NeighDistGroupDir 16-27  
snBgp4NeighDistGroupEntry 16-27  
snBgp4NeighDistGroupInFilterList 16-28  
snBgp4NeighDistGroupInIpAccessList 16-28  
snBgp4NeighDistGroupInPrefixList 16-28  
snBgp4NeighDistGroupNeighIp 16-27  
snBgp4NeighDistGroupOutFilterList 16-28  
snBgp4NeighDistGroupOutIpAccessList 16-28

snBgp4NeighDistGroupOutPrefixList	16-28	snBgp4NeighOperStatusIndex	16-31
snBgp4NeighDistGroupRowStatus	16-28	snBgp4NeighOperStatusIp	16-31
snBgp4NeighDistGroupTable	16-27	snBgp4NeighOperStatusKeepAliveRxCounts	16-33
snBgp4NeighFilterGroupAccessList	16-29	snBgp4NeighOperStatusKeepAliveTime	16-32
snBgp4NeighFilterGroupDir	16-29	snBgp4NeighOperStatusKeepAliveTxCounts	16-32
snBgp4NeighFilterGroupEntry	16-29	snBgp4NeighOperStatusNotifRxCounts	16-33
snBgp4NeighFilterGroupInAsPathAccessList	16-30	snBgp4NeighOperStatusNotifTxCounts	16-33
snBgp4NeighFilterGroupInFilterList	16-29	snBgp4NeighOperStatusOpenRxCounts	16-33
snBgp4NeighFilterGroupNeighIp	16-29	snBgp4NeighOperStatusOpenTxCounts	16-33
snBgp4NeighFilterGroupOutAsPathAccessList	16-30	snBgp4NeighOperStatusRemoteAs	16-31
snBgp4NeighFilterGroupOutFilterList	16-30	snBgp4NeighOperStatusState	16-32
snBgp4NeighFilterGroupRowStatus	16-29	snBgp4NeighOperStatusTable	16-31
snBgp4NeighFilterGroupTable	16-29	snBgp4NeighOperStatusUpdateRxCounts	16-33
snBgp4NeighFilterGroupWeight	16-30	snBgp4NeighOperStatusUpdateTxCounts	16-33
snBgp4NeighFilterGroupWeightAccessList	16-30	snBgp4NeighPrefixGroupDir	16-36
snBgp4NeighGenCfgAdvertlevel	16-24	snBgp4NeighPrefixGroupEntry	16-35
snBgp4NeighGenCfgDefOriginate	16-24	snBgp4NeighPrefixGroupInAccessList	16-36
snBgp4NeighGenCfgDefOrigMap	16-27	snBgp4NeighPrefixGroupNeighIp	16-35
snBgp4NeighGenCfgDesc	16-27	snBgp4NeighPrefixGroupOutAccessList	16-36
snBgp4NeighGenCfgEbgpMultihop	16-24	snBgp4NeighPrefixGroupRowStatus	16-36
snBgp4NeighGenCfgEbgpMultihopTtl	16-26	snBgp4NeighPrefixGroupTable	16-35
snBgp4NeighGenCfgEntry	16-24	snBgp4NeighRouteMapDir	16-30
snBgp4NeighGenCfgHoldTime	16-27	snBgp4NeighRouteMapEntry	16-30
snBgp4NeighGenCfgKeepAliveTime	16-26	snBgp4NeighRouteMapMapName	16-31
snBgp4NeighGenCfgMaxPrefix	16-24	snBgp4NeighRouteMapNeighIp	16-30
snBgp4NeighGenCfgNeighIp	16-24	snBgp4NeighRouteMapRowStatus	16-31
snBgp4NeighGenCfgNextHopSelf	16-25	snBgp4NeighRouteMapTable	16-30
snBgp4NeighGenCfgPass	16-27	snBgp4NetworkBackdoor	16-7
snBgp4NeighGenCfgRemoteAs	16-25	snBgp4NetworkEntry	16-7
snBgp4NeighGenCfgRemovePrivateAs	16-26	snBgp4NetworkIp	16-7
snBgp4NeighGenCfgRouteRefClient	16-26	snBgp4NetworkRowStatus	16-8
snBgp4NeighGenCfgRowStatus	16-25	snBgp4NetworkSubnetMask	16-7
snBgp4NeighGenCfgSendComm	16-25	snBgp4NetworkTable	16-7
snBgp4NeighGenCfgShutdown	16-26	snBgp4NetworkWeight	16-7
snBgp4NeighGenCfgTable	16-24	snBgp4NextBootMaxAttributes	16-5
snBgp4NeighGenCfgUpdateSrcLpblntf	16-26	snBgp4OperNumOfAttributes	16-5
snBgp4NeighGenCfgWeight	16-25	snBgp4RedisEntry	16-20
snBgp4NeighGenCfgWeightFilterList	16-25	snBgp4RedisMatchExternal1	16-21
snBgp4NeighOperStatusAdvertlevel	16-32	snBgp4RedisMatchExternal2	16-21
snBgp4NeighOperStatusBgpType	16-32	snBgp4RedisMatchInternal	16-21
snBgp4NeighOperStatusEntry	16-31	snBgp4RedisMetric	16-21
snBgp4NeighOperStatusHoldTime	16-32	snBgp4RedisProtocol	16-21



---

snBgp4RedisRouteMap 16-21  
snBgp4RedisRowStatus 16-21  
snBgp4RedisTable 16-20  
snBgp4RedisWeight 16-21  
snBgp4RouteMapFilterAction 16-15  
snBgp4RouteMapFilterEntry 16-15  
snBgp4RouteMapFilterMapName 16-15  
snBgp4RouteMapFilterRowStatus 16-15  
snBgp4RouteMapFilterSequenceNum 16-15  
snBgp4RouteMapFilterTable 16-15  
snBgp4RouteMapMatchAddressAccessList 16-17  
snBgp4RouteMapMatchAddressFilter 16-16  
snBgp4RouteMapMatchAddressPrefixList 16-17  
snBgp4RouteMapMatchAsPathAccessList 16-17  
snBgp4RouteMapMatchAsPathFilter 16-16  
snBgp4RouteMapMatchCommunityFilter 16-16  
snBgp4RouteMapMatchCommunityList 16-17  
snBgp4RouteMapMatchEntry 16-16  
snBgp4RouteMapMatchMapName 16-16  
snBgp4RouteMapMatchMetric 16-16  
snBgp4RouteMapMatchNextHopAccessList 16-17  
snBgp4RouteMapMatchNextHopList 16-16  
snBgp4RouteMapMatchNextHopPrefixList 16-18  
snBgp4RouteMapMatchRouteType 16-17  
snBgp4RouteMapMatchRowMask 16-17  
snBgp4RouteMapMatchSequenceNum 16-16  
snBgp4RouteMapMatchTable 16-16  
snBgp4RouteMapMatchTagList 16-17  
snBgp4RouteMapSetAsPathString 16-18  
snBgp4RouteMapSetAsPathType 16-18  
snBgp4RouteMapSetAutoTag 16-18  
snBgp4RouteMapSetCommunityAdditive 16-19  
snBgp4RouteMapSetCommunityNum 16-19  
snBgp4RouteMapSetCommunityNums 16-20  
snBgp4RouteMapSetCommunityType 16-19  
snBgp4RouteMapSetDampenHalfLife 16-20  
snBgp4RouteMapSetDampenMaxSuppress 16-20  
snBgp4RouteMapSetDampenReuse 16-20  
snBgp4RouteMapSetDampenSuppress 16-20  
snBgp4RouteMapSetEntry 16-18  
snBgp4RouteMapSetLocalPreference 16-19  
snBgp4RouteMapSetMapName 16-18  
snBgp4RouteMapSetMetric 16-19  
snBgp4RouteMapSetNextHop 16-19  
snBgp4RouteMapSetOrigin 16-19  
snBgp4RouteMapSetRowMask 16-20  
snBgp4RouteMapSetSequenceNum 16-18  
snBgp4RouteMapSetTable 16-18  
snBgp4RouteMapSetTag 16-19  
snBgp4RouteMapSetWeight 16-19  
snBgp4RouteOperStatusAsPathList 16-23  
snBgp4RouteOperStatusCommunityList 16-23  
snBgp4RouteOperStatusEntry 16-22  
snBgp4RouteOperStatusIndex 16-22  
snBgp4RouteOperStatusIp 16-22  
snBgp4RouteOperStatusLocalPreference 16-22  
snBgp4RouteOperStatusMetric 16-22  
snBgp4RouteOperStatusNextHop 16-22  
snBgp4RouteOperStatusOrigin 16-22  
snBgp4RouteOperStatusRouteTag 16-23  
snBgp4RouteOperStatusStatus 16-23  
snBgp4RouteOperStatusSubnetMask 16-22  
snBgp4RouteOperStatusTable 16-22  
snBgp4RouteOperStatusWeight 16-22  
snBI15000Router 3-3  
snBI15000SI 3-3  
snBI4000Router 3-2  
snBI4000SI 3-2  
snBI4000Switch 3-2  
snBI8000Router 3-2  
snBI8000SI 3-2  
snBI8000Switch 3-2  
snBigIron15000 3-3  
snBigIronSuperX 3-7  
snBigIronSuperXBaseL3Switch 3-8  
snBigIronSuperXFamily 3-7  
snBigIronSuperXRouter 3-7  
snBigIronSuperXSwitch 3-7  
snBIMG8Router 3-5  
snBIMG8Switch 3-5  
snCAMIpStatEntry 20-19  
snCAMIpStatFreeEntries 20-20  
snCAMIpStatIfIndex 20-19  
snCAMIpStatLevel 20-20  
snCAMIpStatTable 20-19

snCAMIpStatTotalEntries 20-20  
 snCamStatAddIPHostCount 20-22  
 snCamStatAddIPMCastCount 20-22  
 snCamStatAddIPRouteCount 20-22  
 snCamStatAddIPSessionCount 20-22  
 snCamStatAddIPXCount 20-22  
 snCamStatAddL2SessionCount 20-22  
 snCamStatAddMACCount 20-22  
 snCamStatAddVLANCount 20-22  
 snCamStatDeleteDMACamCount 20-22  
 snCamStatFreeL2Entries 20-21  
 snCamStatFreeL2LowestSection 20-21  
 snCamStatFreePool0Entries 20-20  
 snCamStatFreePool1Entries 20-20  
 snCamStatFreePool2Entries 20-20  
 snCamStatFreePool3Entries 20-21  
 snCamStatHostLookupCount 20-21  
 snCamStatIPMCastFailCount 20-22  
 snCamStatIPRouteFailCount 20-21  
 snCamStatIPSessionFailCount 20-21  
 snCamStatL2SessionFailCount 20-22  
 snCamStatLevel1 20-21  
 snCamStatLevel2 20-21  
 snCamStatLevel3 20-21  
 snCamStatMacFailCount 20-21  
 snCamStatRouteLookupCount 20-21  
 snCAMStatTable 20-20  
 snChasActualTemperature 4-27  
 snchasarchitectureType 4-28  
 snChasEnableFanTrap 23-4  
 snChasEnablePwrSupplyTrap 23-4  
 snChasEnableTempWarnTrap 23-5  
 snChasExpBrdDescription 4-22  
 snChasExpBrdId 4-22  
 snChasExpPortTotal 4-22  
 snChasFanDescription 4-26  
 snChasFanEntry 4-26  
 snChasFanIndex 4-26  
 snChasFanOperStatus 4-27  
 snChasFanStatus 4-3  
 snChasFanTable 4-26  
 snChasFlashCard 4-28  
 snChasFlashCardLeds 4-28  
 snChasIdNumber 4-7  
 snChasMainBrdDescription 4-22  
 snChasMainPortTotal 4-22  
 snChasMediaLeds 4-23  
 snchasnumslots 4-28  
 snchasProductType 4-28  
 snChasPwrSupplyDescription 4-26  
 snChasPwrSupplyEntry 4-26  
 snChasPwrSupplyIndex 4-26  
 snChasPwrSupplyOperStatus 4-26  
 snChasPwrSupplyStatus 4-2  
 snChasPwrSupplyTable 4-26  
 snChasSerNum 4-25  
 snChasShutdownTemperature 4-27  
 snChasSpeedLeds 4-24  
 snChasStatusLeds 4-23  
 snChasTrafficLeds 4-23  
 snChasType 4-25  
 snChasWarningTemperature 4-27  
 snCpuProcess15MinUtil 20-23  
 snCpuProcess1MinUtil 20-23  
 snCpuProcess5MinUtil 20-23  
 snCpuProcess5SecUtil 20-23  
 snCpuProcessEntry 20-23  
 snCpuProcessName 20-23  
 snCpuProcessRuntime 20-23  
 snCpuProcessTable 20-23  
 snDhcpGatewayListAddrList 5-20  
 snDhcpGatewayListEntry 5-20  
 snDhcpGatewayListId 5-20  
 snDhcpGatewayListRowStatus 5-20  
 snDhcpGatewayListTable 5-20  
 snDnsDomainName 5-19  
 snDnsGatewayIpAddrList 5-19  
 snDvmrpDefaultRoute 10-14  
 snDvmrpEnable 10-13  
 snDvmrpGenerationId 10-13  
 snDvmrpGraftRetransmitTime 10-14  
 snDvmrpNeighborAddress 10-16  
 snDvmrpNeighborCapabilities 10-17  
 snDvmrpNeighborEntry 10-16  
 snDvmrpNeighborEntryIndex 10-16  
 snDvmrpNeighborExpiryTime 10-17

---

snDvmrpNeighborGenerationId	10-17	snDvmrpVlIfStatOutGraftPkts	10-20
snDvmrpNeighborMajorVersion	10-17	snDvmrpVlIfStatOutOctets	10-19
snDvmrpNeighborMinorVersion	10-17	snDvmrpVlIfStatOutPkts	10-19
snDvmrpNeighborRouterTimeout	10-13	snDvmrpVlIfStatOutProbePkts	10-20
snDvmrpNeighborTable	10-16	snDvmrpVlIfStatOutPrunePkts	10-21
snDvmrpNeighborUpTime	10-17	snDvmrpVlIfStatOutRtUpdatePkts	10-20
snDvmrpNeighborVifIndex	10-16	snDvmrpVlIfStatTable	10-19
snDvmrpProbeInterval	10-13	snDvmrpVlIfStatVifIndex	10-19
snDvmrpPruneAge	10-14	snDvmrpVlInterfaceAdvertiseLocal	10-15
snDvmrpReportInterval	10-13	snDvmrpVlInterfaceEncapsulation	10-16
snDvmrpRouteDiscardTime	10-14	snDvmrpVlInterfaceEntry	10-14
snDvmrpRouteEntry	10-17	snDvmrpVlInterfaceLocalAddress	10-15
snDvmrpRouteEntryIndex	10-18	snDvmrpVlInterfaceMetric	10-15
snDvmrpRouteExpireTime	10-14	snDvmrpVlInterfaceOperState	10-15
snDvmrpRouteExpiryTime	10-18	snDvmrpVlInterfaceRemoteAddress	10-15
snDvmrpRouteMetric	10-18	snDvmrpVlInterfaceRemoteSubnetMask	10-15
snDvmrpRouteNextHopEntry	10-18	snDvmrpVlInterfaceStatus	10-16
snDvmrpRouteNextHopSource	10-18	snDvmrpVlInterfaceTable	10-14
snDvmrpRouteNextHopSourceMask	10-19	snDvmrpVlInterfaceTtlThreshold	10-15
snDvmrpRouteNextHopTable	10-18	snDvmrpVlInterfaceType	10-15
snDvmrpRouteNextHopType	10-19	snDvmrpVlInterfaceVifIndex	10-14
snDvmrpRouteNextHopVifIndex	10-19	snFastIronSuperXPremBaseL3Switch	3-7
snDvmrpRouteSource	10-18	snFastIronSuperXPrem	fdry.1.3.36.2 3-7
snDvmrpRouteSourceMask	10-18	snFastIronSuperXPremRouter	3-7
snDvmrpRouteTable	10-17	snFastIronSuperXPremSwitch	3-7
snDvmrpRouteUpstreamNeighbor	10-18	snFastIronSX1	3-7
snDvmrpRouteVifIndex	10-18	snFastIronSX1BaseL3Switch	3-7
snDvmrpTriggerInterval	10-13	snFastIronSX1Router	3-7
snDvmrpVersion	10-13	snFastIronSX1Switch	3-7
snDvmrpVlIfStatDiscardGraftAckPkts	10-21	snFastIronSXFamily	3-7
snDvmrpVlIfStatDiscardGraftPkts	10-20	snFdbEntry	8-4
snDvmrpVlIfStatDiscardProbePkts	10-20	snFdbRowStatus	8-6
snDvmrpVlIfStatDiscardPrunePkts	10-21	snFdbStationAddr	8-5
snDvmrpVlIfStatDiscardRtUpdatePkts	10-20	snFdbStationEntrySize	5-17
snDvmrpVlIfStatEntry	10-19	snFdbStationIfindex	8-6
snDvmrpVlIfStatInGraftAckPkts	10-20	snFdbStationIndex	8-5
snDvmrpVlIfStatInGraftPkts	10-20	snFdbStationPort	8-5
snDvmrpVlIfStatInOctets	10-19	snFdbStationQos	8-5
snDvmrpVlIfStatInPkts	10-19	snFdbStationType	8-5
snDvmrpVlIfStatInProbePkts	10-20	snFdbTable	8-4
snDvmrpVlIfStatInPrunePkts	10-21	snFdbTableCurEntry	5-15
snDvmrpVlIfStatInRtUpdatePkts	10-20	snFdbTableStationFlush	5-15
snDvmrpVlIfStatOutGraftAckPkts	10-20		

---

snFdbVlanId 8-5  
snFdpCacheAddress 5-29  
snFdpCacheAddressType 5-28  
snFdpCacheCapabilities 5-29  
snFdpCachedAddrDeviceAddrEntryIndex 5-30  
snFdpCachedAddrDeviceIndex 5-30  
snFdpCachedAddressEntry 5-30  
snFdpCachedAddressTable 5-30  
snFdpCachedAddrIfIndex 5-30  
snFdpCachedAddrType 5-31  
snFdpCachedAddrValue 5-31  
snFdpCacheDefaultTrafficVlanIdForDualMode 5-30  
snFdpCacheDeviceId 5-28  
snFdpCacheDeviceIndex 5-28  
snFdpCacheDevicePort 5-29  
snFdpCacheDevicePortVlanMask 5-30  
snFdpCacheDeviceTagType 5-30  
snFdpCacheEntry 5-28  
snFdpCacheIfIndex 5-28  
snFdpCacheIsAggregateVlan 5-29  
snFdpCachePlatform 5-29  
snFdpCachePortTagMode 5-30  
snFdpCacheTable 5-28  
snFdpCacheVendorId 5-29  
snFdpCacheVersion 5-29  
snFdpGlobalCdpRun 5-27  
snFdpGlobalHoldTime 5-27  
snFdpGlobalMessageInterval 5-27  
snFdpGlobalRun 5-27  
snFdpInterfaceCdpEnable 5-28  
snFdpInterfaceEnable 5-28  
snFdpInterfaceIfIndex 5-27  
snFdpInterfaceTable 5-27  
snFES12GCFRouter 3-4  
snFES12GCFSwitch 3-4  
snFES2402POERouter 3-4  
snFES2402POESwitch 3-4  
snFES2402Router 3-4  
snFES2402Switch 3-4  
snFES4802POERouter 3-5  
snFES4802POESwitch 3-5  
snFES4802Router 3-4  
snFES4802Switch 3-4  
snFES9604Router 3-4  
snFES9604Switch 3-4  
snFESX424Plus1XGPremRouter 3-5  
snFESX424Plus1XGPremSwitch 3-5  
snFESX424Plus1XGRouter 3-5  
snFESX424Plus1XGSwitch 3-5  
snFESX424Plus2XGPremRouter 3-6  
snFESX424Plus2XGPremSwitch 3-6  
snFESX424Plus2XGRouter 3-6  
snFESX424Plus2XGSwitch 3-5  
snFESX424PremRouter 3-5  
snFESX424PremSwitch 3-5  
snFESX424Router 3-5  
snFESX424Switch 3-5  
snFESX448Plus1XGPremRouter 3-6  
snFESX448Plus1XGPremSwitch 3-6  
snFESX448Plus1XGRouter 3-6  
snFESX448Plus1XGSwitch 3-6  
snFESX448Plus2XGPremRouter 3-6  
snFESX448Plus2XGPremSwitch 3-6  
snFESX448Plus2XGRouter 3-6  
snFESX448Plus2XGSwitch 3-6  
snFESX448PremRouter 3-6  
snFESX448PremSwitch 3-6  
snFESX448Router 3-6  
snFESX448Switch 3-6  
snFI1500Router 3-4  
snFI1500Switch 3-4  
snFI2GCRouter 3-2  
snFI2GCSwitch 3-2  
snFI2PlusGCRouter 3-3  
snFI2PlusGCSwitch 3-2  
snFI2PlusRouter 3-2  
snFI2PlusSwitch 3-2  
snFI2Router 3-2  
snFI2Switch 3-2  
snFI3GCRouter 3-3  
snFI3GCSwitch 3-3  
snFI3Router 3-3  
snFI3Switch 3-3  
snFI800Router 3-4  
snFI800Switch 3-4

---

snFIBBSwitch 3-1  
snFIWGSwitch 3-1  
snFsrpGroupOperMode 12-2  
snFsrplfChassisTrackPortMask 12-4  
snFsrplfEntry 12-2  
snFsrplfIpAddress 12-2  
snFsrplfKeepAliveTime 12-3  
snFsrplfOtherRtrIpAddr 12-3  
snFsrplfPort 12-2  
snFsrplfPreferLevel 12-3  
snFsrplfRouterDeadTime 12-3  
snFsrplfRowStatus 12-3  
snFsrplfState 12-3  
snFsrplfStateChangeTrap 23-5  
snFsrplfTable 12-2  
snFsrplfTrackPortList 12-4  
snFsrplfTrackPortMask 12-3  
snFsrplfVirRtrIpAddr 12-2  
snFWSX424Plus1XGSwitch 3-6  
snFWSX424Plus2XGSwitch 3-7  
snFWSX424Switch 3-6  
snFWSX448Plus1XGSwitch 3-7  
snFWSX448Plus2XGSwitch 3-7  
snFWSX448Switch 3-7  
snGblRtRouteOnly 13-1  
snIfIndexLookupEntry 7-25  
snIfIndexLookupIfIndex 7-25  
snIfIndexLookupInterfaceId 7-25  
snIfIndexLookupTable 7-25  
snIfStpCfgPathCost 7-38  
snIfStpEntry 7-37  
snIfStpOperState 7-38  
snIfStpPathCost 7-38  
snIfStpPortAdminEdgePort 7-40  
snIfStpPortAdminPointToPoint 7-40  
snIfStpPortAdminRstp 7-40  
snIfStpPortDesignatedBridge 7-39  
snIfStpPortDesignatedCost 7-39  
snIfStpPortDesignatedPort 7-40  
snIfStpPortDesignatedRoot 7-39  
snIfStpPortNum 7-37  
snIfStpPortPriority 7-37  
snIfStpPortProtocolMigration 7-40  
snIfStpPortState 7-39  
snIfStpTable 7-37  
snIfStpVlanId 7-37  
snIgmplfGroupMembershipTime 10-2  
snIgmplfEntry 10-2  
snIgmplfEntryIndex 10-2  
snIgmplfGroupAddress 10-3  
snIgmplfGroupAge 10-3  
snIgmplfPortNumber 10-2  
snIgmplfTable 10-2  
snIgmplfQueryInterval 10-2  
snIgmplfStaticGroupAddress 10-3  
snIgmplfStaticGroupEntry 10-3  
snIgmplfStaticGroupIfIndex 10-3  
snIgmplfStaticGroupPortList 10-4  
snIgmplfStaticGroupRowStatus 10-4  
snIgmplfStaticGroupTable 10-3  
snIMRFamily 3-8  
snInterfaceLookupEntry 7-24  
snInterfaceLookupIfIndex 7-24  
snInterfaceLookupInterfaceId 7-24  
snInterfaceLookupTable 7-24  
snIpAsPathAccessListStringAction 13-22  
snIpAsPathAccessListStringEntry 13-22  
snIpAsPathAccessListStringName 13-22  
snIpAsPathAccessListStringRegularExpression 13-22  
snIpAsPathAccessListStringRowStatus 13-23  
snIpAsPathAccessListStringSequence 13-22  
snIpAsPathAccessListStringTable 13-22  
snIpCommunityListAction 6-6  
snIpCommunityListCommNum 6-6  
snIpCommunityListEntry 6-6  
snIpCommunityListIndex 6-6  
snIpCommunityListInternet 6-6  
snIpCommunityListLocalAs 6-7  
snIpCommunityListNoAdvertise 6-6  
snIpCommunityListNoExport 6-7  
snIpCommunityListRowStatus 6-7  
snIpCommunityListSequence 6-6  
snIpCommunityListStringAction 6-8  
snIpCommunityListStringCommNum 6-8  
snIpCommunityListStringEntry 6-7  
snIpCommunityListStringInternet 6-8

snlpcCommunityListStringLocalAs 6-8  
 snlpcCommunityListStringName 6-7  
 snlpcCommunityListStringNoAdvertise 6-8  
 snlpcCommunityListStringNoExport 6-8  
 snlpcCommunityListStringRowStatus 6-8  
 snlpcCommunityListStringSequence 6-7  
 snlpcCommunityListStringTable 6-7  
 snlpcCommunityListTable 6-6  
 snlpcPrefixListAction 13-20  
 snlpcPrefixListAddr 13-20  
 snlpcPrefixListDesc 13-20  
 snlpcPrefixListEntry 13-19  
 snlpcPrefixListGeValue 13-20  
 snlpcPrefixListLength 13-21  
 snlpcPrefixListLeValue 13-20  
 snlpcPrefixListMask 13-20  
 snlpcPrefixListName 13-20  
 snlpcPrefixListRowStatus 13-21  
 snlpcPrefixListSequence 13-20  
 snlpcPrefixListTable 13-19  
 snlpcCacheEncap 17-4  
 snlpcCacheEntry 17-4  
 snlpcCachelf 17-4  
 snlpcCacheIndex 17-4  
 snlpcCacheNetNum 17-4  
 snlpcCacheNode 17-4  
 snlpcCacheOutFilter 17-4  
 snlpcCachePort 17-4  
 snlpcCacheTable 17-4  
 snlpcClearCache 17-1  
 snlpcClearRoute 17-1  
 snlpcClearTrafficCnts 17-2  
 snlpcDestHopCnts 17-5  
 snlpcDestNetNum 17-5  
 snlpcDestPort 17-5  
 snlpcFwdFilterAction 17-7  
 snlpcFwdFilterDestNet 17-7  
 snlpcFwdFilterDestNode 17-7  
 snlpcFwdFilterEntry 17-6  
 snlpcFwdFilterId 17-6  
 snlpcFwdFilterRowStatus 17-7  
 snlpcFwdFilterSocket 17-7  
 snlpcFwdFilterSrcNet 17-7  
 snlpcFwdFilterSrcNode 17-7  
 snlpcFwdFilterTable 17-6  
 snlpcFwdPktsCnt 17-2  
 snlpcFwdRouterNode 17-5  
 snlpcIfFwdAccessDir 17-10  
 snlpcIfFwdAccessEntry 17-10  
 snlpcIfFwdAccessFilterList 17-10  
 snlpcIfFwdAccessPort 17-10  
 snlpcIfFwdAccessRowStatus 17-10  
 snlpcIfFwdAccessTable 17-10  
 snlpcIfRipAccessDir 17-11  
 snlpcIfRipAccessEntry 17-10  
 snlpcIfRipAccessFilterList 17-11  
 snlpcIfRipAccessPort 17-11  
 snlpcIfRipAccessRowStatus 17-11  
 snlpcIfRipAccessTable 17-10  
 snlpcIfSapAccessDir 17-11  
 snlpcIfSapAccessEntry 17-11  
 snlpcIfSapAccessFilterList 17-11  
 snlpcIfSapAccessPort 17-11  
 snlpcIfSapAccessRowStatus 17-12  
 snlpcIfSapAccessTable 17-11  
 snlpcNetBiosFilterMode 17-1  
 snlpcPortAddrEncap 17-12  
 snlpcPortAddrEntry 17-12  
 snlpcPortAddrNetBiosFilterMode 17-13  
 snlpcPortAddrNetNum 17-12  
 snlpcPortAddrPort 17-12  
 snlpcPortAddrRowStatus 17-13  
 snlpcPortAddrTable 17-12  
 snlpcPortCountersEntry 17-13  
 snlpcPortCountersFwdPktsCnt 17-13  
 snlpcPortCountersPort 17-13  
 snlpcPortCountersRcvDropPktsCnt 17-14  
 snlpcPortCountersRcvFiltPktsCnt 17-14  
 snlpcPortCountersRcvPktsCnt 17-13  
 snlpcPortCountersTable 17-13  
 snlpcPortCountersTxDropPktsCnt 17-14  
 snlpcPortCountersTxFiltPktsCnt 17-14  
 snlpcPortCountersTxPktsCnt 17-13  
 snlpcRcvDropPktsCnt 17-2  
 snlpcRcvFiltPktsCnt 17-2  
 snlpcRcvPktsCnt 17-2

---

snlpxRipFilterAction 17-8  
snlpxRipFilterEntry 17-8  
snlpxRipFilterId 17-8  
snlpxRipFilterMask 17-8  
snlpxRipFilterNet 17-8  
snlpxRipFilterRowStatus 17-8  
snlpxRipFilterTable 17-8  
snlpxRipFiltOnAllPort 17-3  
snlpxRipGblFiltList 17-2  
snlpxRouteEntry 17-5  
snlpxRouteIndex 17-5  
snlpxRouteMetric 17-5  
snlpxRouteTable 17-5  
snlpxRoutingMode 17-1  
snlpxSapFilterAction 17-9  
snlpxSapFilterEntry 17-9  
snlpxSapFilterId 17-9  
snlpxSapFilterName 17-9  
snlpxSapFilterRowStatus 17-9  
snlpxSapFilterTable 17-9  
snlpxSapFilterType 17-9  
snlpxSapFiltOnAllPort 17-3  
snlpxSapGblFiltList 17-3  
snlpxServerEntry 17-5  
snlpxServerHopCnts 17-6  
snlpxServerIndex 17-6  
snlpxServerName 17-6  
snlpxServerNetNum 17-6  
snlpxServerNode 17-6  
snlpxServerSocket 17-6  
snlpxServerTable 17-5  
snlpxServerType 17-6  
snlpxTxDropPktsCnt 17-3  
snlpxTxFiltPktsCnt 17-3  
snlpxTxPktsCnt 17-2  
snL4Active 21-5  
snL4Backup 21-5  
snL4BackupInterface 21-5  
snL4BackupMacAddr 21-5  
snL4BackupState 21-6  
snL4BecomeActive 21-5  
snL4BecomeStandBy 21-5  
snL4BindEntry 21-34  
snL4BindIndex 21-34  
snL4BindingRealServerIP 21-35  
snL4BindingRealServerName 21-35  
snL4BindingRealServerPort 21-35  
snL4BindingRowStatus 21-36  
snL4BindingVirtualServerIP 21-35  
snL4BindingVirtualServerName 21-36  
snL4BindingVirtualServerPort 21-36  
snL4BindRealPortNumber 21-35  
snL4BindRealServerName 21-34  
snL4BindRowStatus 21-35  
snL4BindTable 21-34  
snL4BindVirtualPortNumber 21-34  
snL4BindVirtualServerName 21-34  
snL4EnableBecomeActiveTrap 23-9  
snL4EnableBecomeStandbyTrap 23-8  
snL4EnableGslbHealthCheckIpDownTrap 23-9  
snL4EnableGslbHealthCheckIpPortDownTrap 23-9  
snL4EnableGslbHealthCheckIpPortUpTrap 23-9  
snL4EnableGslbHealthCheckIpUpTrap 23-9  
snL4EnableGslbRemoteGslbSiDownTrap 23-9  
snL4EnableGslbRemoteGslbSiUpTrap 23-9  
snL4EnableGslbRemoteSiDownTrap 23-10  
snL4EnableGslbRemoteSiUpTrap 23-10  
snL4EnableMaxSessionLimitReachedTrap 23-8  
snL4EnableRealServerDownTrap 23-8  
snL4EnableRealServerMaxConnLimitReachedTrap 23-8  
snL4EnableRealServerPortDownTrap 23-8  
snL4EnableRealServerPortUpTrap 23-8  
snL4EnableRealServerUpTrap 23-8  
snL4EnableTcpSynLimitReachedTrap 23-8  
snL4FreeSessionCount 21-2  
snL4GslbSiteRemoteServerIronEntry 21-36  
snL4GslbSiteRemoteServerIronIP 21-36  
snL4GslbSiteRemoteServerIronPreference 21-37  
snL4GslbSiteRemoteServerIronTable 21-36  
snL4MaxNumWebCacheGroup 21-10  
snL4MaxNumWebCachePerGroup 21-10  
snL4MaxSessionLimit 21-2  
snL4NoPDUCount 21-6  
snL4NoPDUSent 21-6  
snL4NoPortMap 21-6

snL4PingInterval 21-9  
 snL4PingRetry 21-9  
 snL4PolicyEntry 21-6  
 snL4PolicyId 21-7  
 snL4PolicyPort 21-7  
 snL4PolicyPortAccessEntry 21-8  
 snL4PolicyPortAccessList 21-8  
 snL4PolicyPortAccessPort 21-8  
 snL4PolicyPortAccessRowStatus 21-9  
 snL4PolicyPortAccessTable 21-8  
 snL4PolicyPriority 21-7  
 snL4PolicyProtocol 21-7  
 snL4PolicyRowStatus 21-8  
 snL4PolicyScope 21-7  
 snL4PolicyTable 21-6  
 snL4RealServerCfgAdminStatus 21-18  
 snL4RealServerCfgDeleteState 21-19  
 snL4RealServerCfgEntry 21-18  
 snL4RealServerCfgIP 21-18  
 snL4RealServerCfgMaxConnections 21-19  
 snL4RealServerCfgName 21-18  
 snL4RealServerCfgRowStatus 21-19  
 snL4RealServerCfgTable 21-18  
 snL4RealServerCfgWeight 21-19  
 snL4RealServerHistoryControlBucketsGranted 21-39  
 snL4RealServerHistoryControlBucketsRequested 21-38  
 snL4RealServerHistoryControlDataSource 21-38  
 snL4RealServerHistoryControlEntry 21-38  
 snL4RealServerHistoryControlIndex 21-38  
 snL4RealServerHistoryControlInterval 21-39  
 snL4RealServerHistoryControlOwner 21-39  
 snL4RealServerHistoryControlStatus 21-39  
 snL4RealServerHistoryControlTable 21-38  
 snL4RealServerHistoryCurConnections 21-41  
 snL4RealServerHistoryEntry 21-40  
 snL4RealServerHistoryIndex 21-40  
 snL4RealServerHistoryIntervalStart 21-40  
 snL4RealServerHistoryPeakConnections 21-41  
 snL4RealServerHistoryReassignments 21-41  
 snL4RealServerHistoryReceivePkts 21-40  
 snL4RealServerHistorySampleIndex 21-40  
 snL4RealServerHistoryTable 21-40  
 snL4RealServerHistoryTotalConnections 21-40  
 snL4RealServerHistoryTransmitPkts 21-40  
 snL4RealServerPortCfgAdminStatus 21-20  
 snL4RealServerPortCfgDeleteState 21-20  
 snL4RealServerPortCfgEntry 21-20  
 snL4RealServerPortCfgIP 21-20  
 snL4RealServerPortCfgMaxConnections 21-21  
 snL4RealServerPortCfgPort 21-20  
 snL4RealServerPortCfgRowStatus 21-20  
 snL4RealServerPortCfgServerName 21-20  
 snL4RealServerPortCfgTable 21-20  
 snL4RealServerPortHistoryControlBucketsGranted 21-43  
 snL4RealServerPortHistoryControlBucketsRequested 21-42  
 snL4RealServerPortHistoryControlDataSource 21-42  
 snL4RealServerPortHistoryControlEntry 21-42  
 snL4RealServerPortHistoryControlIndex 21-42  
 snL4RealServerPortHistoryControlInterval 21-43  
 snL4RealServerPortHistoryControlOwner 21-43  
 snL4RealServerPortHistoryControlStatus 21-43  
 snL4RealServerPortHistoryControlTable 21-42  
 snL4RealServerPortHistoryCurConnections 21-45  
 snL4RealServerPortHistoryEntry 21-44  
 snL4RealServerPortHistoryIndex 21-44  
 snL4RealServerPortHistoryIntervalStart 21-44  
 snL4RealServerPortHistoryPeakConnections 21-45  
 snL4RealServerPortHistoryReceivePkts 21-44  
 snL4RealServerPortHistoryResponseTime 21-45  
 snL4RealServerPortHistorySampleIndex 21-44  
 snL4RealServerPortHistoryTable 21-44  
 snL4RealServerPortHistoryTotalConnections 21-44  
 snL4RealServerPortHistoryTransmitPkts 21-44  
 snL4RealServerPortStatisticCurrentConnection 21-26  
 snL4RealServerPortStatisticEntry 21-23  
 snL4RealServerPortStatisticFailTime 21-25  
 snL4RealServerPortStatisticIP 21-24  
 snL4RealServerPortStatisticPeakConnection 21-26  
 snL4RealServerPortStatisticPort 21-24  
 snL4RealServerPortStatisticReassignCount 21-



---

24

snL4RealServerPortStatisticRxBytes 21-26

snL4RealServerPortStatisticRxPkts 21-26

snL4RealServerPortStatisticServerName 21-24

snL4RealServerPortStatisticState 21-25

snL4RealServerPortStatisticTable 21-23

snL4RealServerPortStatisticTotalConnection 21-26

snL4RealServerPortStatisticTxBytes 21-26

snL4RealServerPortStatisticTxPkts 21-26

snL4RealServerStatisticAge 21-22

snL4RealServerStatisticCurConnections 21-21

snL4RealServerStatisticCurrentSessions 21-23

snL4RealServerStatisticEntry 21-21

snL4RealServerStatisticFailedPortExists 21-23

snL4RealServerStatisticFailTime 21-23

snL4RealServerStatisticName 21-21

snL4RealServerStatisticPeakConnections 21-23

snL4RealServerStatisticRealIP 21-21

snL4RealServerStatisticReassignmentLimit 21-23

snL4RealServerStatisticReassignments 21-23

snL4RealServerStatisticReceivePkts 21-21

snL4RealServerStatisticState 21-22

snL4RealServerStatisticTable 21-21

snL4RealServerStatisticTotalConnections 21-21

snL4RealServerStatisticTotalReverseConnections 21-23

snL4RealServerStatisticTransmitPkts 21-21

snL4Redundancy 21-5

snL4slbAged 21-4

snL4slbDangling 21-4

snL4slbDisableCount 21-4

snL4slbDrops 21-4

snL4slbFinished 21-4

snL4slbForwardTraffic 21-3

snL4slbGlobalSDAType 21-2

snL4slbLimitExceeds 21-2

snL4slbReverseTraffic 21-3

snL4slbRouterInterfacePortList 21-10

snL4slbRouterInterfacePortMask 21-10

snL4slbTotalConnections 21-2

snL4TcpAge 21-3

snL4TcpSynLimit 21-2

snL4UdpAge 21-3

snL4unsuccessfulConn 21-4

snL4VirtualServerBindEntry 21-35

snL4VirtualServerBindTable 21-35

snL4VirtualServerCfgAdminStatus 21-27

snL4VirtualServerCfgDeleteState 21-28

snL4VirtualServerCfgEntry 21-27

snL4VirtualServerCfgName 21-27

snL4VirtualServerCfgRowStatus 21-28

snL4VirtualServerCfgSDAType 21-28

snL4VirtualServerCfgSymPriority 21-29

snL4VirtualServerCfgTable 21-27

snL4VirtualServerCfgVirtualIP 21-27

snL4VirtualServerHistoryControlBucketsGranted 21-46

snL4VirtualServerHistoryControlBucketsRequested 21-46

snL4VirtualServerHistoryControlDataSource 21-45

snL4VirtualServerHistoryControlEntry 21-45

snL4VirtualServerHistoryControlIndex 21-45

snL4VirtualServerHistoryControlInterval 21-46

snL4VirtualServerHistoryControlOwner 21-46

snL4VirtualServerHistoryControlStatus 21-47

snL4VirtualServerHistoryControlTable 21-45

snL4VirtualServerHistoryCurConnections 21-48

snL4VirtualServerHistoryEntry 21-47

snL4VirtualServerHistoryIndex 21-47

snL4VirtualServerHistoryIntervalStart 21-47

snL4VirtualServerHistoryPeakConnections 21-48

snL4VirtualServerHistoryReceivePkts 21-47

snL4VirtualServerHistorySampleIndex 21-47

snL4VirtualServerHistoryTable 21-47

snL4VirtualServerHistoryTotalConnections 21-48

snL4VirtualServerHistoryTransmitPkts 21-48

snL4VirtualServerPortCfgAdminStatus 21-30

snL4VirtualServerPortCfgConcurrent 21-30

snL4VirtualServerPortCfgDeleteState 21-31

snL4VirtualServerPortCfgEntry 21-29

snL4VirtualServerPortCfgIP 21-29

snL4VirtualServerPortCfgPort 21-29

snL4VirtualServerPortCfgRowStatus 21-31

snL4VirtualServerPortCfgServerName 21-29

snL4VirtualServerPortCfgSticky 21-30

snL4VirtualServerPortCfgTable 21-29

---

snL4VirtualServerPortHistoryControlBucketsGranted 21-49

snL4VirtualServerPortHistoryControlBucketsRequested 21-49

snL4VirtualServerPortHistoryControlDataSource 21-48

snL4VirtualServerPortHistoryControlEntry 21-48

snL4VirtualServerPortHistoryControlIndex 21-48

snL4VirtualServerPortHistoryControlInterval 21-49

snL4VirtualServerPortHistoryControlOwner 21-49

snL4VirtualServerPortHistoryControlStatus 21-50

snL4VirtualServerPortHistoryControlTable 21-48

snL4VirtualServerPortHistoryCurConnections 21-51

snL4VirtualServerPortHistoryEntry 21-50

snL4VirtualServerPortHistoryIndex 21-50

snL4VirtualServerPortHistoryIntervalStart 21-50

snL4VirtualServerPortHistoryPeakConnections 21-51

snL4VirtualServerPortHistoryReceivePkts 21-50

snL4VirtualServerPortHistorySampleIndex 21-50

snL4VirtualServerPortHistoryTable 21-50

snL4VirtualServerPortHistoryTotalConnections 21-51

snL4VirtualServerPortHistoryTransmitPkts 21-51

snL4VirtualServerPortStatisticCurrentConnection 21-33

snL4VirtualServerPortStatisticEntry 21-33

snL4VirtualServerPortStatisticIP 21-33

snL4VirtualServerPortStatisticPeakConnection 21-34

snL4VirtualServerPortStatisticPort 21-33

snL4VirtualServerPortStatisticServerName 21-33

snL4VirtualServerPortStatisticTable 21-33

snL4VirtualServerPortStatisticTotalConnection 21-34

snL4VirtualServerStatisticEntry 21-31

snL4VirtualServerStatisticIP 21-31

snL4VirtualServerStatisticName 21-31

snL4VirtualServerStatisticReceiveBytes 21-32

snL4VirtualServerStatisticReceivePkts 21-31

snL4VirtualServerStatisticSymmetricActivates 21-32

snL4VirtualServerStatisticSymmetricActiveMacAddr 21-33

snL4VirtualServerStatisticSymmetricBestStandbyMacAddr 21-33

snL4VirtualServerStatisticSymmetricInactives 21-33

snL4VirtualServerStatisticSymmetricKeep 21-32

snL4VirtualServerStatisticSymmetricPriority 21-32

snL4VirtualServerStatisticSymmetricState 21-32

snL4VirtualServerStatisticTable 21-31

snL4VirtualServerStatisticTotalConnections 21-32

snL4VirtualServerStatisticTransmitBytes 21-32

snL4VirtualServerStatisticTransmitPkts 21-32

snL4WebCacheAdminStatus 21-13

snL4WebCacheCurrConnections 21-15

snL4WebCacheDeleteState 21-13

snL4WebCacheEntry 21-12

snL4WebCacheGroupAdminStatus 21-12

snL4WebCacheGroupDestMask 21-11

snL4WebCacheGroupEntry 21-11

snL4WebCacheGroupId 21-11

snL4WebCacheGroupName 21-11

snL4WebCacheGroupRowStatus 21-12

snL4WebCacheGroupSrcMask 21-11

snL4WebCacheGroupTable 21-11

snL4WebCacheGroupWebCacheIpList 21-11

snL4WebCacheIP 21-12

snL4WebCacheMaxConnections 21-13

snL4WebCacheName 21-12

snL4WebCachePortAdminStatus 21-14

snL4WebCachePortDeleteState 21-14

snL4WebCachePortEntry 21-14

snL4WebCachePortPort 21-14

snL4WebCachePortRowStatus 21-14

snL4WebCachePortServerIp 21-14

snL4WebCachePortState 21-16

snL4WebCachePortTable 21-14

snL4WebCacheRowStatus 21-13

snL4WebCacheRxOctets 21-15

snL4WebCacheRxPkts 21-15

snL4WebCacheStateful 21-10

snL4WebCacheTable 21-12

snL4WebCacheTotalConnections 21-15

snL4WebCacheTrafficIp 21-15

snL4WebCacheTrafficPort 21-15

snL4WebCacheTrafficStatsEntry 21-15

---

snL4WebCacheTrafficStatsTable 21-15  
 snL4WebCacheTxOctets 21-15  
 snL4WebCacheTxPkts 21-15  
 snL4WebCacheWeight 21-13  
 snL4WebClientPort 21-17  
 snL4WebClientPortName 21-17  
 snL4WebServerPort 21-17  
 snL4WebServerPortName 21-17  
 snL4WebUncachedRxOctets 21-17  
 snL4WebUncachedRxPkts 21-17  
 snL4WebUncachedTrafficStatsEntry 21-17  
 snL4WebUncachedTrafficStatsTable 21-17  
 snL4WebUncachedTxOctets 21-17  
 snL4WebUncachedTxPkts 21-17  
 snLoopbackIntfConfigEntry 7-32  
 snLoopbackIntfConfigPortIndex 7-32  
 snLoopbackIntfConfigTable 7-32  
 snLoopbackIntfMode 7-32  
 snLoopbackIntfRowStatus 7-33  
 snMacFilterAction 8-2  
 snMacFilterDestMac 8-2  
 snMacFilterDestMask 8-2  
 snMacFilterEntry 8-2  
 snMacFilterFrameType 8-3  
 snMacFilterFrameTypeNum 8-3  
 snMacFilterIndex 8-2  
 snMacFilterOperator 8-2  
 snMacFilterPortAccessEntry 8-3  
 snMacFilterPortAccessFilters 8-4  
 snMacFilterPortAccessPortIndex 8-4  
 snMacFilterPortAccessRowStatus 8-4  
 snMacFilterPortAccessTable 8-3  
 snMacFilterRowStatus 8-3  
 snMacFilterSourceMac 8-2  
 snMacFilterSourceMask 8-2  
 snMacFilterTable 8-2  
 snMacStationVlanId 5-17  
 snmpEnableAuthenTraps 23-2  
 snmplnTraps 23-1  
 snmpOutTraps 23-1  
 snMSTrunkEntry 7-26  
 snMSTrunkPortIndex 7-26  
 snMSTrunkPortList 7-27  
 snMSTrunkRowStatus 7-27  
 snMSTrunkTable 7-26  
 snMSTrunkType 7-27  
 snNetFlowAggregationActiveTimeout 20-12  
 snNetFlowAggregationEnable 20-13  
 snNetFlowAggregationEntry 20-11  
 snNetFlowAggregationInactiveTimeout 20-12  
 snNetFlowAggregationIndex 20-12  
 snNetFlowAggregationIp 20-12  
 snNetFlowAggregationNumberOfCacheEntries 20-12  
 snNetFlowAggregationRowStatus 20-13  
 snNetFlowAggregationSourceInterface 20-12  
 snNetFlowAggregationTable 20-11  
 snNetFlowAggregationUdpPort 20-12  
 snNetFlowCollectorEntry 20-10  
 snNetFlowCollectorIndex 20-11  
 snNetFlowCollectorIp 20-11  
 snNetFlowCollectorRowStatus 20-11  
 snNetFlowCollectorSourceInterface 20-11  
 snNetFlowCollectorTable 20-10  
 snNetFlowCollectorUdpPort 20-11  
 snNetFlowGblActiveTimeout 20-10  
 snNetFlowGblEnable 20-10  
 snNetFlowGblInactiveTimeout 20-10  
 snNetFlowGblProtocolDisable 20-10  
 snNetFlowGblVersion 20-10  
 snNetFlowIfEntry 20-13  
 snNetFlowIfFlowSwitching 20-13  
 snNetFlowIfIndex 20-13  
 snNetFlowIfTable 20-13  
 snNetIron40GSwitch 3-5  
 snNetIronIMR 3-8  
 snNI1500Router 3-3  
 snNI400Router 3-2  
 snNI40GRouter 3-5  
 snNI4802Router 3-5  
 snNI4802Switch 3-5  
 snNI800Router 3-2  
 snNIIMRRouter 3-8  
 snNIRouter 3-1  
 snNTPGeneral 5-21  
 snNTPPollInterval 5-21

snNTPServerEntry 5-23  
 snNTPServerIp 5-24  
 snNTPServerRowStatus 5-24  
 snNTPServerTable 5-23  
 snNTPServerVersion 5-24  
 snNTPSummerTimeEnable 5-23  
 snNTPSync 5-23  
 snNTPSystemClock 5-23  
 snNTPTimeZone 5-22  
 snOspfAdminStat 15-2  
 snOspfAreaEntry 15-4  
 snOspfAreaId 15-4  
 snOspfAreaIdFormat 15-5  
 snOspfAreaRangeAreaId 15-6  
 snOspfAreaRangeAreaIdFormat 15-6  
 snOspfAreaRangeEntry 15-6  
 snOspfAreaRangeMask 15-6  
 snOspfAreaRangeNet 15-6  
 snOspfAreaRangeRowStatus 15-6  
 snOspfAreaRangeTable 15-6  
 snOspfAreaRowStatus 15-5  
 snOspfAreaStatusAreaBdrRtrCount 15-27  
 snOspfAreaStatusAreaId 15-26  
 snOspfAreaStatusAreaIdFormat 15-27  
 snOspfAreaStatusASBdrRtrCount 15-27  
 snOspfAreaStatusEntry 15-26  
 snOspfAreaStatusEntryIndex 15-26  
 snOspfAreaStatusImportASEExtern 15-26  
 snOspfAreaStatusLSACKsumSum 15-27  
 snOspfAreaStatusLSACount 15-27  
 snOspfAreaStatusSpfRuns 15-27  
 snOspfAreaStatusStubMetric 15-27  
 snOspfAreaStatusTable 15-26  
 snOspfAreaTable 15-4  
 snOspfASBdrRtrStatus 15-2  
 snOspfConfigErrorType 23-6  
 snOspfDefaultOspfMetricValue 15-2  
 snOspfDistance 15-3  
 snOspfDistanceExternal 15-4  
 snOspfDistanceInter 15-4  
 snOspfDistanceIntra 15-4  
 snOspfExitOverflowInterval 15-3  
 snOspfExternLSACKsumSum 15-2  
 snOspfExternLSACount 15-2  
 snOspfExtLsdbAdvertisement 15-26  
 snOspfExtLsdbAge 15-26  
 snOspfExtLsdbChecksum 15-26  
 snOspfExtLsdbEntry 15-25  
 snOspfExtLsdbEntryIndex 15-25  
 snOspfExtLsdbLimit 15-3  
 snOspfExtLsdbLsld 15-25  
 snOspfExtLsdbRouterId 15-25  
 snOspfExtLsdbSequence 15-25  
 snOspfExtLsdbTable 15-25  
 snOspfExtLsdbType 15-25  
 snOspfIf2AdminStat 15-10  
 snOspfIf2AreaId 15-10  
 snOspfIf2AreaIdFormat 15-13  
 snOspfIf2AuthKey 15-12  
 snOspfIf2AuthType 15-11  
 snOspfIf2DatabaseFilterAllOut 15-13  
 snOspfIf2Entry 15-10  
 snOspfIf2HelloInterval 15-11  
 snOspfIf2Md5ActivationWaitTime 15-13  
 snOspfIf2Md5AuthKey 15-13  
 snOspfIf2Md5AuthKeyId 15-12  
 snOspfIf2MetricValue 15-12  
 snOspfIf2MtuIgnore 15-13  
 snOspfIf2NetworkP2mp 15-13  
 snOspfIf2NetworkP2pt 15-13  
 snOspfIf2PassiveMode 15-13  
 snOspfIf2Port 15-10  
 snOspfIf2RetransInterval 15-11  
 snOspfIf2RowStatus 15-12  
 snOspfIf2RtrDeadInterval 15-11  
 snOspfIf2RtrPriority 15-11  
 snOspfIf2Table 15-10  
 snOspfIf2TransitDelay 15-11  
 snOspfIfAdminStat 15-7  
 snOspfIfAreaId 15-7  
 snOspfIfAreaIdFormat 15-9  
 snOspfIfAuthFailure(9) 23-22  
 snOspfIfAuthKey 15-8  
 snOspfIfAuthType 15-8  
 snOspfIfConfigError(7) 23-22  
 snOspfIfDatabaseFilterAllOut 15-10

---

snOspfIfEntry 15-7  
snOspfIfHelloInterval 15-8  
snOspfIfMd5ActivationWaitTime 15-9  
snOspfIfMd5AuthKey 15-9  
snOspfIfMd5AuthKeyId 15-9  
snOspfIfMetricValue 15-9  
snOspfIfMtuIgnore 15-10  
snOspfIfNetworkP2mp 15-10  
snOspfIfPassiveMode 15-10  
snOspfIfPort 15-7  
snOspfIfRetransInterval 15-7  
snOspfIfRowStatus 15-9  
snOspfIfRtrDeadInterval 15-8  
snOspfIfRtrPriority 15-7  
snOspfIfRxBadPacket (11) 23-23  
snOspfIfStatusAdminStat 15-28  
snOspfIfStatusAreaId 15-28  
snOspfIfStatusAreaIdFormat 15-31  
snOspfIfStatusAuthKey 15-30  
snOspfIfStatusAuthType 15-30  
snOspfIfStatusBackupDesignatedRouter 15-29  
snOspfIfStatusDesignatedRouter 15-29  
snOspfIfStatusEntry 15-28  
snOspfIfStatusEntryIndex 15-28  
snOspfIfStatusEvents 15-30  
snOspfIfStatusHelloInterval 15-29  
snOspfIfStatusIpAddress 15-28  
snOspfIfStatusMd5ActivationWaitTime 15-31  
snOspfIfStatusMd5AuthKey 15-31  
snOspfIfStatusMd5AuthKeyId 15-30  
snOspfIfStatusMetricValue 15-30  
snOspfIfStatusPort 15-28  
snOspfIfStatusRetransInterval 15-29  
snOspfIfStatusRtrDeadInterval 15-29  
snOspfIfStatusRtrPriority 15-28  
snOspfIfStatusState 15-29  
snOspfIfStatusTable 15-27  
snOspfIfStatusTransitDelay 15-29  
snOspfIfStatusType 15-28  
snOspfIfTable 15-7  
snOspfIfTransitDelay 15-7  
snOspfImportASExtern 15-5  
snOspfLsdbAdvertisement 15-24  
snOspfLsdbAge 15-24  
snOspfLsdbApproachingOverflow(18) 23-25  
snOspfLsdbAreaId 15-23  
snOspfLsdbAreaIdFormat 15-24  
snOspfLsdbChecksum 15-24  
snOspfLsdbEntry 15-23  
snOspfLsdbEntryIndex 15-23  
snOspfLsdbLsId 15-23  
snOspfLsdbOverflow (17) 23-25  
snOspfLsdbRouterId 15-24  
snOspfLsdbSequence 15-24  
snOspfLsdbTable 15-23  
snOspfLsdbType 15-23  
snOspfMaxAgeLsa(16) 23-25  
snOspfNbrEntry 15-18  
snOspfNbrEntryIndex 15-18  
snOspfNbrEvents 15-20  
snOspfNbrIndex 15-18  
snOspfNbrIpAddr 15-18  
snOspfNbrLsRetransQLen 15-21  
snOspfNbrOptions 15-19  
snOspfNbrPort 15-18  
snOspfNbrPriority 15-19  
snOspfNbrRtrId 15-19  
snOspfNbrState 15-20  
snOspfNbrStateChange (5) 23-21  
snOspfNbrTable 15-18  
snOspfOriginateLsa(15) 23-25  
snOspfOriginateNewLSAs 15-2  
snOspfOspfRedisMetricType 15-3  
snOspfPacketSrc 23-7  
snOspfPacketType 23-7  
snOspfRedisAction 15-17  
snOspfRedisEntry 15-16  
snOspfRedisIndex 15-16  
snOspfRedisIpAddress 15-17  
snOspfRedisMask 15-17  
snOspfRedisMatchRipMetric 15-17  
snOspfRedisMode 15-2  
snOspfRedisOspfMetricValue 15-17  
snOspfRedisProtocol 15-17  
snOspfRedisRipMetricValue 15-17  
snOspfRedisRowStatus 15-18

snOspfRedisSetOspfMetric 15-17  
 snOspfRedisTable 15-16  
 snOspfRfc1583Compatibility 15-3  
 snOspfRouterId 15-2  
 snOspfRouterIdFormat 15-3  
 snOspfRoutingInfoEntry 15-34  
 snOspfRoutingInfoIndex 15-34  
 snOspfRoutingInfoNextHopRouterID 15-34  
 snOspfRoutingInfoOutgoingInterface 15-34  
 snOspfRoutingInfoRouter 15-34  
 snOspfRoutingInfoRouterType 15-34  
 snOspfRoutingInfoTable 15-34  
 snOspfRxNewLSAs 15-3  
 snOspfSetTrap 23-6  
 snOspfStubMetric 15-5  
 snOspfTrapsGenerationMode 23-7  
 snOspfTxRetransmit(13) 23-24  
 snOspfVirtIfAreaID 15-14  
 snOspfVirtIfArealdFormat 15-16  
 snOspfVirtIfAuthFailure  
 (10) 23-23  
 snOspfVirtIfAuthKey 15-15  
 snOspfVirtIfAuthType 15-15  
 snOspfVirtIfConfigError  
 (8) 23-22  
 snOspfVirtIfEntry 15-14  
 snOspfVirtIfHelloInterval 15-14  
 snOspfVirtIfMd5ActivationWaitTime 15-16  
 snOspfVirtIfMd5AuthKey 15-16  
 snOspfVirtIfMd5AuthKeyId 15-16  
 snOspfVirtIfNeighbor 15-14  
 snOspfVirtIfRetransInterval 15-14  
 snOspfVirtIfRowStatus 15-15  
 snOspfVirtIfRtrDeadInterval 15-14  
 snOspfVirtIfRxBadPacket(12) 23-23  
 snOspfVirtIfStatusAreaID 15-31  
 snOspfVirtIfStatusArealdFormat 15-33  
 snOspfVirtIfStatusAuthKey 15-33  
 snOspfVirtIfStatusAuthType 15-32  
 snOspfVirtIfStatusEntry 15-31  
 snOspfVirtIfStatusEntryIndex 15-31  
 snOspfVirtIfStatusEvents 15-32  
 snOspfVirtIfStatusHelloInterval 15-32  
 snOspfVirtIfStatusMd5ActivationWaitTime 15-33  
 snOspfVirtIfStatusMd5AuthKey 15-33  
 snOspfVirtIfStatusMd5AuthKeyId 15-33  
 snOspfVirtIfStatusNeighbor 15-31  
 snOspfVirtIfStatusRetransInterval 15-32  
 snOspfVirtIfStatusRtrDeadInterval 15-32  
 snOspfVirtIfStatusState 15-32  
 snOspfVirtIfStatusTable 15-31  
 snOspfVirtIfStatusTransitDelay 15-32  
 snOspfVirtIfTable 15-14  
 snOspfVirtIfTransitDelay 15-14  
 snOspfVirtNbrArea 15-21  
 snOspfVirtNbrArealdFormat 15-23  
 snOspfVirtNbrEntry 15-21  
 snOspfVirtNbrEntryIndex 15-21  
 snOspfVirtNbrEvents 15-22  
 snOspfVirtNbrIpAddr 15-21  
 snOspfVirtNbrLSRetransQLen 15-22  
 snOspfVirtNbrOptions 15-21  
 snOspfVirtNbrRtrId 15-21  
 snOspfVirtNbrState 15-22  
 snOspfVirtNbrStateChange(6) 23-21  
 snOspfVirtNbrTable 15-21  
 snPimCandidateBSREntry 10-10  
 snPimCandidateBSRHashMaskLen 10-11  
 snPimCandidateBSRIPAddress 10-11  
 snPimCandidateBSRPortID 10-10  
 snPimCandidateBSRPreference 10-11  
 snPimCandidateBSRTable 10-10  
 snPimCandidateRPEntry 10-12  
 snPimCandidateRPGroupAddress 10-12  
 snPimCandidateRPIPAddress 10-12  
 snPimCandidateRPMask 10-12  
 snPimCandidateRPRowStatus 10-12  
 snPimCandidateRPTable 10-12  
 snPimEnable 10-4  
 snPimGraftRetransmitTime 10-5  
 snPimHelloTime 10-5  
 snPimInactivityTime 10-5  
 snPimJoinPruneInterval 10-10  
 snPimNeighborAddress 10-7  
 snPimNeighborEntry 10-7  
 snPimNeighborEntryIndex 10-7  
 snPimNeighborExpiryTime 10-8

---

snPimNeighborRouterTimeout	10-5	snPortCARAcclDx	9-3
snPimNeighborTable	10-7	snPortCARConformAction	9-4
snPimNeighborUpTime	10-8	snPortCARDirection	9-3
snPimNeighborVifIndex	10-7	snPortCAREntry	9-3
snPimPruneTime	10-5	snPortCARExceedAction	9-4
snPimRPSetEntry	10-11	snPortCARExtLimit	9-3
snPimRPSetGroupAddress	10-11	snPortCARifIndex	9-3
snPimRPSetHoldTime	10-11	snPortCARLimit	9-3
snPimRPSetIPAddress	10-11	snPortCARRate	9-3
snPimRPSetMask	10-11	snPortCARRowIndex	9-3
snPimRPSetTable	10-11	snPortCARStatCurBurst	9-4
snPimVifStatDiscardAssertPkts	10-9	snPortCARStatFilteredBytes	9-4
snPimVifStatDiscardGraftAckPkts	10-10	snPortCARStatFilteredPkts	9-4
snPimVifStatDiscardGraftPkts	10-9	snPortCARStatSwitchedBytes	9-4
snPimVifStatDiscardHelloPkts	10-9	snPortCARStatSwitchedPkts	9-4
snPimVifStatDiscardJoinPkts	10-8	snPortCARTable	9-3
snPimVifStatDiscardPrunePkts	10-9	snPortCARType	9-3
snPimVifStatEntry	10-8	snPortMacSecurityAgeLeft	8-7
snPimVifStatInAssertPkts	10-9	snPortMacSecurityEntry	8-6
snPimVifStatInGraftAckPkts	10-9	snPortMacSecurityIfIndex	8-6
snPimVifStatInGraftPkts	10-9	snPortMacSecurityMAC	8-7
snPimVifStatInHelloPkts	10-9	snPortMacSecurityQueryIndex	8-7
snPimVifStatInJoinPkts	10-8	snPortMacSecurityResource	8-6
snPimVifStatInPrunePkts	10-8	snPortMacSecurityShutdownStatus	8-7
snPimVifStatOutAssertPkts	10-9	snPortMacSecurityShutdownTimeLeft	8-7
snPimVifStatOutGraftAckPkts	10-10	snPortMacSecurityTable	8-6
snPimVifStatOutGraftPkts	10-9	snPortMacSecurityVlanId	8-7
snPimVifStatOutHelloPkts	10-9	snPortMonitorEntry	7-40
snPimVifStatOutJoinPkts	10-8	snPortMonitorIfIndex	7-40
snPimVifStatOutPrunePkts	10-8	snPortMonitorMirrorList	7-41
snPimVifStatTable	10-8	snPortMonitorTable	7-40
snPimVifStatVifIndex	10-8	snPortStpEntry	7-34
snPimVInterfaceDR	10-6	snPortStpEntrySize	5-17
snPimVInterfaceEntry	10-6	snPortStpOperState	7-35
snPimVInterfaceLocalAddress	10-6	snPortStpPathCost	7-35
snPimVInterfaceLocalSubnetMask	10-6	snPortStpPortDesignatedBridge	7-36
snPimVInterfaceMode	10-7	snPortStpPortDesignatedCost	7-36
snPimVInterfaceRemoteAddress	10-6	snPortStpPortDesignatedPort	7-36
snPimVInterfaceStatus	10-7	snPortStpPortDesignatedRoot	7-36
snPimVInterfaceTable	10-6	snPortStpPortEnable	7-35
snPimVInterfaceTtlThreshold	10-6	snPortStpPortForwardTransitions	7-35
snPimVInterfaceType	10-6	snPortStpPortNum	7-34
snPimVInterfaceVifIndex	10-6	snPortStpPortPriority	7-34

snPortStpPortState 7-36  
 snPortStpSetAll 5-15  
 snPortStpTable 7-34  
 snPortStpVlanId 7-34  
 snPOSDescr 7-27  
 snPOSIfIndex 7-27  
 snPOSInfoAdminStatus 7-28  
 snPOSInfoClock 7-28  
 snPOSInfoCRC 7-29  
 snPOSInfoEntry 7-27  
 snPOSInfoFlagC2 7-29  
 snPOSInfoFlagH1 7-29  
 snPOSInfoFlagJ0 7-29  
 snPOSInfoFraming 7-29  
 snPOSInfoKeepAlive 7-29  
 snPOSInfoLinkStatus 7-28  
 snPOSInfoLoopBack 7-28  
 snPOSInfoPortNum 7-27  
 snPOSInfoScrambleATM 7-29  
 snPOSInfoSpeed 7-28  
 snPOSInfoTable 7-27  
 snPOSInOctets 7-30  
 snPOSName 7-28  
 snPOSOutOctets 7-30  
 snPOSStatsAIS 7-31  
 snPOSStatsAlignErrors 7-30  
 snPOSStatsB1 7-31  
 snPOSStatsB2 7-31  
 snPOSStatsB3 7-31  
 snPOSStatsFCSErrors 7-30  
 snPOSStatsFrameTooLongs 7-30  
 snPOSStatsFrameTooShorts 7-30  
 snPOSStatsInBitsPerSec 7-30  
 snPOSStatsInDiscard 7-30  
 snPOSStatsInFrames 7-29  
 snPOSStatsInPktsPerSec 7-31  
 snPOSStatsInUtilization 7-31  
 snPOSStatsLOF 7-32  
 snPOSStatsLOP 7-32  
 snPOSStatsLOS 7-32  
 snPOSStatsOutBitsPerSec 7-30  
 snPOSStatsOutDiscard 7-30  
 snPOSStatsOutFrames 7-30  
 snPOSStatsOutPktsPerSec 7-31  
 snPOSStatsOutUtilization 7-31  
 snPOSStatsRDI 7-32  
 snPOSTagType 7-31  
 snQosBindEntry 9-2  
 snQosBindIndex 9-2  
 snQosBindPriority 9-2  
 snQosBindProfileIndex 9-2  
 snQosBindTable 9-2  
 snQosProfileCalculatedBandwidth 9-2  
 snQosProfileEntry 9-1  
 snQosProfileIndex 9-1  
 snQosProfileName 9-2  
 snQosProfileRequestedBandwidth 9-2  
 snQosProfileTable 9-1  
 snRadiusDeadTime 6-11  
 snRadiusEnableMethod 6-12  
 snRadiusEnableTelnetAuth 6-11  
 snRadiusGeneral 6-11  
 snRadiusKey 6-11  
 snRadiusLoginMethod 6-12  
 snRadiusRetransmit 6-11  
 snRadiusServerAcctPort 6-14  
 snRadiusServerAuthPort 6-14  
 snRadiusServerEntry 6-13  
 snRadiusServerIp 6-14  
 snRadiusServerRowKey 6-14  
 snRadiusServerRowStatus 6-14  
 snRadiusServerTable 6-13  
 snRadiusServerUsage 6-14  
 snRadiusSNMPAccess 6-11  
 snRadiusSNMPServerMethod 6-13  
 snRadiusTimeout 6-11  
 snRadiusWebServerMethod 6-13  
 snRtArpAge 13-2  
 snRtATAddZoneFilterAction 18-9  
 snRtATAddZoneFilterEntry 18-9  
 snRtATAddZoneFilterPortIndex 18-9  
 snRtATAddZoneFilterRtmpEnable 18-9  
 snRtATAddZoneFilterTable 18-9  
 snRtATArpRetransmitCount 18-2  
 snRtATArpRetransmitInterval 18-2  
 snRtATClearArpCache 18-1



---

snRtATClearFwdCache	18-2	snRtATPortZoneFilterRtmpEnable	18-6
snRtATClearRoute	18-2	snRtATPortZoneFilterTable	18-5
snRtATClearTrafficCounters	18-2	snRtATPortZoneFilterZone	18-5
snRtATDroppedBadHopCountsDdpPkts	18-4	snRtATRoutingEnable	18-1
snRtATDroppedNoRouteDdpPkts	18-4	snRtATRtmpUpdateInterval	18-2
snRtATDroppedOtherReasonsDdpPkts	18-4	snRtATSocketPriorityEntry	18-4
snRtATFilteredRtmpPkts	18-3	snRtATSocketPriorityPriority	18-5
snRtATForwardedDdpPkts	18-4	snRtATSocketPrioritySocket	18-4
snRtATFwdCacheAction	18-8	snRtATSocketPriorityTable	18-4
snRtATFwdCacheEntry	18-7	snRtATZipQueryInterval	18-2
snRtATFwdCacheIndex	18-7	snRtATZoneEntry	18-8
snRtATFwdCacheMacAddr	18-8	snRtATZoneIndex	18-8
snRtATFwdCacheNetAddr	18-7	snRtATZoneName	18-9
snRtATFwdCacheNextHop	18-8	snRtATZoneNetEnd	18-9
snRtATFwdCacheOutgoingPort	18-8	snRtATZoneNetStart	18-9
snRtATFwdCacheTable	18-7	snRtATZoneTable	18-8
snRtATFwdCacheType	18-8	snRtBootpRelayMax	13-2
snRtATFwdCacheVlanId	18-8	snRtBootpServer	13-2
snRtATGleanPacketsEnable	18-2	snRtClearArpCache	13-2
snRtATInAarpPkts	18-4	snRtClearIpCache	13-2
snRtATInDdpPkts	18-3	snRtClearIpRoute	13-2
snRtATInDeliveredDdpPkts	18-4	snRtIpDirBcastFwd	13-3
snRtATInRtmpPkts	18-3	snRtIpFilterAction	13-6
snRtATInZipGZLPkts	18-3	snRtIpFilterDestIp	13-6
snRtATInZipNetInfoPkts	18-3	snRtIpFilterDestMask	13-6
snRtATInZipPkts	18-3	snRtIpFilterEntry	13-5
snRtATOutAarpPkts	18-4	snRtIpFilterEstablished	13-7
snRtATOutDdpPkts	18-3	snRtIpFilterIndex	13-5
snRtATOutRtmpPkts	18-3	snRtIpFilterOperand	13-7
snRtATOutZipGZLPkts	18-3	snRtIpFilterOperator	13-7
snRtATOutZipNetInfoPkts	18-3	snRtIpFilterProtocol	13-6
snRtATOutZipPkts	18-3	snRtIpFilterQosPriority	13-8
snRtATPortArpAge	18-7	snRtIpFilterRowStatus	13-7
snRtATPortEntry	18-6	snRtIpFilterSourceIp	13-6
snRtATPortIndex	18-6	snRtIpFilterSourceMask	13-6
snRtATPortOperationMode	18-7	snRtIpFilterTable	13-5
snRtATPortSeedRouter	18-7	snRtIpFwdCacheAction	13-19
snRtATPortState	18-7	snRtIpFwdCacheCurEntries	13-3
snRtATPortTable	18-6	snRtIpFwdCacheEntry	13-18
snRtATPortZoneFilterAction	18-5	snRtIpFwdCacheFragCheck	13-19
snRtATPortZoneFilterEntry	18-5	snRtIpFwdCacheIndex	13-18
snRtATPortZoneFilterPortIndex	18-5	snRtIpFwdCacheIp	13-18
snRtATPortZoneFilterRowStatus	18-6	snRtIpFwdCacheMac	13-18

snRtIpFwdCacheMaxEntries 13-3  
 snRtIpFwdCacheNextHopIp 13-18  
 snRtIpFwdCacheOutgoingIf 13-19  
 snRtIpFwdCacheOutgoingPort 13-18  
 snRtIpFwdCacheSnapHdr 13-19  
 snRtIpFwdCacheTable 13-18  
 snRtIpFwdCacheType 13-18  
 snRtIpFwdCacheVlanId 13-19  
 snRtIpIfConfigEntry 13-12  
 snRtIpIfConfigInterfaceIndex 13-12  
 snRtIpIfConfigTable 13-12  
 snRtIpIfDirBcastFwd 13-12  
 snRtIpIfEncap 13-12  
 snRtIpIfMetric 13-12  
 snRtIpIfMtu 13-12  
 snRtIpIrdpEnable 13-2  
 snRtIpLoadShare 13-2  
 snRtIpLoadShareMaxPaths 13-3  
 snRtIpLoadShareMinPaths 13-3  
 snRtIpLoadShareNumOfPaths 13-3  
 snRtIpMaxStaticRouteEntries 13-3  
 snRtIpPortAccessDirection 13-10  
 snRtIpPortAccessEntry 13-9  
 snRtIpPortAccessFilters 13-10  
 snRtIpPortAccessPortIndex 13-9  
 snRtIpPortAccessRowStatus 13-10  
 snRtIpPortAccessTable 13-9  
 snRtIpPortAddrEntry 13-8  
 snRtIpPortAddress 13-8  
 snRtIpPortAddrPortIndex 13-8  
 snRtIpPortAddrTable 13-8  
 snRtIpPortAddrType 13-9  
 snRtIpPortConfigEntry 13-10  
 snRtIpPortConfigPortIndex 13-11  
 snRtIpPortConfigTable 13-10  
 snRtIpPortDirBcastFwd 13-11  
 snRtIpPortEncap 13-11  
 snRtIpPortMetric 13-11  
 snRtIpPortMtu 13-11  
 snRtIpPortRowStatus 13-9  
 snRtIpPortSubnetMask 13-8  
 snRtIpProtocolRouterId 13-4  
 snRtIpProxyArp 13-2  
 snRtIpRarp 13-3  
 snRtIpRarpEntry 20-5  
 snRtIpRarpIndex 20-5  
 snRtIpRarpIp 20-5  
 snRtIpRarpMac 20-5  
 snRtIpRarpRowStatus 20-5  
 snRtIpRarpTable 20-5  
 snRtIpRipDistance 14-2  
 snRtIpRipEnable 14-1  
 snRtIpRipFiltOnAllPort 14-2  
 snRtIpRipGblFiltList 14-2  
 snRtIpRipNbrFilterAction 14-6  
 snRtIpRipNbrFilterEntry 14-6  
 snRtIpRipNbrFilterId 14-6  
 snRtIpRipNbrFilterRowStatus 14-7  
 snRtIpRipNbrFilterSourceIp 14-6  
 snRtIpRipNbrFilterTable 14-6  
 snRtIpRipPortAccessDir 14-7  
 snRtIpRipPortAccessEntry 14-7  
 snRtIpRipPortAccessFilterList 14-7  
 snRtIpRipPortAccessPort 14-7  
 snRtIpRipPortAccessRowStatus 14-8  
 snRtIpRipPortAccessTable 14-7  
 snRtIpRipPortConfigEntry 14-3  
 snRtIpRipPortConfigPortIndex 14-3  
 snRtIpRipPortConfigTable 14-3  
 snRtIpRipPortLearnDefault 14-3  
 snRtIpRipPortPoisonReverse 14-3  
 snRtIpRipPortVersion 14-3  
 snRtIpRipRedisAction 14-4  
 snRtIpRipRedisDefMetric 14-1  
 snRtIpRipRedisEnable 14-1  
 snRtIpRipRedisEntry 14-4  
 snRtIpRipRedisIndex 14-4  
 snRtIpRipRedisIp 14-4  
 snRtIpRipRedisMask 14-4  
 snRtIpRipRedisMatchMetric 14-4  
 snRtIpRipRedisProtocol 14-4  
 snRtIpRipRedisRouteMapName 14-5  
 snRtIpRipRedisRowStatus 14-5  
 snRtIpRipRedisSetMetric 14-4  
 snRtIpRipRedisTable 14-3  
 snRtIpRipRouteFilterAction 14-5

---

snRtIIPripRouteFilterEntry	14-5	snRtIIPTraceRouteTimeOut	13-16
snRtIIPripRouteFilterId	14-5	snRtIIPttl	13-3
snRtIIPripRouteFilterIpAddr	14-5	snRtStaticArpEntry	20-6
snRtIIPripRouteFilterRowStatus	14-6	snRtStaticArpIflIndex	20-7
snRtIIPripRouteFilterSubnetMask	14-6	snRtStaticArpIndex	20-6
snRtIIPripRouteFilterTable	14-5	snRtStaticArpIPlp	20-6
snRtIIPripSetAllPortConfig	14-2	snRtStaticArpMac	20-6
snRtIIPripStats	14-8	snRtStaticArpPort	20-6
snRtIIPripStatsBadAddrFamily	14-9	snRtStaticArpRowStatus	20-7
snRtIIPripStatsBadMetrics	14-9	snRtStaticArpTable	20-6
snRtIIPripStatsBadRequestFormat	14-9	snRtUdpBcastFwdEnable	13-13
snRtIIPripStatsBadRespFormat	14-9	snRtUdpBcastFwdPortEntry	13-13
snRtIIPripStatsBadVersion	14-9	snRtUdpBcastFwdPortIndex	13-13
snRtIIPripStatsInRequest	14-8	snRtUdpBcastFwdPortNumber	13-14
snRtIIPripStatsInResponse	14-8	snRtUdpBcastFwdPortRowStatus	13-14
snRtIIPripStatsOutRequest	14-8	snRtUdpBcastFwdPortTable	13-13
snRtIIPripStatsOutResponse	14-8	snRtUdpHelperAddr	13-15
snRtIIPripStatsPacketRejected	14-9	snRtUdpHelperAddrTypr	13-15
snRtIIPripStatsRespFromNonRipPort	14-9	snRtUdpHelperEntry	13-15
snRtIIPripStatsResponseFromLoopback	14-9	snRtUdpHelperIndex	13-15
snRtIIPripStatsUnrecognized	14-8	snRtUdpHelperPortIndex	13-15
snRtIIPripUpdateTime	14-1	snRtUdpHelperRowStatus	13-15
snRtIIPsetAllPortConfig	13-3	snRtUdpHelperTable	13-14
snRtIIPsourceRoute	13-4	snSflowCollectorEntry	20-8
snRtIIPstaticRouteDest	13-4	snSflowCollectorIndex	20-9
snRtIIPstaticRouteDistance	13-5	snSflowCollectorIP	20-9
snRtIIPstaticRouteEntry	13-4	snSflowCollectorRowStatus	20-9
snRtIIPstaticRouteIndex	13-4	snSflowCollectorTable	20-8
snRtIIPstaticRouteMask	13-4	snSflowCollectorUDPPort	20-9
snRtIIPstaticRouteMetric	13-5	snSI	3-1
snRtIIPstaticRouteNextHop	13-4	snSI1500Router	3-3
snRtIIPstaticRouteRowStatus	13-5	snSI1500Switch	3-3
snRtIIPstaticRouteTable	13-4	snSI400Router	3-3
snRtIIPTraceRouteControl	13-17	snSI400Switch	3-3
snRtIIPTraceRouteMaxTtl	13-16	snSI800Router	3-3
snRtIIPTraceRouteMinTtl	13-16	snSI800Switch	3-3
snRtIIPTraceRouteResultAddr	13-17	snSIXL	3-1
snRtIIPTraceRouteResultEntry	13-17	snSIXLTCS	3-1
snRtIIPTraceRouteResultIndex	13-17	snSw8021qTagMode	5-16
snRtIIPTraceRouteResultRoundTripTime1	13-17	snSw8021qTagType	5-17
snRtIIPTraceRouteResultRoundTripTime2	13-17	snSwBroadcastLimit	5-18
snRtIIPTraceRouteResultTable	13-17	snSwClearCounters	5-17
snRtIIPTraceRouteTargetAddr	13-16	snSwDefaultVlanId	5-18

snSwEnableBridgeNewRootTrap 23-7  
 snSwEnableBridgeTopoChangeTrap 23-7  
 snSwEnableLockedAddrViolationTrap 23-7  
 snSwEosBufferSize 5-16  
 snSwFastStpMode 5-19  
 snSwGlobalAutoNegotiate 5-18  
 snSwGlobalStpMode 5-16  
 snSwGroupDefaultCfgMode 5-14  
 snSwGroupIpL3SwMode 5-14  
 snSwGroupIpMcastMode 5-14  
 snSwGroupOperMode 5-14  
 snSwGroupSwitchAgeTime 5-14  
 snSwIfDescr 7-18  
 snSwIfDhcpGateListId 7-18  
 snSwIfFastSpanPortEnable 7-19  
 snSwIfFastSpanUplinkEnable 7-20  
 snSwIfGBICStatus 7-20  
 snSwIfInfoAdminStatus 7-17  
 snSwIfInfoAutoNegotiate 7-19  
 snSwIfInfoChnMode 7-15  
 snSwIfInfoConnectorType 7-17  
 snSwIfInfoEntry 7-14  
 snSwIfInfoFlowControl 7-19  
 snSwIfInfoGigType 7-19  
 snSwIfInfoLinkStatus 7-17  
 snSwIfInfoMediaType 7-17  
 snSwIfInfoMirrorPorts 7-14  
 snSwIfInfoMonitorMode 7-14  
 snSwIfInfoPhysAddress 7-18  
 snSwIfInfoPortNum 7-14  
 snSwIfInfoPortQos 7-18  
 snSwIfInfoSpeed 7-16  
 snSwIfInfoTable 7-14  
 snSwIfInfoTagMode 7-14  
 snSwIfInfoTagMode 7-14  
 snSwIfInOctets 7-22  
 snSwIfLoadInterval 7-20  
 snSwIfLockAddressCount 7-18  
 snSwIfName 7-18  
 snSwIfOutOctets 7-22  
 snSwIfPresent 7-20  
 snSwIfRouteOnly 7-20  
 snSwIfStatsAlignErrors 7-21  
 snSwIfStatsFCSErrors 7-21  
 snSwIfStatsFrameTooLongs 7-21  
 snSwIfStatsFrameTooShorts 7-22  
 snSwIfStatsInBcastFrames 7-22  
 snSwIfStatsInBitsPerSec 7-23  
 snSwIfStatsInDiscard 7-22  
 snSwIfStatsInFrames 7-20  
 snSwIfStatsInMcastFrames 7-22  
 snSwIfStatsInPktsPerSec 7-23  
 snSwIfStatsInUtilization 7-23  
 snSwIfStatsLinkChange 7-22  
 snSwIfStatsMacStations 7-22  
 snSwIfStatsMultiColliFrames 7-21  
 snSwIfStatsOutBcastFrames 7-22  
 snSwIfStatsOutBitsPerSec 7-23  
 snSwIfStatsOutDiscard 7-22  
 snSwIfStatsOutFrames 7-20  
 snSwIfStatsOutMcastFrames 7-22  
 snSwIfStatsOutPktsPerSec 7-23  
 snSwIfStatsOutUtilization 7-23  
 snSwIfStatsRxColliFrames 7-21  
 snSwIfStatsTxColliFrames 7-21  
 snSwIfStpPortEnable 7-18  
 snSwIfVlanId 7-20  
 snSwIpMcastQuerierMode 5-16  
 snSwIpxL3SwMode 5-17  
 snSwMaxMacFilterPerPort 5-18  
 snSwMaxMacFilterPerSystem 5-18  
 snSwPortCacheGroupId 7-8  
 snSwPortDescr 7-10  
 snSwPortDhcpGateListId 7-7  
 snSwPortEntrySize 5-16  
 snSwPortFastSpanPortEnable 7-11  
 snSwPortFastSpanUplinkEnable 7-11  
 snSwPortGBICStatus 7-12  
 snSwPortIfIndex 7-10  
 snSwPortInfoAdminStatus 7-4  
 snSwPortInfoAutoNegotiate 7-8  
 snSwPortInfoChnMode 7-2  
 snSwPortInfoConnectorType 7-4  
 snSwPortInfoEntry 7-2  
 snSwPortInfoFlowControl 7-8  
 snSwPortInfoGigType 7-9

---

snSwPortInfoLinkStatus	7-4	snSwPortStatsTxColliFrames	7-6
snSwPortInfoMediaType	7-4	snSwPortStpPortEnable	7-7
snSwPortInfoMirrorMode	7-13	snSwPortTransGroupld	7-8
snSwPortInfoMonitorMode	7-2	snSwPortVlanld	7-12
snSwPortInfoPhysAddress	7-5	snSwProbePortNum	5-15
snSwPortInfoPortNum	7-2	snSwProtocolVlanMode	5-17
snSwPortInfoPortQos	7-5	snSwQosMechanism	5-18
snSwPortInfoSpeed	7-3	snSwSingleStpMode	5-19
snSwPortInfoTable	7-1	snSwSummaryMode	5-19
snSwPortInfoTagType	7-2	snSwViolatorIfIndex	5-19
snSwPortInLinePowerClass	7-13	snSwViolatorMacAddress	5-16
snSwPortInLinePowerControl	7-13	snSwViolatorPortNumber	5-16
snSwPortInLinePowerWattage	7-13	snT8Router	3-1
snSwPortInOctets	7-10	snT8SI	3-2
snSwPortLoadInterval	7-12	snT8SIXLG	3-2
snSwPortLockAddressCount	7-6	snT8Switch	3-1
snSwPortName	7-7	snTacacsDeadTime	6-15
snSwPortOutOctets	7-11	snTacacsGeneral	6-15
snSwPortPresent	7-12	snTacacsKey	6-15
snSwPortRouteOnly	7-12	snTacacsRetransmit	6-15
snSwPortSetAll	5-15	snTacacsServerAuthPort	6-16
snSwPortStatsAlignErrors	7-5	snTacacsServerEntry	6-15
snSwPortStatsFCSErrors	7-6	snTacacsServerIp	6-16
snSwPortStatsFrameTooLongs	7-6	snTacacsServerRowKey	6-16
snSwPortStatsFrameTooShorts	7-6	snTacacsServerRowStatus	6-16
snSwPortStatsInBcastFrames	7-7	snTacacsServerTable	6-15
snSwPortStatsInBitsPerSec	7-11	snTacacsServerUsage	6-16
snSwPortStatsInDiscard	7-7	snTacacsSNMPAccess	6-15
snSwPortStatsInFrames	7-5	snTacacsTimeOut	6-15
snSwPortStatsInMcastFrames	7-7	snTIRouter	3-1
snSwPortStatsInPktsPerSec	7-11	snTISwitch	3-1
snSwPortStatsInUtilization	7-11	snTrapAccessListDeny	(37) 23-15
snSwPortStatsLinkChange	7-10	snTrapAutoPortDisableRelease(124)	23-35
snSwPortStatsMacStations	7-7	snTrapAutoPortDisableTrigger(123)	23-35
snSwPortStatsMultiColliFrames	7-6	snTrapBgpPeerDown	(66) 23-32
snSwPortStatsOutBcastFrames	7-7	snTrapBgpPeerUp(65)	23-32
snSwPortStatsOutBitsPerSec	7-11	snTrapChasFanFailed	(31) 23-14
snSwPortStatsOutDiscard	7-7	snTrapChasPwrSupply	(1) 23-13
snSwPortStatsOutFrames	7-5	snTrapChasPwrSupplyFailed(30)	23-14
snSwPortStatsOutMcastFrames	7-7	snTrapFsrplfStateChange(33)	23-20
snSwPortStatsOutPktsPerSec	7-11		
snSwPortStatsOutUtilization	7-11		
snSwPortStatsRxColliFrames	7-6		

---

snTrapIcmpLocalExceedBurst(51) 23-30  
 snTrapIcmpTransitExceedBurst(52) 23-30  
 snTrapL4BecomeActive (27) 23-27  
 snTrapL4BecomeStandby(26) 23-27  
 snTrapL4FirewallBecomeActive(48) 23-29  
 snTrapL4FirewallBecomeStandby(47) 23-29  
 snTrapL4FirewallPathDown(50) 23-29  
 snTrapL4FirewallPathUp(49) 23-29  
 snTrapL4GslbHealthCheckIpDown(44) 23-28  
 snTrapL4GslbHealthCheckIpPortDown(46) 23-28  
 snTrapL4GslbHealthCheckIpPortUp(45) 23-28  
 snTrapL4GslbHealthCheckIpUp(43) 23-28  
 snTrapL4GslbRemoteControllerDown(42) 23-28  
 snTrapL4GslbRemoteControllerUp(41) 23-28  
 snTrapL4GslbRemoteDown(40) 23-28  
 snTrapL4GslbRemoteUp(39) 23-27  
 snTrapL4MaxSessionLimitReached(19) 23-26  
 snTrapL4RealServerDown(22) 23-26  
 snTrapL4RealServerMaxConnectionLimitReached (25) 23-27  
 snTrapL4RealServerPortDown(24) 23-26  
 snTrapL4RealServerPortUp(23) 23-26  
 snTrapL4RealServerResponseTimeLowerLimit (67) 23-27  
 snTrapL4RealServerResponseTimeUpperLimit (68) 23-27  
 snTrapL4RealServerUp (21) 23-26  
 snTrapL4TcpSynLimitReached(20) 23-26  
 snTrapLockedAddressViolation(2) 23-13  
 snTrapLockedAddressViolation2(32) 23-14  
 snTrapMacFilterDeny (38) 23-15  
 snTrapMgmtModuleRedunStateChange(35) 23-14  
 snTrapModuleInserted (28) 23-14  
 snTrapModuleRemoved(29) 23-14  
 snTrapMplsAudit(59) 23-31  
 snTrapMplsDeveloper (60) 23-31  
 snTrapMplsException (58) 23-31  
 snTrapMplsProblem(57) 23-31  
 snTrapMrpCamError(80) 23-33  
 snTrapMrpStateChange TRAP(79) 23-33  
 snTrapOspfIfStateChange(3) 23-20  
 snTrapOspfVirtIfStateChange(4) 23-21  
 snTrapPnPStatusChange(125) 23-34  
 snTrapPortPriorityChange(122) 23-19  
 snTrapPortPriorityChange(122) 23-32  
 snTrapTcpLocalExceedBurst(53) 23-30  
 snTrapTcpTransitExceedBurst(54) 23-31  
 snTrapTemperatureWarning(36) 23-15  
 snTrapVsrpCamError(82) 23-20  
 snTrapVsrpStateChange(81) 23-20  
 snTrapWirelessIsrpPeerStateChange(126) 23-34  
 snTrapWirelessSappStateChange(129) 23-33  
 snTrapWirelessStationRoamingEventTrig-  
 gered(128) 23-34  
 snTrapWirelessStationStateChange(127) 23-33  
 snTrunkEntry 7-26  
 snTrunkIndex 7-26  
 snTrunkPortMask 7-26  
 snTrunkTable 7-26  
 snTrunkType 7-26  
 snTurboIronSuperX 3-8  
 snTurboIronSuperXBaseL3Switch 3-8  
 snTurboIronSuperXFamily 3-8  
 snTurboIronSuperXPrem 3-8  
 snTurboIronSuperXPremBaseL3Switch 3-8  
 snTurboIronSuperXPremRouter 3-8  
 snTurboIronSuperXPremSwitch 3-8  
 snTurboIronSuperXRouter 3-8  
 snTurboIronSuperXSwitch 3-8  
 snVlanByATCableChassisStaticMask 11-20  
 snVlanByATCableEntry 11-19  
 snVlanByATCableIndex 11-19  
 snVlanByATCableRouterIntf 11-20  
 snVlanByATCableRowStatus 11-20  
 snVlanByATCableStaticPortList 11-20  
 snVlanByATCableTable 11-19  
 snVlanByATCableVlanId 11-19  
 snVlanByATCableVlanName 11-20  
 snVlanByIpSubnetChassisDynamicMask 11-16  
 snVlanByIpSubnetChassisExcludeMask 11-16  
 snVlanByIpSubnetChassisStaticMask 11-16  
 snVlanByIpSubnetDynamic 11-15

---

snVlanByIpSubnetDynamicMask 11-16  
snVlanByIpSubnetDynamicPortList 11-16  
snVlanByIpSubnetEntry 11-15  
snVlanByIpSubnetExcludeMask 11-15  
snVlanByIpSubnetExcludePortList 11-16  
snVlanByIpSubnetIpAddress 11-15  
snVlanByIpSubnetMaxSubnets 5-17  
snVlanByIpSubnetRouterIntf 11-15  
snVlanByIpSubnetRowStatus 11-15  
snVlanByIpSubnetStaticMask 11-15  
snVlanByIpSubnetStaticPortList 11-16  
snVlanByIpSubnetSubnetMask 11-15  
snVlanByIpSubnetTable 11-14  
snVlanByIpSubnetVlanId 11-15  
snVlanByIpSubnetVlanName 11-16  
snVlanByIpxNetChassisDynamicMask 11-18  
snVlanByIpxNetChassisExcludeMask 11-18  
snVlanByIpxNetChassisStaticMask 11-18  
snVlanByIpxNetDynamic 11-17  
snVlanByIpxNetDynamicMask 11-18  
snVlanByIpxNetDynamicPortList 11-19  
snVlanByIpxNetEntry 11-17  
snVlanByIpxNetExcludeMask 11-17  
snVlanByIpxNetExcludePortList 11-19  
snVlanByIpxNetFrameType 11-17  
snVlanByIpxNetMaxNetworks 5-17  
snVlanByIpxNetNetworkNum 11-17  
snVlanByIpxNetRouterIntf 11-18  
snVlanByIpxNetRowStatus 11-18  
snVlanByIpxNetStaticMask 11-17  
snVlanByIpxNetStaticPortList 11-19  
snVlanByIpxNetTable 11-17  
snVlanByIpxNetVlanId 11-17  
snVlanByIpxNetVlanName 11-19  
snVlanByPortBaseBridgeAddress 11-6  
snVlanByPortBaseNumPorts 11-4  
snVlanByPortBaseType 11-4  
snVlanByPortCfgBaseBridgeAddress 11-11  
snVlanByPortCfgBaseNumPorts 11-9  
snVlanByPortCfgBaseType 11-10  
snVlanByPortCfgEntry 11-7  
snVlanByPortCfgQos 11-8  
snVlanByPortCfgRouterIntf 11-12  
snVlanByPortCfgRowStatus 11-12  
snVlanByPortCfgStpDesignatedRoot 11-11  
snVlanByPortCfgStpForwardDelay 11-11  
snVlanByPortCfgStpGroupForwardDelay 11-9  
snVlanByPortCfgStpGroupHello Time 11-9  
snVlanByPortCfgStpGroupMaxAge 11-9  
snVlanByPortCfgStpHelloTime 11-10  
snVlanByPortCfgStpHoldTime 11-10  
snVlanByPortCfgStpMaxAge 11-10  
snVlanByPortCfgStpMode 11-8  
snVlanByPortCfgStpPriority 11-8  
snVlanByPortCfgStpProtocolSpecification 11-10  
snVlanByPortCfgStpRootCost 11-11  
snVlanByPortCfgStpRootPort 11-11  
snVlanByPortCfgStpTimeSinceTopologyChange 11-11  
snVlanByPortCfgStpTopChanges 11-11  
snVlanByPortCfgStpVersion 11-12  
snVlanByPortCfgTable 11-7  
snVlanByPortCfgVlanId 11-8  
snVlanByPortCfgVlanName 11-11  
snVlanByPortChassisPortMask 11-6  
snVlanByPortEntry 11-1  
snVlanByPortEntrySize 5-16  
snVlanByPortMemberEntry 11-7  
snVlanByPortMemberPortId 11-7  
snVlanByPortMemberRowStatus 11-7  
snVlanByPortMemberTable 11-6  
snVlanByPortMemberVlanId 11-7  
snVlanByPortOperState 11-4  
snVlanByPortPortList 11-6  
snVlanByPortPortMask 11-2  
snVlanByPortQos 11-2  
snVlanByPortRouterIntf 11-6  
snVlanByPortStpDesignatedRoot 11-6  
snVlanByPortStpForwardDelay 11-5  
snVlanByPortStpGroupForwardDelay 11-3  
snVlanByPortStpGroupHello Time 11-3  
snVlanByPortStpGroupMaxAge 11-3  
snVlanByPortStpHelloTime 11-5  
snVlanByPortStpHoldTime 11-5  
snVlanByPortStpMaxAge 11-5  
snVlanByPortStpMode 11-2

snVlanByPortStpPriority 11-2  
 snVlanByPortStpProtocolSpecification 11-4  
 snVlanByPortStpRootCost 11-5  
 snVlanByPortStpRootPort 11-6  
 snVlanByPortStpTimeSinceTopologyChange 11-5  
 snVlanByPortStpTopChanges 11-5  
 snVlanByPortTable 11-1  
 snVlanByPortVlanId 11-2  
 snVlanByPortVlanIndex 11-1  
 snVlanByPortVlanName 11-6  
 snVlanByProtocolChassisDynamicMask 11-14  
 snVlanByProtocolChassisExcludeMask 11-14  
 snVlanByProtocolChassisStaticMask 11-13  
 snVlanByProtocolDynamic 11-13  
 snVlanByProtocolDynamicMask 11-13  
 snVlanByProtocolDynamicPortList 11-14  
 snVlanByProtocolEntry 11-12  
 snVlanByProtocolExcludeMask 11-13  
 snVlanByProtocolExcludePortList 11-14  
 snVlanByProtocolIndex 11-12  
 snVlanByProtocolRouterIntf 11-13  
 snVlanByProtocolRowStatus 11-13  
 snVlanByProtocolStaticMask 11-13  
 snVlanByProtocolStaticPortList 11-14  
 snVlanByProtocolTable 11-12  
 snVlanByProtocolVlanId 11-12  
 snVlanByProtocolVlanName 11-14  
 snVlanCARAcclDx 9-5  
 snVlanCARConformAction 9-6  
 snVlanCARDirection 9-5  
 snVlanCAREntry 9-5  
 snVlanCARExceedAction 9-6  
 snVlanCARExtLimit 9-5  
 snVlanCARLimit 9-5  
 snVlanCARRate 9-5  
 snVlanCARRowIndex 9-5  
 snVlanCARStatCurBurst 9-6  
 snVlanCARStatFilteredBytes 9-6  
 snVlanCARStatFilteredPkts 9-6  
 snVlanCARStatSwitchedBytes 9-6  
 snVlanCARStatSwitchedPkts 9-6  
 snVlanCARTable 9-5  
 snVlanCARType 9-5  
 snVlanCARVlanId 9-5  
 snVlanGroupSetAllVlan 5-14  
 snVlanGroupVlanCurEntry 5-14  
 snVlanGroupVlanMaxEntry 5-16  
 snVrrpClearVrrpStat 12-5  
 snVrrpGroupOperMode 12-4  
 snVrrpGroupOperModeVrrpextended 12-5  
 snVrrpIf2AuthPassword 12-7  
 snVrrpIf2AuthType 12-6  
 snVrrpIf2Entry 12-6  
 snVrrpIf2RxAuthPwdMismatchErrCnts 12-7  
 snVrrpIf2RxAuthTypeErrCnts 12-7  
 snVrrpIf2RxHeaderErrCnts 12-7  
 snVrrpIf2RxVridErrCnts 12-7  
 snVrrpIf2Table 12-6  
 snVrrpIf2Table 2-21  
 snVrrpIfAuthPassword 12-6  
 snVrrpIfAuthType 12-6  
 snVrrpIfEntry 12-5  
 snVrrpIfMaxNumVridPerIntf 12-5  
 snVrrpIfMaxNumVridPerSystem 12-5  
 snVrrpIfPort 12-5  
 snVrrpIfRxAuthPwdMismatchErrCnts 12-6  
 snVrrpIfRxAuthTypeErrCnts 12-6  
 snVrrpIfRxHeaderErrCnts 12-6  
 snVrrpIfRxVridErrCnts 12-6  
 snVrrpIfStateChangeTrap 23-5  
 snVrrpIfTable 12-5  
 snVrrpVirRtr2Activate 12-15  
 snVrrpVirRtr2AdvertiseBackup 12-18  
 snVrrpVirRtr2CfgPriority 12-14  
 snVrrpVirRtr2CurrDeadInt 12-17  
 snVrrpVirRtr2CurrPriority 12-14  
 snVrrpVirRtr2DeadInt 12-15  
 snVrrpVirRtr2Entry 12-13  
 snVrrpVirRtr2HelloInt 12-14  
 snVrrpVirRtr2Id 12-13  
 snVrrpVirRtr2IpAddrCount 12-18  
 snVrrpVirRtr2IpAddrMask 12-15  
 snVrrpVirRtr2MasterIpAddr 12-18  
 snVrrpVirRtr2Ownership 12-13  
 snVrrpVirRtr2PreemptMode 12-15



---

snVrrpVirRtr2RowStatus 12-16  
snVrrpVirRtr2RxArpPktDropCnts 12-16  
snVrrpVirRtr2RxHelloIntMismatchCnts 12-16  
snVrrpVirRtr2RxHigherPriorityCnts 12-17  
snVrrpVirRtr2RxIpMismatchCnts 12-16  
snVrrpVirRtr2RxIpPktDropCnts 12-16  
snVrrpVirRtr2RxNumOfIpMismatchCnts 12-16  
snVrrpVirRtr2RxPortMismatchCnts 12-16  
snVrrpVirRtr2RxPriorityZeroFromMasterCnts 12-16  
snVrrpVirRtr2State 12-15  
snVrrpVirRtr2Table 12-13  
snVrrpVirRtr2TrackPortList 12-17  
snVrrpVirRtr2TrackPriority 12-14  
snVrrpVirRtr2TransToBackupStateCnts 12-17  
snVrrpVirRtr2TransToMasterStateCnts 12-17  
snVrrpVirRtr2VirtualMacAddr 12-18  
snVrrpVirRtrActivate 12-9  
snVrrpVirRtrBackupInt 12-23  
snVrrpVirRtrCfgPriority 12-8  
snVrrpVirRtrCurrDeadInt 12-12  
snVrrpVirRtrCurrPriority 12-8  
snVrrpVirRtrDeadInt 12-9  
snVrrpVirRtrEntry 12-7  
snVrrpVirRtrHelloInt 12-9  
snVrrpVirRtrId 12-8  
snVrrpVirRtrIpAddrMask 12-9  
snVrrpVirRtrOwnership 12-8  
snVrrpVirRtrPort 12-7  
snVrrpVirRtrPreemptMode 12-9  
snVrrpVirRtrRowStatus 12-11  
snVrrpVirRtrRxArpPktDropCnts 12-11  
snVrrpVirRtrRxHelloIntMismatchCnts 12-11  
snVrrpVirRtrRxHigherPriorityCnts 12-12  
snVrrpVirRtrRxIpMismatchCnts 12-11  
snVrrpVirRtrRxIpPktDropCnts 12-11  
snVrrpVirRtrRxNumOfIpMismatchCnts 12-11  
snVrrpVirRtrRxPortMismatchCnts 12-11  
snVrrpVirRtrRxPriorityZeroFromMasterCnts 12-11  
snVrrpVirRtrState 12-9  
snVrrpVirRtrTable 12-7  
snVrrpVirRtrTrackPortList 12-12  
snVrrpVirRtrTrackPortMask 12-10  
snVrrpVirRtrTrackPriority 12-8  
snVrrpVirRtrTrackVifMask 12-10  
snVrrpVirRtrTrackVifPortList 12-13  
snVrrpVirRtrTransToBackupStateCnts 12-12  
snVrrpVirRtrTransToMasterStateCnts 12-12  
snVsrpClearVrrpStat 12-19  
snVsrpGroupOperModeVsrp 12-18  
snVsrpIfAuthPassword 12-19  
snVsrpIfAuthType 12-19  
snVsrpIfEntry 12-19  
snVsrpIfMaxNumVridPerIntf 12-19  
snVsrpIfMaxNumVridPerSystem 12-19  
snVsrpIfStateChangeTrap 23-6  
snVsrpIfTable 12-19  
snVsrpIfVlanId 12-19  
snVsrpVirRtrActivate 12-22  
snVsrpVirRtrAdvertiseBackup 12-22  
snVsrpVirRtrCfgPriority 12-20  
snVsrpVirRtrCurHelloInt 12-24  
snVsrpVirRtrCurHoldDownInt 12-25  
snVsrpVirRtrCurInitTtl 12-25  
snVsrpVirRtrCurrDeadInt 12-24  
snVsrpVirRtrCurrPriority 12-21  
snVsrpVirRtrDeadInt 12-21  
snVsrpVirRtrEntry 12-20  
snVsrpVirRtrHelloInt 12-21  
snVsrpVirRtrHelloMacAddress 12-25  
snVsrpVirRtrHoldDownInt 12-22  
snVsrpVirRtrId 12-20  
snVsrpVirRtrIncPortList 12-23  
snVsrpVirRtrInitTtl 12-23  
snVsrpVirRtrIpAddrMask 12-21  
snVsrpVirRtrMasterIpAddr 12-25  
snVsrpVirRtrOwnership 12-20  
snVsrpVirRtrPreemptMode 12-21  
snVsrpVirRtrRowStatus 12-23  
snVsrpVirRtrRxArpPktDropCnts 12-23  
snVsrpVirRtrRxHelloIntMismatchCnts 12-24  
snVsrpVirRtrRxHigherPriorityCnts 12-24  
snVsrpVirRtrRxIpMismatchCnts 12-24  
snVsrpVirRtrRxIpPktDropCnts 12-23  
snVsrpVirRtrRxNumOfIpMismatchCnts 12-24  
snVsrpVirRtrRxPortMismatchCnts 12-24

snVsrpVirRtrRxPriorityZeroFromMasterCnts 12-24  
 snVsrpVirRtrSave 12-23  
 snVsrpVirRtrState 12-21  
 snVsrpVirRtrTable 12-20  
 snVsrpVirRtrTrackPortList 12-22  
 snVsrpVirRtrTrackPriority 12-20  
 snVsrpVirRtrTransToBackupStateCnts 12-24  
 snVsrpVirRtrTransToMasterStateCnts 12-24  
 snVsrpVirRtrVlanId 12-20  
 Syntax: Gauge 20-23  
 vendors 3-9  
 wglfAutoPortDisable 22-2  
 wglfEntry 22-1  
 wglfFullCompRoamingEnable 22-2  
 wglfIndex 22-2  
 wglfPnPLearnNewAP 22-2  
 wglfTable 22-1  
 wglfVpnPTPolicyId 22-2  
 wglfWirelessEnable 22-2  
 wgMobilityId 22-1  
 wgPnPEntry 22-3  
 wgPnPfIndex 22-3  
 wgPnPIpAddress 22-4  
 wgPnPIpAddressDefaultGw 22-4  
 wgPnPIpAddressMask 22-4  
 wgPnPMacAddress 22-3  
 wgPnPRowStatus 22-4  
 wgPnPStatus 22-4  
 wgPnPTable 22-3  
 wgRoamingPeerConnectionStatus 22-3  
 wgRoamingPeerEntry 22-3  
 wgRoamingPeerIpAddress 22-3  
 wgRoamingPeerRowStatus 22-3  
 wgRoamingPeerTable 22-2  
 wgVpnPTDeletePolicy 22-1  
 wgVpnPTFilterEntry 22-5  
 wgVpnPTFilterPolicyId 22-5  
 wgVpnPTFilterPort 22-5  
 wgVpnPTFilterProtocol 22-5  
 wgVpnPTFilterRowStatus 22-6  
 wgVpnPTFilterTable 22-5  
 wgVpnPTPolicyEntry 22-6  
 wgVpnPTPolicyId 22-6  
 wgVpnPTPolicyPortList 22-6  
 wgVpnPTPolicyTable 22-6  
 wgVpnPTServerEntry 22-4  
 wgVpnPTServerIpAddress 22-5  
 wgVpnPTServerPolicyId 22-5  
 wgVpnPTServerRowStatus 22-5  
 wgVpnPTServerTable 22-4  
 wirelessAp 3-9  
 wirelessProbe 3-9

## A

- AAA 6-9
- accounting 6-10
- ACL 8-7
- agent
  - active management module traps 23-5
- alarm
  - trap 23-12
- AppleTalk 18-1
- ATM 7-29
- authorization 6-9

## B

- BGP 16-1
  - trap 23-32
- bind table 21-34
- board
  - main 4-4
- boards 4-7
  - stackable 4-22

## C

- CAR 9-2
- chassis 4-25
- cold start
  - trap 23-4
- community 6-6
- community list string 6-7
- Conventions
  - manual 1-1

- CPU utilization 20-1

## D

- DVMRP 10-12
- dynamic memory utilization 20-3

## E

- Email Access 1-2

## F

- fan 4-3
  - chassis 4-26
  - trap 23-4
- fdb (Forwarding database) 8-4
- flash card 4-28
- forwarding cache 13-18
- Foundry
  - trap 23-13
- foundry MIBs 2-15
- FSRP 12-1, 23-20
  - trap 23-5

## G

- Getting Help 1-2
- GSLB 21-36

## H

- health checks 21-9
- Help
  - getting 1-2

hot standby 21-5

## I

ICMP

trap 23-30

IGMP 10-1

installing MIBs 2-2

interface lookup 7-24

interface lookup index 7-25

IP

access policy 13-5

AS-Path 13-22

broadcast 13-13

general 13-2

global 13-1

port access 13-9

port address 13-8

port configuration 13-10

prefix list 13-19

IPX 17-1

## L

Layer 4

trap 23-8

Layer 4 policy 21-6

link down

trap 23-4

link up

trap 23-4

loopback 7-32

## M

MAC address, static MAC addresses 8-4

MAC address, dynamically learned MAC addresses 2-6

MAC filters 8-1

Manual nomenclature 1-1

module

trap 23-4

modules 4-15

redundant 4-19

monitor

real server 21-37

virtual server 21-37

MPLS

trap 23-31

multicast 10-1

## N

NetFlow 20-9

## O

obtaining MIBs 2-2

OSPF 15-1

## P

PIM 10-4

port information 7-1

port security

trap 23-32

Port STP 5-25

POS 7-27

power supply 4-2

chassis 4-26

trap 23-4

products 3-1

## Q

QoS 9-1

## R

RADIUS 6-10, 6-13

RARP 20-5

rate limiting 9-2

real server 21-18

monitor 21-37

Related Publication 1-1

RIP 14-1

## S

security 6-2

Session 21-2

sFlow 20-8

sflow

standard 2-14

SLB 21-3

SNMP versions 2-21

standard MIBs 2-2

static ARP 20-5

static route 13-4

STP 7-34, 7-37

trap 23-7, 23-11

---

Syslog 20-13

## **T**

TACACS 6-14, 6-15

TCP

trap 23-30

TCS 21-9

Telephone Access 1-2

temperature 4-27

trap 23-5

trace route 13-15

trap

system status 23-10

traps

foundry 23-2

standard 23-1

trunks 7-26

multi-slot 7-26

## **U**

UDP 13-13, 13-14

upgrading

modules A-1

upgrading

devices A-1

switch processors A-2

user account 6-2

user group 6-1

## **V**

virtual server 21-26

monitor 21-37

VLAN

AppleTalk 11-19

CAR 9-5

IP subnet 11-14

IPX subnet 11-17

port 11-1

port configuration 11-7

port membership 11-6

protocol 11-12

VLAN Table 5-25

VRRP 12-4

trap 23-5, 23-19

VRRPE 12-18

VSRP 12-18

## **W**

Web Access 1-2

Web cache 21-9

